A stylized representation of a tablet or smartphone, shown as a rounded rectangle with a double-line border. Inside this frame is a single-line rectangular border. In the top right corner of the outer frame, there is a small circle representing a camera lens. The text is centered within the inner frame.

**USER'S MANUAL  
MY9308P/844522/844523**

# Table of Contents

Table of Contents.....	P1
Features.....	P2
Unit at a Glance .....	P3
Getting Started.....	P4-P5
About Applications.....	P5-P6
Preinstalled Applications.....	P6
Connect to a Wi-Fi network.....	P7-P8
Optional Connections.....	P9
Specifications.....	P10

## Features

Browse the Web.

Visit your favorite websites

Check your e-mail

Keep in touch with friends and family

Watch YouTube™ videos

Browse the world's most popular video-sharing community

Read your favorite books

Download thousands of books with the included E-book reader \*

Discover thousands of apps for Android™ Games, applications, and more with marketplace(need for customer installed)

Connect to the Internet wirelessly

High-speed Wi-Fi 802.11 b/g/n networking

Enjoy your media library anywhere

Portable powerhouse plays popular music, video, and photo formats  
microSD memory card reader  
Increase your storage capacity (up to 32 GB supported)

Built-in camera


Convenient front-facing camera(0.3MP),

Automatic orientation detection

Read any way you want; the display adjusts automatically!

Reading books in the ePub format requires the included E-book reader application.

## Unit at a Glance



### 1. ESC

Press this button to return to a previous screen.

### 2/3. VOL+/VOL-

Press VOL+ to increase the volume level.  
Press VOL- to decrease the volume level.

### 4. POWER

Press to turn the unit on, or to turn the screen on or off.

Press and hold to access the Power Off menu.

### 5. Headphone

Audio output connection for headphones.

### 6. Micro SD card

Load external micro SD memory cards here.

### 7. Micro USB OTG

Connect to a USB device.



**Warning:** Do not force when you plug your device with the accessories.

### 8. DC IN 5V

Charge and power the tablet with the included power adapter.

# Getting Started


## Turning the Tablet on or off

To turn the tablet on:

Press and hold the Power key until the LCD screen turns on. Wait until the Home screen appears; the tablet is now ready for use.

To turn the tablet off:

1. Press and hold the Power key until the Device Options menu appears.



2. Touch ok the screen to turn off the tablet.

## Turning the Screen On or off (Standby)

When the tablet is on, you can turn off the screen to conserve battery power. Simply press the Power key once to turn the screen off. Press the Power key again to turn the screen back on.

To conserve battery power, the screen can be set to turn off automatically when the tablet is not in use (between 15 seconds and 30 minutes). This Screen timeout option can be found in the Display menu.


# Getting Started

## Unlocking the Screen

When the screen turns off, you will have to unlock the screen

when you turn it back on.


To unlock the screen, drag the lock icon across the screen towards the lock icon.



# About Applications

To open an application, touch the application icon on the home screen or in the Launcher where you can tap the icon right up on the home screen to get in..

Launcher screen:



The screen shown above is for illustrative purposes only. Reserves the right to modify and improve the final list of applications available on the tablet.

## About Applications

### Preinstalled Applications

Some applications have been installed on your tablet for your convenience.

These applications include:



Browse the web.



Perform simple mathematical operations.



Take pictures or videos with the frontfacing camera.



Check your e-mail.



Play music.



Access the Settings menu to adjust the tablet's options.

## Preinstalled Applications

### Installing Applications



You can also download and install additional applications from the device's applications marketplace, the web browser, or other sources.

The tablet must be set to allow installation of applications from non-Market sources. The Unknown sources option can be set in the Application settings menu.

## Download Applications:

The device has a default configuration which include some applications. Discover all others apps by using Goolge Play(Play Store).

You will be able to connect with Wifi for example, and by signing in the application with just an email



## Connect to a Wi-Fi network

The Notification bar displays icons that indicate your tablet's Wi-Fi status.



Notification that an open Wi-Fi network is in range.

Connected to a Wi-Fi network (waves indicate connection strength).



[No icon] There are no Wi-Fi networks in range, or the Wi-Fi radio is off.



**1. Turn on the Wi-Fi radio if it is not already on. To turn on Wi-Fi:**

a. Go to the Home screen: Press the Home key.

b. Open the Settings menu: tap the icon right up on the home screen to get into the launcher, then touch Settings icon.

c. Open the Wireless & networks menu: Slide the icon to ON status.



network in the list, you can force the tablet to re-scan. To scan for networks, tap the Menu key, and then touch Scan.



## Connect to a Wi-Fi network

### 2. Select an available Wi-Fi network to connect to:

In the same Wi-Fi settings menu above, touch a network in the list.

If the network is open, the tablet will prompt you to confirm connection to the network. Touch **Connect** to confirm.

If the network is secured (as indicated by a Lock icon), the tablet will prompt you to enter a password or other credentials. Touch the **Wireless password** box to show the on-screen keyboard and then use it to enter the password. Touch **Connect** to confirm.



When you have successfully connected to a Wi-Fi network, the Notifications bar at the the low of the screen will show a Wi-Fi signal indicator.



To learn about how to add a Wi-Fi network when it is not in range or when the router is set to obscure the network name (SSID) or to configure advanced Wi-Fi options, please refer to the manual.

# Optional Connections


## Connecting to a Computer

Connect the tablet to a computer to transfer files.

### 1. Connect your tablet to the computer.


With the included USB cable: Plug the small end of the cable into the USB 2.0 high speed connector of the tablet. Plug the large end of the cable into an available USB 2.0 high speed port on the computer.

2. When your tablet is connected, slide up the USB icon right down on the screen and then touch icon USB connected.



### 3. Mount the storage.

Touch button Turn on USB storage to mount the tablet's built-in storage. When it is mounted, you can copy files to or from your tablet.



## Specifications

Processor	Amlogic MXS Dual core 1.5GHz(cortex A9)
RAM	1GB DDR3
Storage	4 GB(option) flash built-in; micro SD card slot (max.32GB supported)
Display	9.0" TFT LCD(800x480), Capacitive touchscreen
Wi-Fi Networking	IEEE 802.11 b/g/n
Audio Output	3.5mm headphone
PC Interface	USB 2.0 high speed
Additional Features	Built-in microphone Front facing camera(0.3MP)
Operating System	Android™ 4.1
Power	Rechargeable Li-poly battery power Adapter(DC 5V, 2A)
Playback Time (hours)	Up to 9 hours music, 3 hours video, 3 hours web browsing

Music was tested with a 128 kbps MP3 file; video was tested with a 1920x1080 MPEG-4/AVC file; browsing was tested with the screen brightness set to default. Actual playback results may vary.



1. Correct Disposal of this product.

This marking indicates that this product should not be disposed with other household wastes throughout the EU. To prevent possible harm to the environment or human health from uncontrolled waste disposal, recycle it responsibly to promote the sustainable reuse of material resources. To return your used device, please use the return and collection systems or contact the retailer where the product was purchased. They can take this product for environmental safe recycling.



2. A mettre a l'interieur du manuel d'instructions si l'appareil ou accessoires inclus (telecommande) necessitent des piles



3. To prevent possible hearing damage, do not listen at high volume levels of long periods.

4. NOTE: The socket must be installed near the equipment and must be easily accessible.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.