


CONTROL PANEL



1	Status Display
2	Mode Select Button
3	Previous Track / FM Station Button
4	Play / Pause Button
5	Next Track / FM Station Button
6	Recording and Playback Function Keys
7	Microphone Sound Priority (over music)
8	Charging Indicator Light. Red = Charging, Blue = Charge Complete. Playback via Battery = 2 to 5 hours depending on volume. Charge Time = 4 to 6 hours.
9	Power Adapter Charger Input
10	Wired Microphone Input
11	Auxiliary Audio Input (3.5mm socket)
12	Micro SD Card Socket
13	USB Storage Input
14	Karaoke Microphone Echo Effect
15	Karaoke Microphone Volume
16	Main Volume
17	ON/OFF Switch
18	LED Light Show Switch
19	12V External DC Power Input

QUICK USER GUIDE

LASER



SPK-F220



CHARGING INDICATOR LAMPS

During charging, the charging indicator lamp will turn RED.

When charging is complete, the charging indicator lamp will turn BLUE.

CONNECTING THE WALL CHARGER

1. Connect the wall charger to your speaker
2. When the battery is fully charged, disconnect the charger from the speaker first, then the wall charger from the wall.

Note: The speaker can be used normally during charging

ON / OFF SWITCH

Press and hold the ON / OFF Switch to turn the speaker ON and again to turn the speaker off.

VOLUME

Turn the volume knob anti-clockwise to decrease the volume and clockwise to increase the volume.

PREVIOUS / NEXT BUTTON

To search for a specific song to playback, press the PREVIOUS / NEXT button to either go forward or backwards through track lists.

LINE IN JACK

1. Connect a 3.5mm Audio Cable (not included) to the LINE IN JACK of your SPK-F220 and to your external audio devices eg. MP3 player or Discman etc
2. Then select the LINE feature by pressing the MODE button.
3. Then press PLAY / PAUSE button to begin playback

FM RADIO

1. Select FM (mode) feature by pressing the MODE / SELECT button.
2. Press the PLAY / PAUSE button to begin automatically searching and saving available radio stations.

3. Press PREVIOUS / NEXT button to select a specific radio station.

NOTE: PLEASE MOVE YOUR SPEAKER, TO ENSURE BEST RECEPTION

USB / SD JACK

1. Insert USB drive or Micro SD card for playback
2. Playback will begin automatically
3. Press the PLAY / PAUSE button to pause and play
4. Press PREVIOUS / NEXT button to select a specific track for playback.

BLUETOOTH

1. Select the BT (Bluetooth) feature by pressing the MODE / SELECT button
2. Turn the Bluetooth feature on, on your portable device
3. Find and pair with your SPK-F220 speaker
4. Press the PLAY / PAUSE button to begin playback

MIC IN JACK

Plug in the microphone. The microphone is then ready to use.

RECORDER FUNCTION

1. Insert a USB Drive (Thumb Drive) and plug in your microphone
2. Long press the REC/REPLAY button
3. The speaker will then display REC and begin recording.
4. To stop recording, short press the REC/REPLAY button again
5. To playback a recorded file, press the REC/REPLAY button (while your thumb drive is inserted) then press the PREVIOUS and NEXT buttons to select a track for playback.

SPECIFICATIONS

Power Output: 10W x 2

Frequency Response: 100Hz-20KHz

Power input: 100 – 240V AC

Warranty Against Defects

Laser Corporation Pty Ltd ("Laser") warrants your new product to be free from defects in materials and workmanship for 12 months, from the date of purchase, provided that the product is used in accordance with accompanying recommendations or instructions where provided. The benefit of this warranty is in addition to your rights under the Australian Consumer Law and to other rights and remedies of the consumer under a law in relation to the goods or services to which the warranty relates.

Through a network of retailers and resellers, Laser will provide you with your choice of a repair, exchange (where possible) or refund (within Dead on Arrival period) for this product if it becomes defective within the warranty period.

This warranty will no longer apply where the defect is a result of alteration, accident, misuse, abuse, normal wear and tear, neglect or improper storage. Please retain your receipt as proof of purchase

How to make a product warranty claim:

Step 1: Find your receipt which proves the date of purchase. Where the date of purchase cannot be verified, your place of purchase or Laser will make an assessment based on the date of manufacture, the condition of the Laser Product and the type of defect.

Step 2a): Contact your place of purchase. They will assess the nature of the fault and repair, replace or fund the product as per their store refund or warranty policy.

Step 2b): If your place of purchase cannot be contacted, then you can contact Laser. Customer Service with details of your defective Laser Product: Phone: (02) 9870 3388; or Email: support@laserco.com.au or online www.laserco.com.au/warranty (click on "Consumers (End Users)"). Our business address is at 1/6-8 Byfield Street, North Ryde, NSW 2113

Step 3: Laser will issue you with a Return Authorisation (RA) number within 48 hours. When requested, send us the defective Product and a copy of your receipt. Laser will cover the cost of the return delivery.

Step 4: Wait for us to contact you. Once we have received your defective Laser Product for inspection, we will inform you of our assessment of your claim within 7 days. When we contact you, we will firstly let you know whether you have a valid claim under this Warranty, and if so, we will inform you whether your defective Laser Product will be replaced or repaired, together with the number of days you can expect to wait to receive your replaced or repaired Laser Product.

Step 5: For further details on warranty cover and returns, please check Terms and Conditions for Warranty Returns section on <http://www.laserco.com.au/warranty>

Our goods come with guarantees that cannot be excluded under the Australian Consumer Law. You are entitled to a replacement or refund for a major failure and compensation for any other reasonably foreseeable loss or damage. You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and the failure does not amount to a major failure.

(BLANK PAGE)