



CU575

User Guide

Part 15.21 statement

" Change or Modifications that are not expressly approved by the manufacturer could void the user's authority to operate the equipment. "

Part 15.105 statement

This equipment has been tested and found to comply with the limits for a class B digital device, pursuant to Part 15 of the FCC Rules.

These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. if this equipment does cause harmful interference or television reception, which can be determined by

turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected
- Consult the dealer or an experienced radio/TV technician for help.

LIMITED WARRANTY STATEMENT

1. WHAT THIS WARRANTY COVERS:

LG offers you a limited warranty that the enclosed subscriber unit and its enclosed accessories will be free from defects in material and workmanship, according to the following terms and conditions:

- (1) The limited warranty for the product extends for ONE (1) year beginning on the date of purchase of the product.
- (2) The limited warranty extends on to the original purchaser of the product and is not assignable or transferable to any subsequent purchaser/end user.
- (3) This warranty is good only to the original purchaser of the product during the warranty period as long as it is in the U.S., including Alaska, Hawaii, U.S. Territories and Canada.
- (4) The external housing and cosmetic parts shall not be covered under these limited warranty terms.
- (5) Upon request from LG, the consumer must provide information to reasonably prove the date of purchase.
- (6) The customer shall bear the cost of shipping the product to the Customer Service Department of LG. LG shall bear the cost of shipping the product back to the consumer after the completion of service under this limited warranty.

2. WHAT THIS WARRANTY DOES NOT COVER:

- (1) Defects or damages resulting from use of the product in other than its normal and customary manner.
- (2) Defects or damages from abnormal use, abnormal conditions, improper storage, exposure to moisture or dampness, unauthorized modifications, unauthorized connections, unauthorized repair, misuse, neglect, abuse, accident, alteration, improper installation, or other acts which are not the fault of LG, including damage caused by shipping blown fuses spills of food or liquid.
- (3) Breakage or damage to antennas unless caused directly by defects in material or workmanship.
- (4) That the Customer Service Department at LG was not notified by consumer of the alleged defect or malfunction of the product during the applicable limited warranty period.
- (5) Products which have had the serial number removed or made illegible.
- (6) The limited warranty is in lieu of all other warranties, express or implied either in fact or by operations law, statutory or otherwise, including, but limited to any implied warranty of marketability or fitness for a particular use.
- (7) Damage resulting from use of non-LG approved accessories.
- (8) All plastic surfaces and all other externally exposed parts that are scratched or damaged due to normal customer use.
- (9) Products operated outside published maximum ratings.
3
- (10) Products used or obtained in a rental program.
- (11) Consumables (such as fuses).

3. STATE LAW RIGHTS:

No other express warranty is applicable to this product. THE DURATION OF ANY IMPLIED WARRANTIES, INCLUDING THE IMPLIED WARRANTY OF MARKETABILITY, IS LIMITED TO THE DURATION OF THE EXPRESS WARRANTY HEREIN. LG INFOCOMM INC. SHALL NOT BE LIABLE FOR THE LOSS OF THE USE OF THE PRODUCT, INCONVENIENCE, LOSS OR ANY OTHER DAMAGES, DIRECT OR CONSEQUENTIAL, ARISING OUT OF THE USE OF, OR INABILITY TO USE, THIS PRODUCT OR FOR ANY BREACH OF ANY EXPRESS OR IMPLIED WARRANTY, INCLUDING THE IMPLIED WARRANTY OF MARKETABILITY APPLICABLE TO THIS PRODUCT. Some states do not allow the exclusion of incidental or consequential damages or limitations on how long an implied warranty lasts; so these limitations or exclusions may not apply to you. This warranty gives you specific legal rights and you may also have other rights which vary from state to state.

4. HOW TO GET WARRANTY SERVICE:

To obtain warranty service, please call the following web address:

www.lgeservice.com

For Your Safety

Important Information

This user guide contains important information on the use and operation of this phone. Please read all the information carefully for optimal performance and to prevent any damage to or misuse of the phone. Any changes or modifications not expressly approved in this user guide could void your warranty for this equipment.

Before You Start

Safety Instructions

WARNING! To reduce the possibility of electric shock, do not expose your phone to high humidity areas, such as the bathroom, swimming pool, etc.

Always store your phone away from heat. Never store your phone in settings that may expose it to temperatures less than 32°F or greater than 104°F, such as outside during extreme weather conditions or in your car on a hot day. Exposure to excessive cold or heat will result in malfunction, damage and/or catastrophic failure.

Be careful when using your phone near other electronic devices. RF emissions from your mobile phone may affect nearby in adequately shielded electronic equipment. You should consult with manufacturers of any personal medical devices such as pacemakers and hearing aides to determine if they are susceptible to interference from your mobile phone.

Turn off your phone in a medical facility or at a gas station. Never place your phone in a microwave oven as this will cause the battery to explode.

IMPORTANT! Please read the TIA SAFETY INFORMATION on page 78 before using your phone.

Safety Information

Read these simple guidelines. Breaking the rules may be dangerous or illegal. Further detailed information is given in this user guide.

- ▶ Never use an unapproved battery since this could damage the phone and/or battery and could cause the battery to explode.
- ▶ Never place your phone in a microwave oven as it will cause the battery to explode.
- ▶ Do not dispose of your battery by fire or with hazardous or flammable materials.
- ▶ Make sure that no sharp-edged items come into contact with the battery. There is a risk of this causing a fire.
- ▶ Store the battery in a place out of reach of children.
- ▶ Be careful that children do not swallow any parts such as rubber plugs (earphone, connection parts of the phone, etc.). This could cause asphyxiation or suffocation.

- ▶ Unplug the power cord and charger during lightning storms to avoid electric shock or fire.
- ▶ When riding in a car, do not leave your phone or set up the hands-free kit near to the air bag. If wireless equipment is improperly installed and the air bag is activated, you may be seriously injured.
- ▶ Do not use a hand-held phone while driving.
- ▶ Do not use the phone in areas where its use is prohibited. (For example: aircraft).
- ▶ Do not expose the battery charger or adapter to direct sunlight or use it in places with high humidity, such as a bathroom.
- ▶ Never store your phone in temperatures less than -4°F or greater than 122°F.
- ▶ Do not use harsh chemicals (such as alcohol, benzene, thinners, etc.) or detergents to clean your phone. There is a risk of this causing a fire.
- ▶ Do not drop, strike, or shake your phone severely. Such actions may harm the internal circuit boards of the phone.
- ▶ Do not use your phone in high explosive areas as the phone may generate sparks.
- ▶ Do not damage the power cord by bending, twisting, pulling, or heating. Do not use the plug if it is loose as it may cause a fire or electric shock.
- ▶ Do not place any heavy items on the power cord. Do not allow the power cord to be crimped as it may cause fire or electric shock.
- ▶ Do not handle the phone with wet hands while it is being charged. It may cause an electric shock or seriously damage your phone.
- ▶ Do not disassemble the phone.
- ▶ Do not place or answer calls while charging the phone as it may short-circuit the phone and/or cause electric shock or fire.
- ▶ Only use the batteries, antennas, and chargers provided by LG. The warranty will not be applied to products provided by other suppliers.
- ▶ Only authorized personnel should service the phone and its accessories. Faulty installation or service may result in accidents and consequently invalidate the warranty.
- ▶ Do not hold or let the antenna come in contact with your body during a call.
- ▶ An emergency call can be made only within a service area. For an emergency call, make sure that you are within a service area and that the phone is turned on.

FCC RF Exposure Information

WARNING! Read this information before operating the phone. In August 1996, the Federal Communications (FCC) of the United States, with its action in Report and Order FCC 96-326, adopted an updated safety standard for human exposure to radio frequency (RF) electromagnetic energy emitted by FCC regulated transmitters. Those guidelines are consistent with the safety standard previously set by both U.S. and international standards bodies.

The design of this phone complies with the FCC guidelines and these international standards.

CAUTION

Use only the supplied and approved antenna. Use of unauthorized antennas or modifications could impair call quality, damage the phone, void your warranty and/or result in violation of FCC regulations. Do not use the phone with a damaged antenna. If a damaged antenna comes into contact with skin, a minor burn may result. Contact your local dealer for a replacement antenna.

Body-worn Operation

This device was tested for typical body-worn operations with the back of the phone kept 0.79 inches (2cm) between the user's body and the back of the phone. To comply with FCC RF exposure requirements, a minimum separation distance of 0.79 inches (2cm) must be maintained between the user's body and the back of the phone. Third-party belt-clips, holsters, and similar accessories containing metallic components should not be used. Body-worn accessories that cannot maintain 0.79 inches (2cm) separation distance between the user's body and the back of the phone, and have not been tested for typical body-worn operations may not comply with FCC RF exposure limits and should be avoided.

Vehicle Mounted External Antenna (optional, if available)

A minimum separation distance of 8 inches (20cm) must be maintained between the user/bystander and the vehicle mounted external antenna to satisfy FCC RF exposure requirements. For more information about RF exposure, visit the FCC website at www.fcc.gov

FCC Part 15 Class B Compliance

This device and its accessories comply with part 15 of FCC rules. Operation is subject to the following two conditions: (1) This device and its accessories may not cause harmful interference, and (2) this device and its accessories must accept any interference received, including interference that may cause undesired operation.

Cautions for Battery

- ▶ Do not disassemble.
- ▶ Do not short-circuit.
- ▶ Do not expose to high temperature: 60°C (140°F).]
- ▶ Do not incinerate.

Battery Disposal

- ▶ Please dispose of your battery properly or bring to your local wireless carrier for recycling.
- ▶ Do not dispose in fire or with hazardous or flammable materials.

Adapter (Charger) Cautions

- ▶ Using the wrong battery charger could damage your phone and void your warranty.
- ▶ The adapter or battery charger is intended for indoor use only.

Do not expose the adapter or battery charger to direct sunlight or use it in places with high humidity, such as the bathroom.

Table of Contents

For Your Safety	7	Making International Calls	21
Your Phone	12	Ending a Call	21
Phone Components	12	Making a Call From the Contacts	21
Your Phone's Features	13	Adjusting the Volume	22
Task menu key	14	Answering a Call	22
Display Information	15	Vibrate Mode (Quick)	22
Getting Started	17	Signal Strength.....	22
Installing the SmartChip	17	Entering Text	22
Charging the Battery	18	Selecting Functions and Options	26
Memory card slot	19	In-Call Menu	27
Inserting the memory card	19	During a Call	27
Removing the memory card	19	Making a Second Call	27
Turning Your Phone On and Off	20	Swapping Between Two Calls.....	27
Access Codes	20	Answering an Incoming Call	27
Barring Password	20	Rejecting an Incoming Call	27
General Functions	21	Muting the Microphone	27
Making a Call	21	Using the Speakerphone	28
Making a Call by Send Key.....	21		

Video Share Calling	28	Community	40
Making and Answering a Video Share Calling	28	Music Apps	40
Making a Video Share call in Camera & Recording mode	30	Messaging	41
Conference Calls	31	New Message	41
Making a Second Call	31	Inbox	43
Setting Up a Conference Call.....	31	IM	44
Activate the Conference Call on Hold	31	Mobile Email	47
Adding Calls to the Conference Call	32	Drafts	48
Private Call in a Conference Call.....	32	Outbox	48
Ending a Conference Call	32	Sent	49
Menu Tree	33	Voicemail	49
Music	37	Templates	49
Music Player	37	Text Templates	49
Shop Music	39	Multimedia Templates	50
MusicID	39	Signature	50
Streaming Music	39	Message Settings	50
Music Videos	39	Text Message	50
The Buzz	39	Multimedia Message	50
		Voicemail.....	51

Service Messages	51
Recent Calls	52
Missed Calls.....	52
Dialed Calls	52
Received Calls	52
All Calls.....	52
Call Duration	52
Data Counter.....	53
MEdia Net	54
MEdia Net Home.....	54
Bookmarks.....	55
Saved Pages	55
Enter URL.....	55
Recent Pages	55
Security	55
Browser Settings.....	56
Accounts	56
Primary Storage	57
Cache Settings	57

Cookie Settings	57
Character Encoding.....	57
Scrolling Control	57
Show Image.....	57
AuthWallet.....	57

Mall	59
Shop Tones	59
Shop Games.....	59
Shop Graphics.....	59
Shop Multimedia	59
Shop Applications.....	59
MEdia Net Home.....	59

Cellular Video	60
My Stuff	61
Games	61
Applications	61
Audio & Ringtones	61

Graphics	62	Address Book	69
Video	62	Contact List	69
Tools	62	New Contact	69
Alarm Clock	62	Caller Groups	69
Calendar	63	Speed Dial List	69
Notepad	63	Copy All Contacts	69
Calculator	63	Delete All Contacts	70
Tip Calculator	64	Service Dial Numbers	70
World Clock	64	My Business Card	70
Tasks	64	Settings	70
Stop Watch	64	My Numbers	70
Unit Converter	65	Settings	71
Date Finder	65	Audio & Ringtones	71
D-Day Counter	65	Display	72
Camera & Recordings	65	Bluetooth	72
Take Photo	65	Date & Time	74
Record Video	67	Call	75
Record Voice	68	Security	78
Other Files	68	Connection	80
Memory Card	68		

Flight Mode	80
Software Update	80
Check Memory	80
Handset Information	81
Reset Settings	81
Q&A	82
Accessories	84
Safety Guidelines	85
Glossary	101
Index	103

For Your Safety

Important Information

This user guide contains important information on the use and operation of this phone. Please read all the information carefully for optimal performance and to prevent any damage to or misuse of the phone. Any changes or modifications not expressly approved in this user guide could void your warranty for this equipment.

Before You Start

Safety Instructions

WARNING! To reduce the possibility of electric shock, do not expose your phone to high humidity areas, such as the bathroom, swimming pool, etc.

Always store your phone away from heat. Never store your phone in settings that may expose it to temperatures less than 32°F or greater than 104°F, such as outside during extreme weather conditions or in your car on a hot day. Exposure to excessive cold or heat will result in malfunction, damage and/or catastrophic failure.

Be careful when using your phone near other electronic devices. RF emissions from your mobile

phone may affect nearby in adequately shielded electronic equipment. You should consult with manufacturers of any personal medical devices such as pacemakers and hearing aides to determine if they are susceptible to interference from your mobile phone. Turn off your phone in a medical facility or at a gas station. Never place your phone in a microwave oven as this will cause the battery to explode.

IMPORTANT! Please read the TIA SAFETY INFORMATION on page 85 before using your phone.

Safety Information

Read these simple guidelines. Breaking the rules may be dangerous or illegal. Further detailed information is given in this user guide.

- ▶ Never use an unapproved battery since this could damage the phone and/or battery and could cause the battery to explode.
- ▶ Never place your phone in a microwave oven as it will cause the battery to explode.
- ▶ Do not dispose of your battery by fire or with hazardous or flammable materials.

For Your Safety

- ▶ Make sure that no sharp-edged items come into contact with the battery. There is a risk of this causing a fire.
- ▶ Store the battery in a place out of reach of children.
- ▶ Be careful that children do not swallow any parts such as rubber plugs (earphone, connection parts of the phone, etc.). This could cause asphyxiation or suffocation.
- ▶ Unplug the power cord and charger during lightning storms to avoid electric shock or fire.
- ▶ When riding in a car, do not leave your phone or set up the hands-free kit near to the air bag. If wireless equipment is improperly installed and the air bag is activated, you may be seriously injured.
- ▶ Do not use a hand-held phone while driving.
- ▶ Do not use the phone in areas where its use is prohibited. (For example: aircraft).
- ▶ Do not expose the battery charger or adapter to direct sunlight or use it in places with high humidity, such as a bathroom.
- ▶ Never store your phone in temperatures less than -4°F or greater than 122°F.
- ▶ Do not use harsh chemicals (such as alcohol, benzene, thinners, etc.) or detergents to clean your phone. There is a risk of this causing a fire.
- ▶ Do not drop, strike, or shake your phone severely. Such actions may harm the internal circuit boards of the phone.
- ▶ Do not use your phone in high explosive areas as the phone may generate sparks.
- ▶ Do not damage the power cord by bending, twisting, pulling, or heating. Do not use the plug if it is loose as it may cause a fire or electric shock.
- ▶ Do not place any heavy items on the power cord. Do not allow the power cord to be crimped as it may cause fire or electric shock.
- ▶ Do not handle the phone with wet hands while it is being charged. It may cause an electric shock or seriously damage your phone.
- ▶ Do not disassemble the phone.
- ▶ Do not place or answer calls while charging the phone as it may short-circuit the phone and/or cause electric shock or fire.

- ▶ Only use the batteries, antennas, and chargers provided by LG. The warranty will not be applied to products provided by other suppliers.
- ▶ Only authorized personnel should service the phone and its accessories. Faulty installation or service may result in accidents and consequently invalidate the warranty.
- ▶ Do not hold or let the antenna come in contact with your body during a call.
- ▶ An emergency call can be made only within a service area. For an emergency call, make sure that you are within a service area and that the phone is turned on.
- ▶ Use accessories, such as earphones and headsets, with caution. Ensure that cables are tucked away safely and do not touch the antenna unnecessarily.

Memory card information and care

- ▶ Always insert/ remove the memory card while the handset power is off. If you remove it while the power is on, it may be damaged.
- ▶ If a damage cannot be fixed, format the memory card.

- ▶ The memory card cannot be used for recording copyright- protected data.
- ▶ Do not write forcefully on the memo area.
- ▶ Carry and store the memory card in its case.
- ▶ Do not allow the memory card to get wet.
- ▶ Do not leave the memory card in extremely hot location.
- ▶ Do not disassemble or modify the memory card.

FCC RF Exposure Information

WARNING! Read this information before operating the phone.

In August 1996, the Federal Communications (FCC) of the United States, with its action in Report and Order FCC 96-326, adopted an updated safety standard for human exposure to radio frequency (RF) electromagnetic energy emitted by FCC regulated transmitters. Those guidelines are consistent with the safety standard previously set by both U.S. and international standards bodies.

The design of this phone complies with the FCC guidelines and these international standards.

CAUTION

Use only the supplied and approved antenna. Use of unauthorized antennas or modifications could impair call quality, damage the phone, void your warranty and/or result in violation of FCC regulations. Do not use the phone with a damaged antenna. If a damaged antenna comes into contact with skin, a minor burn may result. Contact your local dealer for a replacement antenna.

Body-worn Operation

This device was tested for typical body-worn operations with the back of the phone kept 0.6 inches (1.5cm) between the user's body and the back of the phone. To comply with FCC RF exposure requirements, a minimum separation distance of 0.6 inches (1.5cm) must be maintained between the user's body and the back of the phone. Third-party belt-clips, holsters, and similar accessories containing metallic components should not be used. Body-worn accessories that cannot maintain 0.6 inches (1.5cm) separation distance between the user's body and the back of the phone, and have not been tested for typical body-worn operations may not comply with FCC RF exposure limits and should be avoided.

Vehicle Mounted External Antenna (optional, if available)

A minimum separation distance of 8 inches (20cm) must be maintained between the user/bystander and the vehicle mounted external antenna to satisfy FCC RF exposure requirements. For more information about RF exposure, visit the FCC website at www.fcc.gov

FCC Part 15 Class B Compliance

This device and its accessories comply with part 15 of FCC rules. Operation is subject to the following two conditions:

(1) This device and its accessories may not cause harmful interference, and (2) this device and its accessories must accept any interference received, including interference that may cause undesired operation.

Cautions for Battery

- ▶ Do not disassemble.
- ▶ Do not short-circuit.
- ▶ Do not expose to high temperature: 60°C (140°F).]
- ▶ Do not incinerate.

Battery Disposal

- ▶ Please dispose of your battery properly or bring to your local wireless carrier for recycling.
- ▶ Do not dispose in fire or with hazardous or flammable materials.

Adapter (Charger) Cautions

- ▶ Using the wrong battery charger could damage your phone and void your warranty.
- ▶ The adapter or battery charger is intended for indoor use only.

Do not expose the adapter or battery charger to direct sunlight or use it in places with high humidity, such as the bathroom.

Avoid damage to your hearing

- ▶ Damage to your hearing can occur if you are exposed to loud sound for long periods of time. We therefore recommend that you do not turn on or off the handset close to your ear. We also recommend that music and call volumes are set to a reasonable level.
- ▶ If you are listening to music whilst out and about, please ensure that the volume is at a reasonable level so that you are aware of your surroundings. This is particularly imperative when attempting to cross the street.

Menu Tree

The following illustration shows the available menu structure and indicates the:

- ▶ Number assigned to each menu option.
- ▶ Page where you can find the feature description.

1. Music (see page 37)

1.1 Music Player

1.2 Shop Music

1.3 MusicID

1.4 Streaming Music

1.5 Music Videos

1.6 The Buzz

1.7 Community

1.8 Music Apps

2. Messaging (see page 41)

2.1 New Message

2.2 Inbox

2.3 IM

2.4 Mobile Email

2.5 Drafts

2.6 Outbox

2.8 Sent

2.8 Voicemail

2. Messaging (continued)

2.9 Templates

2.9.1 Text Templates

2.9.2 Multimedia Templates

2.9.3 Signature

2.0 Message Settings

2.0.1 Text Message

2.0.2 Multimedia Message

2.0.3 Voicemail

2.0.4 Service Messages

3. Recent Calls (see page 52)

3.1 Missed Calls

3.2 Dialed Calls

3.3 Received Calls

3.4 All Calls

3.5 Call Duration

3.6 Data Counter

4. MEdia Net (see page 54)

4.1 MEdia Net Home

4.2 Bookmarks

4.3 Saved Pages

4.4 Enter URL

4.5 Recent Pages

4.6 Security

4.7 Browser Settings

4.7.1 Accounts

4.7.2 Primary Storage

4.7.3 Cache Settings

4.7.4 Cookie Settings

4.7.5 Character Encoding

4.7.6 Scrolling Control

4.7.7 Show Image

4.7.8 AuthWallet

5. Mall (see page 59)

5.1 Shop Tones

5.2 Shop Games

5.3 Shop Graphics

5.4 Shop Multimedia

5.5 Shop Applications

5.6 MEdia Net Home

6. Cellular Video (see page 60)**7. My Stuff (see page 61)**

7.1 Games

7.2 Applications

7.3 Audio & Ringtones

7.4 Graphics

7.5 Video

7.6 Tools

7.6.1 Alarm Clock

7.6.2 Calendar

7.6.3 Notepad

7.6.4 Calculator

7.6.5 Tip Calculator

7.6.6 World Clock

7.6.7 Tasks

7.6.8 Stop Watch

7.6.9 Unit Converter

7.6.0 Date Finder

7.6.* D-Day Counter

7. My Stuff (continued)

7.7 Camera & Recordings

7.7.1 Take Photo

7.7.2 Record Video

7.7.3 Record Voice

7.8 Other Files

7.9 Memory Card

8. Address Book (see page 69)

8.1 Contact List

8.2 New Contact

8.3 Caller Groups

8.4 Speed Dial List

8.5 Copy All Contacts

8.6 Delete All Contacts

8.7 Service Dial Numbers

8.8 My Business Card

8.9 Settings

8.0 My Numbers

9. Settings (see page 71)

9.1 Audio & Ringtones

9.1.1 Shop Tones

9.1.2 Ringtones

9.1.3 Volume

9.1.4 Message Alert Tones

9.1.5 Alert Type

9.1.6 Increasing Ringtone

9.1.7 Power On/Off Tones

9.2 Display

9.2.1 Shop Graphics

9.2.2 Wallpapers

9.2.3 Backlight Timer

9.2.4 Menu Styles

9.2.5 Languages

9.2.6 Dialing Fonts

9.2.7 Clocks & Calendar

9.2.8 Color Schemes

9.3 Bluetooth

9.3.1 Turn On/Off

9.3.2 Search New Devices

9.3.3 Paired Devices

9.3.4 Settings

9. Settings (continued)

9.4 Date & Time

- 9.4.1 Set Date
- 9.4.2 Date Format
- 9.4.3 Set Time
- 9.4.4 Time Format
- 9.4.5 Auto Update

9.5 Call

- 9.5.1 Call forwarding
- 9.5.2 Send My Number
- 9.5.3 Auto Redial
- 9.5.4 Answer Mode
- 9.5.5 Bluetooth Call Answer
- 9.5.6 Minute Minder
- 9.5.7 Call Waiting
- 9.5.8 Call Reject
- 9.5.9 TTY
- 9.5.0 Send DTMF Tones
- 9.5.* Video Share

9.6 Security

- 9.6.1 Lock Handset
- 9.6.2 PIN Code Request
- 9.6.3 Fixed Dial Number
- 9.6.4 Change Codes

9. Settings (continued)

9.7 Connection

- 9.7.1 Network Profiles
- 9.7.2 USB Connection Mode

9.8 Flight Mode

9.9 Software Update

9.0 Check Memory

- 9.0.1 Common
- 9.0.2 Reserved
- 9.0.3 SmartChip
- 9.0.4 Memory Card

9.* Handset Information

9.# Reset Settings

- 9.#.1 Clear Memory
- 9.#.2 Reset Default

Music Player

Menu 1.1

- ▶ **All Songs:** You can view the entire playlist in the internal/external memory.
- ▶ **Playlists:** You can create your own playlists by choosing songs from the All Songs menu list.
- ▶ **Shuffle Songs:** Plays music files in random order.
- ▶ **Settings**
 - **Set Shuffle:** Plays all tracks in random order.
 - **Set Repeat:** Allows you to set the play mode such as Repeat One, All or Off.
 - **Visualization:** Allows you to select the desired equalizer on the main screen.
 - **Equalizer:** Allows you to select the desired sound style.

Note

Copyrights of music files may be protected by copyright and intellectual property laws. Therefore, it may be required to obtain necessary permissions or licenses before you can reproduce or copy the materials. In some countries, national law prohibits copying of copyrighted materials for personal archive as well. Prior to downloading or copying the files, please ensure that you adhere to the applicable laws and

laws of corresponding countries or regions regarding the Terms of Use of materials.

Transferring Music

Listen to music on your phone.

Transfer your favorite tunes today!

1. You must convert your music to either .MP3, .AAC, or .AAC+ format using the media player of your choice.
2. Remove the battery and insert the microSD™ card* (gold contacts facing down) into the slot at the top of the phone.
3. Power on the phone and connect it to your PC using a USB data cable.*
4. When the Hardware Wizard pops up, click **Cancel**.
5. The PC recognizes the phone as a **Removable Disk** under **My Computer**. Open the folder where your music is stored and transfer your files by dragging and dropping them onto the **Removable Disk** icon.
6. When finished, press the **Right Soft Key** for **Exit** and disconnect the USB cable.


Warning

Do not disconnect phone while file transfer is in progress.

*microSD card and USB data cable sold separately; go to www.cingular.com.



Requirement:
Windows 2000 or later Not compatible with Mac OS.



Note

The number of files you can store depends on the size and format options of your memory card.

Playing Music

To listen to music that you have transferred to your phone, follow these quick easy steps:

Playing Music with the Flip Open

1. Press the **Music Key**, select **Music Player (1)**, then **All Songs (1)** or **Playlists (2)**. Select a song or playlist.
2. Press **Navigation Key** to play/pause. Press **up** or **down** on the Navigation Key to change the volume, and **left** or **right** to go to the previous or next song.
3. Press the **Left Soft Key** for **Minimize** to access other phone functionality while music is playing.

Playing Music with the Flip Closed

1. Press and hold the **Play/Pause Key**. Select **All Songs** or a playlist. Use the left side volume keys to scroll.
2. Press **Play/Pause** to play/pause the music. Use the **Left** or **Right** keys to go to the previous or next song.
3. Press and hold the **Play/Pause Key** to exit the music player.

Shop Music

Menu 1.2

This menu option connects to music download site.

📌 **Note**

Additional charges may incur when downloading ringtone.

Contact your service provider for further information.

MusicID

Menu 1.3

This menu allows you to find out title, artist and other information about the song by just sending the sound of the song.

- ▶ **ID song!**: Allows you to find out information of unknown music by sending the sound of the unknown music to the web. If the web identifies the song, it returns with relevant information of the song.
- ▶ **manage IDs**: Once a song has been identified through the MusicID, you can see the list of songs in this folder.
- ▶ **help me out**: Information for how to use this java application.
- ▶ **exit**: Ends the application and exits.

Streaming Music

Menu 1.4

Selecting Streaming Music from the Music sub menu launches a preinstalled java application.

The application allows the user to listen to Streaming Music

Music Videos

Menu 1.5

This menu option connects to music video download site.

📌 **Note**

Additional charges may incur when downloading music video contents.

Contact your service provider for further information.

The Buzz

Menu 1.6

Selecting The Buzz from the Music sub menu launches a preinstalled java application (e.g. Billboard). The application allows the user to obtain relevant music industry news and information.

Community

Menu 1.7

Selecting Community from the Music sub menu launches the browser to either one or more of the hot user communities. This menu allows you to interact with your friends and the community.

Music Apps

Menu 1.8

Selecting Music Apps from the Music sub menu launches the browser to an area where the user can purchase music related applications for download.

Messaging

This menu includes functions related to SMS (Short Message Service), MMS (Multimedia Message Service), voice mail, as well as the network's service messages.

New Message

Menu 2.1

Note

If you select a graphic or an audio file while writing a multimedia message, the file loading time will take about 5 seconds. You will not be able to activate any key during the file loading time. When the file loading is complete, you will be able to write a multimedia message.

Editing a message

The following options are available for Editing a Message. (Press the left soft key [Insert])

- ▶ **Symbol:** You can insert symbols ranging from sentence notes to emoticons. Select the one you want by navigating the left/right soft keys [Previous/Next].
- ▶ **Graphic:** You can select a graphic image by using the left/right navigation keys. You can preview the selected picture by pressing the left soft key [View].

- ▶ **Audio:** You can insert various ringtones.

Note

vCard, vCalendar, vNote and vTask are created by Address Book, Calendar, Notepad and Tasks respectively. Go to the Tools and Address Book sections for more detailed information.

- ▶ **Video:** You can insert a video clip by using the center key [Insert].
- ▶ **New Photo:** You can insert a new image taken from the camera by pressing [Capture]. The following camera options are available when you press [Options]:
 - **Resolution:** The resolution of the image can be captured in **1280*960/640*480/320*240/160*120**
 - **Quality:** The quality of the captured image can be **Super Fine/Fine/Normal**
 - **Primary Storage:** You can assign the primary storage to Handset Memory or Memory Card.
 - **Rotate View:** You can view the photo upside down
 - **View Full Screen:** Extends the photo screen to full.
 - **Self Timer:** Camera timer can be set to **Off/3 Seconds/5 Seconds/10 Seconds**

- **Advanced Settings:** Set the **White Balance** as **Auto/Daylight/Incandescent/Cloudy/Fluorescent/Night mode**. **Color Effects** includes options such as **Color/ Sepia/ Mono/Negative**. **Shutter Tones** can be set to **Tone 1/ Tone 2/ Tone 3/ Off**.
- **Default Settings:** Allows you to set to the default settings.
- ▶ **New Audio:** You can record a new audio by pressing the center key [**Record**]. After recording a new audio, you can cancel it by pressing the right key [**Cancel**]. To control the new audio menu, choose [**Options**] by pressing the right key. Under [**Options**], choose one of following
 - **Record Mode:** Set as **MMS** or **General Mode**.
 - **Quality:** Set the audio's quality to **Fine, Normal** or **Economy**.
 - **Primary Storage:** You can assign the primary storage to **Handset Memory** or **Memory Card**.
- ▶ **New Video:** You can record new video by pressing the center key [**Record**].
- ▶ **Subject:** Type a subject into the message.
- ▶ **Others:** Allows you to insert **vCard, vCalendar, vNote** or **vTask**.

▶ **Template**

- **Text:** You can easily insert the frequently used sentences in the text message.
- **Multimedia:** The preset multimedia templates are available.
- **Signature:** Input your own signature created in (Menu 2.9.3). For further details, see page 50.

▶ **Contact:** You can browse one of your contacts and insert it.

▶ **Slide:** You can insert a slide and place it to **Insert Slide Before** or **Insert Slide After**.

Using Options

Press right soft key [Options].

- **Preview:** Shows the created multimedia message before sending it.(Only for Multimedia Message)
- **Remove:** Removes the selected multimedia or vObject.(Only for Multimedia Message)
- **Save to Drafts:** Saves the selected message to draft.
- **Select Slide:** If the message has more than one slide, you can select and move to the desired slide.(Only for Multimedia Message)

- **Set Slide:** Sets the Duration, Text color and background color of the selected slide.(Only for Multimedia Message)
- **Text Entry Mode:** Sets the text input mode. For more details, refer to **Entering Text** (page 22).
- **Text Entry Settings: Text Entry Languages** allows you to set the text entry language to English, Spanish or French. **T9 Next Word Prediction** is available when it is set to **On**. Use **T9 Dictionary** to add words or delete/reset/modify words.
- **Cancel:** Allows you to exit the text input mode without saving your input message.

Sending a Message

After completing a message using the **Insert/Options**, select **Send To** to send a message.

- Enter the recipient(s) as To, Cc and Bcc. You can use the Contacts option to choose a recipient.
- Press the right soft key [**Options**].

You can insert symbols, refer to recent messages, recent calls and caller groups to set as a recipient, and edit your message. For the **Save to Drafts**, **Text Entry Mode**, **Text Entry Settings** and **Cancel** options, see the descriptions above.

Inbox

Menu 2.2

You will be alerted when you receive a message. They will be stored in the Inbox. In the Inbox, you can identify each message by icons. If you are notified that you have received a multimedia message, you can download the whole multimedia message by selecting it in the Receive menu. For download settings, see (Menu 2.9) for details.

The following [Options] are available in the Inbox list.

- ▶ **Save Contact Info:** You can save the sender's phone number in the Contact List.
- ▶ **Delete:** You can delete the current message.
- ▶ **Forward:** You can forward the selected message to another party.
- ▶ **Reply All:** Allows you to reply to all recipients on the selected message (Only for Multimedia messages).
- ▶ **Information:** You can view information about received messages; Message type, Subject, Sender's address, Message date & time, Priority, Message size, Attached Files (Only for Multimedia messages).
- ▶ **Multi Delete:** Deletes a number of messages you have selected from the folder.

- ▶ **Delete All Read Messages:** You can delete all read messages.
- ▶ **Delete All:** You can delete all messages.

IM

Menu 2.3

The Instant Messaging feature can only be used with the support of the network operator or communities such as AIM, Windows Live and Y! Messenger. For Instant Messaging users, a valid User ID and Password will be required in order to login and exchange messages as well as checking the online status.

There are two ways to use the Instant Messaging feature.

1. Through the Main Menu.
2. Through the IM hotkey (the right navigation key).
Short pressing the hotkey will bring up the available IM clients. The menu items below might not appear since not all IM communities support the various options. Also the menu strings may appear differently based on the selected IM communities. The keywords such as User ID, Login and Contact will be used as general terms in IM menus according to the currently selected communities such as AIM, Windows Live and Y! Messenger.

Offline Menu

Sign On

This allows users to login by filling in the User ID and Password.

Note

Once the User ID and Password are saved, you will not be required to type them in again during Login process. This feature is optional.

Saved Conversations

This is where a user can view saved conversations.

Settings

- ▶ **Set Sound:** Allows you to set on/off an alert for the Contact when they have activity on their session.
- ▶ **Default Provider:** Allows you to set the default IM community to login.
- ▶ **Auto Sign On:** You may set the automatic IM Login process by choosing between the **'When Power On'** or **'When IM Start'** options.
- ▶ **Network:** You may check your IM Network Profiles or Server Address information.

IM Information

This indicates the Instant Messaging Client Information such as Client Name and Version Number.

Online Menu / 1 to 1 conversation

After a successful Login, a list of contacts with Screen Names will appear on screen. Depending on the cursor location in the contacts, the following menu options will be available.

When cursor is located on a Conversations List

Note

The Conversations List contains both the active contact where a conversation has taken place as well as an unknown contact.

Note

When you select the left/right navigation key or the Confirm key on the Conversation List, it offers the ability to view or hide conversations.

- ▶ **Send to Others:** This offers the ability to send a message to an unknown contact. When selected, a User ID must be typed in prior to starting an IM session or conversation.

- ▶ **Saved Conversations:** You may view or delete the stored conversation session.
- ▶ **Search:** This allows you to search for the contact by Email address or name.
- ▶ **Settings**
 - **My Status:** Allows you to set your status to Available, Busy or Invisible.
 - **Set Sound:** Allows you to set an alert for the Contact when they have activity on their session.
 - **Auto Sign On:** You may Login to an IM client automatically with the 'When Power On' or 'When IM Start' options.
- ▶ **Log Out:** This begins the Logout process.

When cursor is located on a Conversation

- ▶ **End Conversation:** This closes the selected conversation. If an unknown contact was selected, that contact is deleted.
- ▶ **Block/Unblock Contact:** This allows you to block/unblock the selected Conversations Contact.
- ▶ **View Information:** This allows you to view the User ID and Status Text information.

- ▶ **Search:** This allows you to search for the contact by Email address or name.
- ▶ **Settings:** Please refer to the previous Settings Menu.
- ▶ **Log Out:** This begins the Logout process.

When cursor is located on a Contact List

- ▶ **Add Contact:** This adds a new contact to the selected contacts' list; in the meantime this searches for the contact on the basis of E-mail Address, First Name, or Last Name.
- ▶ **Refresh List:** This refreshes the present information on the contacts within the contacts.
- ▶ **Send to Others:** This offers the ability to send a message to an unknown contact. When selected, the User ID must be typed in prior to starting an IM session or conversation.
- ▶ **Saved Conversations:** This is where a user can view saved conversations.
- ▶ **Search:** This allows you to search for the contact by Email address or name.
- ▶ **Settings:** Please refer to the previous Settings Menu.
- ▶ **Log Out:** This begins the Logout process.

When cursor is located on a Contact

- ▶ **Add Contact:** This adds a new contact to the selected contacts list; in the meantime this searches for the contact on the basis of E-mail Address, First Name, or Last Name.
- ▶ **Delete Contact:** This deletes the selected Contact.
- ▶ **Block/Unblock Contact:** This allows or blocks conversation with the selected Contact.
- ▶ **Refresh Contact:** This refreshes the present information on the selected contact.
- ▶ **View Information:** This allows you to view information. It provides User ID, Status Text.
- ▶ **Search:** This allows you to search for the contact by Email address or name.
- ▶ **Settings:** Please refer to the previous Settings Menu.
- ▶ **Log Out:** This begins the Logout process.

Menu options available in the Conversation screen

- ▶ **Back To List:** This brings the screen back to the contacts.
- ▶ **Insert:** You can insert Symbol, Template and

emoticons in the conversation screen.

- ▶ **Block/Unblock Contact:** This allows or blocks conversation with the selected Contact.
- ▶ **Save Conversation:** Stores the currently active conversation.
- ▶ **End Conversation:** This ends the active conversation and clears the conversation buffer.
- ▶ **Settings:** Please refer to the previous Settings Menu.
- ▶ **Text Entry Mode:** Sets the text input mode such as abc, Abc, ABC, T9 abc, T9 Abc, T9 ABC and 123.
- ▶ **Text Entry Mode Settings:** This selects the T9 predictive mode Language.

ⓘ Note


- In the conversation window, you can use the up/down navigation key for scrolling through the conversation.
- Maximum number of characters supported by a message is 800 characters for receiving and 127 characters for sending.
- The present information might not update in real time so the “Refresh List”/“Refresh Contact” option can be used for the most up to date status.

Mobile Email

Menu 2.4

Mobile Email allows you to access your Yahoo! Mail, AOL Mail, AIM Mail, Windows Live Mail, Yahoo!, BellSouth Mail and Other providers accounts on your phone. So, now you can quickly and easily check your email while you're away from your computer.

To Set Up Mobile Email

- ▶ **Open Mobile Email:** Slide out the keyboard, highlight **Mobile Email** and press **OK**.
- ▶ **Select an Email Provider:** Use the navigation key to highlight the email provider you wish to use and press **OK**.
- ▶ **Log In**
 1. Highlight the ID entry field, press down on the navigation key, and then type in your existing email ID.
 2. Scroll down and highlight the Password field, press down on the navigation key, and enter your password. Quick Tip: Your password is case sensitive. Press the  on the keypad to change to lower case or upper case.

3. To save your password scroll down to Remember Me and press down on the navigation key to check the box.

4. Select **Sign In**.

- ▶ **Opening an Email:** Just scroll down and highlight the email subject line you want to open and press down on the navigation key. Once the email opens, just select Options to reply, forward, or delete.
- ▶ **Deleting an Email:** Just scroll down to the email you want to delete, press Options, then Delete.

For additional details, visit www.cingular.com/email

Drafts

Menu 2.5

You can view the messages saved as a draft. The draft messages are listed with the date and time of when the messages were saved.


The following [Options] are available.

- ▶ **Information:** Allows you to view the information on the message.
- ▶ **Multi Delete:** Allows you to delete multiple messages you select from the folder.
- ▶ **Delete All:** Deletes all messages in the folder.

Outbox

Menu 2.6

Outbox is a temporary storage place for messages waiting to be sent.

When you press the  [SEND] key, you can make a call to the number of the recipient number of the selected message.

If the message is not sent from the Outbox, you will receive a sound alert along with a Message Sent Fail notice on the screen.

Another attempt will be made to send the failed message and after two unsuccessful attempts, the message will no longer be sent automatically order to send the message that has failed, you must press **Resend** from the Options menu.

After the maximum number of **Send** attempts has been reached the Send function has failed.

If you were trying to send a text message, open the message and check that the Sending options are correct.

When the message Send has failed, the following



[Options] are available.

- ▶ **Delete:** Deletes the selected message which has failed.
- ▶ **Edit:** Allows you to edit the selected message.
- ▶ **Error Status:** Allows you to see the error status of the failed message (Only for Multimedia message).
- ▶ **Information:** Allows you to view the information on the message.
- ▶ **Delete All:** Deletes all messages in the folder.

Sent

Menu 2.7

This is where you can view the lists and contents of sent messages and also verify if transmission was successful.

The following [Options] are available.


- ▶ **Delete:** Deletes the selected message from the Sent list.
- ▶ **Information:** Allows you to view information on the message.
- ▶ **Delete All:** Deletes all messages in the folder.


Voicemail

Menu 2.8

This menu provides you with a quick way of accessing your voice mailbox (if provided by your network).

Before using this feature, you must enter the voice server number obtained from your service provider.

This may already be available; to check the voicemail, press and hold the  key

When new voicemail is received, the symbol  will be displayed on the screen.

Note

Please check with your network service provider for details of their service in order to configure the handset accordingly.

Templates

Menu 2.9

Text Templates *(Menu 2.9.1)*

There are 6 predefined messages in the list. You can view and edit the template messages or create new messages.

The following [Options] are available.

- ▶ **Send:** Allows you to send the selected template via Message.

- ▶ **Delete:** Allows you to delete the selected template message.
- ▶ **Edit:** Allows you to write a new message or edit the selected template message.
- ▶ **Delete All:** Deletes all messages in the folder.

Multimedia Templates *(Menu 2.9.2)*

1. You can add new multimedia templates by pressing the left soft key [New].
2. The following choices are available under Options.
 - ▶ **Preview:** You can preview multimedia messages you have created.
 - ▶ **Text Entry Mode:** Sets the text input mode as abc, Abc, ABC, T9 abc, T9 Abc, T9 ABC and 123.
 - ▶ **Text Entry Settings:** Allows you to set the text entry language to English, Spanish or French.
 - ▶ **Cancel:** Allows you to exit the text input mode without saving your message.

Signature *(Menu 2.9.3)*

This feature allows you to create your Text signature. You can use symbols, text templates and contacts as part of the signature.

Message Settings

Menu 2.0

Text Message *(Menu 2.0.1)*

- ▶ **Message Center Number:** If you want to send a text message, you can get the address of the SMS center by using this menu.
- ▶ **Email Gateway:** You can send the text message to an Email Address via this gateway.
- ▶ **Message Subject:** You can enter the SMS Subject from this menu.
- ▶ **Insert Signature:** You can insert your own signature (Menu 2.9.3) that you created.

Multimedia Message *(Menu 2.0.2)*

- ▶ **Priority:** You can set the priority of the message you choose.
- ▶ **Message Subject:** You can enter the MMS Subject when this menu is on.
- ▶ **Validity Period:** This network service allows you to set how long your multimedia messages will be stored at the message center.
- ▶ **Send Delivery Receipt:** Allows you to send a delivery confirmation mail for a Multimedia Message.

Messaging

- ▶ **Send Read Receipt:** Allows you to send a message read confirmation mail for a Multimedia Message.
- ▶ **Automatic Download:**
 - **On:** You can always receive multimedia messages automatically.
 - **Off:** You only receive notification messages in the inbox and then you can check the notifications.
- ▶ **Message Center:** The details for the Multimedia gateway are pre-loaded onto your handset and should not be changed.
- ▶ **Message Size:** This menu allows you to determine the maximum size of a Multimedia message when writing the message.

Voicemail *(Menu 2.0.3)*

This menu allows you to set the voicemail center number if this feature is supported by the network service provider. Please check with your network service provider for details of their service in order to configure the handset accordingly.

Service Messages *(Menu 2.0.4)*

You can set the Service option to determine whether you will receive service messages or not.

Recent Calls

You can check the record of missed, received, and dialed calls only if the network supports Calling Line Identification (CLI) within the service area.

The number and name (if available) are displayed together with the date and time of the call. You can also view call times.

Missed Calls

Menu 3.1

- View the number, if available, and call it or save it in the Address Book
- Enter a new name for the number and save both in the Address Book
- Send a message using this number
- Delete the call from the list

Dialed Calls

Menu 3.2

- View the number, if available, and call it or save it in the Address Book
- Enter a new name for the number and save both in the Address Book
- Send a message using this number
- Delete the call from the list

Received Calls

Menu 3.3

- View the number, if available, and call it or save it in the Address Book
- Enter a new name for the number and save both in the Address Book
- Send a message using this number
- Delete the call from the list

All Calls

Menu 3.4

Allows you to view all of missed, received, and dialed call records.

Call Duration

Menu 3.5

This allows you to view the duration of incoming and outgoing calls. You can also reset the call times. The following timers are available:

Last Call

Length of the last call.

Received Calls

Length of the incoming calls.

Recent Calls

Dialed Calls

Length of outgoing calls.

All Calls

Total length of all calls made and incoming calls received since the timer was last reset.

Data Counter

Menu 3.6

You can check the Sent, Received or All data volumes and Reset all.


This menu shows how to access the Internet by launching the WAP browser.

MEDIA Net is one of the services provided by and it gives you access to all the cool things you can do with your wireless phone.


Note

Check the availability of WAP services, pricing and tariffs with your network operator and/or the service provider whose service you wish to use. Service providers will also give you instructions on how to use their services.

Please contact your service provider to open an Internet account.

To launch the browser in standby mode, press and hold down the  key.

Once connected, the homepage is displayed. The content depends on the service provider.

To exit the browser at any time, press the  [END] key. The idle screen is displayed.

Menus for the Browser

You can surf the Internet using either the phone keys or the WAP Browser menu.

Using the Navigation Keys

When surfing the Internet, the keys function differently from phone mode.

Key	Description
up/down navigation key	Scroll each line of the content area

Using the WAP Browser Menu

There are various menus available when surfing the Internet.

MEDIA Net Home

Menu 4.1

This connects to the homepage which is defined in the activated account. The default account connects to homepage.

Bookmarks

Menu 4.2

This function allows you to store and edit frequently accessed sites. The following [Options] are available.

Note

Your phone may have some pre-installed bookmarks for sites not affiliated with LG. LG does not warrant or endorse these sites. If you choose to access them, you should take the same precautions for security or content as you would with any site.

- ▶ **View:** Display the bookmark title and URL
- ▶ **Connect:** Connect to the selected bookmark site
- ▶ **New:** Add a new bookmark manually
- ▶ **Edit:** Modify the existing bookmark item
- ▶ **Delete:** Allows you to erase the selected bookmark
- ▶ **Send URL:** Allows the bookmark information to be sent via SMS to another person
- ▶ **Delete All:** Allows you to erase all bookmarks

Note

Pre-installed bookmarks cannot be deleted or edited by users.

In order to change the text input mode for symbol input, please refer to the General Functions section.

Saved Pages

Menu 4.3

This saves the page on display as an off-line file. A maximum of 20 pages can be saved.

Enter URL

Menu 4.4

Input the URL manually to connect to the Internet site.

Recent Pages

Menu 4.5

You can manage the list of the Internet pages you visited.

Security

Menu 4.6

A list of the available certificates is shown.

- ▶ **Certificates:** You can see the list of certificates and view them in detail.
- ▶ **Clear Session:** Removes the secure session.

Browser Settings

Menu 4.7

Accounts (Menu 4.7.1)

This includes the network information used to connect the browser to the Internet.

Select the desired account by pressing the soft key, which is labelled as “Activate”. This will activate the account that will be used for future connection.

MEdia Net is the predefined account that is set as default.

- ▶ **Activate:** Select the account among the list of accounts, so it can be used for future connection.
- ▶ **View:** Allows you to see the specific account information.
- ▶ **Edit:** Allows you to change the account information.
- ▶ **Delete:** Allows you to delete the account.
- ▶ **New:** Allows you to create a maximum of 20 new accounts.

Note

You cannot edit and delete pre-installed accounts.

In order to create a new account, please fill in the network information.

- 1. Account Name:** Name associated with new account.
- 2. Homepage:** Homepage URL
- 3. Connection Mode:** Select from UDP(CO), UDP(CL), TCP with Proxy, TCP without Proxy
- 4. Proxy Address:** Proxy server address
- 5. Proxy Port Number:** Proxy server's port number
- 6. Security:** Select the secure or non-secure mode.
- 7. Time Out:** Values between 10 to 600 seconds
- 8. Network Profiles:** You can choose one from the network profiles. Note you can create a new network profile by selecting the list option on the center key.

Note

1. The account information will be available from your operator.
2. Creating or editing an account requires care. The browser cannot connect to the Internet if the account information is not correct.

Primary Storage *(Menu 4.7.2)*

You can assign the primary storage to Handset Memory or Memory Card.

Cache Settings *(Menu 4.7.3)*

The web pages you have accessed are stored in the memory of the phone.

- ▶ **Clear Cache:** Remove all cached data in the memory.
- ▶ **Allow Cache:** Set a value to determine whether a connection attempt is made through the cache or not.

Note

A cache is a buffer memory, which is used to store data temporarily, especially when it is online.

Cookie Settings *(Menu 4.7.4)*

The information or services you have accessed are stored in the cookie.

- ▶ **Delete Cookies:** Remove all cookies.
- ▶ **Allow Cookies:** Set a value to determine whether a connection attempt is made through the cookie or not.

Character Encoding *(Menu 4.7.5)*

Select a character set from the following list:

- | | |
|----------------------|------------------------|
| 1 Automatic | 2 English(ASCII) |
| 3 English(ISO) | 4 English(LATIN) |
| 5 Unicode(UCS2 BE) | 6 Unicode(UCS2 LE) |
| 7 Unicode(UCS2 Auto) | 8 Unicode(UTF-16 BE) |
| 9 Unicode(UTF-16 LE) | 0 Unicode(UTF-16 Auto) |
| * Unicode(UTF-8) | |

Scrolling Control *(Menu 4.7.6)*

This allows you to determine the scroll speed and select from **1 Line**, **2 Lines** or **3 Lines**.

Show Image *(Menu 4.7.7)*

This allows you to view pictures when browsing.

AuthWallet *(Menu 4.7.8)*

If set to On, the user's personal information such as ID and Password used to access the Internet site will be saved automatically for future use.

Online menu

Once you are connected to the Internet, the following menu options are available:

- ▶ **Back:** Moves to the previous page.
- ▶ **Forward:** Moves to the next page.
- ▶ **Reload:** Loads the current page again.
- ▶ **Home:** Moves to the initial homepage.
- ▶ **Enter URL:** Connects to the specific URL after editing.
- ▶ **Bookmarks:** You can add or save the current page to Bookmark or view the list saved under Bookmark.
- ▶ **Settings:** You can set browser related options such as Clear cache, Clear cookies, etc.

Shop Tones

Menu 5.1

This menu option connects to ringtone download site.

Note

Additional charges may incur when downloading ringtones. Contact your service provider for further information.

Shop Games

Menu 5.2

This menu option connects to game download site. This allows users to download the various games by connecting to the Internet.

Note

Additional charges may incur when downloading games. Contact your service provider for further information.

Shop Graphics

Menu 5.3

This menu option connects to graphic download site.

Note

Additional charges may incur when downloading graphics. Contact your service provider for further information.

Shop Multimedia

Menu 5.4

This allows you to connect to multimedia download site.

Note

Additional charges may incur when downloading multimedia contents. Contact your service provider for further information.

Shop Applications

Menu 5.5

This menu option connects to application download site. This allows users to download the various applications by connecting to the Internet.

Note

Additional charges may incur when downloading applications. Contact your service provider for further information.

MEdia Net Home

Menu 5.6

This connects to the homepage. The homepage is the site which is defined in the activated account.

Cellular Video

Cellular Video (CV) brings you quick, on-demand access to crystal clear news, sports, weather and entertainment video clips. Catch up on TV's hottest shows, funniest comedians, biggest headlines and latest sports scores. You can even personalize your homepage for quick access to your favorites. In addition, the CV service automatically streams localized weather information to your personalized "News & Weather" page each and every day.

To access CV:

1. From standby mode, press the Left Soft Key to access the Menu.
2. Scroll to and select CV (option 6).
3. Select a category and play a clip.

Games

Menu 7.1

Java is a technology developed by Sun Microsystems. Similar to the way you would download the Java Applet using the standard Netscape or MS Internet Explorer browsers, Java MIDlet can be downloaded using a WAP enabled phone. Depending on the service provider, Java based programs such as Java games can be downloaded and run on a phone. Once downloaded, the Java program can be viewed within the Games menu where you can select, execute or delete. Java program files saved in the phone are in .JAD and .JAR formats.

ⓘ Note

The JAR file is a compressed format of the Java program and the JAD file is a description file that includes all detailed information. From the network, prior to download, you can view all detailed file descriptions from the JAD file.

ⓘ Warning

Only J2ME (Java 2 Micro Edition) based programs will run in a phone environment.
J2SE (Java 2 Standard Edition) based programs will only run in a PC environment.

- ▶ **Shop Games:** This menu option connects to game download site.
- ▶ **Games List:** You can see the default and downloaded games in the list.

Applications

Menu 7.2

This menu displays the list of Java programs downloaded using WAP. All previous downloaded programs can be selected, deleted, or viewed in detail within the Application menu.

- ▶ **Shop Applications:** This menu option connects to application download site.
- ▶ **Applications List:** You can see the downloaded games and MobiTV in the list.

Audio & Ringtones

Menu 7.3

- ▶ **Shop Tones:** This menu option connects to ringtone download site.
- ▶ **Record Voice:** You can record your own audio by pressing the center key [OK].
- ▶ **Files:** You can view the audio files in the list.

Graphics

Menu 7.4

- ▶ **Shop Graphics:** This menu option connects to graphic download site.

Note

Additional charges may be incurred when downloading graphics. Contact your service provider for further information.

- ▶ **Take Photo:** You can take your own photo by pressing the center key [OK].
- ▶ **Make Animated GIF:** You can make an animation file with the selected images in the list.
- ▶ **Files:** You can view the graphic files in the list.


Video

Menu 7.5

- ▶ **Record Video:** You can record your own video by pressing the center key [OK].
- ▶ **Files:** You can view the video files in the list.

Note

DRM (Digital Rights Management) Contents Copyright protected contents.

DRM sometimes restricts some functions, such as send, and edit. The  indicates content controlled by DRM protection.


Tools

Menu 7.6

Alarm Clock (Menu 7.6.1)





The alarm function allows you to set up multiple separate alarms. You can also set the time, repetition interval and alarm sound.

Select your desired alarm setting to configure from the alarm list. If there is no alarm setting, press the left soft key [New] to add a new alarm.

- ▶ **Time:** Select the desired set time mode using the navigation key. Input your desired alarm time by specifying the hour and minute. If the time is in 12 hour clock format, you have to select either am' or pm' using the center soft key.
- ▶ **Repeat:** Select the desired repeat mode using the navigation key.
- ▶ **Alarm Tone:** Select the alarm sound to use for the alarm using the  key.
- ▶ **Memo:** Input alarm name.

Calendar (Menu 7.6.2)

When you enter this menu a calendar will be displayed. The square cursor is used to locate a particular day. The bottom bar on the calendar indicates schedule(s) for that day. This function helps to remind you of the schedule. The phone will sound an alarm tone if it has been set for a specific schedule item.

Key	Description
up/down navigation key	Weekly
left/right navigation key	Daily
 key/  key	Annually
 key/  key	Monthly

The following [Options] are available:

- ▶ **Search:** Allows you to search the saved schedule(s) by pressing the character keys.
- ▶ **Delete:** Allows you to delete the selected schedule.
- ▶ **Send via:** Sends the selected schedule by Message or Bluetooth.
- ▶ **Set Holiday:** Allows you to set your personal holiday for the selected date.
- ▶ **View All:** Allows you to view all saved schedules.

- ▶ **Go to Date:** Allows you to jump to a specific date.
- ▶ **Delete Schedules:** Deletes the defined schedules such as Old Schedules, Daily, Weekly, Monthly or All Schedules.


Notepad (Menu 7.6.3)

You can create up to a maximum of 30 memos.

1. Select a memo pad you want to edit.
2. Press the left soft key [New] to create a new memo.
3. Input the memo and press the center key [Save] to save.

Calculator (Menu 7.6.4)

The calculator function allows you to add, subtract, multiply and divide. You can input numbers using the number keys, and input operators using the up, down, left, and right navigation keys.

You can input a decimal point by pressing the  [Star] key.

Whenever you press the  key, characters are sequentially deleted in reverse order.

Tip Calculator (Menu 7.6.5)

This feature allows you to quickly and easily calculate the tip amount based on the total bill as well as the split of the total bill based on the number of people.

World Clock (Menu 7.6.6)

The World clock function provides time information on major cities worldwide.

1. You can view the time of desired city using the navigation or the right soft key [Options] - [Cities].
2. You can select a desired city as a base using the left soft key [Home zone].

If you want to use Dual Clock, you must set "Homezone" to system time where you are currently staying.

Tasks (Menu 7.6.7)

This feature allows you to save and manage a task.

1. To add a new To do item, select the left soft key [New] in the Task enquiry screen.
2. Input due date, notes, priority and status for the new Task.
3. Press the left soft key [Save] to save the Task item.

The following [Options] are available in the Task list.


- ▶ **Status:** Allows you to change the status of the selected task as In Progress or Completed.
- ▶ **Delete:** Deletes the selected task.
- ▶ **Send Via:** Enables the selected task to be sent via Message and Bluetooth.
- ▶ **Edit:** Allows you to edit a saved task.
- ▶ **View Calendar:** The calendar pop-up window is displayed.
- ▶ **Delete Tasks:** Deletes All Completed, All Past Tasks or All Tasks.

Stop Watch (Menu 7.6.8)

This menu allows you to record the elapsed time of an event. The duration of an individual lap time (up to 20 times) and the total time can be displayed.

▶ **New Time**

1. To start timing, press the center key [Start]. The running time is displayed as HH.MM.SS.hh (hours, minutes, seconds, hundredths of a second).
2. During the timing, you can record an individual lap time by pressing the right soft key [Lap]. Up to 20 lap times can be recorded.

3. You can stop or restart timing by pressing the  key.
4. To reset the stop watch, press the left soft key [Reset].


▶ **Saved Times:** You can see the saved recorded times which are in the lap time list of the **New Time** option.

Unit Converter *(Menu 7.6.9)*

This function converts any measurement into a unit you want.

There are 6 types of units that can be converted: Area, Length, Weight, Temperature, Volume, and Velocity.

Note

You can input a decimal number by pressing the  [Star] key.

Date Finder *(Menu 7.6.0)*

The date finder shows the start date, the target date and the number of remaining days.

D-Day Counter *(Menu 7.6.*)*

1. To add a new D-Day Counter item, select the left soft key [New].

2. Input the Date and notes when you add an item.
3. Press the left soft key [Save] to save the item.

▶ **Edit:** You can edit the selected item.

▶ **Delete:** You can delete the selected item.

▶ **Show at Idle Screen:** You can see the Remaining days for this item (D-Day) on the Idle screen top right corner.

▶ **Delete All:** Deletes all saved items.

Camera & Recordings

Menu 7.7

Take Photo *(Menu 7.7.1)*

Using the camera module built into your phone, you can take pictures of people or events while on the move. Additionally, you can send photos to other people in a picture message. The right soft key [Options] will bring up the following options.

▶ **Change to Video Mode:** Go to the video application, enables you to record a video clip.

▶ **Video Share:** You can make a Video Share call. For more details, refer to '**Video Share calling**' (page 28).

- ▶ **Resolution:** Sets the image size to 1280*960 (default), 640*480, 320*240 or 160*120. The selected image size appears on the capture screen.
- ▶ **Quality:** You can select the desired quality of photo by selecting either Super Fine, Fine or Normal mode by using the navigation keys.
- ▶ **Primary Storage:** You can assign the primary storage to Handset Memory or Memory Card.
- ▶ **Rotate View:** Allows you to reverse the image by using the Side Keys.
- ▶ **View Full Screen:** Allows you to view the subject in full screen.
- ▶ **Self Timer:** Determines the camera timer.
- ▶ **Advanced Settings**
 - **White Balance:** This adjusts the Light Effect level and you can select from the following options: Auto / Daylight / Incandescent / Cloudy / Fluorescent / Night Mode - Color
 - **Color Effects:** Allows you to apply special effects to the picture. Press the left or right navigation key to find the tone you want to use from the following options: Color, Sepia, Mono and Negative.

- **Shutter Tones:** Allows you to select a sound when you press the shutter. Tone 1 / Tone 2 / Tone 3 /Off

- ▶ **Default Settings:** This restores the default camera settings (Size, Brightness, Zoom, etc.).

Note

In Take Photo mode, you can adjust the zoom scale by using the up/down navigation keys. The maximum zoom scale depends on the resolution as follows.

Resolution	Zoom scale
1280*960	Level 1
640*480	Level 1~Level 20
320*240	Level 1~Level 20
160*120	Level 1~Level 20

In Take Photo mode, you can adjust the brightness by using the left/right navigation key.

Note


- **Zooming:** You can zoom in/out using the up/down navigation keys except 1290*960(default phone setting).

- **Brightness:** This adjusts the brightness level of the screen using the left/right navigation keys and there are 9 level of setting.


Flip is closed



Flip is opened



Record Video (Menu 7.7.2)

You can record a video clip in this menu by pressing the Camera key. Before starting to record, press the right soft key [Options] to set the following values. Select the desired value and press the  key to confirm.

- ▶ **Change to Photo Mode:** Go to the camera application which enables you to take a still picture.
- ▶ **Video Share:** You can make a Video Share call. For more details, refer to **'Video Share calling'** (page 28).
- ▶ **Video Record Mode:** Sets the recording mode to either MMS Video Mode or General Mode.
- ▶ **Quality:** Determines the quality of a video clip.
- ▶ **Primary Storage:** You can assign the primary storage to Handset Memory or Memory Card.
- ▶ **Reverse View:** Allows you to reverse the image.
- ▶ **White Balance:** This adjusts the light effect level and you can select from the following options:
Auto / Daylight / Incandescent / Cloudy / Fluorescent/ Night mode.
- ▶ **Color Effects:** Allows you to apply special effects to the video clip. Press the Left/Right Navigation Keys

to find the tone you want to use from the following options: Color, Sepia, Mono and Negative.

- ▶ **Default Settings:** This restores the default camera settings (Size, Brightness, Zoom, etc.).

🔔 Note

In Video Record mode, you can adjust the zoom scale by using the up/down navigation keys. The maximum zoom scale depends on the resolution as follows.

Resolution	Zoom scale
176*144	x1~x10

In Record Video mode, you can adjust the brightness by using the left/right navigation keys.

Record Voice *(Menu 7.7.3)*

You can record an audio clip in this menu. The recorded audio file is saved automatically in the Audios menu (Menu 7.2).

The right soft key [Options] will bring up the following options.

- ▶ **Record Mode:** Sets the recording mode to either MMS or General.
- ▶ **Quality:** Determines the quality of an audio clip.

- ▶ **Primary Storage:** You can set the primary storage of the recorded audio to the Handset Memory or the memory Card.

Other Files

Menu 7.8

When you receive files of an undefined format (such as .vcs, .vcf, etc.) via E-mail, the files are saved in this folder.

The following [Options] are available.

- ▶ **Delete:** You can delete the selected file.
- ▶ **Rename:** You can edit the name of the selected file.
- ▶ **New Folder:** You can create a new folder.
- ▶ **Sort By:** You can sort the folders by name, date and type.
- ▶ **Delete All:** You can delete all files.
- ▶ **Multi Delete:** You can delete several files at once.
- ▶ **Information:** You can view information about the selected folder.

Memory Card

Menu 7.9

This function shows the status of the external microSD card memory.

Address Book

Contact List

Menu 8.1

This menu allows you to save and manage contact address information. The Contacts' functions allow you to add a new address or search saved contact addresses by name.

New Contact

Menu 8.2

This menu allows you to add a new contact address. You can enter contact address information including name, phone numbers, email addresses, group information items, memos, ring tones, and image (photograph).

You have to select the Handset or the SmartChip memory using the left and right navigation keys.

Caller Groups

Menu 8.3

This menu allows you to manage group information. By default, there are 4 groups: family, friends, colleagues and school. You can also configure a ring tone for a group so that the group ring tone sounds when a call from a specific contact address within that group arrives and there is no ring tone configured for the specific contact address.

Speed Dial List

Menu 8.4

This menu allows you to configure the speed dial numbers. You can select a number from 2 to 9 as a speed dial. You can configure speed dial numbers for any of the 8 numbers for a specific contact address so that a contact address may have multiple speed dial numbers.

Copy All Contacts

Menu 8.5


This menu allows you to copy all of the information from your SmartChip, e.g. name, handset number, etc., to your handset. If a name is duplicated during the copying operation, the information is also duplicated.

- ▶ **SmartChip to Handset:** You can copy the entry from the SmartChip card to the phone memory.
- ▶ **Handset to SmartChip:** You can copy the entry from the handset memory to the SmartChip card (not all the data will be copied).

Delete All Contacts

Menu 8.6


You can delete all entries in the **SmartChip** and the **Handset**.

Press the  [END] key to return to standby mode.

Service Dial Numbers

Menu 8.7

You can view the list of Service Dialing Numbers (SDN) assigned by your network provider. Such numbers could include the emergency, directory assistance and voice mail numbers.

1. Select the Service dial number option.
2. The names of the available services will be shown.
3. Use the up/down navigation keys to select a service.
Press the  [SEND] key.

My Business Card

Menu 8.8

This option allows you to make your own name card. Key in the Name, Mobile number, Office number, Fax number and E-mail address.

Settings

Menu 8.9

You can select the view option in contact list from Handset & Smartchip, Handset only and Smartchip only.

My Numbers


Menu 8.0

This displays your phone numbers stored in the SmartChip.

Settings

Audio & Ringtones

Menu 9.1

There can be 4 sound modes: General, Vibrate All, Silent and Ear Mic. General, Vibrate, and All Silent modes can be changed from the Volume menu under Ring tone. In addition, pressing and holding the  [Star] key on idle screen mode can swap Normal and Manner mode. Ear Mic is available when respective instruments are attached.

Shop Tones *(Menu 9.1.1)*

Connects to Ring tone Shops.

Ringtones *(Menu 9.1.2)*

Shows and plays ring tones. These can be downloaded ring tones from Ring tone shops.

Volume *(Menu 9.1.3)*

This menu controls Ringtone, Key Tone, Call and Multimedia volume. It is available on Ring tone volume level 1~7.

Message Alert Tones *(Menu 9.1.4)*

Allows you to select an alert tone which is played when a message is received. You can select any one from 10 message alert tones.

Note

Full length music tracks cannot be set as ringtones.

Alert Type *(Menu 9.1.5)*

- ▶ **Ringtones:** Supports 3 ring alert types. Ring, Ring and Vibration, and Ring after Vibration.
- ▶ **Message Alert Tones:** Supports 6 message alert types.
Ring Once, Ring Every 2 Min, Ring Every 15 Min, Ring & Vibrate, Vibrate, Off
- ▶ **Other Alert Tones:** This menu option allows you to select a tone that sounds when popup menu alert. You can set the On or Off.

Increasing Ringtone *(Menu 9.1.6)*

Allows you to select an Increasing Ringtone type which is played when a incoming call. You can set the On or Off.

Power On/Off Tones *(Menu 9.1.7)*

Allows you to select an Power On/Off tonesl. You can set the On or Off.

Display

Menu 9.2

Shop Graphics *(Menu 9.2.1)*

Connects to graphic download site.

Wallpapers *(Menu 9.2.2)*

You can select the background picture in standby mode.

Backlight Timer *(Menu 9.2.3)*

Use this to select whether or not the phone uses the backlight.

Menu Styles *(Menu 9.2.4)*

You can configure the menu style to Icon style or List style.

Languages *(Menu 9.2.5)*

You can change the language for the display text on your phone. This change will also affect the Language Input mode.

Dialing Fonts *(Menu 9.2.6)*

You can configure the font size and color of the numbers which appear in the home screen when you

make a call.

Clocks & Calendar *(Menu 9.2.7)*

This feature allows you to select the internal/external LCD clock or Calendar display on the standby screen.

If you want to use Dual Clock, you must set "Homezone" to system time where you are currently staying

Color Schemes *(Menu 9.2.8)*

You can change the color of the menu, soft key area, title bar area, and cursor by changing the Color Schemes.

You can select the Color Schemes from **Orange**, **Metal**, and **Sky**.

Bluetooth

Menu 9.3

Your phone has built-in Bluetooth wireless technology, which makes it possible for you to connect your phone wirelessly to other Bluetooth devices such as a hands free device, PC, PDA, a remote screen, or other phones. Only one of the devices registered in your phone can be connected at a time. (To make a connection to the same type of device or change Bluetooth preferences, disconnect the existing device first.)

You can have a conversation via a cordless Bluetooth hands-free phone or browse the Internet, wirelessly connected via a mobile phone.

You can also exchange, for example, business cards, calendar items and pictures.

Streaming audio or radio is supported through Stereo Bluetooth.

Hands-free profile

This icon appears when the hands-free profile is used between the hands-free device and the phone. This allows you to call using a Bluetooth connection.

A2DP profile

This icon appears when the A2DP profile is used between the stereo headset device and the phone. This allows you to listen to an audio clip. A2DP is the Advanced Audio Distribution Profile, which provides support for streaming either mono or stereo audio using Bluetooth.

Hand-free +A2DP profile

This icon appears when both profiles of the hands-free and the A2DP are used between the compatible device and the phone. This allows you to call and listen to an audio clip using a Bluetooth connection.

For using each device, see a manual that comes with the device.

Note

We recommend that your phone and the Bluetooth device you are communicating with be no more than 10 metres apart. The connection may be improved if there are no solid objects in between your phone and the other Bluetooth device.

Turn On/Off *(Menu 9.3.1)*

This menu sets the Bluetooth on or off using the navigation key.

Search New Devices *(Menu 9.3.2)*

This function allows you to search and add new device at once.

Paired Devices *(Menu 9.3.3)*

This function allows you to view the list of all devices

that are paired with your phone at once.

To add a new device, press the left soft key [New]

1. Select the [New] key to search the device that can be connected and which is within range.
2. If you want to stop searching, press the right soft key [Cancel].
3. All of the devices found are displayed in the pop-up menu.

Select the desired device by pressing the OK key, and entering the password.

Settings (Menu 9.3.4)

This menu allows you to configure the profile for a Bluetooth.

▶ My Visibility

1. Selecting the Show option exposes your phone to other Bluetooth devices.
2. Selecting Hide shows your phone only to already paired devices.

▶ **My Name:** Allows you to change the handset's name that can be seen by other Bluetooth devices.

▶ **Supported Services:** Show you all services that

CU575 supports.

- ▶ **My Address:** You can check your Bluetooth address. You cannot change the default setting.
- ▶ **Primary Storage:** You can assign the primary storage to **Handset Memory** or **Memory Card**.

Date & Time

Menu 9.4

Set Date (Menu 9.4.1)

This allows you to enter the day, month and year. You can change the date format via the Date Format menu option.

Date Format (Menu 9.4.2)

MM/DD/YYYY(month/day/year)

DD/MM/YYYY(day/month/year)

YYYY/MM/DD(year/month/day)

Set Time (Menu 9.4.3)

This allows you to enter the current time. You can choose the time format via the Time Format menu option.

Time Format (Menu 9.4.4)

12 Hours/24 Hours

Auto Update (Menu 9.4.5)

Select On to set the phone to automatically update the time and date according to the current local time zone.

Call

Menu 9.5

Call Forwarding (Menu 9.5.1)

When this network service is activated, you can direct your incoming calls to another number, for example, to your voice mailbox number. For details, contact your service provider. Select one of the divert options, for example, select **If busy** to divert voice calls when your number is busy or when you reject incoming calls.

The following options are available:


- ▶ **All Voice Calls:** Diverts voice calls unconditionally.
- ▶ **If Busy:** Diverts voice calls when the phone is in use.
- ▶ **If No Answer:** Diverts voice calls which you do not answer.
- ▶ **If Out of Reach:** Diverts voice calls when the phone is switched off or out of coverage.

- ▶ **All Data Calls:** Diverts to a number with a PC connection unconditionally.
- ▶ **All Fax Calls:** Diverts to a number with a fax connection unconditionally.

Send My Number (Menu 9.5.2)

This network service allows you to set your phone number to be displayed **On** or hidden **Off** from the person you are calling. You can select **Set by Network** if you prefer to have different settings for different service providers.

Auto Redial (Menu 9.5.3)

Select On, your phone redials the number you're trying to call up to 10 times after you hear a quick, engaged signal. Press  [END] to stop the call attempts.



This feature attempts to redial numbers that are engaged due to the wireless network. It does not redial numbers to an engaged party.

Note

There will be no alert indicating the call has been connected. You must stay on the line to hear when the call is connected.

Answer Mode *(Menu 9.5.4)*

This allows you to determine how to answer the phone.

- ▶ **Any Key:** You can answer an incoming call by pressing any key, except the  [END] key.
- ▶ **Send Key Only:** You can only answer an incoming call by pressing the  [SEND] key.
- ▶ **Flip Open:** When the phone rings, you can answer a call simply by opening the flip.

Bluetooth Call Answer *(Menu 9.5.5)*

This allow you to determine how to answer the phone.

- ▶ **Answered To Device:** You can hear the sound from the device you answered.
- ▶ **Always To Handsfree:** You can hear the sound from bluetooth headset only.

Minute Minder *(Menu 9.5.6)*

This option allows you to specify whether the phone will beep every minute during an outgoing call to keep you informed of the length of the call.

Call Waiting *(Menu 9.5.7)*

The network will notify you of a new incoming call while you have a call in progress. Select **Activate** to request the network to activate call waiting, **Deactivate** to request the network to deactivate call waiting, or **View Status**, to check if the function is active or not.

Call Reject *(Menu 9.5.8)*

This menu allows you to enable or disable call reject for all numbers or a specific number.

- ▶ **Call Reject On/Off:** This feature allows you to reject or not the incoming calls unconditionally by disconnecting. When the **Reject All Calls** option is set, all incoming calls are routed directly to Voicemail.
- ▶ **Call Reject List:** Configures conditional call reject mode. Press the left soft key [New] to add the phone number to be rejected to the list. When you add a number to the list, you can add the number by entering it directly or by searching for the number in the Contact List.

Menu	User	Feature	Transmission /Receiving Mode	When making communications with a normal terminal
TTY Full	For hearing- /speech- impaired		text message transmission, text message reception	operator required
TTY+TALK	For hearing-impaired	can talk	voice transmission, text message reception	operator required
TTY+HEAR	For speech-impaired	audible	text message transmission, voice reception	operator required

TTY (Menu 9.5.9)

Allows you to attach a TTY device enabling you to communicate with parties also using a TTY device. A phone with TTY support is able to translate typed characters to voice. Voice can also be translated into characters and then displayed on the TTY.

TTY mode (Tele Type writer)

TTY modes are as follows :

1. TTY Full:

- Users who cannot talk and hear send and receive a text message through TTY equipment.

2. TTY Talk:

- Users who can talk but cannot hear receive a text message and send voice messages through TTY equipment.

3. TTY Hear:

- Users who can hear but cannot talk send a text message and receive voice messages through TTY equipment.

Connecting TTY Equipment and a Terminal

1. Connect a TTY cable the TTY connection on the terminal. (the TTY connection location is the same as a hands-free ear socket)
2. Enter the phone menu and set up the desired TTY mode. (For a TTY mode, see below)
3. After setting a TTY mode, check the LCD screen of the phone for the TTY icon.
4. Connect the TTY equipment to the power source and turn it on.

5. Make a phone connection to the desired number.
6. When a connection is made, use the TTY equipment to type in and send a text message or send a voice message.
7. The voice or text message from the receiver end appears on the TTY equipment display.

Send DTMF Tones *(Menu 9.5.0)*

You can send the DTMF (dual tone multi-frequency) tones of the number on the display during a call.

This option is helpful for entering a password or account number when you call an automated system, like a banking service.

Video Share *(Menu 9.5.*)*

▶ Initial Notification

- **On:** If the Video Share call service is available and a voice call has been made, a pop-up window will be shown on the screen to ask whether to make a Video Share call or not.
- **Off:** No notification window is displayed after the phone determines whether or not the Video Share call service is available.

▶ Auto Record

- **On:** Automatically starts recording Video Share call images. You can view the recorded videos on [My stuff] – [Video].
- **Off:** Does not automatically start recording video share call images.

▶ Service

- **On:** This option activates the Video Share call service.
- **Off:** If this option is selected, the Video Share call service will be unavailable even in a 3G service area. (If the service is **Off**, you will have to set it to **On** and restart the phone in order to reactivate the Video Share call service).

Security

Menu 9.6

Various codes and passwords are used to protect the features and settings of your phone. They are described in the following sections.

Lock Handset *(Menu 9.6.1)*

You can use a security code to avoid unauthorized use of the phone.

If you set phone lock to When Power On, the phone

will request a security code whenever you switch the phone on. If you set the phone lock to *When SmartChip Changed*, your phone will request a security code only when you change your SmartChip. If you set the phone lock to *Immediately*, your phone will lock immediately.

PIN Code Request *(Menu 9.6.2)*

When the PIN code request feature is set to 'On', you must enter your PIN each time you switch the phone on. Consequently, any person who does not have your PIN cannot use your phone without your approval.

Note

Before setting the PIN code request feature to Off, you must enter your PIN

The following [Options] are available:

- ▶ **On:** You must enter the PIN each time the phone is switched on.
- ▶ **Off:** The phone connects directly to the network when you switch it on.

Fixed Dial Number *(Menu 9.6.3)*

This allows you to restrict your outgoing calls to selected phone numbers, if this function is supported

by your SmartChip. The PIN2 code is required.

▶ **FDN On/Off**

- **On:** You can only call phone numbers stored in the Address Book. You must enter your PIN2.
- **Off:** You can call any number.

▶ **FDN List**

Note

Not all SmartChips have a PIN2. If your SmartChip does not, this menu option is not displayed.

Change Codes *(Menu 9.6.4)*

The Change codes feature allows you to change your current password to a new one. You must enter the current password before you can specify a new one.

You can change the access codes for: **Security Code, PIN1, PIN2**

Note

PIN: Personal Identification Number.

Connection

Menu 9.7

Network Profiles *(Menu 9.7.1)*

This menu shows the Network Profile. You can register, delete and edit by using the Options Menu. However, you cannot delete or edit default configurations provided by.


USB Connection Mode *(Menu 9.7.2)*

You can transfer files from a compatible PC to the memory in your phone using the Mass Storage. When you connect the phone to a PC using the USB cable, this will be displayed as a removable disk through Windows Explorer.

Flight Mode

Menu 9.8

This allows you to use only the phone's features that do not require the use of the wireless network when you are in an airplane or in places where the wireless network is prevented.

If you set the flight mode on, the  icon will be displayed on the screen instead of the network signal icon.

► **On:** You cannot make (or receive) any calls, including emergency calls, or use other features that require

network coverage

► **Off:** You can deactivate the flight mode and restart your handset to access the network.

Software Update

Menu 9.9

This menu is used to resume a postponed software update. If new software exists, the server notifies devices using a WAP push message. Before updating new software after downloading it from the server, users will whether they would like to postpone the operation. Reminder times can be set to 30 minutes, 1 hour, and 4 hours. When the time is up, users are prompted again or users can resume the postponed operation using this menu at any time.

Check Memory

Menu 9.0

Common *(Menu 9.0.1)*

This function shows the status of the user memory of the handset.

Reserved *(Menu 9.0.2)*

This function shows the status of the reserved memory for the user (Text Message, Contact List, Calendar,

Tasks, Memo).

SmartChip *(Menu 9.0.3)*

This function shows the status of the SmartChip card user memory.

Memory Card *(Menu 9.0.4)*

If your phone has a multimedia memory card in the card slot, you can save images, sounds, and videos on the memory card. You can check the current status of the external memory card in the Memory status menu.

Handset Information

*Menu 9.**

This menu is used to view My Numbers, Manufacturer and Model Name information etc.

Reset Settings

Menu 9.#

This function allows you to restore factory settings. To do this, you need the security code.

Clear Memory *(Menu 9.#.1)*

Deletes downloaded/user created contents (e.g.: images, videos) from Handset content and the External Memory card.

- ▶ **Handset Contents:** Deletes all downloaded/user created Images, Videos & Sounds from the Handset Memory.
- ▶ **Handset Personal info.:** Restores Personal Information stored in the handset memory (e.g.: address book, messages, tasks, alarm, Calendar schedules) to default values.
- ▶ **Memory Card:** Deletes all contents from the External Memory Card.

Reset Default *(Menu 9.#.2)*

Restores the settings (e.g.: Audio, Display, Language, Date & Time, Bluetooth Settings) stored in the handset memory to default values.

Please check to see if any problems you have encountered with the phone are described in this section before taking the phone in for a service or calling a service engineer.

Q How do I view the list of outgoing calls, incoming calls and missed calls?

A Press the  [SEND] key.

Q How do I view all numbers stored in the memory?

A Press the down navigation key.

Q Why is the connection inconsistent or not audible in certain areas?

A When the frequency environment is unstable in a certain area, connection may be inconsistent and not audible. Relocate to another area and try again.

Q Why is the connection not consistent or abruptly disconnects even when established?

A When frequency is unstable or weak or if there are too many users, connection may be cut off even after it was established. Please try again later or attempt after relocating to other areas.

Q Why does the LCD not turn on?

A Remove the battery and turn on the power after placing it back in. If there is no change, fully charge the battery and try again.

Q Why is there an echo when a connection is made with certain telephones in a certain area?

A This is called the 'Echo Phenomenon', which occurs if the connection volume is too high or caused by special properties (semi-electronic telephone exchange) of the equipment on the other end.

Q Why does the phone heat up?

A The phone may get hot when there is a very long call duration or when games are played or even when surfing the Internet for a long time. This has no effect upon the life of the product or performance.

Q Why does the battery life get shorter in standby mode?

A The battery is worn out. As time passes, the battery life gradually becomes shorter. If the battery lasts about half the amount of time as when first purchased, it's time to purchase a new battery.

Q Why does the battery run out so quickly during normal use?

A It is due to the user environment or a large number of calls or a weak signal.

Q Why is no number dialed when you recall an Address Book entry?

A Check that the number has been stored correctly by using the Address book Search feature. Re-store them, if necessary.

Q I cannot find the lock, PIN, or PUK code. What is my password?

A The default lock code is '0000'. If you forget or lose the lock code, contact your phone dealer. If you forget or lose a PIN or PUK code, or if you have not received such a code, contact your network service provider.


Accessories

There are a variety of accessories available for your mobile phone. You can select these options according to your personal communication requirements. Consult your local dealer for availability.

Travel Adapter

This adapter allows you to charge the battery. It supports standard U.S. 120 Volt 60Hz outlets.

It takes under 4 hours to charge a completely discharged battery.



Battery


Standard battery is available.



Vehicle Power Adapter


You can operate the phone and trickle charge the phone battery from your vehicle by using the vehicle power adapter.

It takes 5 hours to charge a completely discharged battery.



Stereo headset

Allows hands-free operation.
Includes earpiece and microphone.



Data Cable Kit

* When installing, make sure to connect to the PC after your phone and the cable have been connected. Otherwise, your PC may have a problem.



Note

- Always use genuine LG accessories. Failure to do this may invalidate your warranty.
- Accessories may be different in different regions; please check with our regional service company or agent for further enquiries.

Safety Guidelines

TIA Safety Information

Provided herein is the complete TIA Safety Information for Wireless Handheld phones. Inclusion of the text covering Pacemakers, Hearing Aids, and Other Medical Devices is required in the owner's manual for CTIA Certification. Use of the remaining TIA language is encouraged when appropriate.

Exposure to Radio Frequency Signal

Your wireless handheld portable telephone is a lowpower radio transmitter and receiver. When it is ON, it receives and also sends out radio frequency (RF) signals.

In August, 1996, the Federal Communications Commissions (FCC) adopted RF exposure guidelines with safety levels for handheld wireless phones. Those guidelines are consistent with the safety standards previously set by both U.S. and international standards bodies:

ANSI C95.1 (1992) *

NCRP Report 86 (1986)

ICNIRP (1996)

Those standards were based on comprehensive and periodic evaluations of the relevant scientific literature. For example, over 120 scientists, engineers, and physicians from universities, government health agencies, and industry reviewed the available body of research to develop the ANSI Standard (C95.1).

* American National Standards Institute; National Council on Radiation Protection and Measurements; International Commission on Non-Ionizing Radiation Protection

The design of your phone complies with the FCC guidelines (and those standards).

Antenna Care

Use only the supplied or an approved replacement antenna. Unauthorized antennas, modifications, or attachments could damage the phone and may violate FCC regulations.

Phone Operation

NORMAL POSITION: Hold the phone as you would any other telephone with the antenna pointed up and over your shoulder.

Tips on Efficient Operation

For your phone to operate most efficiently:

- ▶ Do not touch the antenna unnecessarily when the phone is in use. Contact with the antenna affects call quality and may cause the phone to operate at a higher power level than otherwise needed.

Driving

Check the laws and regulations on the use of wireless phones in the areas where you drive. Always obey them. Also, if using your phone while driving, please:

- ▶ Give full attention to driving - driving safely is your first responsibility;
- ▶ Use hands-free operation, if available;
- ▶ Pull off the road and park before making or answering a call if driving conditions so require.

Electronic Devices

Most modern electronic equipment is shielded from RF signals. However, certain electronic equipment may not be shielded against the RF signals from your wireless phone.

Pacemakers

The Health Industry Manufacturers Association recommends that a minimum separation of six (6') inches be maintained between a handheld wireless phone and a pacemaker to avoid potential interference with the pacemaker. These recommendations are consistent with the independent research by and recommendations of Wireless Technology Research.

Persons with pacemakers:

- ▶ Should ALWAYS keep the phone more than six inches from their pacemaker when the phone is turned ON;
- ▶ Should not carry the phone in a breast pocket.
- ▶ Should use the ear opposite the pacemaker to minimize the potential for interference.
- ▶ If you have any reason to suspect that interference is taking place, turn your phone OFF immediately.

Hearing Aids

Some digital wireless phones may interfere with some hearing aids. In the event of such interference, you may want to consult your service provider.

Other Medical Devices

If you use any other personal medical device, consult the manufacturer of your device to determine if they are adequately shielded from external RF energy. Your physician may be able to assist you in obtaining this information.

Health Care Facilities

Turn your phone OFF in health care facilities when any regulations posted in these areas instruct you to do so. Hospitals or health care facilities may use equipment that could be sensitive to external RF energy.

Vehicles

RF signals may affect improperly installed or inadequately shielded electronic systems in motor vehicles. Check with the manufacturer or its representative regarding your vehicle.

You should also consult the manufacturer of any equipment that has been added to your vehicle.

Posted Facilities

Turn your phone OFF in any facility where posted notices so require.

Aircraft

FCC regulations prohibit using your phone while in the air. Turn your phone OFF before boarding an aircraft.

Blasting Areas

To avoid interfering with blasting operations, turn your phone OFF when in a 'blasting areas or in areas posted: 'Turn off two-way radio'. Obey all signs and instructions.

Potentially Explosive Atmosphere

Turn your phone OFF when in any area with a potentially explosive atmosphere and obey all signs and instructions. Sparks in such areas could cause an explosion or fire resulting in bodily injury or even death.

Areas with a potentially explosive atmosphere are often, but not always, marked clearly. Potential areas may include: fueling areas (such as gasoline stations); below deck on boats; fuel or chemical transfer or storage facilities; vehicles using liquefied petroleum gas (such as propane or butane); areas where the air contains chemicals or particles (such as grain, dust, or metal powders); and any other area where you would normally be advised to turn off your vehicle engine.

For Vehicles Equipped with an Air Bag

An air bag inflates with great force. DO NOT place objects, including either installed or portable wireless equipment, in the area over the air bag or in the air bag deployment area. If in-vehicle wireless equipment is improperly installed and the air bag inflates, serious injury could result.

Safety Information

Please read and observe the following information for safe and proper use of your phone and to prevent damage. Also, keep the user guide in an accessible place at all the times after reading it.

Charger and Adapter Safety

- ▶ The charger and adapter are intended for indoor use only.

Battery Information and Care

- ▶ Please dispose of your battery properly or take it to your local wireless carrier for recycling.
- ▶ The battery does not need to be fully discharged before recharging.

- ▶ Use only LG-approved chargers specific to your phone model since they are designed to maximize battery life.
- ▶ Do not disassemble or impact the battery as it may cause electric shock, short-circuit, and fire. Store the battery in a place out of reach of children.
- ▶ Keep the battery's metal contacts clean.
- ▶ Replace the battery when it no longer provides acceptable performance. The battery can be recharged several hundred times before replacement.
- ▶ Recharge the battery after long periods of non-use to maximize battery life.
- ▶ Battery life will vary due to usage patterns and environmental conditions.
- ▶ Use of extended backlighting, MEdia Net Browsing, and data connectivity kits affect battery life and talk/standby times.
- ▶ The self-protection function of the battery cuts the power of the phone when its operation is in an abnormal state. In this case, remove the battery from the phone, reinstall it, and turn the phone on.

Explosion, Shock, and Fire Hazards

- ▶ Do not put your phone in a place subject to excessive dust and keep the minimum required distance between the power cord and heat sources.
- ▶ Unplug the power cord prior to cleaning your phone, and clean the power plug pin when it is dirty.
- ▶ When using the power plug, ensure that it is firmly connected. If it is not, it may cause excessive heat or fire.
- ▶ If you put your phone in a pocket or bag without covering the receptacle of the phone (power plug pin), metallic articles (such as a coin, paperclip or pen) may short-circuit the phone. Always cover the receptacle when not in use.
- ▶ Do not short-circuit the battery. Metallic articles such as a coin, paperclip or pen in your pocket or bag may short-circuit the + and – terminals of the battery (metal strips on the battery) upon moving. Short-circuit of the terminal may damage the battery and cause an explosion.

General Notice

- ▶ Using a damaged battery or placing a battery in your mouth may cause serious injury.
- ▶ Do not place items containing magnetic components such as a credit card, phone card, bank book or subway ticket near your phone. The magnetism of the phone may damage the data stored in the magnetic strip.
- ▶ Talking on your phone for a long period of time may reduce call quality due to heat generated during use.
- ▶ When the phone is not used for a long period time, store it in a safe place with the power cord unplugged.
- ▶ Using the phone in proximity to receiving equipment (i.e., TV or radio) may cause interference to the phone.
- ▶ Do not use the phone if the antenna is damaged. If a damaged antenna contacts skin, it may cause a slight burn. Please contact an LG Authorized Service Centre to replace the damaged antenna.
- ▶ Do not immerse your phone in water. If this happens, turn it off immediately and remove the battery. If the phone does not work, take it to an LG Authorized

Service Centre.

- ▶ Do not paint your phone.
- ▶ The data saved in your phone might be deleted due to careless use, repair of the phone, or upgrade of the software. Please backup your important phone numbers. (Ring tones, text messages, voice messages, pictures, and videos could also be deleted.) The manufacturer is not liable for damage due to the loss of data.
- ▶ When you use the phone in public places, set the ring tone to vibration so as not to disturb others.
- ▶ Do not turn your phone on or off when putting it in your ear.

FDA Consumer Update

The U.S. Food and Drug Administration Centre for Devices and Radiological Health Consumer Update on Mobile Phones.

1. Do wireless phones pose a health hazard?

The available scientific evidence does not show that any health problems are associated with using wireless phones. There is no proof, however, that

wireless phones are absolutely safe. Wireless phones emit low levels of radiofrequency energy (RF) in the microwave range while being used. They also emit very low levels of RF when in the standby mode. Whereas high levels of RF can produce health effects (by heating tissue), exposure to low level RF that does not produce heating effects causes no known adverse health effects. Many studies of low level RF exposures have not found any biological effects. Some studies have suggested that some biological effects may occur, but such findings have not been confirmed by additional research. In some cases, other researchers have had difficulty in reproducing those studies, or in determining the reasons for inconsistent results.

2. What is the FDA's role concerning the safety of wireless phones?

Under the law, the FDA does not review the safety of radiation-emitting consumer products such as wireless phones before they can be sold, as it does with new drugs or medical devices. However, the agency has authority to take action if wireless phones are shown to emit radiofrequency energy (RF) at a level that is hazardous to the user. In such a

Safety Guidelines

case, the FDA could require the manufacturers of wireless phones to notify users of the health hazard and to repair, replace, or recall the phones so that the hazard no longer exists.

Although the existing scientific data do not justify FDA regulatory actions, the FDA has urged the wireless phone industry to take a number of steps, including the following:

- ▶ Support needed research into possible biological effects of RF of the type emitted by wireless phones;
- ▶ Design wireless phones in a way that minimizes any RF exposure to the user that is not necessary for device function; and
- ▶ Cooperate in providing users of wireless phones with the best possible information on possible effects of wireless phone use on human health.

The FDA belongs to an interagency working group of the federal agencies that have responsibility for different aspects of RF safety to ensure coordinated efforts at the federal level. The following agencies belong to this working group:

- ▶ National Institute for Occupational Safety and

Health

- ▶ Environmental Protection Agency
- ▶ Occupational Safety and Health Administration (Administración de la seguridad y salud laborales)
- ▶ Occupational Safety and Health Administration
- ▶ National Telecommunications and Information Administration

The National Institutes of Health participates in some interagency working group activities, as well.

The FDA shares regulatory responsibilities for wireless phones with the Federal Communications Commission (FCC). All phones that are sold in the United States must comply with FCC safety guidelines that limit RF exposure. The FCC relies on the FDA and other health agencies for safety questions about wireless phones.

The FCC also regulates the base stations that the wireless phone networks rely upon. While these base stations operate at higher power than do the wireless phones themselves, the RF exposures that people get from these base stations are typically thousands of times lower than those they can get from wireless phones. Base stations are thus not the

subject of the safety questions discussed in this document.

3. What kinds of phones are the subject of this update?

The term ‘wireless phone’ refers here to handheld wireless phones with built-in antennas, often called ‘cell’, ‘mobile’, or ‘PCS’ phones. These types of wireless phones can expose the user to measurable radiofrequency energy (RF) because of the short distance between the phone and the user’s head. These RF exposures are limited by FCC safety guidelines that were developed with the advice of the FDA and other federal health and safety agencies. When the phone is located at greater distances from the user, the exposure to RF is drastically lower because a person’s RF exposure decreases rapidly with increasing distance from the source. The so-called ‘cordless phones,’ which have a base unit connected to the telephone wiring in a house, typically operate at far lower power levels, and thus produce RF exposures far below the FCC safety limits.

4. What are the results of the research done already?

The research done thus far has produced conflicting results, and many studies have suffered from flaws in their research methods. Animal experiments investigating the effects of radiofrequency energy (RF) exposures characteristic of wireless phones have yielded conflicting results that often cannot be repeated in other laboratories. A few animal studies, however, have suggested that low levels of RF could accelerate the development of cancer in laboratory animals. However, many of the studies that showed increased tumor development used animals that had been genetically engineered or treated with cancer causing chemicals so as to be pre-disposed to develop cancer in the absence of RF exposure. Other studies exposed the animals to RF for up to 22 hours per day. These conditions are not similar to the conditions under which people use wireless phones, so we don’t know with certainty what the results of such studies mean for human health. Three large epidemiology studies have been published since December 2000. Between them, the studies investigated any possible association between the use of wireless phones and primary brain cancer, glioma, meningioma, or acoustic neuroma, tumors of the brain or salivary gland, leukemia, or other

cancers. None of the studies demonstrated the existence of any harmful health effects from wireless phone RF exposures. However, none of the studies can answer questions about long-term exposures, since the average period of phone use in these studies was around three years.

5. What research is needed to decide whether RF exposure from wireless phones poses a health risk?

A combination of laboratory studies and epidemiological studies of people actually using wireless phones would provide some of the data that are needed. Lifetime animal exposure studies could be completed in a few years. However, very large numbers of animals would be needed to provide reliable proof of a cancer promoting effect if one exists. Epidemiological studies can provide data that is directly applicable to human populations, but 10 or more years follow-up may be needed to provide answers about some health effects, such as cancer. This is because the interval between the time of exposure to a cancer-causing agent and the time tumors develop - if they do - may be many, many years. The interpretation of epidemiological studies is hampered by difficulties in measuring actual RF

exposure during day-to-day use of wireless phones. Many factors affect this measurement, such as the angle at which the phone is held, or which model of phone is used.

6. What is the FDA doing to find out more about the possible health effects of wireless phone RF?

The FDA is working with the U.S. National Toxicology Program and with groups of investigators around the world to ensure that high priority animal studies are conducted to address important questions about the effects of exposure to radiofrequency energy (RF). The FDA has been a leading participant in the World Health Organization International Electromagnetic Fields (EMF) Project since its inception in 1996. An influential result of this work has been the development of a detailed agenda of research needs that has driven the establishment of new research programs around the world. The project has also helped develop a series of public information documents on EMF issues. The FDA and the Cellular Telecommunications & Internet Association (CTIA) have a formal Cooperative Research and Development Agreement (CRADA) to do research on wireless phone safety. The FDA provides the

scientific oversight, obtaining input from experts in government, industry, and academic organizations. CTIA-funded research is conducted through contracts with independent investigators. The initial research will include both laboratory studies and studies of wireless phone users. The CRADA will also include a broad assessment of additional research needs in the context of the latest research developments around the world.

7. How can I find out how much radio frequency energy exposure I can get by using my wireless phone?

All phones sold in the United States must comply with Federal Communications Commission (FCC) guidelines that limit radio frequency energy (RF) exposures. The FCC established these guidelines in consultation with the FDA and the other federal health and safety agencies. The FCC limit for RF exposure from wireless telephones is set at a Specific Absorption Rate (SAR) of 1.6 watts per kilogram (1.6 W/kg). The FCC limit is consistent with the safety standards developed by the Institute of Electrical and Electronic Engineering (IEEE) and the National Council on Radiation Protection and

Measurement. The exposure limit takes into consideration the body's ability to remove heat from the tissues that absorb energy from the wireless phone and is set well below levels known to have effects. Manufacturers of wireless phones must report the RF exposure level for each model of phone to the FCC. The FCC website (<http://www.fcc.gov/oet/rfsafety>) gives directions for locating the FCC identification number on your phone so you can find your phone's RF exposure level in the online listing.

8. What has the FDA done to measure the radio frequency energy coming from wireless phones?

The Institute of Electrical and Electronic Engineers (IEEE) is developing a technical standard for measuring the radio frequency energy (RF) exposure from wireless phones and other wireless handsets with the participation and leadership of FDA scientists and engineers. The standard, 'Recommended Practice for Determining the Spatial-Peak Specific Absorption Rate (SAR) in the Human Body Due to Wireless Communications Devices: Experimental Techniques,' sets forth the first consistent test methodology for measuring the rate

at which RF is deposited in the heads of wireless phone users. The test method uses a tissuesimulating model of the human head. Standardized SAR test methodology is expected to greatly improve the consistency of measurements made at different laboratories on the same phone. SAR is the measurement of the amount of energy absorbed in tissue, either by the whole body or a small part of the body. It is measured in watts/kg (or milliwatts/g) of matter. This measurement is used to determine whether a wireless phone complies with safety guidelines.

9. What steps can I take to reduce my exposure to radiofrequency energy from my wireless phone?

If there is a risk from these products - and at this point we do not know that there is - it is probably very small. But if you are concerned about avoiding even potential risks, you can take a few simple steps to minimize your exposure to radiofrequency energy (RF). Since time is a key factor in how much exposure a person receives, reducing the amount of time spent using a wireless phone will reduce RF exposure. If you must conduct extended conversations by wireless phone every day, you could place more

distance between your body and the source of the RF, since the exposure level drops off dramatically with distance. For example, you could use a headset and carry the wireless phone away from your body or use a wireless phone connected to a remote antenna. Again, the scientific data do not demonstrate that wireless phones are harmful. But if you are concerned about the RF exposure from these products, you can use measures like those described above to reduce your RF exposure from wireless phone use.

10. What about children using wireless phones?

The scientific evidence does not show a danger to users of wireless phones, including children and teenagers. If you want to take steps to lower exposure to radiofrequency energy (RF), the measures described above would apply to children and teenagers using wireless phones. Reducing the time of wireless phone use and increasing the distance between the user and the RF source will reduce RF exposure. Some groups sponsored by other national governments have advised that children be discouraged from using wireless phones at all. For example, the government in the

United Kingdom distributed leaflets containing such a recommendation in December 2000. They noted that no evidence exists that using a wireless phone causes brain tumors or other ill effects. Their recommendation to limit wireless phone use by children was strictly precautionary; it was not based on scientific evidence that any health hazard exists.

11. What about wireless phone interference with medical equipment?

Radio frequency energy (RF) from wireless phones can interact with some electronic devices. For this reason, the FDA helped develop a detailed test method to measure electromagnetic interference (EMI) of implanted cardiac pacemakers and defibrillators from wireless telephones. This test method is now part of a standard sponsored by the Association for the Advancement of Medical Instrumentation (AAMI). The final draft, a joint effort by the FDA, medical device manufacturers, and many other groups, was completed in late 2000. This standard will allow manufacturers to ensure that cardiac pacemakers and defibrillators are safe from wireless phone EMI. The FDA has tested hearing aids

for interference from handheld wireless phones and helped develop a voluntary standard sponsored by the Institute of Electrical and Electronic Engineers (IEEE). This standard specifies test methods and performance requirements for hearing aids and wireless phones so that no interference occurs when a person uses a 'compatible' phone and a 'compatible' hearing aid at the same time. This standard was approved by the IEEE in 2000. The FDA continues to monitor the use of wireless phones for possible interactions with other medical devices. Should harmful interference be found to occur, the FDA will conduct testing to assess the interference and work to resolve the problem.

12. Where can I find additional information?

For additional information, please refer to the following resources:

FDA web page on wireless phones
(<http://www.fda.gov/cdrh/phones/index.html>)

Federal Communications Commission (FCC) RF Safety Program
(<http://www.fcc.gov/oet/rfsafety>)

International Commission on Non-Ionizing Radiation

Protection
(<http://www.icnirp.de>)

World Health Organization (WHO) International EMF Project
(<http://www.who.int/emf>)

National Radiological Protection Board (UK)
(<http://www.nrpb.org.uk/>)

10 Driver Safety Tips

Your wireless phone gives you the powerful ability to communicate by voice almost anywhere, anytime. An important responsibility accompanies the benefits of wireless phones, one that every user must uphold.

When operating a car, driving is your first responsibility.

When using your wireless phone behind the wheel of a car, practice good common sense and remember the following tips:

1. Get to know your wireless phone and its features such as speed dial and redial. Carefully read your instruction manual and learn to take advantage of valuable features most phones offer, including automatic redial and memory. Also, work to memorize the phone keypad so you can use the speed dial function without taking your attention off the road.
2. When available, use a hands-free device. A number of hands-free wireless phone accessories are readily available today. Whether you choose an installed mounted device for your wireless phone or a speaker phone accessory, take advantage of these devices if available to you.
3. Position your wireless phone within easy reach. Make sure you place your wireless phone within easy reach and where you can reach it without removing your eyes from the road. If you get an incoming call at an inconvenient time, if possible, let your voicemail answer it for you.
4. Suspend conversations during hazardous driving conditions or situations. Let the person you are speaking with know you are driving; if necessary, suspend the call in heavy traffic or hazardous weather conditions. Rain, sleet, snow and ice can be hazardous, but so is heavy traffic. As a driver, your first responsibility is to pay attention to the road.
5. Do not take notes or look up phone numbers while driving. If you are reading an address book or

business card, or writing a “to-do” list while driving a car, you are not watching where you are going. It is common sense. Don’t get caught in a dangerous situation because you are reading or writing and not paying attention to the road or nearby vehicles.

6. Dial sensibly and assess the traffic; if possible, place calls when you are not moving or before pulling into traffic. Try to plan your calls before you begin your trip or attempt to coincide your calls with times you may be stopped at a stop sign, red light or otherwise stationary. But if you need to dial while driving, follow this simple tip— dial only a few numbers, check the road and your mirrors, then continue.
7. Do not engage in stressful or emotional conversations that may be distracting. Stressful or emotional conversations and driving do not mix; they are distracting and even dangerous when you are behind the wheel of a car. Make people you are talking with aware you are driving and if necessary, suspend conversations which have the potential to divert your attention from the road.
8. Use your wireless phone to call for help. Your wireless phone is one of the greatest tools you can own to protect yourself and your family in dangerous situations — with your phone at your side, help is only three numbers away. Dial 911 or other local emergency number in the case of fire, traffic accident, road hazard or medical emergency. Remember, it is a free call on your wireless phone!
9. Use your wireless phone to help others in emergencies. Your wireless phone provides you a perfect opportunity to be a “Good Samaritan” in your community. If you see an auto accident, crime in progress or other serious emergency where lives are in danger, call 911 or other local emergency number, as you would want others to do for you.
10. Call roadside assistance or a special wireless non-emergency assistance number when necessary. Certain situations you encounter while driving may require attention, but are not urgent enough to merit a call for emergency services. But you can still use your wireless phone to lend a hand. If you see a broken-down vehicle posing no serious hazard, a broken traffic signal, a minor traffic accident where no one appears injured or a vehicle you know to be stolen, call roadside assistance or other special non-emergency wireless number.

For more information, please call to 888-901-SAFE, or visit our website www.wow-com.com

Consumer Information on SAR (Specific Absorption Rate)

This Model Phone Meets the Government's Requirements for Exposure to Radio Waves.

Your wireless phone is a radio transmitter and receiver. It is designed and manufactured not to exceed the emission limits for exposure to radio frequency (RF) energy set by the Federal Communications Commission (FCC) of the U.S. Government. These limits are part of comprehensive guidelines and establish permitted levels of RF energy for the general population. The guidelines are based on standards that were developed by independent scientific organizations through periodic and thorough evaluation of scientific studies. The standards include a substantial safety margin designed to assure the safety of all persons, regardless of age and health.

The exposure standard for wireless mobile phones employs a unit of measurement known as the Specific Absorption Rate, or SAR. The SAR limit set by the FCC is 1.6W/kg. * Tests for SAR are conducted using

standard operating positions specified by the FCC with the phone transmitting at its highest certified power level in all tested frequency bands. Although SAR is determined at the highest certified power level, the actual SAR level of the phone while operating can be well below the maximum value. Because the phone is designed to operate at multiple power levels to use only the power required to reach the network, in general, the closer you are to a wireless base station antenna, the lower the power output.

Before a phone model is available for sale to the public, it must be tested and certified to the FCC that it does not exceed the limit established by the government-adopted requirement for safe exposure. The tests are performed in positions and locations (e.g., at the ear and worn on the body) as required by the FCC for each model. The highest SAR value for this model phone when tested for use at the ear is 1.12 W/kg and when worn on the body, as described in this user's manual, is 0.612 W/kg. (Body-worn measurements differ among phones models, depending upon available accessories and FCC requirements.) While there may be differences between SAR levels of various phones and at various positions, they all meet the government requirement

for safe exposure.

The FCC has granted an Equipment Authorization for this model phone with all reported SAR levels evaluated as in compliance with the FCC RF emission guidelines. SAR information on this model phone is on file with the FCC and can be found under the Display Grant section of <http://www.fcc.gov/oet/fccid> after searching on FCC ID BEJCU575.

Additional information on Specific Absorption Rates (SAR) can be found on the Cellular Telecommunications Industry Association (CTIA) website at <http://www.wow-com.com>

* In the United States and Canada, the SAR limit for mobile phones used by the public is 1.6 watts/kg (W/kg) averaged over one gram of tissue. The standard incorporates a substantial margin of safety to give additional protection for the public and to account for any variations in measurements.

To help you understand the main technical terms and abbreviations used in this booklet and take full advantage of the feature on your mobile phone, here are a few definitions.

Call Barring

Ability to restrict outgoing and incoming calls.

Call Divert

Ability to reroute calls to another number.

Call Waiting

Ability to inform users that they have an incoming call when engaged on another call.

GPRS (General Packet Radio Service)

GPRS guarantees continuous connection to the Internet for mobile phone and computer users. It is based on the Global System for Mobile Communication (GSM) circuit-switched cellular phone connections and the Short Message Service (SMS).

GSM (Global System for Mobile Communication)

International standard for cellular communication, guaranteeing compatibility between the various network operators. GSM covers most European countries and many other parts of the world.

Java

Programming language generating applications that can run on all hardware platforms, whether small, medium or large, without modification.

It has been promoted for and geared heavily to the Web, both for public Web sites and Intranets. When a Java program runs from a Web page, it is called a Java applet. When it is run on a mobile phone or pager, it is called a MIDlet.

Line Identification Services (Caller ID)

Service allowing subscribers to view or block the telephone numbers of callers.

Conference Calls

Ability to establish a conference call involving up to five additional parties.

Phone Password

Security code used to unlock the phone when you have selected the option to lock it automatically each time it switches on.

Roaming

Use of your phone when you are outside your home area (when traveling for example).

SDN (Service Dial Number)

Telephone numbers supplied by your network provider and giving access to special services, such as voice mail, directory inquiries, customer support and emergency services.

SmartChip

Card containing a chip with all the information required to operate the phone (network and memory information, as well as the subscriber's personal data). The SmartChip fits into a small slot on the back of the phone and is protected by the battery.

SMS (Short Message Service)

Network service sending and receiving messages to and from another subscriber without having to speak to the correspondent. The message created or received (up to 160 characters long) can be displayed, received, edited or sent.

Patent Information

This product was manufactured under one or more of the following U.S.

patents: 5276765 5749067 6061647

Index

A	
Access Codes	20
Address Book	69
Alarm Clock	62
Answer Mode	76
Answering a Call	22
Audio & Ringtones	61
AuthWallet	57
Auto Redial	75
B	
Backlight Timer	72
Battery Disposal	11
Bluetooth	72
C	
Calculator	63
Calendar	63
Call	75
Caller Groups	69
Camera key	12, 13
Cellular Video	60
Charging the Battery	18
Changing the Text Input Mode	23
D	
Date Format	74
Display Information	15
During a Call	27
D-Day Counter	65
E	
Entering Text	22

F	
Fixed Dial Number	79
Flight Mode	80
G	
GPRS	101
I	
Inbox	43
Inserting the memory card	19
Installing the SmartChip	17
L	
Languages	72
Lock Handset	78
M	
Making a Call	21
Memory Card	68, 81
Messaging	41
Minute Minder	76
Music Player	37
My Numbers	70
N	
Network Profiles	80
Notepad	63
O	
Outbox	48
P	
Phone Components	12
Playing Music	38

R	
Record Video	67
Removing the memory card	19
Ringtones	71
S	
Security	55, 78
Security code	20
Service Dial Numbers	70
Shop Games	59
Software Update	80
Speed Dial List	69
Stop Watch	64
T	
Take Photo	65
Tasks	64
Templates	49
Tip Calculator	64
Transferring Music	37
TTY	77
U	
Unit Converter	65
V	
Vibrate Mode	22
Video	62
Video Share Call	28
Voicemail	49, 51
W	
Wallpapers	72
World Clock	64

