

Part 15.21 statement

" Change or Modifications that are not expressly approved by the manufacturer could void the user's authority to operate the equipment. "

Part 15.105 statement

This equipment has been tested and found to comply with the limits for a class B digital device, pursuant to Part 15 of the FCC Rules.

These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. if this equipment does cause harmful interference or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected
- Consult the dealer or an experienced radio/TV technician for help.

LIMITED WARRANTY STATEMENT

1. WHAT THIS WARRANTY COVERS:

LG offers you a limited warranty that the enclosed subscriber unit and its enclosed accessories will be free from defects in material and workmanship, according to the following terms and conditions:

- (1) The limited warranty for the product extends for ONE (1) year beginning on the date of purchase of the product.
- (2) The limited warranty extends on to the original purchaser of the product and is not assignable or transferable to any subsequent purchaser/end user.
- (3) This warranty is good only to the original purchaser of the product during the warranty period as long as it is in the U.S., including Alaska, Hawaii, U.S. Territories and Canada.
- (4) The external housing and cosmetic parts shall not be covered under these limited warranty terms.
- (5) Upon request from LG, the consumer must provide information to reasonably prove the date of purchase.
- (6) The customer shall bear the cost of shipping the product to the Customer Service Department of LG. LG shall bear the cost of shipping the product back to the consumer after the completion of service under this limited warranty.

2. WHAT THIS WARRANTY DOES NOT COVER:

- (1) Defects or damages resulting from use of the product in other than its normal and customary manner.
- (2) Defects or damages from abnormal use, abnormal conditions, improper storage, exposure to moisture or dampness, unauthorized modifications, unauthorized connections, unauthorized repair, misuse, neglect, abuse, accident, alteration, improper installation, or other acts which are not the fault of LG, including damage caused by shipping blown fuses spills of food or liquid.
- (3) Breakage or damage to antennas unless caused directly by defects in material or workmanship.
- (4) That the Customer Service Department at LG was not notified by consumer of the alleged defect or malfunction of the product during the applicable limited warranty period.
- (5) Products which have had the serial number removed or made illegible.
- (6) The limited warranty is in lieu of all other warranties, express or implied either in fact or by operations law, statutory or otherwise, including, but limited to any implied warranty of marketability or fitness for a particular use.
- (7) Damage resulting from use of non-LG approved accessories.
- (8) All plastic surfaces and all other externally exposed parts that are scratched or damaged due to normal customer use.
- (9) Products operated outside published maximum ratings.
3
- (10) Products used or obtained in a rental program.
- (11) Consumables (such as fuses).

3. STATE LAW RIGHTS:

No other express warranty is applicable to this product. THE DURATION OF ANY IMPLIED WARRANTIES, INCLUDING THE IMPLIED WARRANTY OF MARKETABILITY, IS LIMITED TO THE DURATION OF THE EXPRESS WARRANTY HEREIN. LG INFOCOMM INC. SHALL NOT BE LIABLE FOR THE LOSS OF THE USE OF THE PRODUCT, INCONVENIENCE, LOSS OR ANY OTHER DAMAGES, DIRECT OR CONSEQUENTIAL, ARISING OUT OF THE USE OF, OR INABILITY TO USE, THIS PRODUCT OR FOR ANY BREACH OF ANY EXPRESS OR IMPLIED WARRANTY, INCLUDING THE IMPLIED WARRANTY OF MARKETABILITY APPLICABLE TO THIS PRODUCT. Some states do not allow the exclusion of incidental or consequential damages or limitations on how long an implied warranty lasts; so these limitations or exclusions may not apply to you. This warranty gives you specific legal rights and you may also have other rights which vary from state to state.

4. HOW TO GET WARRANTY SERVICE:

To obtain warranty service, please call the following web address:

www.lgeservice.com

For Your Safety

Important Information

This user guide contains important information on the use and operation of this phone. Please read all the information carefully for optimal performance and to prevent any damage to or misuse of the phone. Any changes or modifications not expressly approved in this user guide could void your warranty for this equipment.

Before You Start

Safety Instructions

WARNING! To reduce the possibility of electric shock, do not expose your phone to high humidity areas, such as the bathroom, swimming pool, etc.

Always store your phone away from heat. Never store your phone in settings that may expose it to temperatures less than 32°F or greater than 104°F, such as outside during extreme weather conditions or in your car on a hot day. Exposure to excessive cold or heat will result in malfunction, damage and/or catastrophic failure.

Be careful when using your phone near other electronic devices. RF emissions from your mobile phone may affect nearby in adequately shielded electronic equipment. You should consult with manufacturers of any personal medical devices such as pacemakers and hearing aides to determine if they are susceptible to interference from your mobile phone.

Turn off your phone in a medical facility or at a gas station. Never place your phone in a microwave oven as this will cause the battery to explode.

IMPORTANT! Please read the TIA SAFETY INFORMATION on page 78 before using your phone.

Safety Information

Read these simple guidelines. Breaking the rules may be dangerous or illegal. Further detailed information is given in this user guide.

- ▶ Never use an unapproved battery since this could damage the phone and/or battery and could cause the battery to explode.
- ▶ Never place your phone in a microwave oven as it will cause the battery to explode.
- ▶ Do not dispose of your battery by fire or with hazardous or flammable materials.
- ▶ Make sure that no sharp-edged items come into contact with the battery. There is a risk of this causing a fire.
- ▶ Store the battery in a place out of reach of children.
- ▶ Be careful that children do not swallow any parts such as rubber plugs (earphone, connection parts of the phone, etc.). This could cause asphyxiation or suffocation.

- ▶ Unplug the power cord and charger during lightning storms to avoid electric shock or fire.
- ▶ When riding in a car, do not leave your phone or set up the hands-free kit near to the air bag. If wireless equipment is improperly installed and the air bag is activated, you may be seriously injured.
- ▶ Do not use a hand-held phone while driving.
- ▶ Do not use the phone in areas where its use is prohibited. (For example: aircraft).
- ▶ Do not expose the battery charger or adapter to direct sunlight or use it in places with high humidity, such as a bathroom.
- ▶ Never store your phone in temperatures less than -4°F or greater than 122°F.
- ▶ Do not use harsh chemicals (such as alcohol, benzene, thinners, etc.) or detergents to clean your phone. There is a risk of this causing a fire.
- ▶ Do not drop, strike, or shake your phone severely. Such actions may harm the internal circuit boards of the phone.
- ▶ Do not use your phone in high explosive areas as the phone may generate sparks.
- ▶ Do not damage the power cord by bending, twisting, pulling, or heating. Do not use the plug if it is loose as it may cause a fire or electric shock.
- ▶ Do not place any heavy items on the power cord. Do not allow the power cord to be crimped as it may cause fire or electric shock.
- ▶ Do not handle the phone with wet hands while it is being charged. It may cause an electric shock or seriously damage your phone.
- ▶ Do not disassemble the phone.
- ▶ Do not place or answer calls while charging the phone as it may short-circuit the phone and/or cause electric shock or fire.
- ▶ Only use the batteries, antennas, and chargers provided by LG. The warranty will not be applied to products provided by other suppliers.
- ▶ Only authorized personnel should service the phone and its accessories. Faulty installation or service may result in accidents and consequently invalidate the warranty.
- ▶ Do not hold or let the antenna come in contact with your body during a call.
- ▶ An emergency call can be made only within a service area. For an emergency call, make sure that you are within a service area and that the phone is turned on.

FCC RF Exposure Information

WARNING! Read this information before operating the phone. In August 1996, the Federal Communications (FCC) of the United States, with its action in Report and Order FCC 96-326, adopted an updated safety standard for human exposure to radio frequency (RF) electromagnetic energy emitted by FCC regulated transmitters. Those guidelines are consistent with the safety standard previously set by both U.S. and international standards bodies.

The design of this phone complies with the FCC guidelines and these international standards.

CAUTION

Use only the supplied and approved antenna. Use of unauthorized antennas or modifications could impair call quality, damage the phone, void your warranty and/or result in violation of FCC regulations. Do not use the phone with a damaged antenna. If a damaged antenna comes into contact with skin, a minor burn may result. Contact your local dealer for a replacement antenna.

Body-worn Operation

This device was tested for typical body-worn operations with the back of the phone kept 0.79 inches (2cm) between the user's body and the back of the phone. To comply with FCC RF exposure requirements, a minimum separation distance of 0.79 inches (2cm) must be maintained between the user's body and the back of the phone. Third-party belt-clips, holsters, and similar accessories containing metallic components should not be used. Body-worn accessories that cannot maintain 0.79 inches (2cm) separation distance between the user's body and the back of the phone, and have not been tested for typical body-worn operations may not comply with FCC RF exposure limits and should be avoided.

Vehicle Mounted External Antenna (optional, if available)

A minimum separation distance of 8 inches (20cm) must be maintained between the user/bystander and the vehicle mounted external antenna to satisfy FCC RF exposure requirements. For more information about RF exposure, visit the FCC website at www.fcc.gov

FCC Part 15 Class B Compliance

This device and its accessories comply with part 15 of FCC rules. Operation is subject to the following two conditions: (1) This device and its accessories may not cause harmful interference, and (2) this device and its accessories must accept any interference received, including interference that may cause undesired operation.

Cautions for Battery

- ▶ Do not disassemble.
- ▶ Do not short-circuit.
- ▶ Do not expose to high temperature: 60°C (140°F).]
- ▶ Do not incinerate.

Battery Disposal

- ▶ Please dispose of your battery properly or bring to your local wireless carrier for recycling.
- ▶ Do not dispose in fire or with hazardous or flammable materials.

Adapter (Charger) Cautions

- ▶ Using the wrong battery charger could damage your phone and void your warranty.
- ▶ The adapter or battery charger is intended for indoor use only.

Do not expose the adapter or battery charger to direct sunlight or use it in places with high humidity, such as the bathroom.

Confirming before use

Phone Parts and Functions	28
Display	32
Menu Operations.....	34
Soft Key Operations	34
Side Button Main Operations	35
Using the UIM	36
Attaching/Removing the Battery Pack..	38
Charging the Phone.....	40
Turning Power ON.....	44
Turning Power OFF	44
Date/Time	45
Using Caller ID Notification Service	45
Own Number.....	45

Phone Parts and Functions

The Name and function of each part of the phone are as follows.

- This manual describes operation of each button using an illustration of the button.

① Earpiece

While talking over a call, the other party's voice is heard from here.

② LED display

Lights up and flashes during incoming call or battery charging. You cannot change the light up/flash method.

③ In camera

You can use this camera for shooting yourself or sending movie by Video-phone call.

④ Display → P32**⑤ Earphone/Microphone terminal**

For connecting a Flat-plug Earphone/Microphone Set with Switch (option), etc. Do not forcibly pull the earphone/microphone cover*.

※: You can rotate it forward or backward when it is open.

⑥  Mail button

Press from the Stand-by display to bring up the Mail menu. → P140

Press from the Stand-by display for 2 or more seconds to check new message. → P129, P156

Press this key during auto key lock to cancel the auto lock. → P101

You can execute the items shown on the soft key area. → P34

⑦  Navigation button

For selecting an item and scrolling the display.

The following operations can be performed from the Stand-by display:

 Up button : The phonebook list screen appears. → P67

 Down button : The custom menu screen appears. → P186

 Left button : Received call screen appears. → P86

Press for 1 or more seconds to display the received mail list. → P88

 Right button : Redialed call screen appears. → P87

Press for 1 or more seconds to display the sent mail list. → P88

⑧  Menu/Select button

Press on the Stand-by display to bring up the Main menu. → P34

An operation displayed in the soft key area can be performed. → P34

- 9  **Video-phone button**
Press to make/receive video-phone calls. → P58, P60
Press on the Stand-by display to view the other party that you made the latest call.
Press to switch modes, etc. in entering mode (Pictograph/Symbol/Emoticon). → P223
Press to switch in camera and out camera when camera is started.
- 10  **Start button**
Press to make/receive voice calls. → P48, P50
Press on the Stand-by display to view the other party that you made the latest call. Press for 1 or more seconds to display all received/sent mail history.
Press while characters are entered to switch between full-pitch and half-pitch. → P222
- 11  **Volume buttons**
Press to adjust the volume, etc. → P35
Press these buttons on the Stand-by display for 1 or more seconds to turn on the photo light. → P192
- 12 **Dial button**
- 13  *** (asterisk) button/Public mode (drive mode) button**
Press to enter "*" and to switch between upper case and lower case while characters are entered. → P224
On the stand-by display, press this key for 1 or more seconds to set or cancel Public mode (drive mode).
→ P52
- 14 **Microphone**
For speaking to the other party.
For recording sound when shooting moving images by the camera.
- 15  **i-mode button**
Press from the Stand-by display to bring up the i-mode menu. → P122
Press for 2 or more seconds from the Stand-by display to bring up software list screen of i-appli. → P163
Press from the entering character mode to switch the mode (Hiragana/Katakana/English/ Number)
An operation displayed in the soft key area can be performed. → P34
- 16  **Multitask button**
Press to bring up the Task Manager.
Press for 1 or more seconds to bring up the New Task screen. → P284
- 17  **Power/End button**
Press for 2 or more seconds to turn the power on.
Press for 2 or more seconds to turn the power off.
→ P44
Press to end calls and end functions.
- 18  **Clear button**
Press to return to the previous operation.
Press this button on the Stand-by display (when the phone is closed) for 1 or more seconds to enable the auto key lock → P100
Press to cancel the operation depending on the function such as sending mails or downloading data.*

Also, press to delete entered text.

※ : Note that the operation may not be canceled depending on the timing of canceling*.

⑱  **(Sharp)/ Manner Mode button**

Press for 1 or more seconds from the Stand-by display to activate/deactivate the Manner Mode.

→ P78

Also, press to enter “#” and to start a new line while characters are entered.

⑳ **Connector terminal**

For connecting adapters and cables.

㉑ **Infrared data port**

Point this port to the other device for infrared communication. → P186

㉒ **Strap hole**

㉓ **Speaker**

Ring tone and alarm can be heard from here.

The voice of the other partner can be heard from here when you are calling using the speaker phone.

㉔ **Rear cover**

㉕  **Camera button**

Press this button on the Stand-by display to activate the photo mode and press this for 1 or more seconds to activate the movie mode. → P111, → P117

㉖ **Out camera**

You can use this camera for shooting still image or moving images or sending movie by Video-phone call.

㉗ **Photo light**

You can turn on this light when the out camera is used.

This lights up/flashes in red during shooting still image or moving images. → P111, → P117

You can also use this light as a flashlight. → P192


Opening/closing phone

Slide the body front portion where the Stand-by display exists upward to open the phone. Slide it downward to close the phone.

Information

- Note that sliding it roughly results in a failure.

Display



- ① : Shows the level of the received radio waves.
Strong ↔ Weak
- ② : Displayed during a voice call.
 : Displayed during a video-phone call.
 : Displayed during a voice call using the speaker phone.
- ③ (Blinks): while i-mode is activated.
 (Blinks): during i-mode communication.
 : Displayed during trying dialup connection.
 : Displayed during dialup connection.
 : Displayed while an SSL-enabled page is displayed or obtained.

- ④ : Displayed while "All Call Rejection" is activated.
- ⑤ : Displayed while a function (Task) is activated.
 : Performing multiple functions (Task).
 (Blinking): Alarm starts while talking, activating camera or setting public mode (drive mode).
- ⑥ (White): Displayed when the i-mode Center holds a mail.
 (Pink): Displayed when the box for i-mode mail at the i-mode Center is full.
 (White): Displayed when the i-mode Center holds a MessageR.
 (Pink): Displayed when the box for MessageR at the i-mode Center is full.
 (White): Displayed when the i-mode center holds a MessageF.
 (Pink): Displayed when the box for MessageF at the i-mode Center is full.
 (White): Displayed when the i-mode Center holds mail, a messageR and a messageF.
 (Pink): Displayed when the boxes for i-mode mail, MessageR and MessageF at the i-mode Center are full.
- ⑦ (White): Displayed when an unread mail exists.
 (White): Displayed when an unread SMS message exists.

-  (White): Displayed when an unread mail and SMS message exist.
-  (Pink): Displayed when the inbox is full.
- : Displayed when the area for SMS messages in the UIM is full.
- : The inbox and the SMS in card are full.
- 8  (Yellowish green): Displayed when a Voice Mail message exists.
-  (Orange): Displayed when the box for Voice Mail messages is full.
- 9  (White): Displayed when an unread MessageR exists.
-  (Pink): Displayed when the box for MessageR is full.
- 10  (White): Displayed when an unread MessageF exists.
-  (Pink): Displayed when the box for MessageF is full.
- 11 : Displayed when i-appli is being started.
- : Displayed when i-appli auto start failed.
- 12  ~ : Shows the battery level.
- 13  (Pink): Displayed during Manner mode.
-  (Blue): Displayed during Original manner mode.
- 14 : Displayed when the ringtone for incoming voice call or video-phone call sounds, not operating a vibration.
- : Displayed when the vibration for incoming call is activated to "Pattern 1" or "Pattern 2" when the alarm for incoming voice call or video-call is muted, and the vibration operate linked with a melody.
- : Displayed when a vibration and a ringtone for incoming voice call and video-phone call sounds at the same time and the vibration is set to operate linked with a melody.
- : Displayed when a vibration and a ringtone from incoming voice call or video-phone call do not operate.
- 15 : Public mode (Drive mode) active.
- 16 : Displayed while an alarm is set.
- : Displayed when today's schedule exists.
- : Displayed when an alarm is set and today's schedule exists.
- 17 : Displayed when UIM is not inserted or an error occurs on the UIM.
- 18 **Date counter** → **P200**
Displays the number of days till the registered event.
- 19 **Stand-by memo** → **P198**
Displays the stand-by memo you create.

Menu Operations

This section describes the operation using an example for setting a wall paper on the Stand-by display.


■ Selecting a function by a

1. On the Stand-by display,  [Menu] ▶ Highlight  using  ▶  ▶  Move the cursor to the Stand-by display ▶  ▶  Move the cursor to the Wallpaper ▶  ▶ 



■ Selecting a function by pressing the key corresponding to the menu number

1. On the Stand-by display,  [Menu] ▶ Highlight  using  ▶  ▶  ▶ 



Soft Key Operations

To perform an operation displayed in the soft key area on the 待受画面, press the corresponding button as below.

Information

-  (Navigation icon) that indicates the directions in which you can scroll and select items using  is also displayed in the soft key area.
- Items displayed in the soft key area vary depending on the display.

Side Button Main Operations

- If auto key lock (P100) is enabled with phone closed, the operations are as follows:
 : the auto lock can be cancelled temporarily. Refer to the table below.
 : Cannot be operated.

phone operation	How to operate	Operation of phone
When the display is turned on	When the display is turned off ►  / 	Open/Close
Cancel temporarily the auto key lock	During the auto key lock ►  ► 	Close
Adjust the button check volume	During stand-by ► 	Open/Close
Adjust ring tone volume	During incoming call ► 	Open/Close

phone operation	How to operate	Operation of phone
Adjust phone volume	During voice phone/ Video-phone call ► 	Open/Close
Call rejection	Press ►  for 1 or more seconds during incoming call	Close
Stopping alarm	During the alarm/ schedule alarm is ringing ► 	Open/Close
Scrolling the listing display or site display by page ^{※1}	During displaying each screen ► 	Open/Close
Switch the one month schedule display by month	During displaying the one month display in the Scheduler ► 	Open/Close
Starting camera	During stand-by ►  (Photo mode) Press ►  for 1 or more seconds during stand-by (Movie mode)	Open/Close
Zoom	During the still image/moving images shooting display is displayed ► 	Open/Close
Photo light on/off ^{ff※2}	During stand-by, press ►  or  for 1 or more seconds (light up) When the photo light lights up, press ►  or  (light off)	Open/Close

Confirming before use

phone operation	How to operate	Operation of phone
Adjusting the volume when moving images/ melodies are replayed	When playing moving images/melodies ▶ 	Open/ Close
Playing and pausing moving images/ melodies	When moving images/ melodies are stopped, ▶  (play) When the moving images/ melodies are played, ▶  (pause)	Open/ Close

※1 : Depending on the display type, you can move the cursor up and down.

※2 : "Flashlight" (P192) is set to "Not use", this does not function.

Using the UIM (Card)

Your phone number and contracted contents for the service, etc. are recorded in the UIM. You need to insert it into the phone to make/receive calls or perform communication.

Refer to the UIM manual for details of how to use it.

Inserting/Removing UIM (Card)

Insert/remove the UIM after you turn off the power of the phone and remove the rear cover and battery pack beforehand (P39).

- Remove the AC adapter and options beforehand.

Inserting

1. Insert the UIM with its IC-side facing downwards in the direction of the arrow underneath the guide

Removing

1. Slide the UIM in the direction of the arrow to remove it

Information

- When inserting / removing the UIM, close the flip, and then put it on your hand. Take care not to accidentally torch or scratch the IC.

About Password of UIM

You can set 2 passwords, PIN1 and PIN2, for a UIM.

→ P107

UIM Restriction Functions

The UIM has a restriction function to protect your data and files.

If you obtain the following types of data and files with a UIM inserted, restrictions are automatically imposed to disable them when the UIM is not inserted or when another UIM is inserted.

- Images/melodies/i-motion/i-appli obtained from sites and Internet web pages
- Files attached to i-mode mail messages and MessagesR/F

Differences of UIM

The card (blue) differs from the card (Green/White) as follows:

- About WORLD WING

Function	UIM (Blue)	UIM (Green/White)
Number of digits of the phone number that can be stored in the UIM phonebook	Up to 20 digits	Up to 26 digits
WORLD WING	Not available	Available
Service dialing	Not available	Available

WORLD WING is international roaming service that allows you to use the same mobile phone number for making and receiving calls after inserting your UIM (Green/White) in a phone applicable to the service or mobile phone available for overseas use (WCDMA or GSM).

- Application is not required for the user who signed a service contract after September 1, 2005. However, those who notified that the service is not required during signing the service contract or canceled in the middle of the contract need to apply for the service again.

Confirming before use

- Those who did not apply for WORLD WING before August 31, 2005 need to apply for the service.
- Some billing plans may not be applied to WORLD WING.
- For loss or theft of the phone, account settlement of total charges, or phone failure while overseas, see "Failure while overseas" the back side of the operation manual. Note that the customer shall also pay the fees for call and communication after the phone is lost or stolen.

Attaching/Removing the Battery Pack

Make sure that you attach the dedicated battery pack L02 for L704i to use it.

Attaching

- 1. Press the rear cover in the direction of the arrow ① to slide it in the direction of the arrow ②, then lift it up in the direction of the arrow ③ to remove**
- 2. Insert the battery in the direction of the arrow ① with the label facing downwards, then push it in the direction of the arrow ②**

- Adjust the rear cover to the ditch of the phone holding the cover approx. 3mm off, then press it in the direction of the arrow ① to slide it in the direction of the arrow ②, then push it until it clicks

Removing

- Press the rear cover in the direction of the arrow ① to slide it in the direction of the arrow ②, then lift it up in the direction of the arrow ③ to remove
- Take the projection of the battery pack to lift it up in the direction of the arrow

Information

- Attach/remove the battery pack with the phone closed and held in your hand after you turn off the power. In addition, if you attach/remove the battery pack forcibly, it may damage the charging connector of battery.
- Take care not to attach/remove the rear cover. Note that if the rear cover is forcibly depressed, the slot of the rear cover may be damaged.
- For details about the battery, see the manual for Battery Pack L02.

Charging the Phone

Charging

Connect specified AC Adapter (option) to charge the battery after attaching the battery pack to the phone (P38). You need AC Adapter 01 for both overseas and domestic usage (option) separately when using the phone overseas.

1. Open the cover[※] of the external connector terminal of the phone

※: You can rotate it forward or backward when it is open.

2. Place the arrow side of the AC adaptor connector up and keep the connector level with head set to connect in the arrow direction

3. Insert the AC adapter's plug into a power socket

- If you start to charge the battery, the charging start tone will sound.
The battery level icon () flashes on and off in turn and it is red. After charging, the alarm tone for ending the charging will ring and then the flashing disappears and the LED turns off.
- If you charge the phone with the power off, the animation for the battery level is displayed as follows, depending on the battery level.
 - In case the battery level is low: "Please wait" → "Charging" → "Battery charged"
 - In case the battery is empty: "Please wait" → "Low battery Please wait" → "Charging" → "Battery charged"
- When charging the battery pack overseas, confirm the voltage used in the country or the area of stay, and use Overseas/Domestic AC Adapter 01 (option) (A conversion plug adapter for overseas travel applying to the country or area of stay is required). Also, do not charge the battery pack using an electric transformer for overseas travel.
- Refer to the instruction manuals for AC Adapter 01 (option) and AC Adapter 01 for both overseas and domestic usage (option) for details.

Information

- When you use the phone for the first time, the battery pack is not fully charged. Fully charge the battery before using it.
- When you attach the AC adapter to the phone, do not use unnecessary force. The phone and the connector may be damaged.
- Do not remove the battery pack and the UIM during charging.
- If the battery cannot be charged correctly, turn off the power once, remove the battery pack, and then reattach it to charge the battery again.
- If the battery level becomes very low during a video-phone call, connecting the AC adapter may not charge the battery fully, and the power may go off.

Removing the AC Adapter

After charging completes, disconnect the AC adapter from the phone.

1. **Disconnect the connector of the AC adapter from the power socket**
2. **While pressing the release buttons on both sides of the connector, remove it horizontally from the phone in the direction of the arrow**

- Do not pull the connector forcibly. Malfunction may result.

3. **Close the cover of the external connector terminal of the phone**

Checking the Battery Level

When turning the power on, the battery level (estimate) icon appears.

- The Battery Level display indicates just an estimate of the battery level.

: Almost full

: Getting low

: Almost empty. Charge the battery immediately.

When You Need to Charge the Battery

If the battery is completely flat, a message appears,  flickers, and the battery alarm sounds. If you press , the message disappears and the battery alarm stops.

Information

- If you set "Manner mode" or "Original manner mode" and set battery alarm to OFF, the alert tone does not ring.

Precautions on the Battery Pack

Be sure to use the battery pack dedicated to the phone.

■ Battery life

- The battery pack is a consumable. With repeating the charging, the operating time at a time is gradually reduced.
- It is recommended to change the battery pack early when the operating time at a time is reduced to approximately half compared to the time when the is purchased since the useful life of the battery pack is reaching to the end. The battery pack may expand when it is reaching to the end of useful life depending on its usage condition, this is not a problem. The useful life of the battery pack is one year as a guide line. However, repeated charging/discharging for short time, usage in high temperature environment, or continuous long time charging condition may shorten the useful life of the battery.

For environmental protection, bring the exhausted battery to an , dealer, or recycle shop.



Li-ion

■ Do not charge for long periods of time (several days) with the phone turned on.

- Do not leave the phone power on for long periods of time while charging. Otherwise, when charging finishes, the phone will attempt to receive power from the battery so that when you actually use the phone, you will be able to do so for just a short amount of time before the battery alarm sounds. If this happens, charge the battery correctly. When charging the battery again, first

disconnect the phone from the AC adapter and then set it again.

■ Estimated usage time for battery

The usable time of the battery varies depending on the usage environment or its remaining life.

Network	Stand-by time	Continuous talk time
/3G	Static : about ●●● hrs Dynamic : about ●●● hrs	Voice call : about ●●● min Video call : about ●● min
GSM/GPRS	Static : about ●●● hrs	Voice call : about ●●● minutes

- Continuous talk time is the estimated time when radio waves can be sent and received normally.
- Continuous stand-by time is the estimated time you can use the phone in motion when it is closed and can receive radio waves normally. The standby time could be about half of this estimate depending on the battery level, function settings, other ambient conditions such as temperature, the status of radio waves in the area (weak or no radio waves, for instance) and the status of the network of the country in which you stay. The continuous standby time will be shorter if you don't insert the UIM. When you use i-mode communications, the talk/transmission time and standby time will be shorter. Further, even if you do not make calls or perform i-mode communication, the talk/communication time and standby time will be shorter if you compose i-mode mail, start up a downloaded i-appli.

- The continuous standby time for standstill is the average number of hours you can use the phone in standstill status when it is closed and can receive radio waves normally.
- The continuous standby time for in motion is the average number of hours you can use the phone in the combined status of "standstill", "moving" and "out of the service area" when it is closed, in an area where it can receive radio waves normally.
- The talk/communication time and standby time will also be shorter than the above-mentioned estimates when you perform data transmission or multi-access or when you use the camera.

■ Estimated time for charging battery

AC Adapter 01	Approx. ●● minutes
----------------------	--------------------

- The estimated charging time is for when the phone is off and the battery is being charged from empty. The charging time will be longer if you charge the battery with the power turned on.

■ Other precautions

- Do not use any other adapter than the specified one. It may shorten the life of the battery pack.

Turning Power ON

- Before you turn on the power, make sure that the UIM is inserted and that the battery is fully charged.

1. Press P for 2 or more seconds

- After the Wake-up display is displayed, the Stand-by display appears.

Information

- If "PIN code request" (P101) is set to "ON", you need to enter the PIN1 code.
- If "All lock" (P99) is set to "Power on", you need to enter the terminal security code.

Turning Power OFF

1. Press P for 2 or more seconds

- Select "Yes" on the Confirm display when the phone is closed.
- The Exit display appears and the power is turned off.

Information

- The time to turn off the phone may be long. Depending on the status of network, the lead time may differ. During switching off the power, do not repeat to power on/off.

Date/Time

You can set the date and time. See “Setting Date & Time” (P96) for details of how to set them up.

Using Caller ID Notification Service

The Caller ID Notification Service enables you to notify the other party of your phone number when you make a call. See “Using Caller ID Notification Service” (P208) for details of how to set it up.

Own Number

You can display your phone number recorded in the UIM.

1. On the Stand-by display,   

- See “Displaying Own Number” (P72) for details of how to change the settings on the Own Number display.

Making calls/ Receiving calls

Making calls.....	48
Receiving calls	51
Using Public mode (drive mode)	52
Using Public mode (power off)	54

Making calls

1. Enter the other party's phone number

-  : The last digit is cleared. To clear all digits, press it for 1 or more seconds.
-  [Save]: You can register / add the entered phone number to phonebook. Go to step 2 on page 64 of "Adding to Phonebook".
-  [Search]: You can search for the phone number in phonebook. See the contents after step 3 on page 67.

2. ▶ Start talking when the other party answers

- Press  for 1 or more seconds: You can switch ON/OFF the speaker phone.

3. to end the call after talking

- When the call is disconnected, the alert sound sounds from a receiver.

Information

- If you press  after entering the number from 0 to 9 in the Enter Phone Number screen, you can make a call directly matching the the number saved in memory.
- You can enter a phone number of up to 42 digits.
- If you enter a phone number exceeding 16 digits, dialing will be made displaying the first 16 digits digits of the phone number.
- You can make a call after entering "184" (Not notify) or "186" (Notify) in front of phone number.
- When the Flat-plug Earphone/Microphone Set with Switch (option) is attached, you can only talk on the Earphone / Microphone regardless that the speaker phone is ON/OFF.
- When dialing/receiving overseas, some name of the other party may not be displayed even that name is registered in the phonebook.

Using the Submenus of the Enter Phone Number Display

1. From the Enter Phone Number screen (See left), [Menu] ▶ Select from the following submenu items

Notify caller ID

Set whether to notify your phone number per call.

- **Not notify** : "#31#" is added in front of the phone number entered, but the phone number is not notified.
- **Notify** : "*31#" is added in front of the phone number entered, and the phone number is notified.
- **Cancel** : The added "#31#" or "*31#" is deleted.

Select prefix

The number saved in "Setting Prefix Dial" (P93) is added before the phone number is entered.

International call

The international access code saved in "International dial setting" (P92) is added before the phone number is entered.

Save

You can save the entered phone number entered into the Phonebook. Go to step 2 on page 64 of "Adding to Phonebook".

Search phonebook

You can search for the phone number in phonebook. For operations after searching, see 3 on page 66 of "Searching for Phonebook Entries".

Using the Submenus of the Talking screen

1. From the Talking screen (P48),  [Menu] ► Select from the following submenu items

New call^{**1}

You can put the current call on make and hold a call to another party.

End active call

You can disconnect the call.

Hold^{**1}/Cancel held call^{**1}

You can put/release the call on hold.

Mute^{**2}/Unmute^{**2}

You can mute/unmute the voice transmitted to the other party.

※1: Available only for Call Waiting Service subscribers.

To use this service, go to "Using Call Waiting Service" (P206).

※2: Not displayed during call is held.

Making a Call From the Dialed/Received Call Record

1. From the Stand-by display, / / /  ► Select a record ► 

Information

- See "Using the Submenu of the Received Calls display" (P86) for submenu.

Making a Call from the Phonebook

1.  in the Stand-by display, or search the phonebook ► Select the party you want to call ► 
- When there are multiple registered phone numbers, press  on the phonebook list display. Then, the outgoing call phone number selection display is displayed, select the phone number and press  [Call].

Information

- To switch the phonebook list to display between the phone and UIM, select  [Menu] → “View handset” / “View UIM” on the phonebook list screen.

Using Pause Dial

You can use services such as sending messages to a pocket bell, reserving tickets or checking the balance of your bank account by sending push signal from the handset. When the pause “P” has been entered, you can send while dividing the dial data at the position where the pause is entered.

1. Enter the phone number

2. Enter the dial data

- Press  3 times to enter pause “P”.
- Only  to , ,  and pause “P” can be entered.
- Up to 42 digit can be entered.
- If you enter pause “P” before the phone number, you can not dial.

3.

- A call is made to the other party, and the dial data from the beginning to the first pause “P” is displayed while being connected.

4. Confirm that the other party accepted or [Select]

- The dial data from the beginning to the first “P” is sent, and the dial data to the next pause “P” is displayed. Each time you press  or , the dial data to the next “P” is sent. When you send the last number, the calling screen appears.

Information

- Depending on the target device, the dial data may not be received.
- When using video-phone call, you can not use pause dial.

International Calls

You can make an international call easily using the international call service “WORLD CALL”.

When you have signed up for service, you have contracted to use “WORLD CALL” (except those who have applied not to use it).

- You can make calls to 240 countries and areas worldwide.

■ How to make calls

009130 → **010** → **Country code** → **Area code** → **Destination phone number** 

- This service is not available with some billing plans.
- Application/monthly fee for WORLD CALL is free of charge.
- The WORLD CALL charges are added to your monthly bill.

- Contact “ Information Center” on the back of this manual for inquiries about WORLD CALL.
- If the other party uses a specific 3G mobile phone overseas, you can make an “International Video-phone Call” by dialing out using T after following the dialing method described above.
 - See the International Service web page of for the information about connectable countries and telecommunications carriers.
 - Images sent from the other party may blur on your phone or you may not be able to connect, depending on the other party’s phone used for the international video-phone.
- When the area code begins with “0”, leave this out when dialing. However, include “0” when making a call to some countries or regions such as Italy.

Making an International Call Easily

- Confirm that the “Setting Prefix Dial” (P93) is set to “AUTO” and “009130010” (WORLD CALL) is set for “IDD prefix code” in “IDD prefix setting”.
1. **On the Stand-by display, press  for 1 or more seconds to enter “+”**
 2. **Enter Country code → Area code → Destination phone number ▶  ()**
 3. **“Yes”**
 4. ** to end the call after talking**

Adjusting the Volume

1. **Press   during a call or press  for 1 or more seconds**

Information

- The changed volume is held even after ending the call.

Receiving calls

1. **When you receive a call, **

-  [Silent]: You can set to no sound for incoming call. If you subsequently press  [Reject], incoming call will be rejected.
 - : Reject the call.
2. ** to end the call after talking**
 - A confirmation tone is emitted from the phone when the incoming call is disconnected.

Making calls/Receiving calls

Information

- When dialing/receiving overseas, some name of the other party may not be displayed even that name is registered in the phonebook.

When you didn't get a call

When you could not answer the incoming voice call/video-phone call, the following screen indicating a missed call appears and the LED blinks for approx. 60 seconds.

-  [Select]: You can view the list of received calls.
-  [Close]: You can close the screen for missed calls.

Using the Submenu of the Ringing Display

1. From the Ringing screen (P51),  [Menu] ►
Select from the following submenu items

Voice mail^{※1}

The Call is connected to the Voice Mail Service Center.

Call rejection

The call is disconnected without answering it.

Call forwarding^{※2}

The call is forwarded to the registered phone number.

- ※1: If you use voice mail menu, you should register this service in operator. For details, see "Using voice mail" (P204).
- ※2: If you use call forwarding menu, you should register this service in operator. For details, please refer to the "Using Call Forwarding Service" (P207).

Using Public mode (drive mode)

Public mode is an auto-answer service that puts stress on manners in public spaces. When there is an incoming call in Public mode, a guidance to the effect that you cannot answer the call because you are driving a car or in a place (train, bus, theater, etc.) that requires restraint from using a phone is played for the caller and the call is disconnected.

- Public mode can be set/cancelled only from the stand-by display (in addition, from a screen showing "").
- You can make calls in Public mode.
- When the Caller ID request service is set to "Activate" and the "User unset" incoming call is received, a voice guidance requesting to send Caller ID is played. (No public mode guidance is played.)

Setting the Public Mode (drive mode)

1. On the stand-by display ► Press for 1 or more seconds

- The Public mode is set and  appears.

■ Releasing the Public Mode

On the stand-by display, press for 1 or more seconds

- The Public mode is released, and  disappears.

In Public mode

When an incoming call without Caller ID is received at your phone, no ringtone sounds. The missed calls display (P52) is displayed and the incoming call is recorded as a "missed call history" in the "Call/Mail history".

- A guidance to the effect that you cannot answer the call because you are driving a car or in a place that requires restraint from using a phone is played for the caller and the call is disconnected.

Operations while Network Service and Public mode (drive mode) are both active

While Public mode (drive mode) and Network Service are both active at the same time, the phone operations as listed below. Depending on the settings and/or steps for making a call, Network Service may have precedence, disabling Public mode (drive mode) operations or recording or display of missed calls.

■ Voice Mail

When a voice call is received	When a video-phone call is received
A Public mode (drive mode) guidance is played for the caller and the call is connected to Voice Mail Service Center. ^{#1}	The call is terminated without being connected to the Voice Mail Service Center. ^{#2}

■ Call Waiting

When a voice call is received	When a video-phone call is received
A Public mode (drive mode) guidance is played for the caller and the call is disconnected.	Disconnect the call after displaying the video guidance of the public mode to the other party.

■ Call Forwarding Service

When a voice call is received	When a video-phone call is received
A Public mode (drive mode) guidance is played for the caller and the call is connected to the forwarding destination. [#] Whether the guidance is played to the other party or not depends on the setting of the Call Forwarding Service.	The call is connected to the forwarding destination, with no Public mode (drive mode) video guidance played for the caller. [#] When the target hand set does not support the Video-phone call, the transmission is disconnected.

Making calls/Receiving calls

Nuisance Call Blocking Service

When a voice call is received	When a video-phone call is received
<ul style="list-style-type: none">For a call from a caller registered for nuisance call blocking, a call rejection guidance is played for the caller and the call is disconnected.For a call from a caller not registered, a Public mode (drive mode) guidance is played for the caller and the call is disconnected.	<ul style="list-style-type: none">For a call from a caller registered for nuisance call blocking, a call rejection video guidance is played for the caller and the call is disconnected.For a call from a caller not registered, a Public mode (drive mode) Video guidance is played for the caller and the call is disconnected.

Caller ID Request Service

When a voice call is received	When a video-phone call is received
<ul style="list-style-type: none">For a call with no caller ID notified, a caller ID request guidance is played for the caller and the call is disconnected.For a call with caller ID notified, a Public mode (drive mode) guidance is played for the caller and the call is disconnected.	<ul style="list-style-type: none">For a call with no caller ID notified, a caller ID request video guidance is played for the caller and the call is disconnected.For a call with caller ID notified, a Public mode (drive mode) video guidance is played for the caller and the call is disconnected.

※1: When the Voice Mail ringing time or Call Forwarding ringing time is set to "0 sec", the phone is in out of the service area, or it is turned off, the public mode (drive mode) guidance is not provided and nothing is recorded to the received call history.

※2: This handset is not applicable to Voice Mail (Video-phone call).
Make a voice call to "1412" (free) and set not to be applicable to video-phone call.

Information

In Public mode, the following sounds are not generated:

- Ring alert for incoming voice/video-phone calls
- Ring alert for incoming mail
- Ring alert for incoming MessageR/F
- Wake-up alarm sound ( blinks)[※]
- Schedule alarm sound ( blinks)[※]
- Battery exhaustion alarm sound
- The sound of the i-appli started by the setting of auto-start.
- Battery charging confirmation sound

※: The alarm sounds after releasing the public mode (drive mode).

Using Public mode (power off)

Public mode is an auto-answer service that lays stress on manners in public spaces. Once you activate Public mode (power off), the guidance is played back telling that you cannot take the call as you are currently in a place (in hospital, airplane, or in around priority seat in a train) where use is prohibited. Then the call is disconnected.

Activate Public mode (power off)

1. * 2 5 2 5 1 ►

- Public mode (power off) is set. (Nothing is changed in the Stand-by display.)
- After setting Public mode (power off) and turning off the power, the guidance “The person you are calling is currently in an area where use is prohibited. Please try again later.” is played back for incoming calls.

■ To release Public mode (power off)

* 2 5 2 5 0 ►

■ To check Public mode (power off) for the setting,

* 2 5 2 5 9 ►

When Public mode (power off) is activated

When an incoming call is received at your phone, the guidance is played back to the caller telling that you are currently in an area where use is prohibited, and then the call is disconnected. When there is an incoming video-phone call, the video-guidance of the public mode is played back to the caller, and then the call is disconnected.

- This setting is continued until you release the setting by dialing “*25250”. If you just switch on, this setting is not released.
- The Public mode (power off) guidance is played back even when you are out of the service area or radio waves do not reach.

Activating between network services and Public mode (power off)

If you use Public mode (power off) and Network service at the same time, the operation will be activated as follow. Depending on the setting or calling, the network service can be preferred, so the activation of Public mode (power off) or the record of missed call may not be displayed.

■ Voice Mail

Response to Incoming Voice calls	Response to Incoming Video-phone calls
Plays back the Public mode (power off) guidance to caller, and then the call is connected to the Voice mail Service Center. ^{※1}	The call is terminated without being connected to the Voice Mail Service Center. ^{※2}

■ Call Forwarding Service

Response to Incoming Voice calls	Response to Incoming Video-phone calls
Plays back the Public mode (power off) guidance to caller, and then the call is forwarded to the forwarding destination. ^{※1} The guidance depends on setting of Call Forwarding Service.	Does not play back the video guidance for public mode (power off), and the call is forwarded to the forwarding destination. If the destination does not support video-phone call, the call is disconnected.

Making calls/Receiving calls

Nuisance Call Blocking Service

Response to Incoming Voice calls	Response to Incoming Video-phone calls
<ul style="list-style-type: none">• When the caller is registered to the Nuisance Call Blocking Service, the guidance of the call rejection is played to the caller and the call is terminated.• In other cases, the guidance of the public mode (power off) is played to the caller and the call is terminated.	<ul style="list-style-type: none">• When the caller is registered to the Nuisance Call Blocking Service, the image guidance of the call rejection is played to the caller and the call is terminated.• In other cases, Video guidance of the public mode (power off) is played to the caller and the call is terminated.

Caller ID Display Request

Response to Incoming Voice calls	Response to Incoming Video-phone calls
<ul style="list-style-type: none">• For the caller without a caller ID, plays back the Caller ID Request guidance, and then the call is disconnected.• For the caller with a caller ID, plays back the Public mode (power off) guidance, and then the call is disconnected.	<ul style="list-style-type: none">• For the caller without a caller ID, plays back the video guidance for Caller ID Request, and then the call is disconnected.• For the caller with a caller ID, plays back the video guidance for Public mode (power off), and then the call is disconnected.

※1: When voice mail or call forwarding ring time is set to "0 sec", no Public mode (power off) guidance is played.

※2: This handset is not applicable to Voice Mail (Video-phone call).
Make a voice call to "1412" (free) and set not to be applicable to video-phone call.

Making/Receiving Video-phone calls

About Video-phone	58
Making Video-phone Calls.....	58
Receiving Video-phone Calls.....	60
Changing Settings for Video-phone Calls	61

Making/Receiving Video-phone calls

About Video-phone

When both you and the other party use video-phones, you can talk seeing each other's image.

- video-phones conform to 3G – 324M※1 standardized by the international standard 3GPP※2. You cannot connect to the video-phone that uses a different format.

※1: 3G-324M is the international standard for the third generation of mobile video-phones.

※2: 3GPP (3rd Generation Partnership Project) is the regional standards organization for developing common technical specifications for third-generation mobile telecommunications systems (IMT-2000).

- The video-phone call is activated at the speed of 64K bytes.

Making Video-phone Calls

1. Enter the other party's phone number

- The Enter Phone Number screen (P48) is displayed.

2. ► Start talking when the other party answers

Mark	Description
 	Speaker phone ON/OFF
 	Zooming magnification

- The voice of the other party is heard from the speaker when the call starts.
- Press  for 1 or more second: You can switch ON/OFF the speaker phone.
- /[Image]/[Camera]: You can switch between Substitutive image and your photo image for sending to the other party.
- [Switch]: You can switch the video that is sent to the other party to the image of the in camera or the out camera.
- : You can zoom in/out the image in the camera you are using.

3. Press to end the call after talking

Information

- See "International Calls" (P50) for how to make international calls.
- When the Flat-plug Earphone/Microphone Set with Switch (option) is attached, you can only talk on the Earphone/Microphone regardless of whether the speaker phone is ON/OFF.

[Using the Submenu of the Enter Phone Number screen](#)

See "Using the Submenus of the Enter Phone Number screen" (P48) of voice calls for the submenus available.

Using the Submenus of the Talking Screen

Setting item/Setting at purchase → P257

1. From the Talking screen (P58), [Menu] ► Select from the following submenu items

End call

The call is disconnected.

Hold

You can put the call on hold. You can cancel the function by pressing [Active].

Substitutive image/Camera image

You can switch to the Substitutive image for sending to the other party. → P95

Camera settings

You can set the camera of Video-phone call. You can select the icon by pressing [Close].

- **Zoom** : The camera image is zoomed. (x1/x2)
- **Brightness** : You can change the brightness of photo images.
- **Night mode** : You can set it up when using the camera in a dark place.

Video-phone settings

You can set the display of Video-phone call. After setting, press [Done]. → P94

– **Display setting** : You can set the display method for the Talking screen.

- Both : The other party's image and your image are displayed.
- Other : Only the other party's image is displayed.
- Me : Only your image is displayed.

– **Sub screen** : If you select "Both" of "video-phone settings", you can set the image which displayed each screen.

- Me : Only your image is displayed.
- Other : Only the other party's image is displayed.

– **Display light**: You can set the lighting method of the backlight on the Talking screen.

- Always on : Always lights during a call.
- Terminal setting : Follows the setting of "Backlight". → P83

Sending image quality

You can set the quality of images to be sent to the other party.

- **Normal** : Sends images in standard quality and motion speed.
- **Prefer motion quality** : Sends images laying stress on motion speed. Prefer motion quality is effective for moving images.
- **Prefer image quality** : Sends images laying stress on image quality. Prefer image quality is effective if there is little motion.

Making/Receiving Video-phone calls

Making a Video-phone call from the Dialed/Received Call Record

1. On the Stand-by display, / / / ► **Select a history** ►

Information

- See "Using the Submenu of the Received Call Record Screen" (P86) for the submenu.

Making a Video-phone Call from the Phonebook

1. On the Stand-by display , or Search for phonebook entries (P66) ► **Select a party to call** ►
 - When there are multiple registered phone numbers, press on the phonebook list display. Then, the outgoing call phone number selection display is displayed, select the phone number and press [Call].

Information

- To switch the phonebook to display between the phone and UIM, select [Menu] → Select "View handset" / "View UIM".

Adjusting the Volume

1. Press / during a call

Information

- The changed volume is held even after ending the call.

Receiving Video-phone Calls

1. When you receive a call, /

- [Image]: You can receive a call. The substitutive image will be sent to the other party.
- : You can put the call on hold. The holding image will be sent to the other party. If you press [Answer], you can answer the call.

2. to end the call after talking

Information

- When inserting the switch of the Flat-plug Earphone/Microphone set with Switch (option), you can connect a call by earphone regardless of Speakerphone ON/OFF.

[Using the Submenus of the Ringing screen](#)

See “Using the Submenus of the Ringing screen” (P51) of voice calls for the submenus available. Note that “Voice mail” is not displayed for video-phone calls.

Changing Settings for Video-phone Calls



You can set the operation and display for video-phone calls. See “Setting Operation and Display for video-phone Calls” (P94) and “Selecting an Image for video-phone Calls” (P95) for details of the settings.

Sound/ Display

Adjusting the Ring Volume	76
Adjusting the Effect Tone Volume	76
Setting a Ring Tone.....	76
Setting an Effect Tone	77
Setting a Vibrator	78
Activating the Manner Mode	78
Setting Ringing Operations for Incoming Mail	79
Setting Ringing Time.....	80
Setting Display	80
Setting Fonts of Dial Characters	82
Setting Menu Style	83
Setting Backlight	83
Setting color Scheme.....	83

To display the Sound menu

On the Stand-by display,  [Menu] ►



(Sound) or “Sound”

To display the Display menu

On the Standby display,  [Menu] ►



(Display) or “Display”

Adjusting the Ring Volume



Setting item/Setting at purchase → P250

1. From the Sound menu (P75), “Ring volume” ▶
▶ Select from the following adjustment items ▶
After setting, [OK] [Done]

Voice call

You can adjust the ring tone volume for voice calls.

Video-phone

You can adjust the ring tone volume for video-phone calls.

Mail tone

You can adjust the ring tone volume for mail.

MessageR tone

You can adjust the ring tone volume for MessageR.

MessageF tone

You can adjust the ring tone volume for MessageF.

SMS tone

You can adjust the ring tone volume for SMS.

Information

- This notifies an incoming call by the small volume ring tone at beginning and gradually increasing to the volume you set.

Adjusting the Effect Tone Volume



Setting item/Setting at purchase → P250

1. From the Sound menu (P75), “Effect tone volume” ▶
▶ Select from the following adjustment items ▶
After setting, [OK] [Done]

Key tone

You can adjust the key pad sound volume.

Power ON/OFF

You can adjust the tone volume for when turning the phone on/off.

Slide tone

You can adjust the tone volume for when opening or closing the phone.

Feedback tone

You can adjust the tone volume for when a popup appears.

Setting a Ring Tone



You can set the ring tone for voice call, video-phone call or mail. In addition to ring alerts and melodies registered by default, you can set melodies and/or i-motion downloaded from i-mode sites and web pages as incoming ring alerts. You can set the SMF, MFI or MP4 file as a ringtone.

However, the ring tone may not be set depending on the melody or i-motion.

- For the melody registered at purchase, see “List of melody” (P267).

Setting item/Setting at purchase → P251

1. From the Sound menu (P75), “Select ringtone” ▶ Select from the following adjustment items ▶ After setting, [Done]

- Select from the melodies stored in “Melody” or “i-motion” in “Data box” respectively. →P176, P179
- On a folder list screen, press  to switch between “Melody” and “i-motion”.

Voice call

You can select a ring tone for voice calls.

Video-phone

You can select a ring tone for video-phone calls.

Mail tone

You can select a ring tone for mail.

MessageR tone

You can select a ring tone for messageR.

MessageF tone

You can select a ring tone for messageF.

SMS tone

You can select a ring tone for SMS.

Information

- If you have set a ring tone depending on the voice call/ video phone call/ Mail, the ring tone is preferred. The priority order is

as follows:

- 1 Ringtone set in the phone's phonebook → Set the phonebook (P64)
- 2 Ringtone set for a group of the phone's phonebook → Set group (P71)
- 3 Ringtone volume/Video call ring tone/Mail, Message ring tone → Select the ring tone (P76)

Setting an Effect Tone

C ▶  (Sound) ▶ 4

Setting item/Setting at purchase → P251

1. From the Sound menu (P75), “Select effect tone” ▶
Select from the following adjustment items ▶ After setting,  [Done]

Key tone

You can set to emit an effect tone for when you touch the buttons. The effect tone does not sound when setting to “OFF”.

Power ON/OFF

You can set whether to emit an effect tone for when you switch ON/OFF the phone.

Slide tone

You can set whether to emit an effect tone for when you open/close the phone.

Feedback tone

You can set whether to emit an effect tone for when a popup appears.

Setting a Vibrator



Setting item/Setting at purchase → P251

1. From the Sound menu (P75), **Vibration settings** ▶
Select from the following setting items ▶ After setting, [Done]

Incoming call

You can select a vibration pattern for when a voice call or a video-phone call comes in.

- **melody+vibration:** The vibration and the melody for incoming call are activated at the same time.
- **Pattern 1(Vibration only):** This activates the vibration to pattern 1. Regardless of ring tone, the tone for incoming call does not sound.
- **Pattern 2(Vibration only):** This activates the vibration to pattern 2. Regardless of ring tone, the tone for incoming call does not sound.
- **OFF:** The vibration is not activated in phone.

Message

You can set a vibration pattern for when mail, messageR/F or SMS comes in.

- **melody+vibration:** The vibration and the melody for incoming call are activated at the same time.
- **Pattern 1(Vibration only):** This activates the vibration to pattern 1. Regardless of ring tone, the tone for incoming call does not sound.
- **Pattern 2(Vibration only):** This activates the vibration to pattern 2. Regardless of ringtone, the tone for incoming call does not sound.
- **OFF:** The vibration is not activated in phone.

Activating the Manner Mode

You can set whether to mute the ring tone, key pad sound and any other sound from the speaker to avoid annoying people around you. If the manner mode is activated, an incoming call or alarm, etc. is notified with vibrator.

- You can change the activation on setting manner mode to “Original manner mode”. → P79

1. From the Stand-by display, press for 1 or more seconds

- The handset of the phone vibrates displaying (blue/in the Original manner mode) or (pink/in the Manner mode).
- You can cancel it by pressing for 1 or more seconds with the Manner mode activated.

Changing Manner Modes



You can change operations in the Manner mode.

Setting item/Setting at purchase → P251, P252

1. From the Sound menu (P75), “Manner settings” ▶ Select from the following setting items

Manner mode

You can set the Manner mode.

Original manner mode

You can set the operation of the original manner mode if desired. After setting, press [Done].

- **Incoming call sound:** You can set whether to make the ring tone sound when a voice call or video-phone call comes in.
- **Incoming call vib.:** You can set whether to vibrate the phone when a voice call or video-phone call comes in.
- **Message sound:** You can set whether to make the ring tone sound when mail, messageR/F or SMS comes in.
- **Message vibration:** You can set whether to vibrate the phone when mail, messageR/F or SMS comes in.
- **Key tone:** You can set whether to make the key operation sound when you do key operations.

- **Slide tone:** You can set whether to make an effect tone sound when you open or close the phone.
- **Low battery tone:** You can set whether to make a battery alarm tone sound when the battery is flat.

Information

- The following sounds are emitted even when the manner mode is activated.
 - Shutter sound during camera shooting
 - The alert tone to reconnect
 - The alert tone for the quality of calling
- If you try to play the melody, moving image or i-motion on manner mode, the confirmation screen appears and you can select whether to play with sounds.

Setting Ringing Operations for Incoming Mail



You can set whether to make the ring tone sound when mail or SMS comes in. You can also set ringing duration and cycle of rings.

Setting item/Setting at purchase → P252

- ### 1. From the Sound menu (P75), “Mail ring duration” ▶ Select from the following setting items ▶ After setting, [Done]

Sound/Display

Mail ring ON/OFF

You can set whether to make the ring tone sound when mail comes in. If you select "ON", you can set the ringing duration or cycle of ringing.

Mail ring duration

You can set ringing time and number of rings for the ringing tone.

- **Time:** After selecting Sec. section by pressing , you can enter the duration of ringing.
- **Cycle:** After selecting Cycle section by pressing , you can enter the number of cycle.

Setting Ringing Time



You can specify the mute time in seconds before ringing starts when a voice call or video-phone call which is not registered in phonebook comes in. This function is effective as a countermeasure for nuisance calls such as 1 ring phone scam.

Setting item/Setting at purchase → P252

1. From the Sound menu (P75), Select "Set mute seconds" ▶ Enter ring time. ▶  [Done]

Information

- If the voice call or video-phone call which are not registered in phonebook disconnects within the setting ringing time, they are not recorded in received call list.

Setting Display

You can set the display for stand-by display or Incoming/outgoing screen.

You can set the maximum of the image size of 1280 x 1024, the file size of JPEG file to 700K bytes and the file size of GIF file to 500K bytes on the Stand-by display. Depending on the image, some cannot be set properly.

- When the image saved in stand-by mode, making and receiving a call at purchase, please refer to "Pre-installed data" (P264)

Setting the Stand-by Display

You can set wallpapers and clock displays for the Stand-by display.

Wallpaper



Setting item/Setting at purchase → P252

1. From the Display Menu (P75), "Stand-by display" ▶ "Wallpaper" ▶ Select from the following setting items ▶ After setting,  [Done]

Type

- **Image:** You can select an image (P169) saved within the "My picture" in the "Data box".

- **Stand-by theme:** You can select from two types of stand-by theme in the “Select”.

Select

You can select an image or a stand-by theme saved within “My picture” in “Data box”.

- Depending on the setting in the “Image”, the selection item is changed.

Clock/Calendar Display



- The option cannot be set when the “Type” of the “Wallpaper” (P80) is set to “Stand-by theme”.

Setting item/Setting at purchase → P252

1. From the Display menu (P75), “Stand-by display” ▶ “Clock/Calendar display” ▶ Select next setting item ▶ After setting [Finish]

Clock/Calendar

- **Not show:** The clock is not displayed on the Stand-by display.
- **Clock:** A digital clock is displayed on the Stand-by display. You can select the type of the clock in “Clock display setting”.
- **Calendar + Clock Display:** The calendar and the clock is displayed on the Stand-by display. You can select the character color of the clock in the “Clock Character Color”.

- **Dual-clock:** You can display two date/times of two cities on the Stand-by display. You can select second clock of the city* that is shown under the “City Setting”.

Clock Display Setting/Clock Character Color/City Setting

You can select the type of the digital clock, clock character color, or the city.

- The selection item is changed depending on the settings in “Clock/Calendar”.
- You can also select the clock character color when the “Digital Clock 3” is selected in the “Clock Display Setting”.

※: You can also change the city to display in “World Clock” (P191).

Information

- If you press [View], you can confirm the display set.

Using Stand-by Memo



Setting item/Setting at purchase → P252

1. From the Display menu (P75), “Stand-by display” ▶ “Stand-by Memo” ▶ Select next setting item ▶ After setting [Finish]

Screen Display

You can set whether the stand-by memo is displayed on the Stand-by display. The following items cannot be set when you set to “Not display”.

Layout

You can set, for example, the display location, etc. of the stand-by memo.

Font Color

You can set the character color of the stand-by memo.

Character Frame Color

You can set the character frame color of the stand-by memo.

Background color

You can set the background color of the stand-by memo.

Information

- Register the text shown on the Stand-by display as a stand-by memo on the "Stand-by Memo" (P198), you can register the text shown on the Stand-by display as a stand-by memo. If no text is registered, nothing is displayed even when you set the option to "Show".

Setting the Display for Incoming Calls



You can set the image displayed when you receive an incoming call.

Setting item/Setting at purchase → P253

1. From the Display Menu (P75), "Outgoing/Incoming Calls Display" ► "Incoming call"

- Select from the images saved on "My picture" of "Data box". → P169

Setting Display for Outgoing Calls



You can set the image displayed when you make a call.

Setting item/Setting at purchase → P253

1. From the Display Menu ► "Outgoing/Incoming Calls Display" ► "Outgoing call" (P75)

- Select from the images saved on "My picture" of "Data box". → P169

Setting Fonts of Dial Characters



You can set the sizes and colors of the dial fonts displayed when you make a call, etc.

Setting item/Setting at purchase → P253

1. From the Display Menu (P75), "Font" ► Select from the following setting items ► After setting,  [Done]

Dial font size

Select a size of dial fonts.

Dial font color

Select a color of dial fonts.

Setting Menu Style



You can set the style of the Menu Style that appears when pressing [Menu] on the Stand-by display.

Setting item/Setting at purchase → P253

1. From the Display Menu (P75), “Menu style” ▶ “Grid”/“List” ▶ [Done]

Setting Backlight



You can set the time for the Stand-by display to light up.

Setting item/Setting at purchase → P253

1. From the Display Menu (P75), “Backlight” ▶ Select from the following setting items ▶ After setting, [Done]

Light up time

You can set the light up time of the Stand-by display light.

Brightness

You can set the brightness of Stand-by display.

Setting color Scheme



You can set the color tone of the Stand-by display.

Setting item/Setting at purchase → P253

1. From the Display Menu (P75), “Color scheme” ▶ Select the color scheme you want to set ▶ [Done]

Information

- If you press [View], you can view the screen after setting.

Settings

Call/Answer	86
Call Feature	92
Video-Phone	94
Date & Time	96
Network (for overseas use)	97
Changing a Host from i-mode	99
Setting Lock/Security	99
Setting Bilingual	102
Others Settings	103

To display the Settings menu

On the Stand-by display,  [Menu] 
 (Settings) or “Settings”

Call/Answer

Checking Call/Mail History

Displaying Received Call Records



You can view the record of received call.

1. From the Settings menu (P85), “Call/Answer” ▶ “Call/Mail history” ▶ “Received calls”

Icon	Description
	Received voice calls
	Received video-phone calls
	Rejected calls
	Missed calls (Voice calls)
	Missed calls (Video-phone calls)

- / : You can make a call to the other party of the record being selected.

- [Delete]: You can delete the record being selected.

2. Select a call record ▶

- / : You can make a call to the other party in a list.
- [Delete]: You can delete the list of call record.
- : You can view the call record.

Using the Submenu of the Received Calls screen/ Details screen

1. From the Received Calls screen (See left)/Detail screen (See above), [Menu] ▶ Select from the following submenu items

View^{*1}

You can view details of the call record selected.

Add to phonebook^{*2}

Register a selected/displayed phone number in the history newly/additionally to a phonebook. Go to step 2 (P64) in “Adding to phonebook”.

Send mail^{※3}

Create i-mode mail with a destination set to a mail address saved in phonebook. Go to step 3 (P152) of “Composing i-mode mail message”.

Delete

You can delete the call record selected/displayed.

Delete all^{※1}

You can delete all the call records.

Go to list^{※4}

You can return to the screen of received call list (P86).

International call (Japan)^{※5}

You can call to Japan by the telephone number you select. → P233

※1: Not displayed in submenu of detail screen.

※2: Not displayed if information on the caller of the call record selected is stored in the phonebook.

※3: When you compose a mail on the Received Calls screen, the phone number or the mail address that the cursor is placed on at the bottom of the screen will be entered as the destination. When you compose a mail on the Detail screen, the mail address which is saved in the phonebook will be entered as the destination. However, when no mail address is registered, phone number is entered as the destination.

※4: Displayed in submenu of detail screen.

※5: This service is available only during the international roaming service.

Displaying Dialed Call Records

You can view dialed call records.

1. From the Settings menu (P85), “Call/Answer” ▶ “Call/Mail history” ▶ “Dialed calls”

- The Dialed Call Records appears.

Mark	Description
	Dialed voice calls
	Dialed video-phone calls

2. Select a history ▶

- The Detail screen appears.

Information

- See “Using the Submenu of Received Calls Screen”/“Using the Submenu of the Detailed Screen” (P86) for the display operation method and the submenus available from the Dialed call records/Detail screen.
- The operation of the redial display that is shown when is pressed on the Stand-by display is also the same.

Displaying All Call Records

Received and dialed call records are displayed together.

1. From the Settings menu (P85), “Call/Answer” ▶ “Call/Mail history” ▶ “All calls”

- The All calls screen appears.

2. Select a history ▶

- The Detail screen appears.

Information

- See “Using the Submenu of Received Call Records Screen” / “Using the Submenu of the Detailed Screen” (P86) for the display operation method and the submenus available from the All Calls screen / Detail screen.

Displaying received mail history



Display history of received mail.

1. From Settings menu (P85), select “Call/Answer” ▶ “Call/Mail history” ▶ “Recv. mails”

- A history of the received mail appears.

2. Select a history ▶

- Detail screen appears.

Information

- See “Using the Submenu of Received mail history Screen” / “Using the Submenu of the Detailed Screen” (P86) for the display operation method and the submenus available from the All Calls screen / Detail screen. However, “International call (Japan)” is not displayed.

Displaying sent mail history



Display history of sent mail.

1. From Settings menu (P85), select “Call/Answer” ▶ “Call/Mail history” ▶ “Sent mails”

- A history of sent mail appears.

2. Select a history ▶

- Detail screen appears.

Information

- See “Using the Submenu of Received Call Records Screen” / “Using the Submenu of the Detailed Screen” (P86) for the display operation method and the submenus available from the All Calls screen / Detail screen. However, “International call (Japan)” is not displayed.

Displaying all mail history



Display history of all sent/received mail collectively.

1. From Settings menu (P85), select “Call/Answer” ▶ “Call/Mail history” ▶ “All mails”

- A history of all mail appears.

2. Select a history ▶

- Detail screen appears.

Information

- See “Using the Submenu of Received mail history Screen” / “Using the Submenu of the Detailed Screen” (P86) for the display operation method and the submenus available from the All Calls screen / Detail screen. However, “International call (Japan)” is not displayed.

Displaying Call Time



You can confirm call duration for each call type. You can confirm the following items:

- The displayed call duration is a standard. The real of call duration may differ.

1. From the Settings menu (P85), “Call/Answer” ▶ “Call duration”

- Call duration display appears.

Last call

You can confirm the last call duration.

Received calls

You can confirm the received call duration.

Dialed calls

You can confirm the dialed call duration.

All calls

You can confirm the total call duration.

Information

- If the display of call time exceeds “9999999:59:59”, the setting will be reset to “000000:00:00”.

Resetting call duration

1. Select a call duration you want to clear on the Call duration screen ▶ [Reset] ▶ Enter your terminal security code ▶ ▶ “Yes”

- To clear all the call durations ▶ [Menu] ▶ “Reset all”

Setting Earphone/Microphone Auto Answer



You can set how to answer an incoming call with the Flat-plug Earphone/Microphone Set with Switch (option) connected.

Setting item/Setting at purchase → P253

1. From the Settings menu (P85), “Call/Answer” ▶ “Auto answer” ▶ Select from the following setting items ▶ After setting, [Done]

Auto answering

You can set the earphone/microphone auto answer to ON/OFF.

Delayed time (SEC) (0-120)

You can set the time between receiving call and answering a call automatically.

Information

- You can make a call by pressing the switch during showing a phone number or selecting a phonebook.
- While receiving a call, you can connect it by pressing the switch.
- During talking over a call, you can end the call by pressing the switch for 1 or more seconds.
- If you press the switch for 1 or more seconds while receiving a call, the call will be rejected.

Setting to Reject/Accept Incoming Calls



You can set whether to reject incoming calls.

Setting item/Setting at purchase → P254

1. From the Settings menu (P85), “Call/Answer” ▶ “Reject/Accept call” ▶ Enter your terminal security code ▶

- The Reject/Accept call display appears.

2. Select from the following setting items

Accept

You can set whether to accept all incoming calls.

Reject on list

You can reject the incoming call from the specific parties. You can set the rejecting action and the party's phone number to reject a call by pressing [List] (See below).

Reject all calls

- **Silent** : You can disable the ringing tone for all incoming calls.
- **Disconnect call** : You can reject all incoming calls.

Memory reject call

You can reject calls from parties not registered in phonebook and those with no caller IDs.

Information

- Even when rejecting a call by “Reject on list”, “Reject all calls”, or “Memory reject call”, the record will be remained.

Setting Reject call List

1. From the Reject/Accept call display (See left), Select “Reject on list” ▶ [List]

- The Reject on list will be displayed.

Mark	Description
	The type of reject call is set to “Silent”.
	The type of reject call is set to “Disconnect call”.

- [Menu]: You can edit/delete the list set.

2. [Add] ▶ Select from the following setting items ▶ After setting, [Done]

Reject types

- **Silent** : Disables the ring tone when receiving the call from the other party set to “Reject number”.

- **Disconnect call** : Rejects incoming calls when receiving the call from the other party set to "Reject number".

Reject number

Enter the phone number of a caller you want to reject. You can select a phone number from the phonebook by pressing  [Search][※].

※: If you use  [Menu] → Edit from "Reject on list", you cannot use this function.

Setting an Answer Mode

 ►  (Settings) ►  

You can set whether to answer a voice call by pressing a button other than .

Setting item/Setting at purchase → P254

1. From the Settings menu (P85), "Call/Answer" ► "Answer mode" ► Select from the following setting items

Slide answer

You can answer a call by opening the phone. If the phone is already open, you can answer a call by pressing .

Press any key

You can answer a call by pressing any key except for , , , .

Press send key

You can answer a call by pressing  only.

Information

- This setting is not available for video phone call.

Call Feature

Setting the Reconnect Control



You can set whether to make an alarm sound to inform you when you are reconnected immediately after disconnected owing to bad radio wave conditions.

Setting item/Setting at purchase → P254

1. From the Settings menu (P85), “Call feature” ▶ “Reconnect alarm” ▶ Select from the following setting items

High alarm

Set high alarm sounds.

Low alarm

Set Low alarm sounds.

No alarm

No sound.

Information

- The time to reconnect the network may differ depending on the status of phone or radio (the maximum 10 seconds).
- The duration to reconnect the network can be chargeable.
- Depending on the status of phone or radio, the alarm may not sound, and the call may be disconnected.

Setting Quality Alarm



You can set whether to make an alarm sound to inform you when a call is liable to be disconnected midway because of bad radio wave conditions.

Setting item/Setting at purchase → P254

1. From the Settings menu (P85), “Call feature” ▶ “Quality alarm” ▶ Select from the following setting items

High alarm

Set high alarm sounds.

Low alarm

Set low alarm sounds.

No alarm

No sounds.

Setting Minute Reminder



You can check the call duration by beep sound every minute during a voice call (Not support this function for Video-phone call).

Setting item/Setting at purchase → P254

1. From the Settings menu (P85), “Call feature” ▶ “Minute reminder” ▶ “ON”/“OFF”

Information

- This setting is not available with a video-phone call.

Setting Prefix Dial



You can store prefix numbers such as international access code or “184 / 186” and add it to the beginning of the phone number to dial.

Setting item/Setting at purchase → P254

1. From the Settings menu (P85), “Call feature” ▶ “Prefix dial”


- The Prefix Dial screen appears.

2. Select a PREFIX field to enter ▶ Enter a number ▶

[Done]

Setting International Dial

Setting Auto assist



You can set whether to automatically replace “+” at the beginning of a phone number with an international access code such as “009130010” for making an international call.

Setting item/Setting at purchase → P254

1. From the Settings menu (P85), “Call feature” ▶ “International dial” ▶ “Auto assist setting” ▶ “Auto”/“OFF”

Setting IDD prefix



You can set the international access code to be added to the beginning of a phone number for making an international call.

Setting item/Setting at purchase → P254

1. From the Settings menu (P85), “Call feature” ▶ “International dial” ▶ “IDD prefix setting” ▶ Select from the following setting items ▶ After setting, [Done]

IDD prefix name

Enter the name of an international call service.

IDD prefix code

Enter an international access code.

Setting Close setting



You can select the operation when the phone is closed during a call.

Setting item/Setting at purchase → P254

1. From the Settings menu (P85), “Call feature” ▶ “Close setting” ▶ Select from the following setting items

End the call

The call is disconnected.

Network (for overseas use)

Selecting the Network Connection Mode

Making settings for Network search



You can select a network setting method in case destination networks (Communication carriers) change for overseas use, etc.

Setting item/Setting at purchase → P255

1. From the Settings menu (P85), “Network” ▶ “Network selection” ▶ Select from the following setting items

Auto

Automatically searches for the network for setting.

Manual

The network search display appears, allowing you to select a network from the list displayed after search.

Information

- It may take a few minutes to find the network.
- If you set “Auto”, you can search the network automatically in the following situation.
 - When you switch on
 - Out of the service area
- If you stop searching the network by “Manual”, the setting will be changed to “Auto”.

Setting the Network Mode



You can set a type of network to search for when networks are searched according to “Network selection”.

Setting item/Setting at purchase → P255

1. From the Settings menu (P85), “Network” ▶ “Network mode” ▶ Select from the following setting items

Auto

Searches all the networks connectable.

WCDMA only

Searches only networks supporting 3G.

GSM only

Searches only networks supporting GSM/GPRS.

Information

- You cannot exchange the data through packet service under GSM network.
- When using the handset in Japan or in the service area of 3G network, we recommend you change the setting of the “Network mode” to “WCDMA only” to save battery power.

Registering a Network of Preferred list



Setting Networks

When you search the network automatically, you can add a preferable network (communication carrier) to connect to.

Setting item/Setting at purchase → P255

1. From the Settings menu (P85), “Network” ▶ “Preferred lists”

- Networks registered in UIM are listed downward from the one with the highest priority.
- [Delete]: You can delete the network selected.

2. [Menu] ▶ Select from the following setting items

Add new

- Search network

You can select from the network list stored in the phone for adding.

- Enter new network

You can enter the country code (MCC) and the network code (MNC) for adding. After setting, press

[Done].

Delete

You can delete the selected network.

Move up[※]

You can move the selected network upward. The network moved upward is more preferred.

Move down[※]

You can move the selected network downward. The network moved downward is less preferred.

※: If you register multiple networks, you can use this menu.

Information

- If the network is not registered, [Menu], [Delete] of soft key area on preferred list to register will not be displayed. To add new network, press [Add], select and register.
- The registered data is saved in UIM.

Displaying the Network Name



You can set whether to display the name of the network currently set on the Stand-by display.

Setting item/Setting at purchase → P255

1. From the Settings menu (P85), “Network” ▶ “Network name display” ▶ “Display on”/“Display off”

Changing a Host from i-mode

Setting / Changing the Host



※ Normally, you do not need to change the setting.

You can set a host to use services of various providers other than i-mode. If the host is changed, i-mode becomes unavailable.

Setting item/Setting at purchase → P255

1. From the Settings menu (P85), “Host selection” ▶ From the Host selection screen, [Add] ▶ Enter your terminal security code ▶ ▶ Set the following items ▶ After setting, [Done]

- The host set is displayed on the Host selection screen with attached to it.

Host name

Enter the name displayed on the Host selection screen.

Host address

Enter the address of the host.

Access point

Enter the Access point (URL, etc.).

Information

- To switch the host back to “i-Mode” or to switch to another host, select “i-Mode”/other hosts and press on the Host selection screen.
- If you press [Menu] on the Host selection screen, you can edit / delete / display the host set. Note that you cannot edit / delete pre-installed “i-Mode”.
- In Access point menu, you should enter IP address in PDP type.

Setting Lock/Security

Setting All Lock



You can set whether to lock requiring to enter the terminal security code to operate function. During All Lock, “All lock” is displayed on the Stand-by display.

Setting item/Setting at purchase → P255

1. From the Settings menu (P85), “Lock/Security” ▶ “All lock” ▶ Select from the following setting items

Power on

You can set whether to lock the phone when you turn of the power. You need to enter your terminal security code to set it.

Immediate

Sets All lock immediately. You need to enter your terminal security code to set it.

none

You can release All lock. You need to enter your terminal security code to release it.

Information

- While "All lock" is set, the received mail or message R/F is only saved in i-mode center. When "All lock" is released, the icon that shows there is a mail or a message R/F in the i-mode center is displayed.
- While "All lock" is set, even though you receive an SMS, it is only saved, and it is received after you release "All lock".
- While "All lock" is set, you cannot perform packet transmission connecting a personal computer.
- While "All lock" is set, answering operation is not performed even though you receive a call, and only busy tone is played. It is displayed as a missed call after you release "All lock".
- While "All lock" is set, the alarm tone does not sound, and only the icon appears. The alarm tone sounds after you release "All lock".

Releasing All Lock

1. Press one of  ~  ► Enter your terminal security code ► 

- Pressing  [Emergency Call] key on the "lock" screen: Emergency calls (110/118/119)[※] can be made.
- ※ Display may differ depending on the used UIM.

Information

- If you enter a wrong terminal security code 5 times in a row, the handset turns off automatically. When you turn on the power again, you can enter the terminal security code.

Setting Auto Key Lock



This function prevents the button operation when a specified time elapses after the phone is closed.

Setting item/Setting at purchase → P256

1. From the Settings menu (P85) ► "Auto key lock setting" ► Select the time until the phone keys are automatically locked ► 

- If you do not want to use auto key lock, set the option to "OFF".
- When a specified time elapses after the phone is closed,  is displayed in the soft key area and each button except for   is locked.

Information

- To enable auto key lock regardless of the specified time period, you can press for 1 or more second On the Stand-by display (with phone closed).
- The auto key lock is not enabled when the camera shooting screen is displayed or you are shooting even when the phone is closed.
- You can receive an incoming call during the auto key lock.

Releasing Auto Key Lock

You can release the auto key lock by opening phone, and also release it when the phone is closed.

-  or  **Release lock** ▶ 

Setting PIN Code Request




You can set to enter PIN1 code every time you turn on the power to the phone.

Setting item/Setting at purchase → P256

- From the Settings menu (P85), “Lock/Security” ▶ “PIN code request” ▶ “ON”/“OFF” ▶ Enter PIN1 code ▶ 

Changing Your Password

Changing the PIN1 code / PIN2 code



You can change the PIN1 code / PIN2 code. To change the PIN1 code, you need to set “PIN code request” to “ON” beforehand. The code is set to “0000” at purchase, but you can change to any number as desired.

- In case you purchase a new phone and start using it inserting the UIM you have been using, use the PIN1 code / PIN2 code you have set.
- From the Settings menu (P85), “Lock/Security” ▶ “Change password” ▶ “PIN1 code”/“PIN2 code”

Settings

2. Enter the current PIN1 code/PIN2 code ▶ 
3. Enter a new PIN1 code/PIN2 code ▶ 
4. Enter the same code that you did in Step 3 again ▶ 

Information

- If you enter a wrong PIN code over 3 times, the PIN code will be locked automatically. If you unlock the PIN code, see "Releasing PIN lock code" (P107).



Setting item/Setting at purchase



Setting item/Setting at purchase

Information

- This setting is registered in phone and UIM which is currently inserted. If you insert other UIM which registered other settings, the settings of this UIM will be preferred.

Others Settings

Checking the Memory Status



You can check the usage status and available space of the memories of the handset of the phone.

1. From the Settings menu (P85), “Others” ▶ “Memory status” ▶ Select from the following items

Data box

You can check the empty or the reserved capacity (Approximate) of the Data box for data such as My picture, i-motion or Melody are stored.

Personal info.

You can check the empty or the reserved capacity (Approximate) of the memory for Personal info. for data such as Phonebook, Schedule, Memo or Date Counter.

UIM memory

You can check the empty or the reserved capacity (Approximate) of the memory for data such as “Phonebook” or “SMS”.

Resetting the Settings

Clearing the Memory



You can clear all the data recorded in the phone.

1. From the Settings menu (P85), “Others” ▶ “Reset settings” ▶ “Clear memory” ▶ Select from the following items

- You need to enter your terminal security code for deleting.

Data box

All data saved in the data box (except for the pre-installed data and i-appli) is deleted.

Personal info.

Clears all the personal data saved in the phone such as phonebooks, schedule, call history and so on.

Initializing the Default Settings



You can reset to all settings at purchase except for “i-mode setting” and “Mail setting”.

1. From the Settings menu (P85), “Others” ▶ “Reset settings” ▶ Default settings ▶ “Yes” ▶ Enter the terminal security code ▶ Press

Information

- When the date and time are reset, display or play of i-motion and files with valid period and/or expiration date set may be disabled.

[Changing the Settings for the SMS Center](#)



※ Normally, you do not need to change the settings.

You can change the SMS centers to use.

Setting item/Setting at purchase → P256

1. From the Settings menu (P85), “Others” ▶ “SMS center” ▶ “Select from the following setting items” ▶ After setting, [Done]

SMSC

– : You can use the SMS center.

– Others : You can use another company's SMS center.

Address

If “SMSC” is set to “Others”, enter the address of the SMS center.

[Resetting the holiday](#)



You can restore the holiday setting set in Scheduler (P194) in phone.

1. From the Settings menu (P85), “Others” ▶ “Reset holiday” ▶ “Yes”

i-mode

i-mode Menu	122
What is i-mode?	122
Displaying the iMenu display.....	122
Displaying Sites from Bookmark	123
Displaying Screen memo	124
Displaying Last URL.....	125
Displaying Internet Web Pages	125
Displaying MessageR/F	126
Checking Whether Center Holds MessageR/F	129
Setting Functions of i-mode	129
Displaying Sites.....	132
How to See/Use Sites	134
Using My Menu	137
Changing i-mode Password	138

To display the i-mode menu

On the Stand-by display,  [Menu] 
 (i-mode) or "i-mode"

i-mode Menu

The i-mode menu is the basic display for viewing various sites and Internet web pages. You can use each function of i-mode from the i-mode menu.

Menu item	Description
 Menu	Connects to the i-mode Center
Bookmark	Displays your favorite sites and Internet web pages.
Screen memo	Displays pages of sites, etc. saved in the phone.
Last URL	Displays the most recently accessed site or Internet web page.
Go to location	Enter URL to connect to the internet.
Message	Displays a list of the received MessageR/F.
Check new message	You can check whether the i-mode Center holds mail and MessageR/F.
i-mode setting	You can set the functions related to i-mode.

What is i-mode?

i-mode is the online service that makes use of the display of the i-mode phone to enable you to use convenient information from i-mode sites (programs) and homepages supporting i-mode and to exchange mail easily.

- Refer to “Mobile Phone User’s Guide [i-mode]” for details.
- Not all the services described in “Mobile Phone User’s Guide [i-mode]” are supported. Check the description of the models supporting each service with “Mobile Phone User’s Guide [i-mode]”.

Displaying the iMenu display



You can access each i-mode site from iMenu.

1. From the i-mode menu (P121), “iMenu”

- Refer to “Mobile Phone User’s Guide [i-mode]” for items displayed on the iMenu display.
- See “Displaying Sites” (P132) for the subsequent operations.

Displaying Sites from Bookmark



You can directly access your favorite sites from Bookmark.

- For the registration method, see “Using the Submenus of the Site Screen” (P132).

1. From the i-mode menu (P121), “Bookmark”

2. Select a bookmark ▶

- Connected to the site.

Using the Submenus of the Bookmark List Screen

1. From the Bookmark List screen (See above), [Menu] ▶ Select from the following submenu items

Connect

You can connect to the selected Bookmark site.

Edit bookmark

You can edit the title and URL of the selected Bookmark. After editing, press [Done].

Delete

You can delete the selected Bookmark.

Delete selected

You can select and delete multiple Bookmarks. After selecting, [Menu] → Select “Delete”

Delete all

You can delete all the registered Bookmarks. To delete all, enter terminal security code → [OK].

URL

You can display the URL of the selected Bookmark.

Copy URL

You can copy the URL of the selected Bookmark. For the copy, see “Copying/Cutting/Pasting” (P225).

Compose message

You can paste the URL of the selected Bookmark to the text of i-mode mail and send it. Go to step 2 of “Composing i-mode mail” (P152).

Send

Send a selected bookmark via infrared communication.*

Send all

Send all bookmarks via infrared communication.*

※: For infrared communication, see “Using infrared communication” (P186).

Displaying Screen memo



You can display the web pages saved without connecting to i-mode.

- For the registration method for the site screen, see “Using the submenus for the Site screen” (P132).

1. From the i-mode menu (P121), “Screen memo”

Icon	Description
	Unprotected Screen memo
	Protected Screen memo

2. Select a screen memo ▶

- The Screen Memo List screen appears.

Using the Submenus of the Screen Memo Screen

1. On the Screen Memo List screen (left figure), [Menu] ▶ Select from the following submenu items

View

You can display the selected screen memo.

Edit title

You can edit the title of the selected screen memo.

Delete

You can delete the selected screen memo.

Delete selected

You can select and delete multiple screen memos. After selecting, [Menu]→Select “Delete”.

Delete all

You can delete all the screen memos. To delete all, enter terminal security code → [OK].

URL

You can display the URL of the selected screen memo.

Protect ON/OFF

You can give or cancel protection for the selected screen memo. You cannot delete protected screen memos.

Using the Submenus of the Screen Memo Screen

1. On the Screen Memo List screen (P124),  [Menu] ► Select from the following submenu items

Save graphics^{※1}

You can select and save an image contained in a screen memo. You can confirm the saved image by "My picture" of "Data box"→"i-mode" folder. →P169

Show properties

- **URL** : You can display the URL of the displayed screen memo.
- **Page properties** : You can check the title and URL of the displayed screen memo.
- **Certificates^{※2}** : You can display the certificate used by the displayed screen memo.

Retry^{※3}

A GIF animation is played back from the beginning.

Edit title

You can edit the title of the displayed screen memo.

Delete

You can delete the displayed screen memos.

Protect ON/OFF

You can activate or cancel protection for the displayed the page. You cannot delete protected saved pages.

- ※1: This menu is not selected in case the selected screen memo does not include an image.

※2: This menu is not selected in case the certificate is not used for the displayed screen memo.

※3: This menu is not selected in case the selected screen memo does not include of GIF animation.

Displaying Last URL



When you exit i-mode, the URL of the page displayed last is stored as "Last URL". Using "Last URL", you can connect to the site or Internet web page you visited last time.

1. From the i-mode menu (P121), "Last URL" ►  [Done]

Information

- If you press  in screen of URL, you can edit the latest URL address.

Displaying Internet Web Pages



You can display web pages supporting i-mode and directly access sites from the history of the sites you visited by entering their URLs.

1. From the i-mode menu (P121), "Go to location" ► Select from the following items

Input address

You can display Internet web pages supporting i-mode by entering URLs. After entering, press  [Done] to access.

URL history

You can directly access sites by selecting URLs you visited from the URL history.

Information

- You can enter URL up to 256 half-pitch characters.
- You can view the list up to 50 address in URL history.
- Depending on the type of the accessed Internet site, the page may not be displayed correctly.
- Web pages other than Internet web pages supporting i-mode may not be displayed correctly.

Using the Submenus of the URL Screen

1. From URL history screen, press  [Menu] ►
Select from the following submenu items

Connect

You can connect the site in URL history.

Edit URL

You can connect URL in history after editing URL address.

Delete

You can delete the history of URL.

Delete all

You can delete the history of all registered URL. To delete all, enter terminal security code →  [OK].

Compose message

You can compose i-mode mail with attaching URL to the text. Go to step 2 on page 152 of “Composing i-mode mail”.

Displaying MessageR/F



You can display received MessagesR/F.

- MessageR:
Your required information is delivered automatically once you apply for the message service on the site providing the service.
- MessageF:
Messages are delivered free of charge by performing the Received settings in the option settings. Refer to “Mobile Phone User’s Guide [i-mode]” for how to set it up.
※: If you subscribed to the service after October 1, 2004, the setting at purchase is “Receive”.

1. From the i-mode menu (P121), “Message” ▶ “MessageR”/“MessageF”

- : You can check the previous or next page for multiple pages.

2. Select a MessageR/F to display ▶

- : Displays the history of messageR/F.
- : You can scroll the screen.

Information

- You can save up to 100 MessageR and up to 50 MessageF. Depending on the size of messages, the number of savable messages may be smaller.
- If a message is attached to the received MessageR/F, the melody will be played automatically when you display the message.

Icons on the MessageR/F List Screen and the Display MessageR/F Screen

Icon	Description
	Unread MessageR/F
	Read MessageR/F
	Protected MessageR/F
	MessageR/F with a file attached or pasted
	Subject
	Received date and time
	A melody is pasted.
	A melody is attached.
	An image is attached.
	A file with the UIM operation restriction function set up is attached.

Using the Submenus of the MessageR/F List

Screen

Setting item/Setting at purchase → P260

1. From the MessageR/F List (P127),  [Menu] ►
Select from the following submenu items

Delete

You can delete the selected MessageR/F.

Delete selected

You can select and delete multiple MessagesR/F. After selecting,  [Menu] → Select “Delete”.

Delete all

You can delete all the MessagesR/F. To delete all, enter terminal security code →  [OK].

Protect ON/OFF

You can give or cancel protection for the selected MessageR/F. You cannot delete protected MessagesR/F.

Sort

You can sort MessagesR/F displayed on the List screen.

Filter

You can change types of the MessageR/F displayed on the List screen.

Using the Submenus of the Display MessageR/F

Screen

1. From the Display MessageR/F screen (P127),  [Menu] ► Select from the following submenu items

Delete

You can delete the displayed MessageR/F.

Protect ON/OFF

You can give or cancel protection for the displayed MessageR/F. You cannot delete protected MessagesR/F.

Add to phonebook^{※1}

You can add phone number or mail address displayed on the MessageR/F to phonebook. Go to step 2 on page 64 of “Adding to Phonebook”.

Save attach file^{※2}

You can save the melody () or image () attached to the MessageR/F. You can view the saved melody or the image in “Melody”/“My picture” of “Data box” → “i-mode” folder. → P169, P179

※1: Activate this menu after selecting the phone number or mail address that can be registered. If no item exists, you cannot activate this function.

※2: You can activate this function after selecting the file saved in. If the file to save does not exist, you cannot use this file.

Automatically Receiving MessageR/F

If you are in the service area, MessageR/F are sent automatically.

1. Receive a MessageR or MessageF

-  (White) or  (White) is displayed.

2. The reception results are displayed

- To confirm the received MessageR/F immediately, select "MessageR"/"MessageF" and press .
- : Returns to previous screen.

Checking Whether Center Holds MessageR/F



You can check whether the i-mode Center holds any i-mode mail and/or MessageR/F that arrived while the phone was out of the service area or turned off.

1. From the Stand-by screen, press [Mail] for 2 or more seconds

- The Check Result screen appears. To read the received MessageR/F immediately, select "MessageR"/"MessageF" and press .

Information

- If the i-mode Center holds i-mode mail and/or a MessageR/F, an icon (P32) is displayed. Note that the icon may not be displayed if i-mode mail or a MessageR/F arrived at the i-mode Center while the phone was turned off.

Setting Functions of i-mode

You can set functions of i-mode and MessageR/F.

Home



You can set the URL of a web page displayed when “Home” is selected and whether to enable/disable “Home” (P133).

Setting item/Setting at purchase → P240

1. From the i-mode menu (P121), “i-mode setting” ▶ “Home”
2. “Enable” or “Disable”
3. Select the URL field ▶ ▶ Enter a URL ▶
 - If “ [Done] Disable” is selected, you cannot enter a URL.
4. [Done]

View



You can set functions related to displaying sites and screen memos.

Setting item/Setting at purchase → P240, P241

1. From the i-mode menu (P121), “i-mode setting” ▶ “View” ▶ Select from the following setting items ▶ After setting, [Done]

Character size

You can change the character size for text of sites, screen memos pages and MessagesR/F.

Image display

You can set whether to display images contained in sites, or screen memos.*

Scroll

You can set the number of lines scrolled when pressing on a display displaying text of sites, screen memos or MessagesR/F.

Message list disp.

You can set how to display MessageR/F list (the number of lines).

※: Images of MessageR/F are displayed regardless of this setting.

Certificates



You can set a certificate used for displaying SSL-enabled sites.

1. From the i-mode menu (P121), “i-mode setting” ▶ “Certificates” ▶ [Menu] ▶ Select from the following setting items

Certificate info

You can view the selected certificate.

Valid/Invalid

You can set whether to validate or invalidate the selected certificate.

- You can check the status of a certificate by the following symbols. : Valid : Invalid

Information

- If “Valid/Invalid” is set to “Invalid”, you cannot display the sites with that certificate.

Others



You can set i-mode connection timeout and the type of message to check. You can also check the i-mode settings.

Setting item/Setting at purchase → P241

1. From i-mode menu (P121), “i-mode setting” ▶ “Others” ▶ Select from the following setting items

Connection timeout

It may take time to download from some sites. You can set the time to wait before canceling downloading. After setting, press [Done].

i-motion auto play

You can set whether to play back an i-motion movie automatically when you download a standard (normal) type of i-motion movie from a site. After setting, press [Done].

Check new message

You can set the contents to check by performing “Check new message” from among i-mode mail, MessageR or Message F. After setting, press [Done].

Check settings

You can check the individual “i-mode setting”.

Reset settings

You can reset each of the “i-mode setting” to their defaults. To reset the settings, enter terminal security code → [OK].

Reset data

You can delete all data related to i-mode (Bookmark, Screen memo, URL history) except for MessageR/F. To reset the data, enter terminal security code → [OK].

Information

- Even when you have set “Connection Timeout” to “Unlimited”, you may be disconnected depending on radio wave conditions.

Displaying Sites

You can connect to sites by easy key operation, and use various types of services offered by IPs (Information Service Providers). (For some sites, you may be required to apply to the IPs separately.)

1. From the i-mode menu (P121), “iMenu”

-  blinks during i-mode communication.

2. Select an item (link) ►

- : You can scroll the menu.
- : You can end i-mode.

Information

- If there is a number in front of the item showing the link, you can connect to that link directly by pressing the same number on the keypad. Note that some sites cannot be connected.
- Depending on the site, images may not be displayed.

- Depending on the site connected, the confirmation screen may appear stating that mobile phone information is sent. Your mobile phone information (the model and the serial number of your mobile phone) is sent to the IP (Information Service Provider) over the Internet, so could be perceived by third parties. The phone number, address or age are not sent to IP (Information Service provider).

Using the Submenus of the Site Screen

1. From the Site screen (See left), [Menu] ► Select from the following submenu items

Add bookmark

You can add the displayed URL of the Site to Bookmark. The bookmark screen is displayed, and you can register the site by pressing  [Done]. You can access directly to the site from the registered bookmark. → P123

Add screen memo

You can save a displayed web page as a screen memo. You can display saved screen memos without connecting to i-mode. → P124

Save graphics^{※1}

You can select and save an image contained in a web page. → P136

Show properties

- **URL** : You can check the URL of the displayed site.
- **Page properties** : You can check information on the displayed web page.
- **Certificates**^{**2} : You can check the certificate used in the displayed site.

Bookmark list

You can view a list of bookmarks registered by "Add bookmark". If you select a bookmark, you can directly access the site.

Go to location

- **Input address** : You can access web pages supporting i-mode by entering URL. After entering it, press [OK] [Done] to connect to the site.
- **URL history** : You can select the URL history of a displayed site to directly access the web page.

Screen memo list

You can view a list of pages saved as "Screen Memo". You can display the saved page by selecting it.

Menu

You can bring up the iMenu display.

Home

You can display the web page registered as "Home" (P130).

Reload

You can reload data of a site. The contents of the site will change to the latest information each time you reload if the site has been updated.

Compose message

You can send the URL of site being displayed or the URL for link with them attaching to the message text. Go to step 2 on page 152 of "Composing message".

Change char. code

When characters are not displayed correctly, you can convert them to the correct ones.

Add to phonebook^{**3}

You can add the phone number and mail address displayed on the web page to the phonebook. Go to step 2 on page 64 of "Adding to phonebook".

Retry^{**4}

You can play back a GIF animation from the beginning.

- ※1: You cannot activate this menu in case the image that can be saved is not included in a site or "Image" is set not to display. (P130)
- ※2: If no certificate is used in the site, you cannot use this menu.
- ※3: Activate this menu after selecting the phone number or mail address to register. Otherwise, you cannot activate this menu.
- ※4: You cannot activate this menu when GIF animation is not included in displayed site.

Information

- Some sites may not be saved as bookmarks.
- When characters are not displayed correctly even after “Change char. code”, repeat the operation. However, even if you repeat this operation, the correct characters may not come up. The original characters are displayed if you repeat the operation 4 times.
- If you perform “Change char. code” when the correct characters are displayed, wrong characters may come up instead.

SSL Pages


SSL pages use data encryption for data transmission to prevent hacking and source-file overwriting so that you can more safely exchange personal information.

- If you try to display an SSL-enabled page, the SSL communication starting message appears. When an SSL page is displayed,  appears.
- When moving from an SSL page to an ordinary page, the confirmation display appears. After “Yes” is selected, a regular page is displayed and  disappears.

How to See/Use Sites

Entering/Selecting Information on Sites

When you use a site, you may enter characters (text box) or select an item from multiple options (radio button, checkbox, pull down menu).

Display Example	Name	Description
 : Unselected  : Selected	Radio button	Used for item selection. You can select only 1 item.
 : Unselected  : Selected	Checkbox	Used for item selection. You can select multiple items.
ID  Password 	Text box	You can enter characters.
	Pull down menu	Used for item selection. If you select a pull down menu, a list of selectable items is displayed.

[Returning to Obtained Previous Page/Going to Obtained Next Page](#)

The phone stores the last few screens displayed.

1. To display the previous page,

To display the next page, 

[Operations from Highlighted Information](#)

You can easily make calls, send mails, and display Internet web pages using highlighted information (phone numbers, mail addresses, URLs, and so on) displayed on sites and in mail and MessageR/F.

Phone To function/AV Phone To function

You can make a call by selecting displayed information such as a phone number.

- You may not be able to use the Phone To/AV Phone To function depending on the site.

1. Select information such as a phone number

2. “Voice call”/“Video-phone call”

- You can make a call after setting the Caller ID notification according to the screen.

[Information](#)

- You can add phone number information displayed on a web page to the phonebook using the submenu of the site screen.

Mail To function

You can send mails by selecting displayed information such as a mail address.

- You may not be able to use the Mail To function depending on the site.

1. Select information such as a mail address

- Go to step 3 of “Composing i-mode mail” (P152).

[Information](#)

- You can add mail address information displayed on a web page to the phonebook using the submenu of the site screen.

Web To function

You can access a web page by selecting displayed information such as a URL.

- You may not be able to use the Web To function depending on the site.

1. Select information such as URL Press

- If the confirmation screen to connect appears, press  [Yes].

i-appli To function

You can start i-appli by selecting the displayed URL (link).

1. Select i-appli information ▶ ▶ [Yes]

Information

- If "i-appli To" (P164) is set to "OFF", you cannot start i-appli by this operation.

Downloading Images from Sites

You can set images saved from the displayed web page or screen memos. You can check the saved images in "My picture" of "Data box" → "i-mode" folder. → P169

1. Displaying Site / Saved Page screen ▶ [Menu] ▶ "Save graphics" ▶ ▶ Select an image ▶ ▶ "Yes"

Information

- Some images may not be saved.
- You cannot select "Save graphics" if the image that can be saved is not included or "Image" (P130) is set not to be saved.

Downloading i-melody from Sites

You can download a melody from a site and set it. A saved melody can be checked by "Melody" of "Data box" → "i-mode" folder (P179).

1. Display a site that supports downloading of melodies ▶ Select a melody ▶

- After the download is completed, the confirmation screen appears.

2. Video content menu

- "Play": You can play the downloaded melody.
- "File Protection": You can view the information of i-motion downloaded from network.
- "Back": You can return to the site without saving the melody.

Information

- Depending on the site, you may not be able to download melodies.
- Some downloaded melodies may not be played back successfully.

Obtaining i-motion Movies from Sites

The i-motion movie is a moving image file containing images and sound. Acquired i-motion can be checked by “i-motion” of “Data box” → “i-mode” folder (P176).

- See “Mobile Phone User’s Guide [i-mode]” for details.

1. Select an i-motion movie on a site that supports downloading of i-motion movies ▶

- The download of i-motion starts.
- For i-motion that can be played back during downloading, it is played back during downloading.

2. After the completion of download ▶ “Save”

- “Play”: You can play i-motion downloaded from network.
- “File property”: You can view the information of i-motion downloaded from network.
- “Back”: You can return to the site without saving i-motion.

Information

- You can change the playback methods for while downloading i-motion movies. → P131
- Some downloaded i-motion movies might not be played back correctly.
- You cannot download i-motion movies of the streaming type and the ASF format.

Using My Menu

If you register frequently-used sites in My Menu, you can access them easily.

Registering Sites in My Menu

1. Bring up the page of the site to be registered ▶ Select “Register My Menu” ▶

2. Select the i-mode password text box ▶ ▶ Enter the i-mode password ▶ ▶ “Select”

- For i-mode password, see “Changing i-mode Password”. (P138)

Information

- Some sites may not be registered in My Menu.
- If you subscribe to Menu/Search in a pay site, it will be registered in My Menu automatically.

Displaying Sites from My Menu

1. From the Stand-by display, [i-mode] ▶ “iMenu” ▶ “My Menu” ▶ Select a site to access ▶

Changing i-mode Password

The “i-mode password” (4 digits) is required to subscribe to and unsubscribe from message services and i-mode pay sites, and to perform i-mode mail settings. At purchase, this password is set to “0000” (4 zeros), so you need to change it to your own i-mode password. Be sure not to let others know your i-mode password.

1. On the Stand-by display,  [i-mode] ▶ “iMenu” ▶ “English” ▶ “Options” ▶ “Change i-mode Password”

2. Select the “Current Password” text box  ▶ Enter your i-mode password (4 digits) 

- At purchase, the setting is “0000”, so enter “0000” for the first time.

3. Select the “New Password” text box  ▶ Enter a new i-mode password (4 digits) 

4. Select the “New Password (Confirmation)” text box  ▶ Enter a new i-mode password (4 digits)  ▶ “Select”

- Enter the same number as you entered in step 3.

Information

- If you forget your i-mode password, you can have it reset to “0000” at a handling counter such as a shop. You will be required to show your official identification (driver’s license, etc.).

Mail Menu

On the mail menu, the mail functions offered by the phone are displayed.

Menu item	Description
Inbox	You can check the records and contents of received i-mode mails and SMS messages.
Outbox	You can check the records and contents of sent i-mode mails and SMS messages.
Unsent message	You can check the contents of temporarily saved i-mode mails and SMS messages.
Compose mail	You can bring up the display to compose i-mode mails and SMS messages.
Check new message	You can receive i-mode mails held at the i-mode Center.
Receive option	You can check the subjects of i-mode mail held at the i-mode Center and select mail to receive, or delete mail at the Center before receiving it.
Check new SMS	You can receive SMS messages by checking the SMS Center.
Mail setting	You can change the settings of each mail function of the phone.

i-mode Mail

The i-mode phone has the mail functions for exchanging e-mail (electronic mail) via the Internet. You need to subscribe to “i-mode” to use i-mode mail.

- See “Mobile Phone User’s Guide [i-mode]” for more details.
- This model does not support all the services described in “Mobile Phone User’s Guide [i-mode].” Check which models support which services in “Mobile Phone User’s Guide [i-mode]”.

SMS messages (short messages)

You can send and receive SMS messages between phones without subscribing to i-mode. Sending and receiving SMS messages with subscribers to overseas carriers in addition to are also available. For information on the countries and overseas carriers with which SMS messages can be exchanged, see the International Service web page of .

- Refer to “Network Services User’s Guide” for more details.

Displaying Mail in Inbox



The inbox folder list is displayed. You can sort mails by folder. You can check the records and contents of received i-mode mails and SMS messages.

1. From the Mail menu (P139), “Inbox”

2. Select a folder ▶

-  [Simple]: You can use the fixed text registered on the simple reply phrase (P158) for the mail body and reply to the sender. Fixed the mail is sent immediately after the text is selected.
-  / : You can view previous or after pages for multiple pages.

3. Select mail ▶

-  [Reply]: You can select how to reply and then reply to the sender, etc. “Simple reply”... Refer to the descriptions for  [Simple] on the Received Mail List display. Except for “Simple reply”... Go to the step 3 (P152) in “Compose i-mode mail”/the step 3 (P155) in “Creating SMS”.
- : You can view previous or next mail.
- : You can scroll the screen.

Information

- To delete all displayed the contents in box setting “Security” (P159), enter terminal security code →  [OK].
- The deco mail via phone includes of text and URL.
If you select the URL, you can read deco mail. → P146
- You can save up to 400 received mails/SMS. Depending on the size of mails/SMS messages, the number of mails/SMS messages to save may be fewer.

Icons on the Received Mail Folder List Screen

Icon	Description
 (gray)	Folder without unread mails/SMS messages
 (gray)	Folder with unread mails/SMS messages
 (blue)	Created folder without unread mails/SMS messages
 (blue)	Created folder with unread mails/SMS messages

Received Mail List and Marks on Display Screen

Icon	Description
	Unread mail messages
	Read mail messages
	Unread SMS messages
	Read SMS messages
	Unread SMS reports
	Read SMS reports
	Unread SMS messages in the UIM
	Read SMS messages in the UIM
	Protected mails
	Forwarded mails
	Replied mails/SMS messages
	Mail with a file attached or pasted

Icon	Description
	Mail with a file to which the UIM restrictions are set attached
	Subject
 ※	Mail received as To-type
 ※	Mail received as Cc-type
 ※	Mail received as Bcc-type
 ※	To-type broadcast mail address
 ※	Cc-type broadcast mail address
 ※	Received date and time
 ※	A melody is pasted.
 ※	i-appli launch information is pasted.
 ※	A melody is attached.
 ※	An image of up to 10,000 bytes is attached.
 ※	A URL of i-shot is attached.
 ※	A URL or i-motion file is attached.
 ※	A pasted melody is damaged.
 ※	An attached file is damaged.

※: Appears only on the Received Mail Display Screen.

Using the Submenu of the Received Mail Folder List Display

1. On the Received Mail Folder List screen (P141),  [Menu] ► Select from the following submenu items

Create folder

You can add a folder.

Rename folder[※]

You can edit the name of the selected folder.

Delete folder[※]

You can delete the selected folder. You cannot delete a folder if a mail is saved.

Auto sort[※]

You can set sort conditions to the selected folder. Go to step 2 of “Distributing the received mail to the folder automatically” (P145).

※: These operations are not available when you select Inbox.

Using the Submenu of the Received Mail List**Screen**

Setting item/Setting at purchase → P260

1. On the Received Mail List screen (P141),  [Menu] ▶
Select from the following submenu items

Move to folder^{※1}

You can move the selected mails and messages to other added folders.

Delete

You can delete the selected mails and messages.

Delete selected

You can select and delete multiple mails and messages. After selecting mail messages,  [Menu] → Select “Delete”.

Delete all

You can delete all mail messages in the folder. To delete all, enter terminal security code →  [OK].

Protect ON/OFF^{※1}

You can set or cancel the protection of the selected mails and messages. Protected mail cannot be moved/deleted.

Sort

You can sort the mails and messages displayed on the List display.

Filter

You can change the type of the mails and messages displayed on the List display.

UIM^{※2}

You can move and copy the selected SMS messages in the phone to the UIM, and move and copy the SMS messages in the UIM to the phone.

Simple reply

You can use the fixed text registered on the simple reply phrase (P158) for the mail body and reply. The mail is sent immediately after the text is selected.

※1: You cannot use this menu for SMS in the UIM.

※2: You cannot use this menu for protected SMS or SMS delivery report.

Using the Submenu of the Received Mail Display Screen

1. On the Received Mail List screen (P141),  [Menu] ► Select from the following submenu items

Reply

You can reply after selecting the method to reply. When you select any of following items (except for “Simple reply”), please go to the step 3 (P152) in “Compose i-mode mail” / the step 3 (P155) in “Creating SMS”.

- **Reply:** You can reply to the sender of i-mode mail from the detailed received mail list.
- **Reply quoted**^{*1}: You can send the reply quoting the original text in your received i-mode mail.
- **Reply all**^{*1}: You can reply all receivers and senders at the same time.
- **Reply quoted all**^{*1}: You can reply all receivers and senders with quoting the original text in your received i-mode mail.
- **Simple reply:** You can use the fixed text registered on the simple reply phrase (P158) for the mail body and reply. Fixed text the mail is sent immediately after the text is selected.

Forward

You can forward the displayed mail to other party. Go to step 2 (P152) of “Composing i-mode mail” or step 2 (P155) of “Composing SMS messages”.

Move to folder

^{*2}

You can move the displayed mail to other added folders.

Delete

You can delete the displayed mail.

Protect ON/OFF

^{*2}

You can set or cancel the protection to the displayed mail. The protected mail messages cannot be moved/deleted.

Store Address

You can register mail address / phone number of receiver on displaying the mail. Go to step 2 on page 64 of “Adding to Phonebook”.

Add to phonebook

^{*3}

You can add the mail address / phone number written on the displayed mail text to the phonebook. Go to step 2 of “Adding to Phonebook” (P64).

Save attach file

^{*4}

You can save an image () and a melody () of up to 10,000 bytes attached to the displayed mail. You can check the saved images by selecting “Data box”. → “My picture”. → “i-mode” folder. → P169, P170

Copy

- For copying after selecting the following items, see “Copying/Cutting/Pasting” (P225).
- **Body:** You can copy the text.
- **Subject**^{*1}: You can copy the title.
- **Sender:** You can copy e-mail address / phone number of the sender.

UIM

^{*5}

You can move / copy the displayed SMS message in the phone to the UIM, and move / copy the SMS messages in the UIM to the phone.

Simple reply

You can use the fixed text registered on the simple reply phrase (P158) for the mail body and reply. The mail is sent immediately after the text is selected.

- ※1: This menu is not displayed for SMS.
- ※2: You cannot use this menu for SMS of UIM.
- ※3: Activate this menu after selecting mail address / phone number to register. If nothing to be registered is included, you cannot activate this function.
- ※4: Activate this menu after selecting the file to save. If the file to register does not exist, you cannot activate this function.
- ※5: You cannot activate this function for i-mode mail or protected SMS.

Information

- The Submenu items for the SMS report / voice mail incoming notification display screen are "Move to folder", "Delete", and "Protect ON/OFF" only.

Distributing the received mail to the folder automatically

The mails / SMS messages is applicable for the condition can be saved to the folder automatically. You can set this only to additional folder.

1. On the Received Mail Folder List screen (P141), select a folder to specify conditions ▶ [Menu] ▶ Auto Sort

- The screen for automatic sort is displayed.

2. [Menu] ▶ Select submenu.

Address^{※1}

You can enter e-mail address or phone number to distribute each folder.

- **Open phonebook:** You can enter the phone number searching from phonebook.
- **Input address:** You can directly enter the address. When you enter e-mail address, you input correctly to a domain (the part of after @ mark).

Subject^{※1 ※2}

You can input the subject of mail to distribute a folder.

Release

You can cancel one of conditions of distribution of folder.

Release all

You can cancel all distribution conditions of folders.

- ※1 : When a received mail contains multiple conditions, it is distributed to the top folder of the folder list that corresponding condition is set.
- ※2 : You cannot set the multiple conditions in the same folder.

Receiving i-mode Mail/SMS Messages Automatically

When the phone is in the service area, it automatically receives i-mode mail/ SMS messages.

1. A mail or an SMS message is received

-  (White) or  (White) is displayed.

2. The result of the reception is displayed

- If you want to check the received i-mode mail message immediately, select “i-mode mail”, and press .
- If you want to check the received SMS message immediately, press .
- : Go to previous screen.

Saving Images over 10,000 bytes

A JPEG image over 10,000 bytes is not downloaded properly to the handset. Therefore, you can save it after extracting the data from URL for image view in mail text, and connecting i-shot center.

1. On the Received Mail Folder List screen (P141), select “URL” “Yes”

- For the method of saving images, see “Obtaining Images from Sites” (P136).

Information

- You can view the contents of received Deco-mails in this way.

Downloading i-motion Movies from i-motion Mail

Data of i-motion mail is not downloaded to the phone even when it is received. You need to access the i-motion mail Center from its URL given to the mail text to see an i-motion movie to download and save the data. The saved i-motion can be checked in “i-motion” of “Data box” → “i-mode” folder (P175).

1. From the Received Mail Folder List screen (P141), select the URL “Yes”

- Downloading of i-motion starts.
- The i-motion is played while being downloaded in the case it is possible.

2. After downloading, press

- “Play”: You can play downloaded i-motion.
- “File property”: You can view information of downloaded i-motion from a site.
- “Back”: The site will be returned, not saving i-motion.

Displaying Mail in Outbox



The Sent Mail List is displayed. You can check the records and contents of sent i-mode mail and SMS messages.

1. From the Mail menu (P139), select “Outbox”.

The time to send the mail※1 Receiver※2
Subject※3

- ※1: The mail you receive is displayed on a time basis that day. From the next day on, each message is displayed by the date when you received it.
- ※2: The name is displayed when the entry is saved in phonebook.
- ※3: SMS is displayed as SMS

- : Display the previous or next page for multiple pages.

2. Select a mail ►

- : Display the previous or next page.
- : Scroll by screen.

Information

- To display the box which is set “Security” (P159), enter terminal security code →  [OK].
- You can save up to 400 mails / SMS. Depending on the size of mails / SMS messages, the number of mails / SMS messages that can be saved may be smaller.

Icons on the Sent Mail List display and the Sent Mail display screen

Icon	Description
	Mail successfully sent
	Mail failed to be sent
	SMS message successfully sent
	SMS message failed to be sent
	Sent SMS messages in the UIM
	Protected mail / SMS messages
	Mail with a file attached
	Mail with an attached file to which UIM restrictions are set
	Subject
 ※	Mail address successfully sent as To-type mail
 ※	Mail address failed to be sent as To-type mail
 ※	Mail address successfully sent as Cc-type mail
 ※	Mail address failed to be sent as Cc-type mail
 ※	Mail address successfully sent as Bcc-type mail

Icon	Description
 ※	Mail address failed to be sent as Bcc-type mail
 ※	Sent date and time
 ※	A pasted melody file is attached.
 ※	An i-appli activation information file is attached.
 ※	A melody is attached.
 ※	An image of up to 10,000 bytes is attached.
 ※	An image (JPEG) of over 10,000 bytes is attached.
 ※	Moving images are attached.
 ※	A corrupted melody file is attached.
 ※	A corrupted file is attached.

※: Appears only on the Sent Mail Display Screen.

Using the Submenu of the Sent Mail List Screen

Setting item/Setting at purchase → P260

1. From the Sent Mail Folder List screen (P147), [Menu] ▶ Select from the following Submenu items

Edit

You can edit the selected mail again. See “Composing i-mode mail” (P152) / “Composing SMS messages” (P155).

Delete

You can delete the selected mail.

Delete selected

You can select and delete multiple mail messages. After selecting mail messages,  [Menu] → Select “Delete”.

Delete all

You can delete all mail messages in the Sent box. To delete all, enter terminal security code →  [OK].

Protect ON/OFF^{※1}

You can set or cancel the protection to the selected mail. Protected mail cannot be deleted.

Sort

You can sort the mail messages displayed in the list screen.

Filter

You can change the type of the mail messages displayed in the list screen.

UIM^{※2}

You can move and copy the selected SMS message in the phone to the UIM, and move and copy the SMS messages in the UIM to the phone.

※1 : You cannot use this menu for SMS in the UIM.

※2 : You cannot use this menu for i-mode mail or SMS delivery report.

Using the Submenu of the Sent Mail Display Screen

1. From the Sent Mail Display screen (P147), [Menu] ▶ Select from the following Submenu items

Edit

You can edit the displayed mail again. Go to step 2 in “Composing i-mode mail” (P152) / “Composing SMS messages” (P155).

Delete

You can delete the displayed mail.

Protect ON/OFF^{※1}

You can set or cancel the protection to the displayed mail. The protected mail messages cannot be deleted.

Store address

You can register mail address/phone number of receiver on displaying the mail. Go to step 2 on page 64 of “Adding to Phonebook”.

Add to phonebook^{※2}

You can add the mail address and phone number of the sender of the displayed mail to the phonebook. Go to step 2 (P64) of “Adding to Phone Book”.

Copy^{※3}

- For copying after selecting the item, see “Copying / Cutting / Pasting” (P225).
- **Body:** You can copy the text.
- **Subject:** You can copy the subject.

UIM^{※4}

You can move and copy the displayed SMS message to the UIM, and move and copy the SMS messages in the UIM to the phone.

※1: This function is not available in SMS of UIM.

※2: After selecting the mail address / phone number, you can activate the function. If nothing that can be registered is included, you cannot activate the menu properly.

※3: This function is not available for SMS.

※4: This function is not available for the protected SMS.

Displaying Mail in Unsent Message



The Unsent message List is displayed. You can check the contents of saved i-mode mail and SMS messages which have been saved without being sent.

1. From the Mail menu (P139), “Unsent message”

The time to save^{※1} Receiver^{※2}
Subject^{※3}

- ※1: The mail you save is displayed on a time basis that day. From the next day on, each message is displayed by the date when you saved it.
- ※2: The name is displayed when the entry is saved in phonebook.
- ※3: SMS is displayed as “SMS”

- : Displays the previous or next page for multiple pages.

2. Select a mail ►

Information

- To display the box which is set “Security” (P159), enter terminal security code →  [OK].
- You can save up to 400 mails / SMS. Depending on the size of mail/ SMS, the number of mails / SMS messages that can be saved may be smaller.

Icons on the Unsent Mail List display and the Unsent Mail display screen

Icon	Description
	Unsent mail
	Unsent SMS message
	Mail with a file attached
	Mail with an attached file to which UIM restrictions are set
	Subject
 ※	Address of To-type
 ※	Address of Cc-type
 ※	Address of Bcc-type
 ※	Attached file
 ※	A pasted melody file is attached.
 ※	i-appli launch information is attached.
 ※	A melody file is attached.
 ※	An image file of up to 10,000 bytes is attached.
 ※	An image (JPEG) of over 10,000 bytes is attached.
 ※	A moving image file is attached.
 ※	A damaged melody file is attached.
 ※	A damaged file is attached.
 ※	Text

※: Only appears on the Unsent Mail display screen.

Using the Submenu of the Unsent Message

List Screen

Setting item/Setting at purchase → P261

- 1. From the Unsent Message List screen (P150),**  [Menu] ► **Select from the following submenu items**

Send

You can send the selected mails and messages.

Delete

You can delete the selected mails and messages.

Delete selected

You can select and delete multiple mail mails and messages. After selecting mail messages,  [Menu] → Select “Delete”.

Delete all

You can delete all mail messages in the folder. To delete all, enter terminal security code →  [OK].

Sort

You can sort the mail messages displayed in the list display.

Filter

You can change the type of the mail messages displayed on the list display.

Using the Submenu of the Unsent Mail Display Screen

From the Unsent Mail display screen (P150), press  [Menu] and select a submenu item. See “Using the Submenu of the Compose mail display” (P152) / “Using the Submenu of the Compose SMS Screen” (P155) for the available submenu items.

Composing Mail

Composing i-mode Mail



You can create and send new i-mode mail.

- 1. From the Mail menu (P139), select “Compose mail”**
► **“Compose message”**

2.  **Select the Address field** ▶  ▶ **“Enter Address”** ▶ **Enter the address** ▶ **“Enter Address”** ▶ 
 - For a menu displayed for destinations, see “Address menu” (P153) of “Using the Submenu of the Compose Mail Display”.
3.  **Select the Subject field** ▶  ▶ **Enter the subject** ▶ 
 - In case of not attaching the file, go to step 5.
4.  **Select (Attach file) field** ▶  ▶ **Add attached file**
 - Select the file saved in “My picture” / “i-motion” (P176) / “Melody” (P175) of Data box” (P179) / “Melody”.
 - For a menu displayed for attachment files, see “Attach file menu” (P153) of “Using the Submenu of the Compose Mail Display”.
 - If a file is attached, it can be displayed/played by pressing  [Play].
5.  **Select the Message field** ▶  ▶ **Enter message** ▶ 
6.  [Send]

Information

- Depending on the radio wave conditions, the characters may not be sent successfully to the destination.
- Half-pitch katakana or pictographs may not be displayed properly when exchanging mails between i-mode phones.
- When you enter the destination of the phonebook that a secret code is set, the secret code is automatically added. However, the secret code does not remain on the destination of the sent mail.

Using the Submenu of the Compose Mail Display

1. **From the Compose Mail display (P151),**  **[Menu]**
▶ **Select from the following Submenu items**

Send

You can send the i-mode mail that you are composing or editing.

Save

You can save the i-mode mail that you are composing or editing in unsent message.

Add address

You can add addresses. When you add addresses, you can send same i-mode mail to multiple recipients at the same time. You can send same mail to up to 5 addresses at a time.

- **Open phonebook:** You can add the address by searching the phonebook.
 - **Input address:** You can enter the address directly.
-

- **Received list:** Set an address selected from received mail history.
- **Sent list:** Set an address selected from sent mail history.

Address menu^{*1}

- **Open phonebook:** You can add the address by searching the phonebook.
- **Input address:** You can enter the address directly.
- **Change to To:** You can change the setting of receiver to "To type".
- **Change to Cc:** You can change the setting of receiver to "Cc type".
- **Change to Bcc:** You can change the setting of receiver to "Bcc type".
- **Delete address:** You can delete the address.
- **Received list:** Set an address selected from received mail history.
- **Sent list:** Set an address selected from sent mail history.

Attach file menu

- **Attach file:** You can select the file in "My picture" (P169) / "i-motion" (P176) / "Melody" (P179) of "Data box".
- **Take a picture^{*2}:** A Still Image Finder Stand-by screen appears. → P112
Press  [Attach] on Still Image Shooting End display to add to the attachment file.

- **Take a movie^{*4}:** A Moving Image Finder Stand-by screen appears. → P117
Press  [OK] on Moving Image Shooting End display to add to the attachment file.
- **Delete att. file^{*2}:** You can delete the attachment file.
- **Play/ Display file^{*2}:** You can play or view the file.

Add signature

You can insert a signature at the end of the text of mail.

- You need to register the signature beforehand.
→ p158

Delete body

You can delete the the text of mail that you are composing or editing.

Delete mail

You can delete the mail under composing or editing.

- ※1 : After selecting  /  / , you can operate the menu.
- ※2 : After selecting , you can operate the menu.
- ※3 : Unavailable when a shot still image exceeding 5,000 bytes is already attached to an attachment file.
- ※4 : Unavailable when a moving image/i-motion or JPEG image exceeding 10,000 bytes is already attached to an attachment file.

Information

- The type or receiver
 - To: Ordinary receiver
 - Cc: To inform the contents in addition to the receiver.
 - Bcc: To inform the contents if you do not want other receivers to know except for direct receiver.

- About attachable files

Type of file	Maximum number of files
Melody	Up to 10 files ^{※1}
Image of 10,000 bytes or less (JPEG, GIF)	
Image over 10,000 bytes (JPEG)	1 file ^{※2}
Moving image/ i-motion movie	

- ※1 : Up to 10 files when the total size of a data file including melodies, images and the text is equivalent to 5,000 full-pitch characters (i.e., 10,000 bytes).
- ※2 : You can attach either an image or moving image/ i-motion movie of up to 100K bytes. You can attach the file separately from melody files and images of 10,000 bytes or less.
- You cannot attach files that are prohibited from being attached to mail or output from the phone to other devices.
 - When a JPEG image or an i-motion movie in excess of 10,000 bytes is attached, the number of characters you can enter in the text field decreases by the equivalent of 100 full-pitch (200 half-pitch) characters.
 - The i-mode phone of the mova service cannot receive GIF images and melodies.
 - Some attached files may be deleted at the i-mode Center or not be received, displayed, or played properly by the recipients.

Using the Submenu of the Creating next Entry Screen

From creating next Entry screen, press  [Menu] and select a Submenu item. See “Using the Submenu of Character Entry display” (P224) for the available Submenu items.

Composing SMS messages



You can create and send SMS messages. You can send and receive SMS messages to and from the subscribers to overseas carriers in addition to . For information on the countries and overseas carriers with which SMS messages can be exchanged, see the International Service web page of .

1. From the Mail menu (P139), select “Compose mail”
 - ▶ “Compose SMS”

2.  **Select the Address field** ▶  ▶ **“Enter Address”** ▶ **Enter the recipient’s phone number** ▶ 
 - For a menu displayed for destinations, see “Address menu” (shown on the right) of “Using the Submenu” of the Compose SMS Display.
3.  **Select the Message field** ▶  ▶ **Enter the message** ▶ 
4.  **[Send]**

If the recipient is a subscriber to an overseas carrier other than :

- “+” (Press * key 2 times) ▶ “Country code” ▶ “Mobile phone number of the recipient”
 or
 “010” ▶ “Country code” ▶ “Mobile phone number of the recipient”
- If the mobile phone number starts with 0, enter the number by omitting “0”.

Information

- Depending on the radio wave conditions, the characters may not be sent successfully to the destination.
- When you send an SMS message to a subscriber to an overseas carrier, if characters that the other party does not support are included in its text, they may not be displayed correctly.
- If the receiver has an i-mode phone of mova service, it may receive SMS from phone as i-mode mail.

- If the sender does not notify caller ID (including public phone/Unknown ID), you cannot answer to the SMS message.
- It is recommended to use half-width alpha-numeric when sending to a user having a service contract of foreign mobile phone.
- When you send an international SMS, a communication fee occurs (when receiving an international SMS, no communications fee occurs). However, note that a communications fee may occur even when the transmission has not been completed due to error of address, etc.

Using the Submenu of the Compose SMS Display

1. From the Compose SMS display (P154),  **[Menu]**
 ▶ **Select from the following Submenu items**

Send

You can send an SMS message that you are composing or editing.

Save

You can save an SMS message that you are composing or editing in Draft box.

Address menu

- **Open phonebook:** You can add the address by searching the phonebook.
- **Input address:** You can enter the address directly.
- **Received list:** Set an address selected from received mail history.
- **Sent list:** Set an address selected from sent mail history.

SMS report request

You can set whether to request a report for the SMS message that you are composing. An SMS report is an SMS message to notify you when your SMS message reaches the recipient.

SMS validity term

You can set the period during which the SMS Center holds the SMS message that you are composing or editing when the recipient cannot receive it immediately.

Delete body

You can delete whole sentences entered in the text. The phone number of receiver will not be deleted.

Delete SMS

You can delete the SMS message that you are composing or editing.

Using the Submenu of of the Character Entering Display while Composing SMS

From the Compose SMS display, press  [Menu] and select a submenu item. See "Using the Submenu of the Character Entry display" (P224) for the available Submenu items.

Checking New i-mode mail and Message



When your phone has been turned off or out of the service area, you can check whether or not the i-mode Center holds i-mode mail and messageR/F.

1. From the Stand-by screen, press for 2 or more seconds

- The Check results display appears. To read the received i-mode mail immediately, select "Mail" and press .

Information

- When the i-mode Center holds i-mode mail and messageR/F, the relevant icon (P32) is displayed. When mail or messages arrive at the Center when, for instance, your phone is turned off, the icon may not be displayed.
- When "Receive option" is set to "ON," you will receive all mail held at the Center if you use "Check new message." If you do not want to receive mail, first deselect the "Mail" of the "i-mode check" (P158) in "Mail Setting", then check messages.

Receiving Selected Mail



You can check the subject of i-mode mail held at the i-mode Center and select mails to receive, or delete mails at the Center before receiving them.

To use this function, you need to set “Receive option” (shown on the right) to “ON” beforehand. Note that, when this is “ON”, i-mode mail cannot be received automatically.

1. From the Mail menu (P139), “Receive option”

- The phone is connected to the Center, and the display for selecting mail to receive is displayed.

2. Select the pull-down menu for each mail ▶ ▶ Select “Receive”, “Delete” or “Hold” ▶

3. Select “Receive/Delete” ▶

- The confirmation screen appears.

4. Select “OK” ▶

- In step 2, the mail for which “Receive” was selected are received immediately.

Checking whether Center Holds SMS



When your phone has been turned off or out of the service area, you can check whether or not the SMS Center holds SMS messages.

1. From the Mail menu (P139), “Check new SMS”

- The Check results display appears. To read the received SMS messages immediately, press .

Changing Mail Setting

Communication



You can make settings related to communication of mail and SMS messages.

Setting item/Setting at purchase → P245

1. From the Mail menu (P139), “Mail setting” ▶ “Communication” ▶ Select from the following setting items ▶ After setting, [Done]

Receive opt. setting

You can set whether to select i-mode mail to receive. If this function is set to “ON,” you cannot receive i-mode mail automatically.

Receive attach file

You can set whether to receive images or melodies attached to i-mode mail.

Check new message

When you receive messages by performing "Check New Message," you can select an item to check from i-mode mail, messageR/F.

SMS report request

You can set whether to request a report for the SMS message that you are composing. An SMS report is an SMS message to notify you when your SMS message reaches the recipient.

SMS validity term

You can set the period during which the SMS Center keeps the SMS message that you are composing or editing when the recipient cannot receive it immediately.

Information

- The attachment file set to by "Receive attach file" cannot be received as the file is deleted at i-mode center.
- You can receive the melody of MFI format attached to the body of mail even if you set the "Melody" to by "Receive attach file".

Edit



You can set a signature attached to the mail body, a quotation mark used for mail reply, and items related to the fixed text that is inserted as a body when the simple reply is used.

Setting item/Setting at purchase → P245

1. From the Mail menu (P139), "Mail setting" ▶ "Edit"
▶ Select from the following setting items ▶ After setting, [Done]

Edit signature

You can set whether to automatically attach your name and address (signature) at the end of the text and can set the contents of the signature.

Edit quotation

You can set symbols or sentences to be attached to the head of the original text (quotation mark) for "Reply quoted".

Simple reply phrase

You can set the fixed text that is inserted as a body when the simple replay is used.

- [Add]: You can type and add a new fixed text.

Information

- You cannot edit or delete the registered fixed text that has been registered to "Simple reply phrase" in advance.

View



You can make the settings related to the display of mail and SMS messages.

Setting item/Setting at purchase → P245

1. From the Mail menu (P139), “Mail setting” ▶ “View” ▶ Select from the following setting items ▶ After setting, [Done]

Character size

You can set the character size of the text on the Mail display screen.

Scroll

You can set the number of lines to scroll when pressing on the Mail display screen.

Mail list display

You can set the display method (the number of lines/the contents displayed) on the mail list display.

Folder security

You can set security to Inbox, Outbox, and Unsent messages in the Mail menu. To display the messages in the box with security set, enter terminal security code → [OK].

Melody auto play

You can set whether to automatically play a melody attached or pasted on the mail display screen.

Others



You can check the settings made in “Mail setting” and reset the settings to the default.

1. From the Mail menu (P139), “Mail setting” ▶ “Others” ▶ Select from the following setting items.

Check settings

You can check the settings made in the “Mail settings”.

Reset settings

You can reset the settings made in the “Mail settings” to the default. To reset settings, enter terminal security code → [OK].

Reset data

You can delete all mail messages and MessageR/F stored in the phone. To reset the data, enter terminal security code → [OK].

Network Service

Available Services	204
Using Voice Mail	204
Using Call Waiting Service	206
Using Call Forwarding Service.....	207
Using Nuisance Call Barring Service...	208
Using Caller ID Notification Service	208
Using Caller ID Request Service.....	209
Using Set Arrival Act	209
Selecting Arrival Call Act.....	209
Setting Remote Control.....	210
International Roaming Service.....	210
Registering Additional Services.....	211
Registering Additional Guidance	212
Using English Guidance	212
Using Service Dialing Number	213
Using Call Barring.....	213

To display the Service menu

On the Stand-by display,  [Menu] 
 (NW service) or “NW service”

In this manual, the outline of the service is explained by the method of using the handset menu.
For details, refer to “Services User's Guide”.

Available Services

With phone, following Services are available.

Service	Application	Monthly fee	Reference
Voice Mail	Required	Charged	See right
Call Waiting Service	Required	Charged	P206
Call Forwarding Service	Required	Free	P207
Nuisance Call Barring Service	Required	Free	P208
Caller ID Notification Service	Not required	Free	P208
Caller ID Request Service	Not required	Free	P209
Remote control	Not required	Free	P210
International roaming service	Not required	Free	P210
English Guidance	Not required	Free	P212
Service Dialing Number	Not required	Free	P213
Public mode (drive mode)	Not required	Free	P51
Public mode (power off)	Not required	Free	P54

- In this manual, the summaries each service are explained in the ways using the menu of the phone. For detail, see “Mobile Phone User’s Guide [Services]”.

- This phone is not applicable to all the services described in “Mobile Phone User’s Guide [Services]”.
- Contact “Information Center” on the back of this manual for application or inquiry.

Information

- The Services that are operated by connecting to the Service Center are not available when When “國外” is displayed on your handset.
- You can register newly provided services when additionally provided by . → P211

Using Voice Mail



When you are in an area where radio waves do not reach, when you turn off the phone or when you cannot answer the call, this service answers to the party who made a voice call to you, and the Voice Mail Center holds voice mail messages for you.

- When you did not answer a voice call that came in while Voice Mail is activated, it is recorded to the received call history as a missed call and a screen notifying a missed call appears.
- This handset is not applicable to Voice Mail (Video-phone call). Make a voice call to “1412” (free) and set not to be applicable to video-phone call.

- If a call comes in from a caller not notifying caller ID with “Caller ID request” activated, the Caller ID Request guidance is played back and the center will not hold voice mail messages.

1. From the Service menu (P203), “Voice mail”

► Select from the following setting items

Activate voice mail

You can start using Voice Mail.

Set ringing time

You can set the time from the first ring until the call is connected to the Voice Mail Service Center. (period)

Deactivate voice mail

You can stop using Voice Mail.

Voice mail status request

You can check the current settings of Voice Mail Service. If you press  [Menu], you can start/stop the service of voice mail or set the length of ringing time.

Play messages

You can play back recorded Voice Mail messages.

Voice mail setting

You can connect to the Voice Mail Service Center to change the settings of Voice Mail by following the voice guidance.

Check messages

You can check whether or not new messages are recorded.

Notify missed call

If the phone is turned off or out of the service area, you are informed by SMS (Short Message Service) of missed calls when the phone is turned on or in the service area again.

– **Activate missed call notification:** You can start using Missed Call Notice Service.

– **Deactivate missed call notification:** You can stop using Missed Call Notice Service.

– **Missed call notification status request:** You can check the settings of the Missed Call Notice Service.

Delete voice mail icon

You can delete  displayed in the icon view area.

Set message alert ringer

You can set the ring tone to sound when a new message is recorded.

Using Call Waiting Service



When you receive another voice call during a call, you will be notified of it by busy ring tone, and you can put the current call on hold to answer the new call. You can also newly make a call to another party by putting the current call on hold.

- To use Call Waiting Service, set “Arrival call act” (P209) to “Answer” beforehand. If this is set to another setting, you cannot answer the incoming voice call while you are performing a voice call even if you start Call Waiting Service.
- If a call comes in from a caller not notifying caller ID while Caller ID request is set to “Activate caller ID request”, the Caller ID Request guidance is played back and Call Waiting is not available.
- When a video-phone call comes in during a voice call, or a voice call comes in during a video-phone call, Call Waiting does not work. The second call is recorded as a missed call in Received Calls.

1. From the Service menu (P203), “Call waiting”

▶ Select from the following setting items

Activate call waiting

You can start using Call Waiting.

Deactivate call waiting

You can stop using Call Waiting.

Call waiting status request

You can check whether the Call Waiting is activated or deactivated.

Submenus on using Call Waiting Service

- Press  [Menu] to view the submenu.

■ When a new call comes in during a call

Voice mail^{※1}

When a new call comes in, the caller can connect the voice mail center.

Call rejection

You can reject a call without receiving.

Call forwarding^{※2}

You can forward the incoming call to the forwarding destination you have registered beforehand.

End active call

Hangs up the current call and displays the incoming call display for another party. You can receive an incoming call.

Mute/Unmute

The voice to send to the other party is set to mute or unmute.

※1: You can use the voice mail when you have signed up this service. See “Using Voice Mail” (P204) for details.

※2: You can use the call forwarding service only when you have signed up this service. See “Using Call Forwarding Service” on the next page.

- **When you are talking with a party while a call to another party is put on hold (Multi call).**

Switch

Put the current call on hold to enable talking with another party on hold.

End

- **End active call:** After ending a call, you can take the new call on hold.
- **End held call:** You can end a call on hold.
- **End all calls:** You can end both calls.

Mute/Unmute

The voice to send to the other party is set to mute or unmute.

Using Call Forwarding Service



This is a service to forward a voice call/video-phone call when you are in an area where radio waves do not reach, you turn off the handset or you did not answer within the set ring time.

- When you did not answer a voice call or video-phone call that came in while Call Forwarding Service is activated, it is recorded to the received call history as a missed call and a screen notifying a missed call appears.
- If a call comes in from a caller not notifying caller ID while Caller ID Request Service is set to “Activate caller ID

request”, the Caller ID Request guidance is played back and the call is not forwarded.

- Call Forwarding Service will be automatically deactivated if “Voice mail” is set to “Activate voice mail”.
- This service is not available with some billing plans.

1. **From the Service menu (P203), “Call forwarding”**
▶ **Select from the following setting items**

Activate call forwarding

You can start using Call forwarding Service.

- **Register fwd number:** You can register the phone number of the forwarding destination. If you press [Search], you can search for phonebook.
- **Set ringing time:** You can set the time from the first ring until the call is forwarded.

Deactivate call forwarding

You can stop using Call forwarding Service.

Register the forwarding number

You can change the phone number of the forwarding destination. If you press [Search], you can search for phonebook.

Setting at forwarded party busy

You can set an incoming call to be connected to the Voice Mail Service Center if the forwarded destination is busy.

Call forwarding status request

You can check the current setting status of Call Forwarding Service.

Setting to enable or disable call forwarding guidance

Press .

- Make settings following the voice guidance.
- For details, see “Mobile Phone User’s [Services]”.

Using Nuisance Call Barring Service

 ▶  (NW service) ▶

This is a service to reject “Nuisance calls” such as prank calls. If you register a caller to reject, calls from the caller will be automatically rejected and the caller will be answered by the guidance.

- Even if a call from a caller who is registered to be rejected, the ring tone will not sound, and the call will not be recorded in the received call history.

1. From the Service menu (P203), “Nuisance call barring” ▶ Select from the following setting items

Register nuisance caller

You can register the phone number of the call that you answered the last for rejection.

Delete all entries

All the phone numbers registered for rejection are deleted.

Delete most recent entry

You can delete the last registered telephone number. You can delete the numbers one by one by repeating the same operation first from the last saved one.

Using Caller ID Notification Service

 ▶  (NW service) ▶

You can notify your phone number to the other party when making a call. When the other party’s phone is the digital terminal that supports caller ID, your phone number appears on the other party’s phone.

- Your caller ID is important information, so take great care to notify it.

1. From the Service menu (P203), “Caller ID notification” ▶ Select from the following setting items

Activate/Deactivate caller ID notification

You can display your phone number on the other party’s phone (display) when making a call. To use this service, enter the Network Security Code.

Caller ID notification status request

You can check the current setting status of Caller ID Notification.

Using Caller ID Request Service



This is a service to request for the Caller ID notification by guidance to the call from the party who does not notify Caller ID, and terminate the call.

- A call that was not answered by Caller ID Request Service will not be recorded in the received call history, and the screen notifying of the missed call does not appear.

1. From the Service menu (P203), “Caller ID request”

▶ Select from the following setting items

Activate caller ID request

You can start using Caller ID Request Service.

Deactivate caller ID request

You can stop using Caller ID Request Service.

Caller ID request status request

You can check the current settings of Caller ID Request Service.

Using Set Arrival Act



You can activate or cancel the arrival call act set by “Arrival call act” (See right). You can view the current settings.

1. From the Service menu (P203), “Set arrival act”

▶ Select from the following setting items

Activate arrival act

You can start using the response you set in “Arrival Call Act”.

Deactivate arrival act

You can stop using the response you set in “Arrival Call Act”.

Arrival act status request

You can check the current settings of Set Arrival Act.

Selecting Arrival Call Act



You can set how to react to a voice call/video-phone call that comes to a customer who has subscribed to “Voice Mail”, “Call Forwarding Service” or “Call Waiting Service” while performing a call.

- If you have not subscribed to “Voice Mail”, “Call Forwarding Service” or “Catch Phone (Call Waiting Service)”, you cannot answer a call while performing a call.
- To use arrival act, set “Set arrival act” to “Activate arrival act”.

Setting item/Setting at purchase → P243

1. From the Service menu (P203), “Arrival call act”

- ▶ Select from the following setting items

Answer

The phone rings. If Voice Mail, Call Waiting Service, or Call Forwarding Service is activated, the phone follows each setting.

Voice mail

Connects incoming calls to Voice Mail. Even if Call Waiting Service is activated, the calls are connected to Voice Mail.

Call forwarding

Forwards incoming calls to the forwarding phone number registered. Even if Call Waiting Service or Voice Mail is activated, the calls are forwarded.

Call rejection

Rejects incoming calls.

Setting Remote Control



This service allows you to operate “Voice Mail” or “Call Forwarding Service” from touch-tone phones, public phones or cellular phones.

- To use “Voice Mail” or “Call Forwarding Service” overseas, you need to set “Remote control” to “Activate remote control” beforehand.

1. Select “Remote control” from Service menu (P203)

- ▶ Select one of the following items to be set

Activate remote control

Start remote control.

Deactivate remote control

Stop remote control.

Remote control status request

Check settings for remote control.

International Roaming Service



This service allows you to use functions such as Voice Mail and Call Forwarding Service while you stay overseas.

1. Select “International service” from Service menu (P203) ▶ Select one of the following items to be set

Voice mail (Int.)

- **Activate voice mail:** Start Voice Mail.
- **Deactivate voice mail:** Stop Voice Mail.
- **Play messages:** Play recorded voice message.
- **Voice mail setting:** Check current settings of Voice Mail.

Call forwarding (Int.)

- **Activate call forwarding:** Start Call Forwarding Service.
- **Deactivate call forwarding:** Stop Call Forwarding Service.

Roaming guidance (Int.)^{*}

Set roaming guidance.

^{*}: Even if the option has been set, a foreign language guidance may played because of the situation for overseas carriers.

Using OFFICEED

“OFFICEED” is an in-group flat-rate service that is provided by the specified IMCS (Indoor Mobile Communication System). You need to apply separately to use this service. For details, see the corporate service home page

Registering Additional Services



When a new service is added by , you can register the service to the menu and use.

1. From the Service menu (P203), “Others”
 - ▶ “Additional service”
 - The additional service list will be displayed.

2. [Edit] ▶ After editing, press [OK]

USSD code

Enter the service code (USSD) supplied by .

Service name

Enter any service name. Press [Edit] to edit.

Using the Submenu of the Additional Service List Screen

1. From the Additional Service List screen,
 - [Menu] ▶ Select from the following submenu items

Edit

Edit a service.

Select^{*}

The selected service is performed.

Delete 1 item^{*}

The selected service is deleted.

Delete all

All the registered services are deleted.

^{*}: Not displayed if an unregistered service is selected.

Using Registered Services

1. From the Additional Service List screen, select a registered service ▶

Registering Additional Guidance



When you perform services added by “Additional service”, you can register reply messages that correspond to the codes (USSD) returned from the Service Center. The reply message is displayed when the registered code is returned as a reply.

1. From the **Service menu (P203)**, “Others”
 - ▶ “Additional guidance”
 - The reply message list will be displayed.
2. [Edit] ▶ After setting, press [OK]

USSD code

Enter the service code (USSD) supplied by .

Reply message

Enter a reply message name. Press [Edit] to edit.

Using the Submenu of the Reply Message List Screen

1. From the **Reply Message List screen**, [Menu]
 - ▶ Select from the following Submenu items

Edit

You can set a reply message.

Delete 1 item**

The selected reply message is deleted.

Delete all

The all registered reply messages are deleted.

** : Not displayed if an unregistered service is selected.

Using English Guidance



You can set the guidance of setting services such as “Voice Mail” or voice guidance such as “out of the service area” to English.

Available Languages

Setting	Language
Japanese	Plays back the guidance in Japanese.
English	Plays back the guidance in English.
Japanese + English	First plays back the guidance in Japanese and then in English.
English + Japanese	First plays back the guidance in English and then in Japanese.

1. From the Service menu (P197), “Others” ▶ “English guidance” ▶ Select from the following setting items

Guidance setting

- **Outgoing + Incoming call:** You can set languages of the guidance for outgoing and incoming calls. Select “Yes” and then select a language.
- **Outgoing call:** You can set a language of the guidance only for outgoing calls. Select “Yes” and then select a language.
- **Incoming call:** You can set a language of the guidance only for incoming calls. Select “Yes” and then select a language.

Guidance status request

You can check the current settings of the guidance.

Using Service Dialing Number



You can make a call to Information Center or repair counter.

- The displayed item may differ or some items may not be displayed depending on the card.

1. From the Service menu (P203), “Others” ▶ “Service dialing number” ▶ Select from the following items

Malfunction information

Connect to the repair counter.

General information

Connect to the Information Center.



You can block all incoming calls while you are roaming outside Japan with the phone.

- This service is not available in some overseas carriers.

1. From the Service menu (P203), “Others” ▶ “Call barring” ▶ Select from the following setting items

Activate barring of incoming call - roam

- **Barring all incoming calls:** All incoming calls are restricted. Enter your Network Security Code.
- **Data calls barring:** Only incoming video-phone calls are restricted. Enter your Network Security Code.

Deactivate barring of incoming call - roam

You can stop using Barring All Incoming When Roam. Enter your Network Security Code.

Barring of incoming call - roam status request

You can check the settings of Barring All Incoming When Roam.

Overseas Use

International Roaming Service	230
Setting the Network Mode	231
Confirming Before Using Overseas	231
Using the Phone Overseas	233

International Roaming Service

International roaming service (WORLD WING) is a service that allows you to make calls or communications overseas using the same phone number as that used in Japan, utilizing networks of affiliate telecommunications carriers overseas. Refer to "Network Services User's Guide (Chapter of International Service)" for details of the communications services available while in international roaming. The International Service web page of offers the downloadable latest version of "Network Services User's Guide (Chapter of International Service)" as well as the latest information about WORLD SERVICE:

Application for WORLD WING

- The customer who subscribed to the service on or after September 1, 2005 is not required to apply to this service. However, those who notified that the service is not required during signing the service contract or canceled in the middle of the contract need to apply for the service again.
- The customer who subscribed to the service on and before August 31, 2005 and has not applied to the "WORLD WING" is required to apply to this service.
- This service is not available with some billing plans.

Overseas Networks and Services Available

Network	Icon	Voice	Packet transmission (i-mode, mopera U, etc.)	SMS	Video-phone
3G		○	○	○	○
GPRS		○	○	○	X
GSM		○	X	○	X

- ※ Services marked with "O" in the table above may not be available depending on the mobile phone carrier being used or the place of stay.
- See the International Service web page for details about services available in each country or region [e/world/](#)

Information

- You can set to display Japan time together with the local time on the stand-by display. → P81

Setting the Network Mode



Network mode of the phone is set to “Auto” at purchase. If you know the network in your area, you can select it directly.

Setting item/Setting at purchase → P255

1. From the Settings menu (P85), “Network” ► “Network mode” ► Select from the following setting items

Auto

Searches all the networks connectable.

WCDMA only

Searches only networks supporting 3G.

GSM only

Searches only networks supporting GSM/GPRS.

For the network search setting (changing of the communication carriers), see P97.

Information

- You cannot exchange the data through packet service under GSM network.
- When using the handset in Japan or in the service area of 3G network, we recommend you change the setting of the “Network mode” to “WCDMA only” to save battery power.

Confirming Before Using Overseas

Before Departure

Charging the Battery

Make sure of the voltage available in the country or area of stay and use the Overseas/Domestic AC Adaptor 01 (option) for overseas and domestic usage (a conversion plug adapter according to the place of stay will be required).

And, do not charge the phone using an electrical transformer for overseas travel.

Using Voice Mail/Call Forwarding from Overseas

Use of the Voice Mail or Call Forwarding service from overseas is part of “remote operation” and requires the activation of Remote operation before your departure. For details to set the remote operations, refer to “Remote Operation Settings” (P210).

- Before departure, make sure that you have the Network Security Code, which may be required for remote-accessing the Voice Mail etc. If you have forget your Network Security Code, visit a Shop or World Counter with an identification such as the driver’s license to make necessary changes.

Using i-mode Overseas

To use i-mode overseas, you need to set "International Settings" to "YES".

- To change settings in Japan
No packet transmission fees apply.

"iMenu" ▶ "English" ▶ "Options" ▶ "International Settings" ▶ "i-mode services Settings" ▶ "YES"

- To change settings outside Japan
Packet transmission fees apply.

"iMenu" ▶ "International Settings" ▶ "i-mode services Settings" ▶ "YES"

- If set to "NO", you can send and receive i-mode mail messages and view the i Menu only. The setting at purchase is "NO".
- ※ Some i-mode sites may not be available depending on the information provider.
- ※ Packet transmission fees apply to all types of access from overseas including transmissions that are free of charge in Japan.
- ※ Japan time applies even if i-mode sites are accessed from overseas. Be careful when registering entries to or deleting entries from My Menu at the beginning or end of a month.

Using phone overseas

Setting Mobile Phone Carrier

The network will be set after searching it automatically if "Setting the Network Mode" (P97) is set to "Auto" in international roaming.

- You can set up beforehand the type of network on searching by "Setting the Network Mode" (P97).
- If you search the network automatically, you can set the preferred network by "Registering a Network from the list" (P98).
- You can select the network manually. Refer to "Selecting the Network Connection Mode" (P97).

Information

- "Network mode" is set to "Auto" after you search with "Network mode" set to "WCDMA only" or "GSM only" and "Network selection" set to "Auto", "Network mode" will be set to "Auto" after searching.
- If you search with "Network mode" set to "Auto" and "Network selection" set to "Auto", the same mode ("WCDMA only" / "GSM only") of the network (communication carrier) you selected after searching will be set.

Settings to be made after returning to Japan

After Coming Back to Japan

When network settings have been changed for use overseas, “圏外” may appear in Japan. In that case, make settings given below.

- You have to set “Network selection” (P97) to “Auto/WCDMA only”.
- You have to set “Network selection” (P97) to “Auto” or “Manual” and select “3G” on the network selection screen displayed after searching.

Using the Phone Overseas

- If the other party subscribes to a mobile phone carrier supporting the video-phone, you can make a video-phone call by pressing T.

Making Calls

- Making a call to Japan from the country you stay
When entering the phone number directly

Press for 1 or more seconds to display “+”
▶ (Country code for Japan) ▶ Other party's phone number excluding “0 (zero)” at the beginning of the area code ▶  ()

Example: When the other party is in one of the 23 wards of Tokyo (area code: 03)

“+” → → → XXXX – XXXX

Making a call to the phone number registered in the phonebook or call/mail history

On the Phonebook List (P67)/Call/Mail history (P86) display or Detailed Phonebook (P67)/Detail (P86) display,  [Menu] ▶ “International call (Japan)” ▶ After the other party's number is displayed [Call]

Example: When the phone number registered in the Phonebook or Call history is one of the 23 districts in Tokyo
+813XXXX - XXXX

- A recipient's phone number is generated, automatically prefixed with Japan's Country code “+81” and “0” removed from area code.

- Calling another WORLD WING/WORLD WALKER user

Press for 1 or more seconds to display “+”
▶ (Country code for Japan) ▶ The other party' mobile phone number excluding “0 (zero)” ▶  ()

Example: When the other party has a mobile phone number beginning with (090)
“+” → → → XXXX – XXXX

- Calling a mobile phone or fixed-line phone within the country of stay

Dial the other party's phone number including the area code ▶  ()

- Calling from the country of stay to a mobile phone or fixed-line phone in another country (except for Japan)
 - ※ In some countries or areas such as Italy, "0" may be required.

Press for 1 or more seconds to display "+"
▶ Country code of the other party ▶ Other party's phone number excluding "0 (zero)" at the beginning of the area code ▶  ()

Receiving calls

When a call comes in,  ()

Having Others Call You

- Receiving a call from Japan

Have the other party call you at your mobile phone number as usual.

→ XXXX - XXXX/

→ XXXX - XXXX ▶ CALL

- Receiving a call from a country other than Japan

International access code of the country where you make the call ▶ (Country code for Japan)
▶ Your phone number excluding "0 (zero)" at the beginning ▶ CALL

Troubleshooting

Unable to Make or Receive Calls/Always Out of the Service Area/Handset Does Not Turn ON

Possible causes for inability to make or receive calls, reception level indication permanently being "Out of the service area" or the handset not turning on are as follows:

- Weak radio waves being received or being out of the service area
- Failure of the local switchboard or base station or temporary line congestion
- Wrong operation of the handset
- Others

See the International Service web page of the latest information about service areas and network interruption:

In addition, make sure of the operation and try the following:

- If you are indoors, confirm if the condition is the same outdoors.
- Confirm if your monthly charges have not exceeded the limit.
- Turn OFF the handset once and back ON.
- Manually select the mobile phone carrier to use.

If the problem persists after the above troubleshooting procedures are taken, contact the Network Technical Support and Operations Center (P235).

If i-mode is inaccessible

- If i-mode sites other than “iMenu” is unavailable, first make “International Settings” (P232). Some sites may not be available depending on the information provider.
- The i-mode services may not be available depending on the operator being used.
- Select a mobile phone carrier compatible with packet transmission.
- For the latest information about overseas carriers compatible with packet transmission, see the International Service web page .
- “i-mode” services offered by overseas carriers are not available.

Contact (While outside Japan)**If the handset is lost or stolen, etc.**

< Information Center > (24-hour service)

- Universal Number

International Call ID Number for the Universal Number
(See Table 1)

– 800-0120-0151

※ Domestic call charges of the country you stay apply if you make a call from a mobile phone.

- If the Universal Number (above) is not available

International access code for the country of stay
(See Table 2)

– 81-3-5366-3114

For loss or theft of the phone, account settlement of total charges, or phone failure while overseas, see “Failure while overseas” the back side of the operation manual. Note that the customer shall also pay the fees for call and communication after the phone is lost or stolen.

If the Handset is not Working Properly

<Network Technical Support and Operations Center>
(24-hour service)

- Universal Number

International Call ID Number for the Universal Number
(See Table 1)

– 800-5931-8600

※ Domestic call charges of the country you stay apply if you make a call from a mobile phone.

- If the Universal Number above is not available

International access code for the country of stay
(See Table 2)

– 81-3-6718-1414

Major Country Codes

Country/Region	Code	Country/Region	Code
Australia	61	Maldives	960
Austria	43	Netherlands	31
Belgium	32	New Caledonia	687
Brazil	55	New Zealand	64
Canada	1	Norway	47
China	86	Peru	51
Czech	420	Philippines	63
Egypt	20	Russia	7
Fiji	679	Singapore	65
Finland	358	South Korea	82
France	33	Spain	34
Germany	49	Sweden	46
Greece	30	Switzerland	41
Hong Kong	852	Tahiti	689
Hungary	36	Taiwan	886
India	91	Thailand	66
Indonesia	62	Turkey	90
Italy	39	UK	44
Japan	81	USA	1
Macao	853	Vietnam	84
Malaysia	60		

- See the International Service web page of for the latest information international call ID numbers for the universal number and international access number.

International Call ID Number for the Universal Number (Table 1)

Country/Region	Code	Country/Region	Code
Argentina	00	Luxembourg	00
Australia	0011	Malaysia	00
Austria	00	Netherlands	00
Belgium	00	New Zealand	00
Brazil	0021	Norway	00
Canada	011	Philippines	00
China	00	Singapore	001
Columbia	009	South Africa	09
Denmark	00	South Korea	001
Finland	990	Spain	00
France	00	Sweden	00
Germany	00	Switzerland	00
Hong Kong	001	Taiwan	00
Hungary	00	Thailand	001
Ireland	00	UK	00
Israel	014	USA	01
Italy	00		