



| LG410G User Guide |

- ENGLISH

Part 15.21 statement

" Change or Modifications that are not expressly approved by the manufacturer could void the user's authority to operate the equipment. "

Part 15.105 statement

This equipment has been tested and found to comply with the limits for a class B digital device, pursuant to Part 15 of the FCC Rules.

These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. if this equipment does cause harmful interference or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected
- Consult the dealer or an experienced radio/TV technician for help.

For Your Safety

Important Information

This user guide contains important information on the use and operation of this phone. Please read all the information carefully for optimal performance and to prevent any damage to or misuse of the phone. Any changes or modifications not expressly approved in this user guide could void your warranty for this equipment.

Before You Start

Safety Instructions

WARNING! To reduce the possibility of electric shock, do not expose your phone to high humidity areas, such as the bathroom, swimming pool, etc.

Always store your phone away from heat. Never store your phone in settings that may expose it to temperatures less than 32°F or greater than 104°F, such as outside during extreme weather conditions or in your car on a hot day. Exposure to excessive cold or heat will result in malfunction, damage and/or catastrophic failure.

Be careful when using your phone near other electronic devices. RF emissions from your mobile phone may affect nearby in adequately shielded electronic equipment. You should consult with manufacturers of any personal medical devices such as pacemakers and hearing aides to determine if they are susceptible to interference from your mobile phone.

Turn off your phone in a medical facility or at a gas station. Never place your phone in a microwave oven as this will cause the battery to explode.

IMPORTANT! Please read the TIA SAFETY INFORMATION on page 78 before using your phone.

Safety Information

Read these simple guidelines. Breaking the rules may be dangerous or illegal. Further detailed information is given in this user guide.

- ▶ Never use an unapproved battery since this could damage the phone and/or battery and could cause the battery to explode.
- ▶ Never place your phone in a microwave oven as it will cause the battery to explode.
- ▶ Do not dispose of your battery by fire or with hazardous or flammable materials.
- ▶ Make sure that no sharp-edged items come into contact with the battery. There is a risk of this causing a fire.
- ▶ Store the battery in a place out of reach of children.
- ▶ Be careful that children do not swallow any parts such as rubber plugs (earphone, connection parts of the phone, etc.). This could cause asphyxiation or suffocation.

- ▶ Unplug the power cord and charger during lightning storms to avoid electric shock or fire.
- ▶ When riding in a car, do not leave your phone or set up the hands-free kit near to the air bag. If wireless equipment is improperly installed and the air bag is activated, you may be seriously injured.
- ▶ Do not use a hand-held phone while driving.
- ▶ Do not use the phone in areas where its use is prohibited. (For example: aircraft).
- ▶ Do not expose the battery charger or adapter to direct sunlight or use it in places with high humidity, such as a bathroom.
- ▶ Never store your phone in temperatures less than -4°F or greater than 122°F.
- ▶ Do not use harsh chemicals (such as alcohol, benzene, thinners, etc.) or detergents to clean your phone. There is a risk of this causing a fire.
- ▶ Do not drop, strike, or shake your phone severely. Such actions may harm the internal circuit boards of the phone.
- ▶ Do not use your phone in high explosive areas as the phone may generate sparks.
- ▶ Do not damage the power cord by bending, twisting, pulling, or heating. Do not use the plug if it is loose as it may cause a fire or electric shock.
- ▶ Do not place any heavy items on the power cord. Do not allow the power cord to be crimped as it may cause fire or electric shock.
- ▶ Do not handle the phone with wet hands while it is being charged. It may cause an electric shock or seriously damage your phone.
- ▶ Do not disassemble the phone.
- ▶ Do not place or answer calls while charging the phone as it may short-circuit the phone and/or cause electric shock or fire.
- ▶ Only use the batteries, antennas, and chargers provided by LG. The warranty will not be applied to products provided by other suppliers.
- ▶ Only authorized personnel should service the phone and its accessories. Faulty installation or service may result in accidents and consequently invalidate the warranty.
- ▶ Do not hold or let the antenna come in contact with your body during a call.
- ▶ An emergency call can be made only within a service area. For an emergency call, make sure that you are within a service area and that the phone is turned on.

FCC RF Exposure Information

WARNING! Read this information before operating the phone. In August 1996, the Federal Communications (FCC) of the United States, with its action in Report and Order FCC 96-326, adopted an updated safety standard for human exposure to radio frequency (RF) electromagnetic energy emitted by FCC regulated transmitters. Those guidelines are consistent with the safety standard previously set by both U.S. and international standards bodies.

The design of this phone complies with the FCC guidelines and these international standards.

CAUTION

Use only the supplied and approved antenna. Use of unauthorized antennas or modifications could impair call quality, damage the phone, void your warranty and/or result in violation of FCC regulations. Do not use the phone with a damaged antenna. If a damaged antenna comes into contact with skin, a minor burn may result. Contact your local dealer for a replacement antenna.

Body-worn Operation

This device was tested for typical body-worn operations with the back of the phone kept 0.79 inches (2cm) between the user's body and the back of the phone. To comply with FCC RF exposure requirements, a minimum separation distance of 0.79 inches(2cm) must be maintained between the user's body and the back of the phone. Third-party belt-clips, holsters, and similar accessories containing metallic components should not be used. Body-worn accessories that cannot maintain 0.79 inches(2cm) separation distance between the user's body and the back of the phone, and have not been tested for typical body-worn operations may not comply with FCC RF exposure limits and should be avoided.

Vehicle Mounted External Antenna (optional, if available)

A minimum separation distance of 8 inches (20cm) must be maintained between the user/bystander and the vehicle mounted external antenna to satisfy FCC RF exposure requirements. For more information about RF exposure, visit the FCC website at www.fcc.gov

FCC Part 15 Class B Compliance

This device and its accessories comply with part 15 of FCC rules. Operation is subject to the following two conditions: (1) This device and its accessories may not cause harmful interference, and (2) this device and its accessories must accept any interference received, including interference that may cause undesired operation.

Cautions for Battery

- ▶ Do not disassemble.
- ▶ Do not short-circuit.
- ▶ Do not expose to high temperature: 60°C (140°F).]
- ▶ Do not incinerate.

Battery Disposal

- ▶ Please dispose of your battery properly or bring to your local wireless carrier for recycling.
- ▶ Do not dispose in fire or with hazardous or flammable materials.




Adapter (Charger) Cautions

- ▶ Using the wrong battery charger could damage your phone and void your warranty.
- ▶ The adapter or battery charger is intended for indoor use only.





Do not expose the adapter or battery charger to direct sunlight or use it in places with high humidity, such as the bathroom.

General Functions



Making a Call

1. Make sure your phone is powered on.
2. Enter a phone number including the area code. To edit a number on the display screen, simply press the Clear key to erase one digit at a time.
 - ▶ Press and hold the Clear key to erase the entire number and return to the idle screen.
3. Press the  [SEND] key or left soft  key to call the number.
4. When finished, press the  [PWR/END] key.


Making a Call by Send Key

2. Press the  [SEND] key, and the most recent incoming, outgoing and missed phone numbers will be displayed.
2. Use  ,  to highlight a number.
3. Press  [SEND] key to call the highlighted number.

Making International Calls


1. Press and hold the  key and the international access character '+' will appear.
2. Enter the country code, area code, and the phone number.
3. Press the  [SEND] key.

Ending a Call

When you have finished a call, press the  [PWR/END] key.

Making a Call From the Contact List

You can store names and phone numbers in the SIM, as well as in the phone memory from the Contacts menu. (Menu 2.2)

You can dial a number by simply selecting a name in the contacts and pressing the  [SEND] key.




General Functions

Adjusting the Volume

During a call, if you want to adjust the earpiece volume, use the up/down navigation key of the phone.

Answering a Call


When you receive a call, the phone rings or vibrates, and the LED blinks until the call is answered. If the caller can be identified, the caller's phone number (or name if stored in your Contacts) is displayed on the screen.

1. Press the  [SEND] key or the Left Soft Key **Accept** to answer an incoming call. If the answer mode has been set to Any Key (Menu 9.4.1), any key press will answer a call except for the  [PWR/END] Key or the Right Soft Key **Silent**.
2. End the call by closing the phone or pressing the  [PWR/END] key.

Notice

You can answer a call while using the Contacts or other menu features.

Vibrate Mode (Quick)

Vibrate Mode can be activated by pressing and holding down the  [Star] key.

Signal Strength

If you are inside a building, being near a window may give you better reception. You can see the strength of your signal by the signal indicator on your phone's display screen.

Entering Text

You can enter alphanumeric characters by using the phone's keypad. For example, storing names in the Address Book, writing a message, or creating scheduling events in the Calendar all require entering text.

The following text input methods are available in the phone.

General Functions

T9 Mode

This mode allows you to enter words with only one keystroke per letter. Each key on the keypad has more than one letter. The T9 mode automatically compares your keystrokes with an internal linguistic dictionary to determine the correct word, thus requiring far fewer keystrokes than the traditional ABC mode. You can set T9 input mode to On or Off by selecting Right Soft Key **Options**, then 3 **Set T9** from the text message window screen.


Notice

T9 Mode is set to Off by default.


ABC Mode

This mode allows you to enter letters by pressing the key labeled with the required letter once, twice, three or four times until the letter is displayed.


123 Mode (Numbers Mode)

Type numbers using one keystroke per number. To change to 123 mode in a text entry field, press  key until 123 mode is displayed.

Symbol Mode

This mode allows you to enter special characters. Press  [Star] Key to access Symbols.



Changing the Text Input Mode

Change the text input mode by pressing . You can check the current text input mode in the upper right corner of the screen.



Using the T9 Mode



The T9 predictive text input mode allows you to enter words easily with a minimum number of key presses. As you press each key, the phone begins to display the characters that it thinks you are typing based on a built-in dictionary. As new letters are added, the word changes to reflect the most likely candidate from the dictionary.



General Functions



1. When you are in the T9 predictive text input mode, start entering a word by pressing keys  to .


▶ The word changes as letters are typed - ignore what's on the screen until the word is typed completely.

▶ If the word is still incorrect after typing it completely, press the ,  keys to cycle through the other word options.

Example: To type the word "Cook", press 2, 6, 6, 5. Press ,  until the word "Cook" is displayed.




- ▶ If the desired word is missing from the word choices list, add it by using the ABC mode.
2. Enter the whole word before editing or deleting any keystrokes.
 3. Complete each word with a space by pressing the  key or the right navigation  key.

To delete letters, press the  [Clear] key. Press and hold down the  [Clear] key to erase the letters continuously.

To switch between English and Spanish while in T9 Mode, hold down the  [Star] Key for 2 seconds.

Using the ABC Mode

Use the alphanumeric keypad to enter your text.

1. Press the key labeled with the required letter:
 - ▶ Once for the first letter
 - ▶ Twice for the second letter
 - ▶ And so on
2. To insert a space, press the  key once. To delete letters, press the  [Clear] key. Press and hold down the  [Clear] key to erase the letters continuously.

Notice

Refer to the table below for more information on the characters available using the keys.

General Functions

Key	Characters in Display Order	
	Upper Case	Lower Case
1	., - ?!'@:1	., - ?!'@:1
2	ABC2	abc2
3	DEF3	def3
4	GHI4	ghi4
5	JKL5	jkl5
6	MNO6	mno6
7	PQRS7	pqr s7
8	TUV8	tuv8
9	WXYZ9	wxyz9
0	Space Key, 0 (Long press)	Space Key, 0 (Long press)



Using the 123 (Numbers) Mode

The 123 Mode enables you to enter numbers in a text message (a telephone number, for example) more quickly.

Press the keys corresponding to the required digits before manually switching back to the appropriate text entry mode.

Using the Symbol Mode

The Symbol Mode enables you to enter various symbols or special characters.

To enter a symbol, press the  key. Use  to highlight the desired symbol, and press Left Soft Key **OK**.

T9 dictionary

The T9 dictionary is a feature that allows the user to add any unique or personal words to the T9 standard language database. To add a word to the T9 Dictionary:

1. Type the word you wish to add while in T9 mode.
2. Select Left Soft Key **Spell**.
3. Type the word again, and press Left Soft Key **Save**.

In-Call Menu




Your phone provides a number of control functions that you can use during a call. To access these functions during a call, press the right soft key [**Options**].

During a Call


The menu displayed on the phone's screen during a call is different than the default main menu displayed when in idle screen, and the options are described below.

Making a Second Call


You can select a number you wish to dial from the Contacts to make a second call. Press the right soft key [**Options**] then select **Contact List**.


Use ,  to highlight the contact you wish to call, then press .

Swapping Between Two Calls




To switch between two calls, press the  [SEND] key.



Answering an Incoming Call

To answer an incoming call when the phone is ringing, simply press the  [SEND] key. The phone is also able to warn you of an incoming call while you are already on a call. A tone sounds in the earpiece, and the display will show that a second call is waiting. This feature, known as **Call Waiting**, is only available if your network supports it.

If Call Waiting is on, you can put the first call on hold and answer the second call, by pressing the  [SEND] key.

Rejecting an Incoming Call

You can reject an incoming call by pressing , or by pressing  **Silent**, then  **Reject**.


During a call, you can reject an incoming call by pressing , or  **Reject**.

In-Call Menu

Muting the Microphone

You can mute the microphone during a call by pressing the left soft key [**Mute**]. The phone can be unmuted by pressing the left soft key [**Unmute**]. When the phone is muted, the caller cannot hear you, but you can still hear the caller.

Using the Speakerphone

You can use the integrated Speakerphone during a call by pressing the right soft key [Options] then select Speaker On. The speakerphone indicator [] will display on the display screen. The loudspeaker is automatically deactivated when you end the call.

Warning



Because of the higher volume level, don't place the phone too close your ear while the speakerphone is enabled.

Conference Calls

The conference service provides you with the ability to have a simultaneous conversation with more than one caller. The conference call feature can be used only if your network service provider supports this feature. The conference call can only be set up when you have one call active and one call on hold, meaning both calls must have been answered. Once a conference call is set up, calls may be added, disconnected or separated (that is, removed from the conference call but still connected to you) by the person who set up the conference call. These options are all available from the In-Call menu. The maximum number of callers in a conference call is five. Once started, you are in control of the conference call, and only you can add calls to the conference call.

In-Call Menu


Making a Second Call

You can make a second call while currently on a call simply by entering the second number and pressing the  [SEND] key. When the second call is connected, the first call is automatically placed on hold. You can swap between calls, by pressing the  [SEND] key.

Setting Up a Conference Call

To set up a conference call, place one call on hold, conference in the second active call by pressing the right soft key and select the Join Calls sub menu option from the Conference Call menu.

Activate the Conference Call on Hold

To activate a conference call on hold, press the  [SEND] key.


Adding Calls to the Conference Call

To add a call to an existing conference call, press the right soft key, and then select the Join Calls sub menu from the Conference Call option.

Private Call in a Conference Call

To have a private call with one caller from a conference call, press the right soft key and select the Private Menu from the Conference Call option. When the numbers of the callers are displayed, select the one you wish to speak in private.

Ending a Conference Call

Currently active conference call can be disconnected by pressing the  [PWR/END] key.

Menu Tree

The following illustration shows the available menu structure and indicates the:

- ▶ Number assigned to each menu option.
- ▶ Page where you can find the feature description.

1. Prepaid	2. Contacts
1.1 Add Airtime	2.1 Contact List
1.2 Buy Airtime	2.2 New Contact
1.3 My Phone Number	2.3 Speed Dial List
1.4 Airtime Info.	2.4 Caller Groups
1.5 Airtime Display	2.5 Copy All Contacts
1.6 Serial Number	2.6 Delete All Contacts
1.7 SIM Number	2.7 Information
1.8 Code Entry Mode	3. Games
	4. Alarm Clock

Menu Tree

5. Messaging
5.1 New Message
5.2 Inbox
5.3 Drafts
5.4 Outbox
5.5 Sent
5.6 Voicemail
5.7 Templates
5.8 Message Settings
5.9 Check Memory
6. Recent Calls
6.1 Missed Calls
6.2 Dialed Calls
6.3 Received Calls
6.4 All Calls
6.5 Call Duration

7. My Stuff
7.1 Games
7.2 Audio & Ringtones
7.3 Graphics
8. Tools
8.1 Alarm Clock
8.2 Calendar
8.3 Record Voice
8.4 Notepad
8.5 Calculator
8.6 Tip Calculator
8.7 World Clock
8.8 Stop Watch
8.9 Unit Converter
8.0 SIM App.

Menu Tree

9. Settings
9.1 Audio & Ringtones
9.2 Display
9.3 Date & Time
9.4 Call
9.5 Security
9.6 Power Save
9.7 Phone Information
9.8 Reset Default

Prepaid

With prepaid service, you buy wireless network services in advance. Your phone works the same way it did before, with some additional features. You can check your prepaid balance, add money to your account, and call customer service.

Prepaid service may not be available from your wireless service provider. Contact your service provider for availability and more information.

In the Prepaid menu, you can activate and deactivate prepaid service, replenish your prepaid credits, and provide other information requested by the prepaid service provider.

Add Airtime **Menu 1.1**

Add Airtime allows you to start an over-the-air request for additional airtime.

Buy Airtime **Menu 1.2**

Buy Airtime allows you to start an over-the-air request to purchase additional airtime.

My Phone Number **Menu 1.3**

My Phone Number displays the SIM's own number.

Airtime Info. **Menu 1.4**

Airtime Info displays the amount of airtime currently available on your phone, and the due date of your next payment.

Airtime Display **Menu 1.5**

Airtime Display allows your phone to display your airtime information on the idle screen. This feature can be turned on or off.

Serial Number **Menu 1.6**

Serial Number displays the Phone's Serial Number.

SIM Number **Menu 1.7**

SIM Number displays the SIM Card's Serial Number.

Code Entry Mode **Menu 1.8**

Code Entry Mode will allow the phone to accept Service Provider - Related codes in order to add airtime, modify specific data, and troubleshoot any issues with the phone. While using Code Entry Mode, you cannot receive incoming calls or use event alerts.

Contacts

Contact List Menu 2.1

This menu allows you to save and manage contact address information. The Contact List functions allow you to add a new address or search saved contact addresses by name.

New Contact Menu 2.2

This menu allows you to add a new contact address. You can input contact address information including name, phone numbers, email addresses, group information items, and memos.

Speed Dial List Menu 2.3

This menu allows you to configure the speed dial numbers. You can select a number as a speed dial from 2 to 9. You can configure speed dial numbers for any of the 8 numbers for a specific contact address.

Caller Groups Menu 2.4

1. Every Group list will be displayed:
Family, VIP, Friends, Colleague, Group 1, Group 2, No Group.
2. Select the Group name that you want to manage by pressing the right soft key [Options].
3. You will see the following submenus under the predefined groups except for the **No Group** group.
 - **Group Ringtone:** Allows you to select the ringtone to be used when you receive a voice phone call from a person in the group.
 - **Group Icon:** Allows you to select the graphic icon to be displayed on the group of Group List.
 - **Add Member:** Allows you to add the member to the group.
 - **Remove Member:** Allows you to delete the member in the group.
 - **Rename:** Allows you to assign a name to the group.

Contacts

Copy All Contacts Menu 2.5

This menu allows you to copy all of the information from your SIM (e.g. name, phone number, etc.) to your phone, and vice versa. If a name is duplicated during the copying process, the information is also duplicated.

- ▶ **SIM to Phone:** You can copy the entry from the SIM card to the phone memory.
- ▶ **Phone to SIM:** You can copy the entry from the phone memory to the SIM card (not all the data will be copied).

Delete All Contacts Menu 2.6

You can delete all entries in the **SIM** and the **Phone**.

Information Menu 2.7

Check Memory (Menu 2.7.1)

You can check how many names and numbers are stored in the Address Book (SIM card and phone memories).

My Numbers (Menu 2.7.2)


Allows you to display your phone number in the SIM card.

Games

You can play the games that are pre-installed on the phone.

Alarm Clock

Set the alarm to ring at a specific time. In the **Set Alarm Clock** menu, the following options are available:

1. Navigate to the Alarm Clock menu.
2. Select [**On**] by pressing the right/left navigation keys.
3. If you want to set the time for activating the alarm, press the down navigation key.
4. Enter the desired time, and press .
5. Set the repeat frequency. The following options are available:
 - **Once:** The alarm rings only once and is then deactivated.
 - **Daily:** The alarm rings every day at the set time.
 - **Mon ~ Fri:** The alarm rings every weekday (Monday - Friday) at the set time.
 - **Sat ~ Sun:** The alarm rings every Saturday and Sunday at the set time.

6. Set the alarm melody by using the right/left navigation keys.

7. Press the left soft key [**Save**].

Off: Cancel the alarm setting.

Notice

If this option is set to On, the alarm will ring at the specified time, even when the phone is switched off. To stop the alarm when it rings, press the right soft key[Quit].

Messaging

New Message Menu 5.1

You can write and edit text messages of up to 913 characters.


1. Type in a message using key presses. For details on how to enter text, refer to page 19 (**Entering Text**).
2. After completing the message select the desired option by pressing the right soft key [**Options**].

The following options are available.

▶ **Insert**

- **Symbol:** You can insert symbols ranging from sentence notes to emoticons. Use the navigation keys to highlight a symbol, then press OK or the left soft key **OK**.
- **Text Template:** You can easily insert frequently used sentences in the text message.
- **Contact:** You can browse one of your contacts and place their information within the body of the text message.

- **Business Card:** Input your own business card created in (Menu 5.7.2). For further details, see page 40.

- ▶ **Save to Drafts:** Saves the selected message as a draft.
- ▶ **Set T9:** You can turn T9 Mode on or off.
- ▶ **Clear Text:** Deletes the written message.
- ▶ **Cancel:** Exit the text editor.
- ▶ **Left Soft Key**  **SEND:** Enter the recipient's phone number or select the number from your contact list.


Messaging

Inbox

Menu 5.2

You will be alerted when you receive a message. They will be stored in the Inbox.

In the Inbox, you can identify each message by icons.

Press  **Options**. Choose from the following options:

- ▶ **Delete:** Deletes the selected message from the Inbox.
- ▶ **Reply:** Allows you to reply to the sender of the selected message.
- ▶ **Forward:** Forwards a received message to other recipients. After recipients are entered, the message can be forwarded.
- ▶ **Return call:** Call back the sender.
- ▶ **Delete All Read:** Deletes all messages that you have read in the list.
- ▶ **Delete All Unread:** Deletes all the messages that you have not read.
- ▶ **Delete All:** Deletes all messages in the list.

- ▶ **Left Soft Key  View:** You can view the received messages.


Press the left soft key [**Reply**]:

Allows you to reply to the sender of the selected message.



Drafts


Menu 5.3

You can view the messages you have saved as drafts. The draft messages are listed with the dates and times of when they were saved.

Press  **Options**. Choose from the following options:

- ▶ **Delete:** Deletes the highlighted message.
- ▶ **Delete all:** Deletes all messages in the folder.

Press  **View**. While viewing the message, press  **Edit** to edit the message.

When you are finished editing the message, press  **Send** to send the message to a recipient.

Messaging

Outbox

Menu 5.4

If the message transmission fails, you can save the message in the Outbox.

The following [Options] are available in the Outbox list.

- ▶ **Delete:** Deletes the message you choose.
- ▶ **Delete All:** Deletes all messages in the folder.


Press the left soft key [View]

- ▶ **View:** View the message you choose.
- ▶ **Edit:** Allows you to edit the selected message.

Sent

Menu 5.5


This menu allows you to save the messages you have sent successfully. You can also view the delivery status.


Press  **Options.** Choose from the following options:

- ▶ **Delete:** Deletes the selected message from the Sent list.
- ▶ **Forward:** Forwards the current message to other recipients.

- ▶ **Delete all:** Deletes all messages in the folder.

- ▶ **Left Soft Key  View:** View the selected message from the Sent list.

While viewing the selected sent message, press  **Options.** Select **Delete** to delete the message.


Press  **Send** to send the message to a recipient.


Voicemail

Menu 5.6

This menu provides you with a quick way of accessing your voice mailbox (if provided by your network).

Before using this feature, you must enter the voice server number obtained from your service provider.

This may already be available; to check the voicemail, press and hold the  key.

When new voicemail is received, the symbol  will be displayed on the screen.

Messaging

Note

Please check with your network service provider for details of their service in order to configure the phone accordingly.


Templates

Menu 5.7

There are 6 predefined messages in the list. You can view and edit the template messages or create new messages.

Text Templates (Menu 5.7.1)

- **Please call me back**
- **I'm late. I will be there at**
- **Where are you now?**
- **I'm on the way.**
- **Urgent! Please contact.**
- **I love you**

Press  **Options**. Choose from the following options:

- ▶ **Edit:** Allows you to write a new message or edit the selected template message.
- ▶ **Send Via Text Message:** Allows you to send the selected template message via SMS.
- ▶ **Delete:** Allows you to delete the selected template message.
- ▶ **New Template:** Use this to create a new template.
- ▶ **Delete All:** Deletes all messages in the folder.
- ▶ **Left Soft Key  View:** Allows you to view the the selected template message.

Messaging

Business Card (Menu 5.7.2)

This feature allows you to create your own name card. You can key in the Name, Mobile number, Office number, Fax number and E-mail address.

- ▶ **Send Via Text Message:** Sends the selected name card by SMS.
- ▶ **Delete:** Allows you to delete the selected name card.

Press the left soft key [Edit]

- ▶ **Edit:** Allows you to write a new message or edit the selected name card.

Message settings Menu 5.8

Text Message (Menu 5.8.1)

- ▶ **Message Center Number:** If you want to send a text message, you can receive the address of the SMS center through this menu.
- ▶ **Email Gateway:** You can send the text message to an Email Address via this gateway.

- ▶ **Subject:** You can enter the SMS Subject when this menu is on.

Voicemail Number (Menu 5.8.2)

Allows you to change the voicemail server number, if necessary.

Note

Voice Mail is a network feature. Please contact your service provider for further details.

Check Memory Menu 5.9

You can check the current used and available text message memory.

Recent Calls

You can check the record of missed, received, and dialed calls only if the network supports the Calling Line Identification (CLI) within the service area.

The number and name (if available) are displayed together with the date and time of the call. You can also view call times.

Missed Calls Menu 6.1

- View the number, if available, and call it or save it in the Contacts
- Enter a new name for the number and save both in the Contacts
- Send a message to this number
- Delete the call from the list

Dialed Calls Menu 6.2

- View the number, if available, and call it or save it in the Contacts
- Enter new name for the number and save both in the Contacts
- Send a message to this number

- Delete the call from the list

Received Calls Menu 6.3

- View the number, if available, and call it or save it in the Contacts
- Enter a new name for the number and save both in the Contacts
- Send a message to this number
- Delete the call from the list

All Calls Menu 6.4

Allows you to view all of missed, received, and dialed call records.

Call Duration Menu 6.5

This allows you to view the duration of the incoming and outgoing calls. You can also reset the call times. The following timers are available:

Last Call (Menu 6.5.1)

Duration of the last call.

Recent Calls

Dialed Calls (Menu 6.5.2)

Duration of the outgoing calls.

Received Calls (Menu 6.5.3)

Duration of the incoming calls.

All Calls (Menu 6.5.4)

Total duration of all incoming and outgoing calls since the timer was last reset.

Games

Menu 7.1

You can play the games that are pre-installed on the phone.

Audio & Ringtones Menu 7.2

The right soft key [**Options**] will bring up the following options.

- ▶ **Set as Ringtone:** Allows you to set the selected audio file as your phone's ringtone.

Note

Sounds supplied as default can only be used under the Set as Ringtone mode.

- ▶ **Left Soft Key  View:** You can view the currently selected image.

Note

Pictures supplied as default can only be used under the Set as Wallpaper mode.

Graphics

Menu 7.3

The right soft key [**Options**] will bring up the following options.

- ▶ **Set as Wallpaper:** Currently selected picture can be set as a Wallpaper.
- ▶ **List/Icon View:** You can configure the graphic files to List style or Icon style.

Tools





Alarm Clock Menu 8.1


For further details, see page 35.

Calendar Menu 8.2

When you enter this menu a calendar will be displayed. The square cursor is used to locate a particular day. An orange colored date indicates schedule entries for that day. This function helps remind you of entries you have input in the calendar. The phone will sound an alarm tone if it has been set for a specific schedule item.

For changing the day, month, and year.

Key	Description
up/down navigation key	Weekly
left/right navigation key	Daily
 key /  key	Yearly
 key /  key	Monthly

- ▶ **Left Soft Key  View:** Allows you to view the selected schedule.
- ▶ **Delete:** Allows you to delete the selected schedule entry.

- ▶ **New Schedule:** You can enter a maximum of 30 characters and create up to 30 notes.
- ▶ **Edit:** Allows you to edit the selected schedule.
- ▶ **Calendar:** Allows you to view the calendar.
- ▶ **Scheduler Tone:** The phone can sound an alarm tone when the scheduled date for an event has been reached.
- ▶ **All Schedules:** Shows the notes that are set for all days. Use the up/down navigation keys to browse through the note lists. You can view additional options by pressing the right soft key [**Options**].
- ▶ **Go to Date:** Allows you to jump to a specific date.
- ▶ **Delete Old:** Delete past schedule events.
- ▶ **Delete All:** Delete all schedule entries. You are asked to confirm your action.

Record Voice Menu 8.3

Allows you to record a memo. You can record up to 3 voice messages with each message up to 30 seconds.

You can use the Voice Memo feature to:

- Play the recorded voice memos
 - Delete one or all voice memos
1. Once recording is started, the message '**Recording...**' and the remaining time is displayed.

Note

If all memo locations are full, you must delete an old memo before recording a new one.

2. If you want to finish recording, press the left soft key [**Save**].
- ▶ **Play:** Allows you to play back all memos recorded, starting with the most recent memo. The screen displays the date and time when the memo was recorded.

- ▶ **Delete:** Allows you to delete a specific memo.
- ▶ **Record New:** Allows you to record a memo.
- ▶ **Delete All:** Allows you to delete all memos.

Notepad Menu 8.4

You can create up to a maximum of 20 memos.

1. Select a memo pad to edit.
2. Press the left soft key [New] to create a new memo.
3. Input the memo and press the left soft key [Save] to save.

Calculator Menu 8.5


Using this feature, you can use the phone as a calculator. The calculator provides the basic arithmetic functions: addition, subtraction, multiplication and division.


Tools

Using the Calculator

1. Enter the first number using the numeric keys.
2. Use the navigation keys to select a sign for calculation.

Note

To input a decimal point, press the  key.

3. To calculate the result, press **OK** key.
4. To erase your calculation, press  **Reset**.

Tip Calculator Menu 8.6

Allows you to quickly and easily estimate the tip and total amount of a bill by inputting the bill amount before tip, the tip percentage, and dividing it by the number of people paying.

World Clock Menu 8.7

Allows you to check the current Greenwich Mean Time(GMT) and major cities around the world, using the left/right navigation keys.

The screen shows the city name, current date and time.

To select the time zone in which you are located, proceed as follows:

1. Select the city corresponding to your time zone by pressing the left/right navigation keys one or more times. The local date and time are displayed.
2. If you want to set the selected city's time to your phone, press the left soft key [**Set**].
3. If you want to set Daylight Savings, press the right soft key [**DST**].

Note

The time zone setting of each city in World time menu may be affected by network condition.

Stop Watch Menu 8.8

1. Press **[Start]** to start the timer, and record lap times by pressing **[Lap]**.
2. Press **[Stop]** to ascertain the record of lap time.
3. Press **[Reset]** to set the timer back to 0.


Unit Converter Menu 8.9

This feature allows you to convert units of measurement.

There are 4 types of units of measurement that can be converted:

Length, Surface, Weight and Volume.

1. You can select one of four unit types by pressing the left soft key **[Unit]**.
2. Select the standard value by using the left/right navigation keys.
3. Select the unit you want to convert by pressing the up/down navigation keys.


4. You can check the converted value for the unit you want. Also, you can input a decimal number by pressing the  key.

SIM App. Menu 8.0

This feature is dependent on your service provider. Please contact the customer call center of your service provider for more information.

Settings

Audio & Ringtones Menu 9.1

Pressing and holding  while on the idle screen will switch between Normal mode and Vibrate mode.

Ringtones (Menu 9.1.1)

Shows and plays ringtones.

Volume (Menu 9.1.2)

This menu controls Ringtone, Key Tone, Earpiece and Headset volume. There are 5 volume levels available.

Ring Alert Type (Menu 9.1.3)

Supports 3 ring alert types. **Ring, Ring and Vibrate**, and **Vibrate then Ring**.

Message Alert Tones

(Menu 9.1.4)

Allows you to select an alert tone which is played when a message is received.

Increasing Ringtone (Menu 9.1.5)

Allows you to set an Increasing Ringtone which will play when receiving an incoming call. You can set this feature to On or Off.

Power On/Off Tones (Menu 9.1.6)

Allows you to set a Power On/Off tone. You can set this feature to On or Off.

Display Menu 9.2

Wallpapers (Menu 9.2.1)

This option allows you to change the background image (wallpaper) to be displayed in idle mode.

1. Scroll through the list by pressing the navigation keys.

You have various preset images available. You can also select any images downloaded from the Internet.

2. Press the left soft key **[View]** when the desired image is highlighted.

3. Press the left soft key **[Set]**, then the selected image will be displayed in idle mode.

Backlight Timer (Menu 9.2.2)

This option allows you to set the duration of the Display and Keypad backlighting.

Contrast (Menu 9.2.3)

This option allows you to adjust the contrast of the LCD screen by pressing the navigation key.

Languages (Menu 9.2.4)

This option allows you to change the display text language on your phone. You can also change the Input Language.

Date & Time Menu 9.3

Date Format (Menu 9.3.1)

YYYY/MM/DD(year/month/day)

DD/MM/YYYY(day/month/year)

MM/DD/YYYY(month/day/year)

Time Format (Menu 9.3.2)

24 Hours/12 Hours

Call Menu 9.4

Call Forwarding (Menu 9.4.1)

When this network service is activated, you can direct your incoming calls to another number, for example, to your voice mailbox number. For details, contact your service provider. Select one of the divert options, for example, select **If busy** to divert voice calls when your number is busy or when you reject incoming calls.

The following options are available:

- ▶ **All Voice Calls:** Diverts voice calls unconditionally.
- ▶ **If Busy:** Diverts voice calls when the phone is in use.
- ▶ **If No Reply:** Diverts voice calls which you do not answer.
- ▶ **If Out Of Reach:** Divert voice calls when the phone is turned off or out of the coverage area.
- ▶ **Cancel All:** Cancels all Call Forwarding settings.



Settings

Note

If this network service is not activated, this menu option will not appear on your phone. Contact your service provider for details.

Answer Mode (Menu 9.4.2)

This allows you to determine how you would like to answer your phone.

- ▶ **Flip Open:** When the phone rings, you can answer a call simply by opening the flip.
- ▶ **Any Key:** You can answer an incoming call by pressing any key, except the  [PWR/END] key or the right soft key **Silent/Reject**.
- ▶ **SEND Key Only:** You can only answer an incoming call by pressing the  [SEND] key.

Send My Number (Menu 9.4.3)

This network service allows you to set your phone number to be displayed **On** or hidden **Off** from the person to whom you are calling. You can select **Set by Network** if you prefer to have

different settings for different service provider.


Call Waiting (Menu 9.4.4)

The network will notify you of a new incoming call while you have a call in progress. Select **Activate** to request the network to activate call waiting, **Cancel** to request the network to deactivate call waiting, or **View Status**, to check if the function is active or not.

Minute Minder (Menu 9.4.5)

This option allows you to specify whether the phone must beep every minute during an outgoing call to keep you informed of the length of the call.

Auto Redial (Menu 9.4.6)

When set to On, your phone redials the number you are trying to call up to 10 times after you hear a quick busy signal. Press  [PWR/END] key to stop the call attempts.

This feature attempts to redial numbers that are busy due to the wireless network. It does not redial numbers to a busy party.

TTY (Menu 9.4.7)

Allows you to attach a TTY device enabling you to communicate with parties also using a TTY device. A phone with TTY support is able to translate typed characters to voice. Voice can also be translated into characters and then displayed on the TTY.

Send DTMF Tones (Menu 9.4.8)

You can send the DTMF (dual tone multi-frequency) tones of the number on the display during a call.

This option is helpful for entering a password or account number when you call an automated system, like a banking service.

Security

Menu 9.5

Various codes and passwords are used to protect the features of your phone. They are described in the following sections (see page 17)

PIN Code Request (Menu 9.5.1)

When the PIN code request feature is set to 'Enable', you must enter your PIN each time you switch the phone on. Consequently, any person who does not have your PIN cannot use your phone without your approval.

Note

Before disabling the PIN code request feature, you must enter your PIN.

The following options are available:

- ▶ **Enable:** You must enter the PIN each time the phone is switched on.
- ▶ **Disable:** The phone connects directly to the network when you switch it on.

Settings

Fixed Dial Number (Menu 9.5.2)

Allows you to restrict your outgoing calls to selected phone numbers, if this function is supported by your SIM card. The PIN2 code is required.

The following options are available:

- ▶ **Enable:** You can only call phone numbers stored in the phonebook. You must enter your PIN2.
- ▶ **Disable:** You can call any number.
- ▶ **Number list:** You can view the number list saved as fixed dial number.

Note

Not all SIM cards have a PIN2. If your SIM card does not, this menu option is not displayed.

Change Codes (Menu 9.5.3)

The Change codes feature allows you to change your current password to a new one. You must enter the current password before you can specify a new one.

You can change the access codes for:
Security Code, PIN1 Code, PIN2 Code

Note

PIN: Personal Identification Number.

Power Save Menu 9.6

You can save the power when you don't use the phone.

Phone Information Menu 9.7

This menu is used to view My Number, Manufacturer and Model Name, etc.

Reset Default Menu 9.8

You can easily reset your phone to its default configuration. To do so:

1. Select the Reset Settings menu option.
2. Enter the 8-digit phone password.

Note

The password is preset to **00000000**.

Q&A

Please check to see if any problems you have encountered with the phone are described in this section before taking the phone in for service or calling a service engineer.

Q How do I view the list of outgoing calls, incoming calls and missed calls?

A Press the  [SEND] key.

Q How do I view all numbers stored in memory?

A Press the down navigation key.

Q Why is the connection inconsistent or not audible in certain areas?

A When frequency environment is unstable in a certain area, connection may be inconsistent and not audible. Relocate to another area and try again.

Q Why is the connection not consistent and abruptly disconnects, even when established?

A When frequency is unstable or weak or if there are too many users, connection may be cut off even after it was established. Please try again later or attempt after relocating to other areas.

Q Why does the LCD not turn on?

A Remove the battery and turn on the power after placing it back on. If there is no change, fully charge the battery and try again.

Q Why is there an echo when a connection is made with certain telephones in a certain area?

A This is called the "Echo Phenomenon", which occurs if connection volume is too high, or by

special properties (semi electronic telephone exchange) of the equipment on the other end.

Q Why does the phone heat up?

A The phone may get hot when there is a very long call duration or when games are played for a long time. This has no effect upon the life of the product or performance.

Q Why does the battery life get shorter in standby mode?

A The battery is worn out. As time passes, the battery life gradually becomes shorter. If the battery lasts about half the amount of time as when first purchased, it's time to purchase a new battery.

Q Why does the battery run out so quickly during normal use?

A It is due to the user's environment, a large number of calls, or a weak signal.

Q Why is no number dialed when you recall a Contacts entry?

A Check that the number has been stored correctly by using the Contact List feature. Re-store them, if necessary.

Q I cannot find the lock, PIN, or PUK code. What is my password?

A The default lock code is '0000'. If you forget or lose the lock code, contact your phone dealer. If you forget or lose a PIN or PUK code, or if you have not received such a code, contact your network service provider.

Hearing Aid Compatibility (HAC) with Mobile Phones

When some mobile phones are used near some hearing devices (hearing aids and cochlear implants), users may detect a buzzing, humming, or whining noise. Some hearing devices are more immune than others to this interference noise, and phones also vary in the amount of interference they generate. The wireless telephone industry has developed ratings for some of their mobile phones, to assist hearing device users in finding phones that may be compatible with their hearing devices. Not all phones have been rated. Phones that are rated have the rating on their box or a label on the box. The ratings are not guarantees. Results will vary depending on the user's hearing device and hearing loss. If your hearing device happens to be vulnerable to interference, you may not be able to use a rated phone successfully. Trying out the phone with your hearing device is the best way to evaluate it for your personal needs.

M-Ratings: Phones rated M3 or M4 meet FCC requirements and are likely to generate less interference to hearing devices than phones that are not labeled. M4 is the better/higher of the two ratings.

T-Ratings: Phones rated T3 or T4 meet FCC requirements and are likely to be more usable with a hearing device's telecoil ("T Switch" or "Telephone Switch") than unrated phones. T4 is the better/higher of the two ratings. (Note that not all hearing devices have telecoils in them.)

Hearing devices may also be measured for immunity to this type of interference. Your hearing device manufacturer or hearing health professional may help you find results for your hearing device. The more immune your hearing aid is, the less likely you are to experience interference noise from mobile phones.

To ensure that the Hearing Aid Compatibility rating for your phone is maintained, secondary transmitters such as Bluetooth and WLAN components must be disabled during a call.