




ZigBee

4Keys Remote Controller

Remote Control & Connected Bulb

User Guide

6A-RC-ZAB-H0




Working frequency range:2400-2483.5MHz

Max.RF output power:8dBm

1. Commissioning(Pairing)Light(s)

Follow instruction bellow to commission new smart light(s).In case you buy new smart light(s) or the current smart light(s) are set to Factory Default.



2. Unpairing light(s)

Press "ON/OFF" button first, and press "Dim up" button together for 3 seconds that you want the light(s) to unpair. When the light(s) blink thrice, means that the operation is successful.

Remote controller gets close to light about 10cm distance for touch link.



Note: After remove the light(s) from the Remote Controller, user need to reopen this light(s) if wants to touch link the Remote Controller again.

3. ON/OFF

Every press turns the light ON or OFF.

4. Dimming

Dimming: Dim the light(s) which is touched link the Remote Controller.

Up("+")/Down("-")button:

Every press: dims the lumen step by step.

Keep pressing: dims until max./min. in one time.



5. Quick scene

Long press " quick scene " button to memory the lumen that you want,so you can press it to launch the scene at the next time.When bulb blink once,it means remote memory successfully.

Remote Controller will remove the lumen memory after memory other lumen.




6. Reset remote controller to factory default

Press pin hole for 3 seconds. After relax the pin hole,the remote controller will be reset to factory default and search ZigBee which can be added automatically.If user press anyother button on Remote Controller,searching will stop.Remote Controller will reset again if wants to added to the gateway.

Resetting Bulb(s)

1. Restored to factory default by switch



Bulb(s) could be restored to factory default status either by remote controller or by wall switch. Factory default by remote controller is same as un-pairing Bulb(s), while by wall switch is as following.

Warning

1. This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference.

(2) This device must accept any interference received, including interference that

may cause undesired operation.

Note: The grantee is not responsible for any changes or modifications not expressly approved by the party responsible for compliance. Such modifications could void the user' s authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help

RF Exposure Statement

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance of 5 mm between the radiator and your body.