

Wireless Driveway Alert System


Model 615

FEATURES

- Including PIR Sensor & Receiver
- Wireless RF Transmission Up to 400 Feet
- PIR Sensor Detect Motion and Trigger Receiver Turn on Chime
- Sound Hi/Low Switch
- Chime On/Off Select Switch
- PIR Sensor 9V Battery (not included) Operation
- Receiver 3 C Size Batteries (not included)
- Compatible with DC Adaptor (not included) for Receiver Unit
- Battery Low Indicator LED for PIR Sensor and Receiver
- Trigger Flash LED
- No Wiring, Easy to Installs
- Water Resistant for PIR Sensor


OPERATION

1. Remove the screw of Pir sensor unit and Receiver unit from battery compartment cover, screw it off to remover the cover.(Fig.1)



(Fig. 1)

2. Install an alkaline 9V batteries (not included) for pir sensor, 3x1.5 "C-size" batteries for receiver to the battery compartment make sure install with correct polarity. (Fig. 2)



(Fig. 2)

3. Hang the pir sensor at the entrance of your driveway (such as on a mailbox, on a tree or on a ground stake). You may also place the pir sensor on your garage, near the front entrance or rear door. Any movement nearby will transmit a signal to the receiver chime unit triggering it to signal the chime.(Fig.3)




Fig.3



4. Please ensure to place the pir sensor unit at least three feet high above the ground.

5. On/Off switch of receiver

Turn the switch to ON position, now the unit is standby to working mode, when pir sensor detected trigger, will sound door chime and the led will light up. You can turn HI/LOW switch to select sound volume.

6. To test the pir sensor unit detection area

After selecting a location for installation of the unit you can turn the switch to on and wait for 30 seconds for "WARM-UP". Then you try walking in front of the unit. When the unit detects motion, the chime will sound. There will be no chime sound if you walk beyond the detection range. By testing the detection range, you can adjust the location the sensor angle for best coverage. Turn the chime off after your test.

7. Battery low indicator

A) Pir sensor

When pir sensor batteries goes low, the LED will lighting to indicate the low battery. Then replace the new battery.

B) Receiver

When receiver batteries goes low, the LED of the middle will lighting to indicate the low battery. Then replace the new battery.

8. Power adapter (not included) for receiver unit with output 6V DC, 200mA female plug, center (+) positive can be applied to the DC jack for long time use.

CAUTION:

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. Changes of modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.