

lenovo

IdeaCentre Horizon 2 27 All-In-One PC
Hardware Maintenance Manual

lenovo® **FOR**
THOSE
WHO DO.™

Machine Types: F0AQ



IdeaCentre Horizon 2 27 All-In-One PC Hardware Maintenance Manual

Machine Types: F0AQ

Second Edition (May 2014)27th

© Copyright Lenovo 2014.

LIMITED AND RESTRICTED RIGHTS NOTICE: If data or software are delivered pursuant a General Services Administration "GSA" contract, use, reproduction, or disclosure is subject to restrictions set forth in Contract No. GS-35F-05925

Contents

Chapter 1. About this manual	1	Power Supply Problems	19
Important Safety Information	1	POST error codes	20
Chapter 2. Safety information	3	Undetermined problems	20
General safety	3	Chapter 7. Replacing hardware	21
Electrical safety	3	General information	21
Safety inspection guide	5	Replacing the keyboard and mouse	22
Handling electrostatic discharge-sensitive devices	5	Removing the rear cover	22
Grounding requirements	6	Replacing the battery	24
Safety notices	6	Replacing a memory module	25
Chapter 3. General information	9	Replacing the Wi-Fi card	26
Specifications	9	Replacing the hard disk drive	27
Chapter 4. General Checkout	11	Replacing the fan module	29
Chapter 5. Using the Setup Utility.	13	Replacing the heat-sink modules	29
Starting the Lenovo BIOS Setup Utility program	13	Replacing the speaker system	30
Viewing and changing settings	13	Replacing the I/O board	31
Using passwords.	13	Replacing the power switch board	32
Enabling or disabling a device	15	Replacing the motherboard.	33
Selecting a startup device	16	Replacing the camera	34
Exiting the Lenovo BIOS Setup Utility program	17	Replacing the LED panel module	35
Chapter 6. Symptom-to-FRU Index	19	Chapter 8. FRU lists	37
Hard disk drive boot error	19	Chapter 9. General information	43
		Additional Service Information	43

Chapter 1. About this manual

This manual contains service and reference information for IdeaCentre Horizon 2 27 All-In-One computers listed on the cover. It is intended only for trained servicers who are familiar with Lenovo computer products.

Before servicing a Lenovo product, be sure to read the Safety Information.

The description of the TV-tuner card in this manual applies only to computers with a TV-tuner card installed. It does not apply to computers without a TV-tuner card.

Important Safety Information

Be sure to read all CAUTION and DANGER sections in this manual before following any of the instructions.

Veillez lire toutes les consignes de type DANGER et ATTENTION du présent document avant d'exécuter les instructions.

Lesen Sie unbedingt alle Hinweise vom Typ "ACHTUNG" oder "VORSICHT" in dieser Dokumentation, bevor Sie irgendwelche Vorgänge durchführen

Leggere le istruzioni introdotte da ATTENZIONE e PERICOLO presenti nel manuale prima di eseguire una qualsiasi delle istruzioni

Certifique-se de ler todas as instruções de cuidado e perigo neste manual antes de executar qualquer uma das instruções

Es importante que lea todas las declaraciones de precaución y de peligro de este manual antes de seguir las instrucciones.

执行任何说明之前，请确保已阅读本书中的所有警告和危险声明。

執行任何指示前，請確實閱讀本書中的所有警告及危險聲明。

Chapter 2. Safety information

This chapter contains the safety information that you need to be familiar with before servicing a computer.

General safety

Follow these rules to ensure general safety:

- Keep the areas around the computer clear and clean during and after maintenance.
- When lifting any heavy object:
 1. Ensure you can stand safely without slipping.
 2. Distribute the weight of the object equally across both feet.
 3. Lift slowly. Never move suddenly or twist when you attempt to lift.
 4. Lift by standing or by pushing up with your leg muscles; this action removes the strain from the muscles in your back.
Do not attempt to lift any objects that weigh more than 16 kg (35 lbs.) or objects that you think are too heavy for you.
- Do not perform any action that would create a hazard for the customer, or would make the computer unsafe.
- Before you start the computer, ensure that other service representatives and customer personnel are not in a position that would create a hazard for them.
- Place removed covers and other parts in a safe place, away from all personnel, while you are servicing the computer.
- Keep your tool case away from areas that people may walk through to ensure no-one trips over it.
- Do not wear loose clothing that can be trapped in the moving parts of a machine. Ensure that your sleeves are fastened or rolled up above your elbows. If your hair is long, tie or fasten it back.
- Insert the ends of your necktie or scarf inside clothing or fasten it with a nonconductive clip, approximately 8 centimeters (3 inches) from the end.
- Do not wear jewelry, chains, metal-frame eyeglasses, or metal fasteners for your clothing.
Remember: Metal objects are good electrical conductors.
- Wear safety glasses when you are: hammering, drilling soldering, cutting wire, attaching springs, using solvents, or working in any other conditions that might be hazardous to your eyes.
- After service, reinstall all safety shields, guards, labels, and ground wires. Replace any safety device that is worn or defective.
- Reattach all covers correctly before returning the computer to the customer.

Electrical safety



CAUTION:

Electrical current from power, telephone, and communication cables can be hazardous. To avoid personal injury or equipment damage, disconnect any attached power cords, telecommunication cables, network cables, and modem cables before you open the computer covers, unless instructed otherwise in the installation and configuration procedures.

Observe the following rules when working on electrical equipment.

Important: Use only approved tools and test equipment. Some hand tools have handles covered with a soft material that does not insulate you when working with live electrical currents. Many customers have rubber floor mats near their equipment that contain small conductive fibers to decrease electrostatic discharge.

- Find the room emergency power-off (EPO) switch, disconnecting switch, or electrical outlet. If an electrical accident occurs, you can then operate the switch or unplug the power cord quickly.
- Do not work alone under hazardous conditions or near equipment that has hazardous voltages.
- Disconnect all power before:
 - Performing a mechanical inspection
 - Working near power supplies
 - Removing or installing Field Replaceable Units (FRUs)
- Before you start to work on the computer, unplug the power cord. If you cannot unplug it, ask the customer to power-off the electrical outlet that supplies power to the machine and to lock the electrical outlet in the off position.
- If you need to work on a computer that has exposed electrical circuits, observe the following precautions:
 - Ensure that another person, familiar with the power-off controls, is near you.
Remember: Another person must be there to switch off the power, if necessary.
 - Use only one hand when working with powered-on electrical equipment; keep the other hand in your pocket or behind your back.
Remember: There must be a complete circuit to cause electrical shock. By observing the above rule, you may prevent a current from passing through your body.
 - When using a tester, set the controls correctly and use the approved probe leads and accessories for that tester.
 - Stand on suitable rubber mats (obtained locally, if necessary) to insulate you from grounds such as metal floor strips and machine frames.

Observe the special safety precautions when you work with very high voltages; these instructions are in the safety sections of the maintenance information. Use extreme care when measuring high voltages.

- Regularly inspect and maintain your electrical hand tools to ensure they are safe to use.
- Do not use worn or broken tools and testers.
- *Never assume* that power has been disconnected from a circuit. First, *check* that it has been powered off.
- Always look carefully for possible hazards in your work area. Examples of these hazards are wet floors, non-grounded power extension cables, conditions that may cause or allow power surges, and missing safety grounds.
- Do not touch live electrical circuits with the reflective surface of a plastic dental mirror. This surface is conductive, and touching a live circuit can cause personal injury and damage to the computer.
- Do not service the following parts with the power on when they are removed from their normal operating positions in a computer:
 - Power supply units
 - Pumps
 - Blowers and fans
 - Motor generatorsand similar units. (This practice ensures correct grounding of the units.)
- If an electrical accident occurs:
 - Use caution; do not become a victim yourself.

- Switch off power.
- Send another person to get medical aid.

Safety inspection guide

The intent of this inspection guide is to assist you in identifying potential hazards posed by these products. Each computer, as it was designed and built, had required safety items installed to protect users and service personnel from injury. This guide addresses only those items. However, good judgment should be used to identify potential safety hazards due to attachment of features or options not covered by this inspection guide.

If any hazards are present, you must determine how serious the apparent hazard could be and whether you can continue without first resolving the problem.

Consider the following items and the safety hazards they present:

- Electrical hazards, especially primary power (primary voltage on the frame can cause serious or fatal electrical shock).
- Explosive hazards, such as a damaged CRT face or bulging capacitor
- Mechanical hazards, such as loose or missing hardware

The guide consists of a series of steps presented as a checklist. Begin the checks with the power off, and the power cord disconnected.

Checklist:

1. Check exterior covers for damage (loose, broken, or sharp edges).
2. Power-off the computer. Disconnect the power cord.
3. Check the power cord for:
 - a. A third-wire ground connector in good condition. Use a meter to measure third-wire ground continuity for 0.1 ohm or less between the external ground pin and frame ground.
 - b. The power cord should be the appropriate type as specified in the parts listings.
 - c. Insulation must not be frayed or worn.
4. Remove the cover.
5. Check for any obvious alterations. Use good judgment as to the safety of any alterations.
6. Check inside the unit for any obvious hazards, such as metal filings, contamination, water or other liquids, or signs of fire or smoke damage.
7. Check for worn, frayed, or pinched cables.
8. Check that the power-supply cover fasteners (screws or rivets) have not been removed or tampered with.

Handling electrostatic discharge-sensitive devices

Any computer part containing transistors or integrated circuits (ICs) should be considered sensitive to electrostatic discharge (ESD). ESD damage can occur when there is a difference in charge between objects. Protect against ESD damage by equalizing the charge so that the computer, the part, the work mat, and the person handling the part are all at the same charge.

Notes:

1. Use product-specific ESD procedures when they exceed the requirements noted here.
2. Make sure that the ESD protective devices you use have been certified (ISO 9000) as fully effective.

When handling ESD-sensitive parts:

- Keep the parts in protective packages until they are inserted into the product.
- Avoid contact with other people while handling the part.
- Wear a grounded wrist strap against your skin to eliminate static on your body.
- Prevent the part from touching your clothing. Most clothing is insulative and retains a charge even when you are wearing a wrist strap.
- Use the black side of a grounded work mat to provide a static-free work surface. The mat is especially useful when handling ESD-sensitive devices.
- Select a grounding system, such as those listed below, to provide protection that meets the specific service requirement.

Note: The use of a grounding system is desirable but not required to protect against ESD damage.

- Attach the ESD ground clip to any frame ground, ground braid, or green-wire ground.
- Use an ESD common ground or reference point when working on a double-insulated or battery-operated system. You can use coax or connector-outside shells on these systems.
- Use the round ground-prong of the AC plug on AC-operated computers.

Grounding requirements

Electrical grounding of the computer is required for operator safety and correct system function. Proper grounding of the electrical outlet can be verified by a certified electrician.

Safety notices

The CAUTION and DANGER safety notices in this section are provided in the language of English.



DANGER

Electrical current from power, telephone and communication cables is hazardous.

To avoid a shock hazard:

- **Do not connect or disconnect any cables or perform installation, maintenance, or reconfiguration of this product during an electrical storm.**
- **Connect all power cords to a properly wired and grounded electrical outlet.**
- **Connect any equipment that will be attached to this product to a properly wired outlet.**
- **When possible, use one hand only to connect or disconnect signal cables.**
- **Never turn on any equipment when there is evidence of fire, water, or structural damage.**
- **Disconnect the attached power cords, telecommunications cables, network cables, and modem cables before you open the device covers, unless instructed otherwise in the installation and configuration procedures.**
- **Connect and disconnect cables as described in the following table when installing, moving, or opening covers on this product or attached devices.**

To Connect	To Disconnect
<ol style="list-style-type: none"> 1. Turn everything OFF. 2. First, attach all cables to devices. 3. Attach signal cables to connectors. 4. Attach power cords to outlet. 5. Turn device ON. 	<ol style="list-style-type: none"> 1. Turn everything OFF. 2. First, remove power cords from outlets. 3. Remove signal cables from connectors. 4. Remove all cables from devices.



CAUTION:

When replacing the lithium battery, use only Part Number 45C1566 or an equivalent type battery recommended by the manufacturer. If your system has a module containing a lithium battery, replace it only with the same module type made by the same manufacturer. The battery contains lithium and can explode if not properly used, handled, or disposed of.

Do not:

- Throw into or immerse in water
- Heat to more than 100°C (212°F)
- Repair or disassemble

Dispose of the battery as required by local ordinances or regulations.



CAUTION:

When laser products (such as CD-ROMs, DVD-ROM drives, fiber optic devices, or transmitters) are installed, note the following:




- Do not remove the covers. Removing the covers of the laser product could result in exposure to hazardous laser radiation. There are no serviceable parts inside the device.
- Use of controls or adjustments or performance of procedures other than those specified herein might result in hazardous radiation exposure.



Some laser products contain an embedded Class 3A or Class 3B laser diode. Note the following:

These diodes emit radiation when open. Do not stare into the beam, do not view directly with optical instruments, and avoid direct exposure to the beam.




		
≥18 kg (37 lbs)	≥32 kg (70.5 lbs)	≥55 kg (121.2 lbs)

CAUTION:
Use safe practices when lifting.



CAUTION:
The power control button on the device and the power switch on the power supply do not turn off the electrical current supplied to the device. The device also might have more than one power cord. To remove all electrical current from the device, ensure that all power cords are disconnected from the power source.



CAUTION:
Do not place any object weighing more than 82 kg (180 lbs.) on top of rack-mounted devices.



Chapter 3. General information

This chapter provides general information that applies to all computer models covered by this manual.

Specifications

This section lists the physical specifications for your computer.

This section lists the physical specifications for your computer.

Type IdeaCentre Horizon 2 27

This section lists the physical specifications.

Environment

Air temperature:

Operating: 10° to 35°C

Transit: -20° to 55°C

Humidity:

Operating: 35% to 80%

Transit: 20% to 90% (40°C)

Altitude: 86KPa to 106KPa

Electrical input:

Input voltage: 90V-264V(AC)

Input frequency: 47Hz-63Hz

Chapter 4. General Checkout

Attention: The drives in the computer you are servicing might have been rearranged or the drive startup sequence may have been changed. Be extremely careful during write operations such as copying, saving, or formatting. Data or programs can be overwritten if you select an incorrect drive.

General error messages appear if a problem or conflict is found by an application, the operating system, or both. For an explanation of these messages, refer to the information supplied with that software package.

Use the following procedure to help determine the cause of the problem:

1. Power-off the computer and all external devices.
2. Check all cables and power cords.
3. Set all display controls to the middle position.
4. Power-on all external devices.
5. Power-on the computer.
 - Look for displayed error codes.
 - Look for readable instructions or a main menu on the display.

If you did not receive the correct response, proceed to step 6.

If you did receive the correct response, proceed to step 7.

6. If one of the following happens, follow the instruction given:
 - If the computer displays a POST error, go to “POST error codes”.
 - If the computer hangs and no error is displayed, continue at step 7.
7. If the test stops and you cannot continue, replace the last device tested.

Chapter 5. Using the Setup Utility

The Setup Utility program is used to view and change the configuration settings of your computer, regardless of which operating system you are using. However, the operating system settings might override any similar settings in the Setup Utility program.

Starting the Lenovo BIOS Setup Utility program

To start the Lenovo BIOS Setup Utility program, do the following:

1. If your computer is already on when you start this procedure, shut down the operating system and turn off the computer.
2. Press and hold the **F1** key then turn on the computer. When the Lenovo BIOS Setup Utility program is displayed, release the **F1** key.

Note: If a Power-On Password or an Administrator Password has been set, the Setup Utility program menu will not be displayed until you type your password. For more information, see “Using passwords.”

Viewing and changing settings

System configuration options are listed in the Lenovo BIOS Setup Utility program menu. To view or change settings, see “Starting the Setup Utility program.”

You must use the keyboard when using the Lenovo BIOS Setup Utility menu. The keys used to perform various tasks are displayed on the bottom of each screen.

Using passwords

You can use the Lenovo BIOS Setup Utility program to set passwords to prevent unauthorized persons from gaining access to your computer and data. See “Starting the Setup Utility program.” The following types of passwords are available:

- Administrator Password
- Power-On Password

You do not have to set any passwords to use your computer. However, if you decide to set passwords, read the following sections.

Password considerations

A password can be any combination of letters and numbers up to 16 characters (a-z and 0-9). For security reasons, it is a good idea to use a strong password that cannot be easily compromised. We suggest that passwords should follow these rules:

- For a strong password, use 7-16 characters and a mix of letters and numbers.
- Do not use your name or your user name.
- Do not use a common word or a common name.
- Use something significantly different from your previous password.

Attention: Administrator and Power-On passwords are not case sensitive.

Administrator Password

Setting an Administrator Password deters unauthorized persons from changing configuration settings. You might want to set an Administrator Password if you are responsible for maintaining the settings of several computers.

After you set an Administrator Password, a password prompt is displayed every time you access the Lenovo BIOS Setup Utility program.

If both the Administrator and Power-On Password are set, you can type either password. However, you must use your Administrator Password to change any configuration settings.

Setting, changing, or deleting an Administrator Password

To set an Administrator Password, do the following:

Note: A password can be any combination of letters and numbers up to 16 characters (a-z and 0-9). For more information, see “Password considerations” on page 13.

1. Start the Lenovo BIOS Setup Utility program (see “Starting the Lenovo BIOS Setup Utility program” on page 13).
2. From the **Security** menu, select **Set Administrator Password** and press the **Enter** key.
3. The password dialog box will be displayed. Type the password then press the **Enter** key.
4. Retype the password to confirm, then press the **Enter** key. If you typed the password correctly, the password will be installed. A Setup Notice will be displayed confirming that your changes has been saved.
5. Return to the Lenovo BIOS Setup Utility program menu and select the **Exit** option.
6. Select **Save Changes and Exit** from the menu.

To change an Administrator Password, do the following:

1. Start the Lenovo BIOS Setup Utility program (see “Starting the Lenovo BIOS Setup Utility program” on page 13).
2. From the **Security** menu, select **Set Administrator Password** and press the **Enter** key.
3. The password dialog box will be displayed. Type the current password then press the **Enter** key.
4. Type the new password, then press the **Enter** key. Retype the new password to confirm it. If you typed the new password correctly, the new password will be installed. A Setup Notice will be displayed confirming that your changes have been saved.
5. Return to the Lenovo BIOS Setup Utility program menu and select the **Exit** option.
6. Select **Save Changes and Exit** from the menu.

To delete a previously set Administrator Password, do the following :

1. Start the Lenovo BIOS Setup Utility program (see “Starting the Lenovo BIOS Setup Utility program” on page 13).
2. From the **Security** menu, select **Set Administrator Password** and press the **Enter** key.
3. The password dialog box will be displayed. Type the current password and press the **Enter** key.
4. Leave each new password line item blank, then press the **Enter** key. A Setup Notice will be displayed confirming that your changes have been saved.
5. Return to the Lenovo BIOS Setup Utility program menu and select the **Exit** option.
6. Select **Save Changes and Exit** from the menu.

Power-On Password

When a Power-On Password is set, you cannot start the Lenovo BIOS Setup Utility program until a valid password is typed from the keyboard.

Setting, changing, or deleting a Power-On Password

Note: A password can be any combination of letters and numbers up to 16 characters (a-z and 0-9).

To set a Power-On Password, do the following:

1. Start the Lenovo BIOS Setup Utility program (see "Starting the Lenovo BIOS Setup Utility program" on page 13).
2. From the **Security** menu, select **Set Power-On Password** and press the **Enter** key.
3. The password dialog box will be displayed. Type the password, then press the **Enter** key.
4. Retype the password to confirm. If you typed the password correctly, the password will be installed.
5. Return to the Lenovo BIOS Setup Utility program menu and select the **Exit** option.
6. Select **Save Changes and Exit** from the menu.

To change a Power-On Password, do the following:

1. Start the Lenovo BIOS Setup Utility program (see "Starting the Lenovo BIOS Setup Utility program" on page 13).
2. From the **Security** menu, select **Set Power-On Password** and press the **Enter** key.
3. The password dialog box will be displayed. Type the current password then press the **Enter** key.
4. Type the new password, then press the **Enter** key. Retype the new password to confirm it. If you typed the new password correctly, the new password will be installed. A Setup Notice will be displayed confirming that your changes have been saved.
5. Return to the Lenovo BIOS Setup Utility program menu and select the **Exit** option.
6. Select **Save Changes and Exit** from the menu.

To delete a previously set Power-On Password, do the following :

1. Start the Lenovo BIOS Setup Utility program (see "Starting the Lenovo BIOS Setup Utility program" on page 13).
2. From the **Security** menu, select **Set Power-On Password** and press the **Enter** key.
3. The password dialog box will be displayed. Type the current password and press the **Enter** key.
4. Leave each new password line item blank, then press Enter. A Setup Notice will be displayed confirming that your changes have been saved.
5. Return to the Lenovo BIOS Setup Utility program menu and select the **Exit** option.
6. Select **Save Changes and Exit** from the menu.

Enabling or disabling a device

The Devices options is used to enable or disable user access to the following:	
USB Functions	Select whether to enable or disable USB (Universal Serial Bus) functions. If the functions are disabled, no USB devices can be used.

SATA Mode	Select Disabled/IDE/AHCI mode. Device driver support is required for AHCI or RAID . Depending on how the hard disk drive image was installed, changing this setting may prevent the system from booting.
Onboard Audio Controller	Select whether to enable or disable the Onboard Audio Controller . When this feature is set to Disabled all devices connected to the audio connectors (e.g. headphones or a microphone) are disabled and cannot be used.

To enable or disable a device, do the following:

1. Start the Setup Utility program (see “Starting the Setup Utility program” on page 13).
2. From the Setup Utility program menu, select **Devices**.
3. Select an option as follows:
 - Select **USB Setup**, press the **Enter** key, then select **USB Functions**.
 - Select **ATA Drivers Setup**, press the **Enter** key, then select **SATA Mode**.
 - Select **Audio Setup**, press the **Enter** key, then select **Onboard Audio Controller**.
4. Select **Disabled** or **Enabled** and press the **Enter** key.
5. Return to the Lenovo BIOS Setup Utility program menu and select the **Exit** option.
6. Select **Save Changes and Exit** from the menu.

Notes:

- a. If you do not want to save the settings, select **Discard Changes and Exit** from the menu.

Selecting a startup device

If your computer does not boot from a device such as the CD/DVD-ROM drive disk or hard disk as expected, follow one of the procedures below.

Selecting a temporary startup device

Use this procedure to start up from any boot device.

Note: Not all CDs, DVDs or hard disk drives are bootable.

1. Turn off your computer.
2. Press and hold the **F12** key then turn on the computer. When the **Startup Device Menu** appears, release the **F12** key.

Note: If the **Startup Device Menu** does not display using these steps, repeatedly press and release the **F12** key rather than keeping it pressed when turning on the computer.

3. Use **↑** and **↓** arrows to select the desired startup device from the **Startup Device Menu** and press the **Enter** key to begin.

Note: Selecting a startup device from the **Startup Device Menu** does not permanently change the startup sequence.

Selecting or changing the startup device sequence

To view or permanently change the configured startup device sequence, do the following:

1. Start the Lenovo BIOS Setup Utility program (see “Starting the Lenovo BIOS Setup Utility program” on page 13).
2. From the Lenovo BIOS Setup Utility program main menu, select the **Startup** option.
3. Press the **Enter** key, and select the devices for the **Primary Boot Sequence**. Read the information displayed on the right side of the screen.
4. Use - and $\bar{\quad}$ arrows to select a device. Use the <+> or <-> keys to move a device up or down. Use the <x> key to exclude the device from or include the device in the boot sequence.
5. Return to the Lenovo BIOS Setup Utility program menu and select the **Exit** option.
6. Select **Save Changes and Exit** from the menu.

Notes:

- a. If you do not want to save the settings, select **Discard Changes and Exit** from the menu.
- b. If you have changed these settings and want to return to the default settings, select **Load Optimal Defaults** from the menu.

Exiting the Lenovo BIOS Setup Utility program

After you finish viewing or changing settings, press the **Esc** key to return to the Lenovo BIOS Setup Utility program main menu. You might have to press the **Esc** key several times. Do one of the following:

- If you want to save the new settings, select **Save Changes and Exit** from the menu. When the **Save & reset** window shows, select the **Yes** button, and then press the **Enter** key to exit the Lenovo BIOS Setup Utility program.
- If you do not want to save the settings, select **Discard Changes and Exit** from the menu. When the **Reset Without Saving** window shows, select the **Yes** button, and then press the **Enter** key to exit the Lenovo BIOS Setup Utility program.

Chapter 6. Symptom-to-FRU Index

The Symptom-to-FRU index lists error symptoms and possible causes. The most likely cause is listed first. Always begin with Chapter 4, “General Checkout,” on page 11. This index can also be used to help you decide which FRUs to have available when servicing a computer. If you are unable to correct the problem using this index, go to “Undetermined problems” on page 20.

Notes:

- If you have both an error message and an incorrect audio response, diagnose the error message first.
- If you cannot run the diagnostic tests or you get a diagnostic error code when running a test but did receive a POST error message, diagnose the POST error message first.
- If you did not receive any error message look for a description of your error symptoms in the first part of this index.

Hard disk drive boot error

A hard disk drive boot error can have the following causes.

Error	FRU/Action
The startup drive is not included in the boot sequence configuration.	Check the configuration and ensure the startup drive is in the boot sequence.
No operating system is installed on the boot drive.	Install an operating system on the boot drive.
The boot sector on the startup drive is corrupted.	The drive must be formatted. Do the following: <ol style="list-style-type: none">1. Attempt to back up the data on the failing hard disk drive.2. Use the operating system to format the hard disk drive.
The drive is defective.	Replace the hard disk drive.

Power Supply Problems

Follow these procedures if you suspect there is a power supply problem.

Check/Verify	FRU/Action
Check that the following are properly installed: <ul style="list-style-type: none">• Power Cord• On/Off Switch connector• System Board Power Supply connectors• Microprocessor connections	Reseat connectors
Check the power cord.	Power Cord
Check the power-on switch.	Power-on Switch

POST error codes

Each time you turn the computer on, it performs a series of tests to check that the system is operating correctly and that certain options are set. This series of tests is called the *Power-On Self-Test*, or *POST*. POST does the following:

- Checks some basic motherboard operations
- Checks that the memory is working correctly
- Starts video operations
- Verifies that the boot drive is working

POST Error Message	Description/Action
Keyboard error	Cannot initialize the keyboard. Make sure the keyboard is properly connected to the computer and that no keys are held pressed during POST. To purposely configure the computer without a keyboard, select Keyboardless operation in Startup and set the option to Enabled . The BIOS then ignores the missing keyboard during POST.
Reboot and Select proper Boot device or Insert Boot Media in selected Boot device	The BIOS was unable to find a suitable boot device. Make sure the boot drive is properly connected to the computer. Make sure you have bootable media in the boot device.

Undetermined problems

1. Power-off the computer.
2. Remove or disconnect the following components (if connected or installed) one at a time.
 - a. External devices (modem, printer, or mouse)
 - b. Extended video memory
 - c. External Cache
 - d. External Cache RAM
 - e. Hard disk drive
 - f. Disk drive
3. Power-on the computer to re-test the system.
4. Repeat steps 1 through 3 until you find the failing device or component.

If all devices and components have been removed and the problem continues, replace the system board.

Chapter 7. Replacing hardware

Attention: Do not remove the computer cover or attempt any repair before reading the “Important safety information” in the Safety and Warranty Guide that was included with your computer. To obtain copies of the Safety and Warranty Guide, go to the Support Web site at: <http://support.lenovo.com>.

Note: Use only parts provided by Lenovo.

General information

Pre-disassembly instructions


Before starting the disassembly procedure, make sure that you do the following:

1. Turn off the power to the system and all peripherals.
2. Unplug all power and signal cables from the computer.
3. Place the system on a flat, stable surface.

Replacing the keyboard and mouse

To replace the keyboard and mouse:

- Step 1. Remove any media (disks, CDs, DVDs or memory cards) from the drives, shut down the operating system, and turn off the computer and all attached devices.
- Step 2. Unplug all power cords from electrical outlets.
- Step 3. Disconnect all cables attached to the computer. This includes power cords, input/output (I/O) cables, and any other cables that are connected to the computer. Refer to “Left and right view” and “Rear view” for help with locating the various connectors.



Note: Your keyboard will be connected to a USB connector on one side or at the rear of the computer.

- Step 4. Disconnect the defective keyboard cable from the computer and connect the new keyboard cable to the same connector.

Note: The mouse can be replaced using the same method.

Removing the rear cover

Note: Turn off the computer and wait 3 to 5 minutes to let it cool down before removing the base cover.

Note: It may be helpful to place the computer face-down on a soft flat surface for this procedure. Lenovo recommends that you use a blanket, towel, or other soft cloth to protect the computer screen from scratches or other damage.

To remove the base cover:

- Step 1. Remove any media (disks, CDs, DVDs, or memory cards) from the drives, shut down the operating system, and turn off the computer and all attached devices.
- Step 2. Unplug all power cords from electrical outlets.
- Step 3. Disconnect all cables attached to the computer. This includes power cords, input/output (I/O) cables, and any other cables that are connected to the computer. Refer to “Left and right view” and “Rear view” for help with locating the various connectors.


Step 4. For this procedure it requires using a flat head screw driver. Use a piece of soft clothes to wrap the screw driver head before proceeding.



Step 5. The front panel and the rear cover are pinned together, use the wrapped screw driver to push into the hole as illustrated to force the front panel separating from the rear cover. For this procedure it might requires using some strengthens while pushing. **1** Working along the gap opened in-between the front panel and the rear cover gently to separating the front panel from rear cover. **2**



Step 6. Disconnect the two scalar cables from the connectors on the motherboard as shown. **1 2**



Step 7. Put the front panel and rear cover aside.

Step 8. To reattach the rear cover:

- a. Line up the front panel with the rear cover, and then reconnect the two scalar cables to the motherboard.
- b. Press down along the edge of the rear cover and secure the rear cover to the front panel with the mounting pins.


Replacing the battery

Note: Turn off the computer and wait 3 to 5 minutes to let it cool down before removing the base cover.

To replace the battery:

- Step 1. Remove any media (disks, CDs, DVDs, or memory cards) from the drives, shut down the operating system, and turn off the computer and all attached devices.
- Step 2. Unplug all power cords from electrical outlets.
- Step 3. Disconnect all cables attached to the computer. This includes power cords, input/output (I/O) cables, and any other cables that are connected to the computer. Refer to “Left and right view” and “Rear view” for help with locating the various connectors.
- Step 4. Remove the rear cover. Refer to “Removing the rear cover”.

- Step 5. Disconnect the power cable from the connector on the motherboard. **1**
- Step 6. Remove the six screws that secure the battery to the rear cover **2**, then lift up the battery pack as shown.



- Step 7. To install a new battery:
- Line up the holes with mounting holes on the rear cover, then place it into position.
 - Secure the new battery to the chassis with the six screws.
 - Connect the power cable to the connector on the motherboard.
- Step 8. Reattach the rear cover.


Replacing a memory module

Attention: Turn off the computer and wait 3 to 5 minutes to let it cool down before removing the base cover.

To replace a memory module:

- Step 1. Remove any media (disks, CDs, DVDs, or memory cards) from the drives, shut down the operating system, and turn off the computer and all attached devices.
- Step 2. Unplug all power cords from electrical outlets.
- Step 3. Disconnect all cables attached to the computer. This includes power cords, input/output (I/O) cables, and any other cables that are connected to the computer. Refer to “Left and right view” and “Rear view” for help with locating the various connectors.
- Step 4. Remove the rear cover. Refer to “Removing the rear cover”.
- Step 5. Disconnect the battery cable from the connector on motherboard. Refer to “Replacing the battery”.

- Step 6. Push out the latches on both sides of the memory socket to release the memory module. Gently pull the memory module upward to remove it from its socket.



- Step 7. To install the new memory module:
- Align the new memory module with the memory socket, then insert it and push down on the top edge.
 - Make sure the latches lock the memory module in place.
 - Reconnect the battery cable to the connector on the motherboard.
- Step 8. Reattach the rear cover.


Replacing the Wi-Fi card

Note: Turn off the computer and wait 3 to 5 minutes to let it cool down before removing the base cover.

To replace the Wi-Fi card:

- Remove any media (disks, CDs, DVDs, or memory cards) from the drives, shut down the operating system, and turn off the computer and all attached devices.
- Unplug all power cords from electrical outlets.
- Disconnect all cables attached to the computer. This includes power cords, input/output (I/O) cables, and any other cables that are connected to the computer. Refer to “Left and right view” and “Rear view” for help with locating the various connectors.
- Remove the rear cover. Refer to “Removing the rear cover”.
- Remove the EMI cover. Refer to “Removing the EMI cover”.
- Disconnect the battery cable from the connector on motherboard. Refer to “Replacing the battery”.

- Step 7. Remove the screw that secures the Wi-Fi card to the motherboard. **1**
- Step 8. Disconnect the antenna cable and data cable from the Wi-Fi card. **2**
- Step 9. Pull the Wi-Fi card upward to remove it from the card port. **3**



- Step 10. To install the new Wi-Fi card:
- Line up the new Wi-Fi card with the card port, insert the card into position and secure it with the screw.
 - Reconnect the antenna and data cable to the new Wi-Fi card.
 - Reconnect the battery cable to the connector on the motherboard.
- Step 11. Reattach the rear cover.

Replacing the hard disk drive


Attention: Turn off the computer and wait 3 to 5 minutes to let it cool down before removing the base cover.

To replace the hard disk drive:

- Step 1. Remove any media (disks, CDs, DVDs or memory cards) from the drives, shut down the operating system, and turn off the computer and all attached devices.
- Step 2. Unplug all power cords from electrical outlets.
- Step 3. Disconnect all cables attached to the computer. This includes power cords, input/output (I/O) cables, and any other cables that are connected to the computer. Refer to “Left and right view” and “Rear view” for help with locating the various connectors.
- Step 4. Remove the rear cover. Refer to “Removing the rear cover”.
- Step 5. Disconnect the battery cable from the connector on motherboard. Refer to “Replacing the battery”.


Step 6. Disconnect the data and power cables from the hard disk drive. **1**

Step 7. Remove the four screws that secure the hard disk drive to the chassis, then lift up the hard disk drive to remove it. **2**



Step 8. Remove the four screws that secure the hard disk drive to the bracket.

Step 9. Slide the hard disk drive out of the bracket.



Step 10. Install the new hard disk drive as follows:

- a. Slide the new hard disk drive into the bracket.
- b. Secure the new hard disk drive to the bracket with the four screws.
- c. Connect the data and power cables to the new hard disk drive.
- d. Secure the new hard disk drive and bracket to the chassis with the four screws.
- e. Reconnect the battery cable to the connector on the motherboard.

Step 11. Reattach the rear cover.

Replacing the fan module

Note: Turn off the computer and wait 3 to 5 minutes to let it cool down before removing the base cover.

To replace the fan module:

- Step 1. Remove any media (disks, CDs, DVDs or memory cards) from the drives, shut down the operating system, and turn off the computer and all attached devices.
- Step 2. Unplug all power cords from electrical outlets.
- Step 3. Disconnect all cables attached to the computer. This includes power cords, input/output (I/O) cables, and any other cables that are connected to the computer. Refer to “Left and right view” and “Rear view” for help with locating the various connectors.
- Step 4. Remove the rear cover. Refer to “Removing the rear cover”.
- Step 5. Disconnect the battery cable from the connector on motherboard. Refer to “Replacing the battery”.
- Step 6. Remove the six screws that secure the fan module to the rear cover.
- Step 7. Disconnect the power cables from the motherboard.
- Step 8. Lift up the fan module to remove it.




- Step 9. To install the new fan module:
 - a. Line up the new fan module with the mounting holes on the rear cover and place it into position.
 - b. Secure the new fan module to the rear cover with the six screws.
 - c. Connect the new power cable to the connectors on motherboard.
 - d. Reconnect the battery cable to the connector on the motherboard.
- Step 10. Reattach the rear cover.

Replacing the heat-sink modules

Note: Turn off the computer and wait 3 to 5 minutes to let it cool down before removing the base cover.

To replace the heat-sink modules:

- Step 1. Remove any media (disks, CDs, DVDs or memory cards) from the drives, shut down the operating system, and turn off the computer and all attached devices.
- Step 2. Unplug all power cords from electrical outlets.
- Step 3. Disconnect all cables attached to the computer. This includes power cords, input/output (I/O) cables, and any other cables that are connected to the computer. Refer to “Left and right view” and “Rear view” for help with locating the various connectors.
- Step 4. Remove the rear cover. Refer to “Removing the rear cover”.
- Step 5. Disconnect the battery cable from the connector on motherboard. Refer to “Replacing the battery”.
- Step 6. Remove the eight screws that secure the heat-sink module to the motherboard.
- Step 7. Lift up the heat-sink module to remove it.



Attention: Place the heat-sink upside down on a flat surface to prevent thermal grease from contaminating other components.

- Step 8. To install the new heat-sink module:
 - a. Use an alcohol pad to wipe the thermal grease off the CPU.
 - b. Line up the new heat-sink with mounting holes on the motherboard.
 - c. Secure the new heat-sink to the motherboard with the eight screws.
 - d. Attach the system fans to the new heat-sink and secure it with the screws.
 - e. Reconnect the battery cable to the connector on the motherboard.
- Step 9. Reattach the rear cover.

Replacing the speaker system

Note: Turn off the computer and wait 3 to 5 minutes to let it cool down before removing the base cover.

To replace the speaker system:

- Step 1. Remove any media (disks, CDs, DVDs, or memory cards) from the drives, shut down the operating system, and turn off the computer and all attached devices.
- Step 2. Unplug all power cords from electrical outlets.

- Step 3. Disconnect all cables attached to the computer. This includes power cords, input/output (I/O) cables, and any other cables that are connected to the computer. Refer to “Left and right view” and “Rear view” for help with locating the various connectors.
- Step 4. Remove the rear cover. Refer to “Removing the rear cover”.
- Step 5. Disconnect the battery cable from the connector on motherboard. Refer to “Replacing the battery”.
- Step 6. Disconnect the speaker cable from the connector on the motherboard. **1**
- Step 7. Push the rubber mounting pins outward to release the speaker. **2**



- Step 8. To install the new speaker system:
 - a. Attach the new speaker system to the chassis, then secure it with mounting rubber pins.
 - b. Connect the new speaker cable to the connector on the motherboard.
 - c. Reconnect the battery cable to the connector on the motherboard.
- Step 9. Reattach the rear cover.

Replacing the I/O board

Note: Turn off the computer and wait 3 to 5 minutes to let it cool down before removing the base cover.

To replace the I/O board:

- Step 1. Remove any media (disks, CDs, DVDs, or memory cards) from the drives, shut down the operating system, and turn off the computer and all attached devices.
- Step 2. Unplug all power cords from electrical outlets.
- Step 3. Disconnect all cables attached to the computer. This includes power cords, input/output (I/O) cables, and any other cables that are connected to the computer. Refer to “Left and right view” and “Rear view” for help with locating the various connectors.
- Step 4. Remove the rear cover. Refer to “Removing the rear cover”.
- Step 5. Disconnect the battery cable from the connector on motherboard. Refer to “Replacing the battery”.

- Step 6. Disconnect the power connector cable from the connector on the motherboard. **1**
- Step 7. Remove the two screws that secure the I/O board to the rear cover. **2**
- Step 8. Slide out the I/O board as shown and disconnect the data cable from the I/O board. **3**



- Step 9. To install the new I/O board:
- Connect the data cable to connector on the new I/O board.
 - Line up the holes on the new I/O board with the mounting holes on the I/O board and secure the I/O board to the rear cover with the two screws.
 - Connect the power connector cable to the connector on the motherboard.
 - Reconnect the battery cable to the connector on the motherboard.
- Step 10. Reattach the rear cover.

Replacing the power switch board

Note: Turn off the computer and wait 3 to 5 minutes to let it cool down before removing the base cover.

To replace the power switch board:

- Step 1. Remove any media (disks, CDs, DVDs, or memory cards) from the drives, shut down the operating system, and turn off the computer and all attached devices.
- Step 2. Unplug all power cords from electrical outlets.
- Step 3. Disconnect all cables attached to the computer. This includes power cords, input/output (I/O) cables, and any other cables that are connected to the computer. Refer to “Left and right view” and “Rear view” for help with locating the various connectors.
- Step 4. Remove the rear cover. Refer to “Removing the rear cover”.
- Step 5. Disconnect the battery cable from the connector on motherboard. Refer to “Replacing the battery”.
- Step 6. Disconnect the power cable from the power switch board.

Step 7. Remove the two screws that secure the power switch board to the rear cover **1**, lift up the power switch board **2** and disconnect the cable from the switch board. **3**



Step 8. To install the power switch board:

- a. Connect the power cable to the new power switch board.
- b. Secure the power switch board to the rear cover with the two screws.
- c. Reconnect the battery cable to the connector on the motherboard.

Step 9. Reattach the rear cover.

Replacing the motherboard

Note: Turn off the computer and wait 3 to 5 minutes to let it cool down before removing the base cover.

To replace the motherboard:

Step 1. Remove any media (disks, CDs, DVDs, or memory cards) from the drives, shut down the operating system, and turn off the computer and all attached devices.

Step 2. Unplug all power cords from electrical outlets.

Step 3. Disconnect all cables attached to the computer. This includes power cords, input/output (I/O) cables, and any other cables that are connected to the computer. Refer to “Left and right view” and “Rear view” for help with locating the various connectors.

Step 4. Remove the rear cover. Refer to “Removing the rear cover”.


Step 5. Disconnect the battery cable from the connector on motherboard. Refer to “Replacing the battery”.

Step 6. Remove the memory modules. Refer to “Replacing a memory module”.

Step 7. Remove the heat-sink modules. Refer to “Replacing the heat-sink modules”.

Step 8. Remove all the cables connected to the motherboard. **1 2 3 4 5 6 7 8**

Step 9. Remove the six screws that secure the motherboard to the rear cover and lift up the motherboard to remove it.



Step 10. To install the new motherboard:

- a. Insert the notched end of the Wi-Fi card into the card port on the new motherboard and secure it with the screw.
- b. Connect the antenna cable(s) to the Wi-Fi card.
- c. Attach the heat-sink modules, and the memory modules to the motherboard.
- d. Align the holes on the new motherboard with the mounting holes on the rear cover and secure the motherboard to the rear cover with the screws.
- e. Connect all the cables to the new motherboard.

Step 11. Reattach the rear cover.


Replacing the camera

Note: Turn off the computer and wait 3 to 5 minutes to let it cool down before removing the base cover.


To replace the camera:

- Step 1. Remove any media (disks, CDs, DVDs, or memory cards) from the drives, shut down the operating system, and turn off the computer and all attached devices.
- Step 2. Unplug all power cords from electrical outlets.
- Step 3. Disconnect all cables attached to the computer. This includes power cords, input/output (I/O) cables, and any other cables that are connected to the computer. Refer to “Left and right view” and “Rear view” for help with locating the various connectors.
- Step 4. Remove the rear cover. Refer to “Removing the rear cover”.

Step 5. Remove the two screws that secure the camera and bracket to the front bezel. Lift up the camera and bracket to remove it.



Step 6. Remove the camera from bracket by removing the two screws and disconnect the data cable from the camera.



Step 7. To install the new camera:

- a. Connect the data cable to the new camera.
- b. Secure the new camera to the bracket with the two screws.
- c. Line up the holes in the bracket with the mounting holes on the front bezel and secure the new camera with the two screws.

Step 8. Reattach the rear cover.

Replacing the LED panel module

Note: Turn off the computer and wait 3 to 5 minutes to let it cool down before removing the base cover.

Note: It may be helpful to place the computer face-down on a soft flat surface for this procedure. Lenovo recommends that you use a blanket, towel, or other soft cloth to protect the computer screen from scratches or other damage.

To replace the LED panel module:

- Step 1. Remove any media (disks, CDs, DVDs, or memory cards) from the drives, shut down the operating system, and turn off the computer and all attached devices.
- Step 2. Unplug all power cords from electrical outlets.
- Step 3. Disconnect all cables attached to the computer. This includes power cords, input/output (I/O) cables, and any other cables that are connected to the computer. Refer to “Left and right view” and “Rear view” for help with locating the various connectors.
- Step 4. Remove the rear cover. Refer to “Removing the rear cover”.
- Step 5. Remove the camera. Refer to “Replacing the camera”.
- Step 6. Remove all the cables attached to the front bezel.



- Step 7. To install the new the LED panel:
 - a. Connect all the cables to the connectors on the LED panel module.
 - b. Attach the camera to the new LED panel.
- Step 8. Reattach the rear cover.

Chapter 8. FRU lists

This chapter lists the information on the field replaceable units (FRUs).

Attention: Be sure to read and understand all the safety information before replacing any FRUs.

Notes: FRUs that have a 1 or 2 in the CRU column are Customer Replaceable Units (CRUs).

- **1**– identifies parts that are fairly simple to replace, requiring few or no tools.
- **2**– identifies parts that are slightly more difficult to replace.
- **N**– identifies parts that are not to be replaced by the customer.

Description	Lenovo P/N	CRU ID
Motherboard		
Description	90005883	N
W8S M ULT i3-4010U 2G MB	90005884	N
W8P M ULT i3-4010U 2G MB	90005885	N
W8S M i7-4510U 2G MB	5B20F66810	N
W8P M i5-4210U 2G MB	5B20F66811	N
W8S M i5-4210U 2G MB	5B20F66812	N
NOK M i5-4210U 2G MB	5B20F66813	N
W8P M i7-4510U 2G MB	5B20F66814	N
NOK M i7-4510U 2G MB	5B20F66815	N
NOK M i3-4010U 2G S MB	90005883	N
W8S M i3-4010U 2G S MB	90005884	N
W8P M i3-4010U 2G S MB	90005885	N
NOK M i7-4510U 2G S MB	5B20F66815	N
W8S M i7-4510U 2G S MB	5B20F66810	N
W8P M i7-4510U 2G S MB	5B20F66814	N
NOK M i5-4210U 2G S MB	5B20F66813	N
W8S M i5-4210U 2G S MB	5B20F66812	N
W8P M i5-4210U 2G S MB	5B20F66811	N
NOK M i3-4030U 2G S MB	5B20G05103	N
W8S M i3-4030U 2G S MB	5B20G05100	N
W8P M i3-4030U 2G S MB	5B20G05099	N
LCD Touch Module		
Alpha II FHD LCM for Ofilm	888016973	N
Alpha II FHD LCM for LGE	888016974	N
Memory		

MT16KTF1G64HZ-1G6E1	1100635	N
M471B5173DB0-YK0 4GB D3L-1600S-HF	1100942	N
M471B1G73DB0-YK0 8GB D3L-1600S-HF	1100943	N
MT8KTF51264HZ-1G6E1 4GB D3L-1600S-HF	1100957	N
Mic_S D9QBJ 4GB D3L-1600S	1100959	N
Mic_R D9QBJ 4GB D3L-1600S-HF	1100967	N
HMT451S6BFR8A-PB 4GB D3L-1600S-HF	1100985	N
HMT41GS6BFR8A-PB 8GB D3L-1600S-HF	1100986	N
Mic_R D9QBJ 8GB D3L-1600S-HF	1101012	N
Hard Drive		
HTS545050A7E380	16200067	N
WD5000LPVX-08V0T	16200379	N
ST500LM000	16200420	N
WD10SPCX-24HWST0 6G 7mm 1T HDD	16200554	N
ST500LT012 6G 7mm 5.4K 500G HDD	16200626	N
Boards		
LTN RTL8821AE 1x1ac+BT4.0 Combo HMC	11202485	N
Liteon WB335 1x1BGN+BT4.0 HMC	20200437	N
Cbt RTL8723BE 1x1BGN+BT HMC	20200440	N
FXN BCM20792M NFC Module	11202583	N
MSI Alphall power button board MP	11202641	N
MSI Alphall IO board MP	11202647	N
MSI Alphall Home board MP	11202650	N
Camera		
AVC 1080P 2MIC WV WB Cam Apha II	20200611	N
Bison 1080P 2MIC WV WB Cam Apha II	20200612	N
Speaker		
Alpha2 Wabony 2.5W speaker	25216223	N
Keyboard & Mouse		
Liteon SK-8861(US) 2.4G KB-Metal8	25216020	1
Liteon SK-8861(TW) 2.4G KB-Metal8	25216021	1
Liteon SK-8861(TH) 2.4G KB-Metal8	25216022	1
Liteon SK-8861(CS-SK) 2.4G KB-Metal8	25216023	1
Liteon SK-8861(US-IN) 2.4G KB-Metal8	25216024	1
Liteon SK-8861(RU) 2.4G KB-Metal8	25216025	1
Liteon SK-8861(GB) 2.4G KB-Metal8	25216026	1
Liteon SK-8861(Nordic) 2.4G KB-Metal8	25216027	1
Liteon SK-8861(LA) 2.4G KB-Metal8	25216028	1
Liteon SK-8861(SA) 2.4G KB-Metal8	25216030	1
Liteon SK-8861(DE) 2.4G KB-Metal8	25216031	1

Liteon SK-8861(TR) 2.4G KB-Metal8	25216032	1
Liteon SK-8861(ES) 2.4G KB-Metal8	25216033	1
Liteon SK-8861(IT) 2.4G KB-Metal8	25216034	1
Liteon SK-8861(FR) 2.4G KB-Metal8	25216035	1
Liteon SK-8861(KR) 2.4G KB-Metal8	25216036	1
Liteon SK-8861(JP) 2.4G KB-Metal8	25216037	1
Liteon SK-8861(EN-FR) 2.4G KB-Metal8	25216038	1
Liteon SK-8861(BE-EN) 2.4G KB-Metal8	25216039	1
Liteon SK-8861(US-EU) 2.4G KB-Metal8	25216040	1
SK-8861(CH) 2.4G KB-Metal8	SD50F65816	1
Liteon ZTM600 2.4G Mouse (WW) Silver	25216043	1
Liteon ZTM600 2.4G Mouse (No BTY) Silver	25216044	1
Power Cord		
US/Canada/Barbados/Belize/Bolivia/Costa Rica/Columbia/Dominican Republic/Ecuador/El Salvador/Guatemala/Haiti/Honduras/Jamaica/ Mexico/Netherlands Antilles/ Nicaragua/ Panama/ Philippines/Peru/Venezuela/ (Thainland)	31033857	1
US/Canada/Barbados/Belize/Bolivia/Costa Rica/Columbia/Dominican Republic/Ecuador/El Salvador/Guatemala/Haiti/Honduras/Jamaica/ Mexico/Netherlands Antilles/ Nicaragua/ Panama/ Philippines/Peru/Venezuela/ (Thainland)	31033858	1
Albania/Algeria/Angola/Austria/Azerbaijan/Belarus/Belgium/Bosnia/Bulgaria/Croatia//Cambodia/Cote d'ivoire/Czech/Estonia/Egypt/Finland/France/Georgia/Germany/ Greece/Herzegovina/Hungary/Indonesia/Iceland/Kazakhstan/Kyrgyzstan/Laos/Latvia/ Lebanon/Lithuani	31035332	1
India/(Bangladesh/Sri Lanka)	31035395	1
UK/Hong Kong/Singapore/ Malaysia/Bahrain/Bangladesh/Botswana/Burma/ Brunei /Cyprus/Ghana/Ireland/Jordan/Kenya/Kuwait/Malta/ Nigeria/Oman/ Qatar/United Arab Emirates/Trinidad and Tobago/Saudi Arabia/Sri Lanka	31035396	1
Australia/New Zealand	31035397	1
Brazil	31035828	1
Taiwan	31038885	1
LA (High Voltage) Argentina, Paraguay, Uruguay	31039100	1
Denmark	31039101	1
Switzerland/Liechtenstein	31039103	1
Italy/ Chile/Libya	31039104	1
South Africa/Macao/Namibia/Nepal/Pakistan/Swaziland /Uganda	31039105	1
Korea	31039106	1
Israel	31039107	1
UK/Hong Kong/Singapore/ Malaysia/Bahrain/Bangladesh/Botswana/Burma/ Brunei /Cyprus/Ghana/Ireland/Jordan/Kenya/Kuwait/Malta/ Nigeria/Oman/ Qatar/United Arab Emirates/Trinidad and Tobago/Saudi Arabia/Sri Lanka	31049496	1
Albania/Algeria/Angola/Austria/Azerbaijan/Belarus/Belgium/Bosnia/Bulgaria/Croatia//Cambodia/Cote d'ivoire/Czech/Estonia/Egypt/Finland/France/Georgia/Germany/ Greece/Herzegovina/Hungary/Indonesia/Iceland/Kazakhstan/Kyrgyzstan/Laos/Latvia/ Lebanon/Lithuani	31049497	1
Korea	31049498	1

Taiwan	31049499	1
Australia/New Zealand	31049500	1
South Africa/Macao/Namibia/Nepal/Pakistan/Swaziland /Uganda	31049501	1
Israel	31049502	1
Denmark	31049503	1
Italy/ Chile/Libya	31049504	1
Brazil	31049505	1
LA (High Voltage) Argentina, Paraguay, Uruguay	31049507	1
Switzerland/Liechtenstein	31049508	1
US/Canada/Barbados/Belize/Bolivia/Costa Rica/Columbia/Dominican Republic/Ecuador/El Salvador/Guatemala/Haiti/Honduras/Jamaica/ Mexico/Netherlands Antilles/ Nicaragua/ Panama/ Philippines/Peru/Venezuela/ (Thailand)	31049517	1
Albania/Algeria/Angola/Austria/Azerbaijan/Belarus/Belgium/Bosnia/Bulgaria/Croatia//Cambodia/Cote d'ivoire/Czech/Estonia/Egypt/Finland/France/Georgia/Germany/ Greece/Herzegovina/Hungary/Indonesia/Iceland/Kazakhstan/Kyrgyzstan/Laos/Latvia/ Lebanon/Lithuani	31049518	1
Australia/New Zealand	31049520	1
UK/Hong Kong/Singapore/ Malaysia/Bahrain/Bangladesh/Botswana/Burma/ Brunei /Cyprus/Ghana/Ireland/Jordan/Kenya/Kuwait/Malta/ Nigeria/Oman/ Qatar/United Arab Emirates/Trinidad and Tobago/Saudi Arabia/Sri Lanka	31503352	1
India/(Bangladesh/Sri Lanka)	31503353	1
Taiwan	31503354	1
South Africa/Macao/Namibia/Nepal/Pakistan/Swaziland /Uganda	31503355	1
LA (High Voltage) Argentina, Paraguay, Uruguay	31503356	1
Brazil	31503357	1
Korea	31503358	1
Italy/ Chile/Libya	31503359	1
Denmark	31503360	1
Switzerland/Liechtenstein	31503361	1
Israel	31503362	1
Japan	31503423	1
Japan	31503424	1
Japan	31503425	1
Thermal Module & Fan		
AVC SE42600001 Alphall HS	31506671	N
SUNON EG70040S1-C030-S9A AlphallCPUFAN	31506672	N
SUNON EG70040S1-C040-S9A AlphallSYSFAN	31506673	N
Accessories		
Joystick	20002656	1
Striker	20002657	1
Alpha E-dice 2nd	31504621	1
Alpha E-dice 2nd	31504621	1

Alpha E-dice China USA UK Germany	31504730	1
Alpha E-dice China USA UK Germany	31504730	1
Alpha E-dice MX,PE,VEN,RU,TL	31505756	1
Alpha E-dice MX,PE,VEN,RU,TL	31505756	1
Beta E-dice UA,JO,KU,OMA,QAT,KSA,UAE	31506602	1
E-dice for Asia and South America	31506642	1
E-dice for Asia and South America	31506642	1
Beta E-dice UA,JO,KU,OMA,QAT,KSA,UAE	31506602	1
Battery		
Sanyo Polymer 3S2P 73Wh	31506605	N
Mechanicals		
ASM-ALPHA2_27INCH_BACK_COVER	31506851	N
ASM_Alphall_bracket-A for HDD	31506853	N
ASM_Alphall_BKT_CAMERA	31506854	N
Rear Cover Victory Alpha II	5CB0G15207	N
Hinge Stronkin Alpha II	5H50G15206	N
Cables		
LS Alpha II DC IN Cable	31506675	N
LS Alpha II FFC Cable_158mm	31506676	N
LS Alpha II LVDS CABLE (30PIN)_310mm	31506677	N
LS Alpha II LVDS CABLE (40PIN)_260mm	31506678	N
LS Alpha II NFC Module To MB FFC Cable	31506679	N
LS Alpha II Power Button Cable_710mm	31506680	N
LS Alpha II SATA HDD Cable_120mm	31506681	N
LS Alpha II Side IO Board Cable_FPC	31506682	N
LS Alpha II TO_SCA_Board Cable(Coaxial)	31506683	N
LS Alpha II TO_SCA_Board Cable(Wire)	31506684	N
LS Alpha II WEBCAM CABLE	31506687	N
LS Alpha II FFC for telecontrol	31506688	N
LS Alpha2 WLAN antenna L1 610mm	31506689	N
LS Alpha2 WLAN antenna L2 340mm	31506690	N
LS Alpha II FHD CVT to panel FFC_240mm	31507030	N
LS Alpha II FHD CVTt to scalar board FFC	31507031	N
LS Alpha II LVDS CABLE (30PIN_FHD)_280mm	31507032	N
DELTA ADP-120ZB BBHT common 120W adapter	36200439	N
Liteon PA-1121-04LB 120w common adapter	36200440	N

Chapter 9. General information

This chapter provides general information that applies to all computer models covered by this manual.

Additional Service Information

This chapter provides additional information that the service representative might find helpful.

Power management

Power management reduces the power consumption of certain components of the computer such as the system power supply, processor, hard disk drives, and some monitors.

Advanced configuration and power interface (ACPI) BIOS

As this computer has an ACPI BIOS system, the operating system is allowed to control the power management features of the computer and the settings for Advanced Power Management (APM) BIOS mode is ignored. Not all operating systems support ACPI BIOS mode.

Automatic Power-On features

The Automatic Power-On features within the Power Management menu allow you to enable and disable features that turn on the computer automatically.

- **Wake Up on Alarm:** You can specify a date and time at which the computer will be turned on automatically. This can be either a single event, a daily event or a weekly event.
- **Wake Up on LAN:** This feature allows LAN adapter card to wake the System.