

# Ubuntu Linux Setup Guide

For ThinkStation P520c-P520-P720-P920

Lenovo™



---

## Section 1 - BIOS Setup and Preinstallation Steps

The first step before installing Linux is to make sure BIOS is setup correctly. By default, the system BIOS should be set up to handle both UEFI/GPT and Legacy/MBR partitions.


- **For UEFI/GPT installations (recommended):**
  - Boot into BIOS by pressing the function F1 key at the “Lenovo” splash screen.
  - Select “Setup” from the screen indicated below.

# Lenovo™


# ThinkStation®




- Select “Exit” menu option (left) and set “OS Optimized Defaults” (right) to “Enabled”.




- Select “Yes” at the confirmation screen indicated below.




- Select the “Security” menu option (left), then select “Secure Boot” option (right).




- Disable “Secure Boot”.




- Select F10 to “Save and Exit” BIOS.



- Insert the Ubuntu install media (either through USB or CD/DVD).
- Power on the system and press the F12 function key whenever the following Lenovo splash screen appears:



- Select the Linux bootable installation media “UEFI” option from the F12 boot menu list.




- **For Legacy/MBR installations (not recommended):**
  - Boot into BIOS by pressing the function F1 key at the “Lenovo” splash screen.
  - Select “Setup” from the screen indicated below.



Version 1.01.0040. Copyright (C) 2017 American Megatrends, Inc.

- Select “Exit” menu option (left) and set “OS Optimized Defaults” (right) to “Disabled”.



- Select "Startup" menu option (left) and "CSM Configuration" (right).


The screenshot shows the UEFI Setup Utility interface. On the left, the 'Startup' menu option is highlighted in red. The main area displays the 'CSM Configuration' screen. The 'CSM' dropdown menu is set to 'Enabled', and the 'Boot Mode' dropdown menu is set to 'Auto'. The interface includes a navigation sidebar on the right with options like 'Previous Values(F2)', 'Optimized Defaults(F9)', 'Back (ESC)', and 'Save & Exit (F10)'. The bottom of the screen displays the 'Lenovo UEFI Setup Utility' logo and the version information: 'Version 1.01.0040. Copyright (C) 2017 American Megatrends, Inc.'

- Select the "Storage" option ROM and set the pull-down menu to "Legacy".

The screenshot shows the UEFI Setup Utility interface. On the left, the 'Startup' menu option is highlighted in red. The main area displays the 'Option ROM execution order' screen. The 'Storage' option ROM is highlighted, and its pull-down menu is set to 'Legacy'. The interface includes a navigation sidebar on the right with options like 'Previous Values(F2)', 'Optimized Defaults(F9)', 'Back (ESC)', and 'Save & Exit (F10)'. The bottom of the screen displays the 'Lenovo UEFI Setup Utility' logo and the version information: 'Version 1.01.0040. Copyright (C) 2017 American Megatrends, Inc.'



- Select F10 to “Save and Exit” BIOS.



- Insert the Ubuntu install media (either through USB or CD/DVD).
- Power on the system and press the F12 function key whenever the following Lenovo splash screen appears:



- Select the Linux bootable installation media “Legacy” option from the F12 boot menu.

```
Startup Device Menu:
-----
SATA 1: SanDisk SD7SB6S256G1001
└ Legacy: SanDisk SD7SB6S256G1001
SATA 6: HL-DT-ST DVDROM DH60N
└ Legacy: HL-DT-ST DVDROM DH60N
└ UEFI: HL-DT-ST DVDROM DH60N
Network 1:
└ Legacy: IBA CL Slot 00FE v0110
└ UEFI: IPV4 Intel(R) Ethernet Connection (H) I219-LM
└ UEFI: IPV6 Intel(R) Ethernet Connection (H) I219-LM
Network 2:
└ Legacy: IBA GE Slot 0400 v1555
└ UEFI: IPV4 Intel(R) I210 Gigabit Network Connection
└ UEFI: IPV6 Intel(R) I210 Gigabit Network Connection
Enter Setup


↑ and ↓ to move selection
```



## Section 2 – Installing Ubuntu 16.04 LTS

Please refer to the following instructions and screenshots on how to install Ubuntu 16.04 LTS on the ThinkStation P520c, P520, P720, and P920 workstations.

- Highlight the “*Install Ubuntu*” from the Installer menu and press Enter.




- With Intel Kaby-Lake CPU's, the following warning message may appear.







- Select the language to use during the installation process.




- Optional: Select options to install updates automatically and select “Continue”.




- Select “Erase disk and install Ubuntu” option and “Install Now”.




- Select “Continue” to confirm making changes to the disk.




- Select your location from the map.




- Select your keyboard layout.




- Enter a Username and Password and select "Continue".



- Installing Ubuntu.




- Installation Complete. Select "Restart Now".






- Remove installation media and press ENTER.



- Ubuntu desktop screen.



---

## Section 3 – Installing the Nvidia Graphics Driver


In order to get optimal performance out of the Nvidia GPU, it's a good idea to install the Nvidia graphics driver.

To install the latest Nvidia graphics driver, follow the steps below:


- **Step 1:**
  - Download the Nvidia graphics driver from the Lenovo Support Website.  
<http://pcsupport.lenovo.com/us/en/products/WORKSTATIONS/THINKSTATION-P-SERIES-WORKSTATIONS/THINKSTATION-P320/downloads/DS121444>
- **Step 2:**
  - Blacklist the Linux Nouveau driver.
    - Edit /etc/modprobe.d/blacklist.conf and add the line "**blacklist nouveau**".
    - Run the command from a terminal window: **update-initramfs -u**
    - Reboot the system.
- **Step 3:**
  - Press "Ctrl-Alt-F2", login as root and stop the x-server by running "**service lightdm stop**".
- **Step 4:**
  - Browse to the directory location to where the Nvidia driver installer is located.
- **Step 5:**
  - Run the Nvidia installer.


```
root@lenovo-Lenovo-Product:/home/lenovo/Desktop# ls
NVIDIA-Linux-x86_64-375.61.run
root@lenovo-Lenovo-Product:/home/lenovo/Desktop# ./NVIDIA-Linux-x86_64-375.61.run
```

- **Step 6:**
  - Accept the Nvidia driver license.




- **Step 7:**
  - Continue the installation.







- **Step 8:**
  - Select "OK".



- **Step 9:**
  - Select “Yes” to update the X-configuration file.



- **Step 10:**
  - Driver installation complete.



- **Step 11:**
  - Verify the Nvidia driver is loaded by running “nvidia-smi”.

```
root@lenovo-Lenovo-Product:/home/lenovo/Desktop# nvidia-smi
Mon Jul 31 14:26:23 2017

+-----+
| NVIDIA-SMI 375.61                  Driver Version: 375.61          |
+-----+-----+-----+-----+-----+-----+
| GPU  Name      Persistence-M | Bus-Id  Disp.A | Volatile Uncorr. ECC |
| Fan  Temp  Perf  Pwr:Usage/Cap |      Memory-Usage | GPU-Util  Compute M. |
+-----+-----+-----+-----+-----+-----+
|   0   Quadro P600      Off      | 0000:01:00:0    Off      |      0%      N/A     |
|  0%   44C    P0      12W /  N/A     |    0MiB /  1996MiB |              Default |
+-----+-----+-----+-----+-----+-----+

Processes:
+-----+-----+-----+-----+-----+-----+
| GPU  PID  Type  Process name      | GPU Memory Usage |
+-----+-----+-----+-----+-----+-----+
| No running processes found |
+-----+-----+-----+-----+-----+-----+

root@lenovo-Lenovo-Product:/home/lenovo/Desktop# _
```

- **Step 12:**
  - Reboot the system.
- **Step 13:**
  - Verify the Nvidia driver is loaded properly from within X-windows.

```
Terminal
lenovo@lenovo-Lenovo-Product:~$ sudo su -
[sudo] password for lenovo:
lenovo@lenovo-Lenovo-Product:~$ nvidia-smi
Mon Jul 31 14:28:09 2017

+-----+
| NVIDIA-SMI 375.61                  Driver Version: 375.61          |
+-----+-----+-----+-----+-----+-----+
| GPU  Name      Persistence-M | Bus-Id  Disp.A | Volatile Uncorr. ECC |
| Fan  Temp  Perf  Pwr:Usage/Cap |      Memory-Usage | GPU-Util  Compute M. |
+-----+-----+-----+-----+-----+-----+
|   0   Quadro P600      Off      | 0000:01:00:0    Off      |      0%      N/A     |
| 34%  39C    P8      12W /  N/A     |   178MiB /  1996MiB |              Default |
+-----+-----+-----+-----+-----+-----+

Processes:
+-----+-----+-----+-----+-----+-----+
| GPU  PID  Type  Process name      | GPU Memory Usage |
+-----+-----+-----+-----+-----+-----+
|   0   989  G    /usr/lib/xorg/Xorg |    13MiB |
|   0   1417  G    compiz             |    40MiB |
+-----+-----+-----+-----+-----+-----+

lenovo@lenovo-Lenovo-Product:~$
```

---

## Section 4 – Installing the Network Wireless Driver

The wireless network device offered for the P320 is native to Ubuntu 16.04 LTS; therefore, you will not need to install any additional drivers separately.

---

## Section 5 – Installing the Network LAN Driver

The network LAN device is native to Ubuntu 16.04 LTS; therefore, you will not need to install any additional drivers separately.