



Logitech® Mobile Speakerphone P170e

Setup Guide



Guide d'installation

Need image of product for front cover

Contents

English	4	Français	9
www.logitech.com/support 			15

Product Features






1. NFC target area
2. Call answer
3. Microphone mute
4. Increase volume
5. Decrease volume
6. Call end
7. Power on
8. Bluetooth pairing
9. Battery indicator light
10. Headphone jack

	Power button	Powers on or off the P710e
	Bluetooth pairing button	Press and hold until blue lights appear on the top to place P710e in pairing mode
	Battery level indicator	Will show green once it is fully charged.
	Call answer button	Press to answer a call or to “flash for an incoming call”
	Call end/reject button	Press to end a call or reject an incoming call
	Volume up button	Press to increase speaker volume
	Volume down button	Press to decrease speaker volume
	Microphone button	Press to mute the microphone
	NFC target area	Place the NFC antenna of your mobile device near the target area to pair or connect/disconnect

We recommend you charge the P710e prior to first use. You can charge by either using the enclosed AC adapter or by connecting to a USB port on a computer—although the AC adapter charges more quickly.

Charge times with the AC adapter	
15 minutes of charge	Provides about 2 hours of talk time
½ hour of charge	Provides about 4 hours of talk time
3 hours of charge	Provides a full charge

Inserts/sliding top




The top of the P170e can be slid back to reveal a parking slot for your mobile device. This slot is especially useful when using your mobile device for video conferences for greater stability of the image for those on the other end of the call.

There is an insert that can be used in the parking slot to adjust to the size of your mobile device. The insert can be placed in two ways as illustrated.

The approximate size of mobile device that will fit in the parking slot is:


Side 2: 0mm–8.5mm

Side 1: 8.5mm–10.5mm




Setup with a computer

- Connect the USB cable from the P170e into your PC.
- Ensure that the P170e is selected as the default audio device in your OS settings and in your application.



Setup with a Bluetooth device

- Press and hold the Bluetooth button on the side of the P170e until the blue lights start flashing on the top. Place your mobile device in pairing mode and pair to the P170e.
- If you have an NFC enabled device, position it near the NFC target area on the P170e. You should see a message on your phone asking if you would like to pair to the P170e.
 - Note, position your NFC enabled device near the NFC target area a second time to disconnect from the P170e. This is helpful if you're still in range of the P170e, but want to handle calls on the mobile device.
 - Repeat the procedure again to reconnect.



Troubleshooting

Bad or no audio?

- Check if USB cable is fully inserted into the computer's USB port.
- Check that your mobile device is paired with the P710e
- Using a non-powered USB hub may degrade headset performance.
- Check the volume level in both your media/voice application and your PC.
- Try restarting your media/voice application. Ensure the microphone is not muted.
- Make sure the Logitech P710e Speakerphone is the default audio device.

Windows Vista, Windows 7:

- Close all media/voice applications
- Go to Start/Control Panel/ Sound/ Playback Devices tab.
- Choose Logitech P710e.
- Click on Set Default.
- Click on the "Recording" tab.
- Choose Logitech P710e.
- Click on "Set Default".
- Restart your media/video application.

Windows 8:

- Close all media/voice applications
- From the Start Menu, select "Desktop" tile.
- From the Charms menu, select Settings>Control Panel>Hardware and then Sound.
- Go to Sound and select the "Playback" tab.
- Choose Logitech P710e
- Click on Set Default.
- Click on the "Recording" tab.
- Choose Logitech P710e. Click on "Set Default".
- Restart the media/video application.

Mac OS X:

- Close all media/voice applications
- Open System Preferences.
- Select Sound/ Output tab, and then select Logitech P710e".
- Restart media/video application.

For additional support, please visit us at www.logitech.com/support



www.logitech.com/business

www.logitech.com/support



1-877-897-9879

© 2013 Logitech. All rights reserved. Logitech, the Logitech logo, and other Logitech marks are owned by Logitech and may be registered. The Bluetooth word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. and any use of such marks by Logitech is under license. The N Mark is a trademark or registered trademark of NFC Forum, Inc. in the United States and in other countries. All other trademarks are the property of their respective owners. Logitech assumes no responsibility for any errors that may appear in this manual. Information contained herein is subject to change without notice.

© 2013 Logitech. All rights reserved. Logitech, the Logitech logo, and other Logitech marks are owned by Logitech and may be registered. The Bluetooth word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. and any use of such marks by Logitech is under license. The N Mark is a trademark or registered trademark of NFC Forum, Inc. in the United States and in other countries. All other trademarks are the property of their respective owners. Logitech assumes no responsibility for any errors that may appear in this manual. Information contained herein is subject to change without notice.

620-05270.002