


Safety Precautions

- Read this guide carefully and keep it for future reference.
- Follow all instructions for safe use and handling of the product.
- Use the camera within given temperature, humidity and voltage levels noted in the camera's specifications.
- Do not disassemble the camera.
- Do not point the camera directly at the sun or a source of intense light.
- Periodic cleaning may be required. Use a damp cloth only. Do not use any harsh, chemical-based cleaners.

Dimensions



Disclaimers

- The camera is rated for indoor use only. Do not mount the camera outdoors.
- Do not place the magnetic mounting plate on or near other electrical devices.
- This camera includes an Auto Mechanical IR Cut Filter. When the camera changes between Day/Night viewing modes, an audible clicking noise may be heard from the camera. This clicking is normal, and indicates that the camera filter is working.
- Audio recording without consent is illegal in certain jurisdictions. Lorex Corporation assumes no liability for use of its products that does not conform with local laws.

Troubleshooting

Problem	Solution
Cannot set up camera	<ul style="list-style-type: none"> • Ensure your mobile device is within 1ft (30cm) of the camera during setup.
No picture / signal	<ul style="list-style-type: none"> • Ensure the LED indicator on the camera is glowing steady green. See 'LED Behavior' section for details if otherwise. • Ensure the camera is properly connected to power using the included USB power adapter. • Try repositioning the camera, router, or both to improve signal strength.
Picture is not clear	<ul style="list-style-type: none"> • Check the camera lens for dirt, dust, and spiderwebs. Clean the lens with a soft, clean cloth. • Remove the vinyl cover on the camera lens.
No audio	<ul style="list-style-type: none"> • Ensure audio function on camera is turned on. • Ensure audio is turned up on viewing device.
Person detection is not working	<ul style="list-style-type: none"> • Ensure you have enabled Person Detection in the Device Settings screen of the Lorex Home app. See 'Overview of Lorex Home app' for details.

LOREX®

2K SMART INDOOR WI-FI CAMERA

Please take attention that changes or modification not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) This device must accept any interference received, including interference that may cause undesired operation.

This device complies with Industry Canada licence-exempt RSS standard(s). Operation is subject to the following two conditions:

- (1) this device may not cause interference, and
- (2) this device must accept any interference, including interference that may cause undesired operation of the device.

Le présent appareil est conforme aux CNR d'Industrie Canada applicables aux appareils radioexemptés de licence. L'exploitation est autorisée aux deux conditions suivantes :

- (1) l'appareil ne doit pas produire de brouillage, et
- (2) l'utilisateur de l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.

This equipment complies with FCC/IC RSS-102 radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator & your body.

ce matériel est conforme aux limites de dose d'exposition aux rayonnements, FCC / CNR-102 énoncée dans un autre environnement. cette équipement devrait être installé et exploité avec distance minimale de 20 entre le radiateur et votre corps.

W461AS Series Quick Start Guide

lorex.com

Need Help?

Visit us online for up-to-date software and complete instruction manuals



- 1 Visit lorex.com
- 2 Search for the model number of your product
- 3 Click on your product in the search results
- 4 Click on the **Downloads** tab

Copyright © 2019 Lorex Corporation

As our products are subject to continuous improvement, Lorex reserves the right to modify product design, specifications and prices, without notice and without incurring any obligation. E&OE. All rights reserved.

LED Behavior

See table below for definitions of camera's LED behaviors:


Behavior	Meaning
● (steady)	Operating correctly.
● (flashing)	Ready for connection.
● (flashing rapidly)	Mobile device is attempting to connect to the camera.
● (steady)	Device malfunction. Try resetting the camera (see 'Camera Overview' for details) and repeating the setup.
● (flashing)	Network connection failed. Try resetting the camera (see 'Camera Overview' for details) and repeating the setup.
● (flashing rapidly)	microSD error. Try removing and re-inserting the included microSD card, or try a different card.
●● (alternating)	Firmware upgrade in progress.

FCC Notice

THIS DEVICE COMPLIES WITH PART 15 OF THE FCC RULES. OPERATION IS SUBJECT TO THE FOLLOWING TWO CONDITIONS:

- (1) THIS DEVICE MAY NOT CAUSE HARMFUL INTERFERENCE, AND
- (2) THIS DEVICE MUST ACCEPT ANY INTERFERENCE RECEIVED, INCLUDING INTERFERENCE THAT MAY CAUSE UNDESIRE OPERATION.

Package Contents




ATTENTION:

A REGULATED UL / CSA APPROVED power supply is REQUIRED for use with this camera (included). Use of a non-regulated, non-conforming power supply can damage this product and voids the warranty.

Camera Overview

- A Status LED**
- B Microphone**
- C microSD slot:** microSD card pre-inserted (expandable up to 256GB, microSD class 10 or higher).
- D Speaker**
- E Reset button:** Press and hold until the chime sounds to reset the camera.
- F Power:** Connect the included USB power adapter.



W261AS_QSG_EN_R2

STEP 1: Connecting to Lorex Home

Connect to the camera using the free Lorex Home app on your iPhone® or Android™ phone.

To connect your camera to Lorex Home:

1. Connect the camera cable to the included USB adapter and plug into a nearby outlet.
2. Download and install the free **Lorex Home** app from the App Store or Google Play Store.
3. Tap the Lorex Home icon to launch the app. Tap **Sign up**, then follow the on screen prompts to create an account. Record your account details below:



Email: _____

Account Password: _____

4. Once the status LED on the camera is flashing green and the startup chime sounds, tap **+**.
5. Scan the QR code on the back of the camera using your mobile device's camera.

NOTE: If your mobile device cannot scan the QR code, tap **Manually enter Device ID**.

6. Create a secure password for the camera. Record your camera password below:


Camera Password: _____

7. Select your Wi-Fi network from the list, then enter the password to connect your camera to the Internet.
8. Once the status LED on the camera is solid green, tap **Next** to add the camera to your Lorex Home account.
9. Set a name for the camera and configure date & time preferences, then tap **Complete** to finish the setup.

STEP 2A: Installation Tips

To ensure the best possible wireless performance, it is recommended to keep the following installation tips in mind when choosing a location for the camera:

- Place the camera as close to your Wi-Fi router or access point as possible.
- Reduce the number of obstructive materials between the camera and the router or access point. Concrete, brick, metal and wood are the most common materials in your house that can cause poor signal strength.



- Other electronic devices such as microwaves, TVs, cordless phones, and baby monitors can cause signal interference. It is recommended to install the camera as far away from these devices as possible.





STEP 2B: Wall/Ceiling Mounting (Optional)

The camera is ready at this point to be placed on any surface and begin monitoring if you would like to keep the placement of your camera flexible.

You also have the option to mount the camera to an indoor wall or ceiling using the included mounting accessories. Use the included double-sided tape to mount the camera with no drilling required, or follow the steps below for permanent mounting.

To mount the camera:

1. Mark the camera's mounting position using the included mounting template.
2. Drill holes where marked on the mounting template.
3. Position the holes in the magnetic mounting plate over the mounting points.
4. Attach the magnetic mounting plate to the mounting surface using the included mounting screws.
5. Place the camera base on the magnetic mounting plate to secure it to the mounting surface. Adjust the camera's position as needed.



NOTE: If you are installing the camera on a ceiling, use the **Image Rotation** feature on the Device Settings screen of the Lorex Home app to flip the camera image (see 'Overview of Lorex Home App' for details).

Overview of Lorex Home App

Overview of the live viewing screen and controls in the Lorex Home app. For complete instructions on using the app, see the Lorex Home app manual on your product page at lorex.com.

The screenshot shows the app interface with the following labels and functions:

- Back to previous screen:** Arrow icon on the top left.
- Device name:** 'Lorex-IPC' at the top center.
- Device settings:** Gear icon on the top right.
- Play back recorded video:** Timeline icon on the left side of the video player.
- Snapshot:** Camera icon on the bottom left.
- Manual recording:** Video camera icon on the bottom right.
- 2-way audio: tap to speak, tap again to disable:** Microphone icon in the center.
- Pause / Play:** II icon on the bottom left.
- Viewing modes:** 1 icon on the bottom left.
- Streaming quality*:** SD icon on the bottom left.
- Mute / Unmute:** Speaker icon with an X on the bottom left.
- Fullscreen:** Four arrows icon on the bottom right.

* Change the streaming quality to **SD** (Standard Definition) to conserve bandwidth while watching live video. This will not impact the quality of recorded video.