

Microsoft Corporation

Xbox 360 Video Game and Entertainment System

Position Your Xbox
Connect to Your TV
Electrical Safety
Connect to Power
Set Up Your Controller
Set Up Your Headset
Choose Your Family's Experience
Play Discs
Set Up Storage
Set Up Your Home Network
Join Xbox LIVE
Share Music, Pictures, and Videos
Troubleshoot
Take Care of Your Xbox
Healthy Playing
Limited Warranty and Returns
Regulations
Copyright
Customer Support

WARNING

[IMAGE: alert.jpg]

Failure to properly set up, use, and care for the Xbox 360 video game and entertainment system can increase the risk of serious injury or death, or damage to the Xbox 360 video game and entertainment system. Read this manual and the manuals of any accessories for important safety and health information. Keep all manuals for future reference. For replacement manuals, go to www.xbox.com/support.

Before allowing children to use the Xbox 360 video game and entertainment system:

- 1 Determine how each child can use the Xbox 360 console (playing games, connecting to Xbox LIVE, replacing batteries, making electrical, AV cable, and network connections) and whether they should be supervised during these activities.
- 2 If you allow children to use the Xbox 360 console without supervision, be sure to explain all relevant safety and health information and instructions.

The Xbox 360 console will not play copied or "pirated" games or other unauthorized media. Attempting to defeat the Xbox 360 anti-piracy protection system may cause your Xbox 360 console to stop working permanently. It will also void your Limited Warranty, and may make your Xbox 360 console ineligible for authorized repair, even for a fee.

BY USING YOUR XBOX 360 YOU AGREE TO THE WARRANTY IN THIS MANUAL. BEFORE SETTING UP YOUR XBOX 360, PLEASE READ THIS WARRANTY CAREFULLY. IF YOU DO NOT ACCEPT THIS WARRANTY, DO NOT USE YOUR XBOX 360. RETURN IT TO MICROSOFT FOR A REFUND.

[IMAGE: Alert.jpg] This symbol identifies safety and health messages in this manual and Xbox 360 accessories manuals. For your warranty and other important information, see the Xbox 360 Warranty manual.

POSITION YOUR XBOX

Orientation

You can position your console horizontally or vertically, whichever you prefer. However, change console orientation from one to the other only when it is turned off with no disc in the tray.

Prevent the Console from Falling

[IMAGE: Alert.jpg]

If the Xbox 360 console falls and hits someone, especially a small child, it could cause serious injury. To reduce the risk of such injuries and damage to the Xbox 360 console, set up the Xbox 360 console according to these instructions. Place the console on a surface that:

- Is flat and level.
- Is stable and not likely to tip over.
- Allows all four feet of the console to be in contact with the surface.
- Is not likely to allow the console to slip or slide off.
- Is clean and free of dust and debris.

If the surface or console feet become dirty or dusty, clean them with a dry cloth. If the console is positioned vertically, put it on a surface where it is not likely to fall if it tips over.

Arrange all cables and cords so that people and pets are not likely to trip over or accidentally pull on them as they move around or walk through the area. When the console is not in use, you may need to disconnect all cables and cords from the front and rear of the console to keep them out of the reach of children and pets. Do not allow children to play with cables and cords.

Prevent the Console from Overheating

Do not block any ventilation openings on the console or power supply. Do not place the console or power supply on a bed, sofa, or other soft surface that may block ventilation openings. Do not place the console or power supply in a confined space, such as a bookcase, rack, or stereo cabinet, unless the space is well ventilated.

Do not place the console or power supply near any heat sources, such as radiators, heat registers, stoves, or amplifiers.

Avoid Smoke and Dust

Do not use the console in smoky or dusty locations. Smoke and dust can damage the console, particularly the DVD drive.

CONNECT YOUR TV

Connect the AV Cable

ART OF COMPOSITE CONNECTION

To connect to your standard TV with composite:

- 1 Connect the AV cable to the AV port on the console.
- 2 Set the switch on the cable to TV.
- 3 Connect the yellow color-banded composite connector on the cable to the yellow input on your TV. Leave the red, green, and blue video connectors unconnected.
- 4 Connect the solid color left and right (white and red) audio connectors on the cable to the audio inputs on your TV. Don't confuse the red audio connector with the red video connector.
For mono audio, connect either the right or left audio connector to the single audio input.
- 5 Select the appropriate video input on your TV (such as "input," "AUX," "Line in," "source" or other TV setting).

ART OF COMPONENT CONNECTION

To connect to your high definition TV with component:

- 1 Connect the AV cable connector to the AV port on the console.
 - 2 Set the switch on the AV port connector to HDTV.
 - 3 Connect the red, green, and blue color-banded video connectors on the AV cable to the corresponding color inputs (Y, Cb/Pb, Cr/Pr) on your TV. Leave the yellow color-banded composite connector unconnected.
 - 4 Connect the solid color left and right (white and red) audio connectors on the HD AV cable to the audio inputs on your TV or stereo receiver.
 - 5 Select the appropriate video input on your TV (such as "input," "AUX," "Line in," "source" or other TV setting).
- After you've set up your console, you can test your connection in the Xbox Dashboard. First, proceed through the steps for connecting to power, connecting your controller, and other settings.

Connect to a Digital Audio System

ART OF TOSLINK CONNECTION

If your system (typically, a receiver or amplifier) supports digital audio input, you can connect to digital audio rather than to the standard left and right audio. Digital audio should produce higher-quality sound.

To connect to digital audio:

- 1 Connect your video input as described above.
- 2 Connect a digital audio cable (not included) to the digital audio output on your console and to the digital audio input on your receiver.

Other Input

You can also connect to additional TV input types such as HDMI and VGA with cables sold separately. For more information, go to www.xbox.com/setup.

IMPORTANT

Stationary images in video games can "burn" into some TV screens, creating a permanent shadow. Consult your TV owner's manual or manufacturer before playing games.

CONNECT TO POWER

Connect to Power

ART OF POWER CONNECTION

Always connect the power cords according to the following instructions:

- 1 Fully insert the power supply cord into the Xbox 360 console.
- 2 Plug the AC power cord into the power supply until it stops.
- 3 Plug the other end of the AC power cord into the wall outlet.

Electrical Safety

[IMAGE: Alert.jpg]

As with many other electrical devices, failure to take the following precautions can result in serious injury or death from electric shock or fire or damage to the Xbox 360 video game and entertainment system.

Select an appropriate power source for your Xbox 360 console:

- Use only the power supply unit and AC power cord that came with your console or that you received from an authorized repair center. If you are not sure if you have the correct power supply unit, compare the model number on the power supply unit with the model number specified on your console. If you need a replacement power supply unit or power cord, you can find Xbox Customer Support contact information at www.xbox.com/support.
- Confirm that your electrical outlet provides the type of power indicated on the power supply unit (in terms of voltage [V] and frequency [Hz]). If you are not sure of the type of power supplied to your home, consult a qualified electrician.
- Do not use non-standard power sources, such as generators or inverters, even if the voltage and frequency appear acceptable. Only use AC power provided by a standard wall outlet.
- Do not overload your wall outlet, extension cord, power strip, or other electrical receptacle. Confirm that they are rated to handle the total current (in amps [A]) drawn by the Xbox 360 console (indicated on the power supply unit) and any other devices that are on the same circuit.
- Do not connect any other devices between the Xbox 360 power supply unit and the Xbox 360 console or between the power cord and the Xbox 360 power supply unit.

To avoid damaging the power cords and power supply:

- Protect the power cords from being walked on.
- Protect cords from being pinched or sharply bent, particularly where they connect to the power outlet, the power supply unit, and the console.
- Do not jerk, knot, sharply bend, or otherwise abuse the power cords.
- Do not expose the power cords to sources of heat.
- Do not wrap power cords around the power supply unit.
- Keep children and pets away from the power cords. Do not allow them to bite or chew on them.
- When disconnecting the power cords, pull on the plug—do not pull on the cord.
- Do not let the power supply hang from either power cord.

If a power cord or power supply becomes damaged in any way, stop using it immediately. Visit www.xbox.com/support for Xbox Customer Support contact information.

Unplug your Xbox 360 console during lightning storms or when unused for long periods of time.

SET UP YOUR CONTROLLER

Insert batteries before using your controller with your console.

Insert Batteries

The wireless controller uses either disposable AA or LR6 batteries (included) or rechargeable NiMH batteries (sold separately). If you want to use rechargeable batteries, you'll need the Xbox 360 Play and Charge Kit, sold separately.

[IMAGE: insertAA.jpg]

To insert batteries:

- 1 Press the tab on the top of the AA battery pack and pull down to detach it from the controller.
- 2 Insert two new AA (LR6) batteries with their positive (+) and negative (-) ends as shown on the underside of the battery pack.
- 3 Slide the battery pack back into place on the controller and push it in to lock.

NOTE

To avoid pinching your fingers when inserting, push only on the flat surface of the battery pack.

Disposable Battery Safety

[IMAGE: Alert.jpg]

Improper use of batteries may result in battery fluid leakage, overheating, or explosion. Risk of fire if batteries are replaced by an incorrect type.

Released battery fluid is corrosive and may be toxic. It can cause skin and eye burns, and is harmful if swallowed. To reduce the risk of injury:

- Keep batteries out of reach of children.
- Do not heat, open, puncture, mutilate, or dispose of batteries in fire.
- Use only alkaline batteries, type AA (LR6).
- Do not mix new and old batteries.
- Remove the batteries if they are worn out or before storing your controller for an extended period of time. Do not leave batteries in the AA battery pack when it is not installed in the controller.
- If a battery leaks, remove all batteries, taking care to keep the leaked fluid from touching your skin or clothes. If fluid from the battery comes into contact with skin or clothes, flush skin with water immediately. Before inserting new batteries, thoroughly clean the battery compartment with a damp paper towel, or follow the battery manufacturer's recommendations for cleanup.
- Dispose of batteries in accordance with local and national disposal regulations (if any).

Remove Controller Batteries Aboard Aircraft

Before boarding any aircraft or packing the wireless controller in luggage that will be checked, remove any batteries from the wireless controller. The wireless controller can transmit radio frequency (RF) energy, much like a cellular telephone, whenever batteries are installed.

Turn Your Console and Controller On

ART OF XBOX GUIDE BUTTON ON NEW CONTROLLER

To turn your console and controller on, press and hold the Xbox Guide button on your controller.

Connect Your Controller to Your Console

Your controller comes already wirelessly connected to your console, right out of the box. However, additional controllers can be connected, or you might want to connect to a different console.

To connect a wireless controller to your console:

- 1 Press and hold down the Xbox Guide button until the controller turns on.
- 2 Make sure the console is turned on. If not, press the Power button.
- 3 Press and release the Connect button on the console.
- 4 Press and release the Connect button on the controller.
- 5 After the lights on the controller and console spin and flash once, the controller is connected.

SET UP YOUR HEADSET

Use your Xbox 360 Headset to friends while on Xbox LIVE.

ART OF HEADSET CONNECTION

Connect Your Headset to Your Controller

To connect your headset:

- 1 Turn down the volume by rotating the volume control all the way to the left. Insert the headset connector into the controller expansion port.

[IMAGE: Headset2.jpg]

- 2 Put on your headset and adjust the microphone position.

[IMAGE: HeadsetPosition.jpg]

Use Your Headset

To chat and send voice messages, you need to play a game on Xbox LIVE.

To temporarily turn off voice transmission, slide the mute switch on the headset control. To adjust the listening volume of the headset, rotate the volume control knob. For more information about using your Xbox 360 Headset with a particular game, see your game manual.

CHOOSE YOUR FAMILY'S EXPERIENCE

The Family Settings feature for Xbox 360 gives parents and caregivers the ability to provide age-appropriate entertainment through customized settings. Console settings can limit the games and movies that can be played on your console. Xbox LIVE settings can customize the Xbox LIVE experience for each child account, even when playing away from home.

Apply Family Settings

You can apply Family Settings for games, movies, and Xbox LIVE in the Xbox Dashboard. For information and instructions, see www.xbox.com/familysettings.

In the U.S. and Canada, Xbox 360 Family Settings for games follow the ESRB (Entertainment Software Rating Board) rating system. Movie settings for the U.S. are based on the MPAA (Motion Picture Association of America) rating system, and those for Canada are based on CHVRS (Canadian Home Video Rating System). By default, Xbox 360 Family Settings are set to Allow All for games and movies. For more information about game ratings, see www.esrb.org.

Not all movies have the rating encoded on the DVD. These DVD movies will always play unless you block unrated video in Family Settings.

Xbox LIVE Settings

You can make sure that your family has a positive experience on Xbox LIVE by setting limits for each child's account. Your child's Xbox LIVE settings are pre-selected when their Xbox LIVE account is created. You can make changes at any time in the Xbox Dashboard. For information and instructions, see www.xbox.com/familysettings.

Family Settings for Xbox LIVE includes:

- Parental approval for adding individuals to your child's friends list.
- Limiting voice, video, and text chat to individuals on your child's friends list.
- Blocking or limiting the display of your child's profile information and online status.
- Blocking or limiting your child's ability to view content created by other gamers.
- Blocking access to Xbox LIVE multiplayer games.
- Preventing your child from purchasing items on Xbox LIVE Marketplace.

PLAY DISCS

The Xbox 360 console can play game discs licensed by Microsoft for the Xbox 360, Region 1 DVD movie discs, or CD music/audio discs. An Xbox compatible disc has one of these logos:

[IMAGE: xe.jpg]

[IMAGE: dvd.jpg]

[IMAGE: cd.jpg]

Just press the eject button to open the disc tray to insert a disc.

ART OF DISC TRAY EJECTED

NOTE

When the console is oriented vertically, make sure the disc is held in place by the tabs on the disc tray so that it doesn't fall.

IMPORTANT

To avoid jamming the disc drive and damaging discs or the console:

- Remove discs before moving the console or tilting it between the horizontal and vertical positions.
- Never use cracked discs. They can shatter inside the console and jam or break internal parts.
- When the console is vertical, do not use discs that are smaller than standard DVDs and CDs.

STORAGE

With the Xbox 360 Hard Drive (included) or a USB flash drive (sold separately), you can save games and other media and enable Xbox LIVE sign-in.

Remove and Reattach Your Hard Drive

Your Xbox 360 console comes with a hard drive attached, but should you need to remove it, use the following procedures for removal and reattachment.

ART OF HARD DRIVE REMOVAL WITH COVER OFF

To remove your hard drive:

- 1 Turn off your console.
- 2 Remove the hard drive cover.
- 3 Remove the hard drive from the console.

IMPORTANT

Do not remove or attach the hard drive when power is on, and avoid touching hard drive bay contacts and hard drive connector contacts with fingers or metal objects.

To attach your hard drive:

- 1 Turn off your console.
- 2 With the hard drive cover removed, insert the hard drive fully into its slot.
- 3 Replace the hard drive cover.

Use USB Flash Drives

For portable storage, connect any Xbox 360 compatible USB flash drive to any available console USB port. The flash drive will be available for storage in the Xbox Dashboard.

INSERT GENERIC THUMBRIVE INTO USB PORT

SET UP YOUR HOME NETWORK

TRINITY ON A GENERIC WIRELESS INFRASTRUCTURE

The Xbox 360 should be connected to a home network for Xbox LIVE and to share media with a Windows Media Center PC. You can even set up a connection between one Xbox 360 and another for head-to-head play. Your console can be has integrated networking, or can be connected to an Ethernet network using an Ethernet cable (sold separately). For more information about setting up your connection and further home networking options, go to www.xbox.com/setup.

If you don't have a wireless home wireless network yet, you'll want to make a few decisions before you set one up. Specifically, you'll need to decide on the wireless standard you'll use, the network hardware you'll need, and your network security. Your console supports the following:

- 2.4-GHz operation.
- 802.11b/g/n standards
- WEP, WPA, and WPA2 security

Connecting your Xbox 360 console to a wireless network is easy as long as you know what your wireless network settings are. You can find most of your wireless network settings on the set-up screens for your wireless access point or router. The device documentation will have instructions for accessing these screens. If your network was set up by someone else, contact the installer for a user name and password to access the set-up screens.

To connect your console to a wireless network:

- 1 Turn on your console and any wireless networking devices (such as access points or routers).
- 2 In the Xbox Dashboard system settings, enter your settings for network name, security (SSID) and workgroup (if used).
- 3 The console will connect to your network and proceed through network configuration.

Alternately, you cannot use wireless connect directly to an Ethernet router or modem. For wired networking options, go to www.xbox.com/setup.

CONNECT TO XBOX LIVE

ART THAT CONVEYS XBOX LIVE FUN WITH MARKETPLACE, AVATARS, CHAT, ETC

You can instantly become an Xbox LIVE member for free by simply connecting to Xbox LIVE after your console is connected to your home network with high-speed Internet access. Xbox LIVE is evolving entertainment, in the way we watch, the way we play, the way we come together for fun. Find the perfect game with a free trial of hundreds of titles from the largest library available. Extend the fun of your favorites with Game add-ons like new songs, levels and characters then invite friends all over the world to connect, cheer and play along. Plus, with thousands of HD movies and TV episodes to watch instantly from Netflix, movie night flickers to life at the press of a button.

In the Xbox Dashboard, just join Xbox LIVE. Follow the instructions onscreen to create your free account.

If you're ready for the full Xbox LIVE experience, experience the best in entertainment with Xbox LIVE Gold. Raise the curtain on your own instant movie night with thousands of HD movies and TV episodes streamed instantly from Netflix (Netflix sold separately). And as a Gold member, you'll enjoy exclusive weekly discounts on the best content anywhere and special sneak-peak game demos that give you early access to the newest and latest. Plus Xbox LIVE Gold's advanced online multiplayer gaming allows you to invite friends all over the world to connect, cheer and play along.

NOTE

You must have a high-speed (cable or DSL) Internet connection for Xbox LIVE. For more information, go to www.xbox.com/live.

SHARE MUSIC, PICTURES, AND VIDEOS

ART OF MEDIA DEVICES CONNECTING TO TRINITY

Use your Xbox 360 console to play music, view pictures, and watch video from other devices. You can connect devices such as Zunes or other portable audio players, digital cameras and USB flash drives to the Xbox 360 USB ports. You can also share media to your console from a Windows-based PC or a Windows Media Center-based PC on the same home network.

For a list of third-party devices supported by Xbox 360, go to www.xbox.com/media.

To stream music or view pictures, just configure your device for output through USB, and connect it to your console with a USB cable (sold separately). Or for media on USB flash drives, just connect the drive to any console USB port directly.

To learn more about home networking with a Windows-based PC or Windows Media Center-based PC, go to www.xbox.com/media.

NOTE

Not all music formats or devices are fully supported, and you cannot play copyright-protected music on your device from certain services such as

Zune Marketplace and Apple iTunes.

To play unprotected AAC music from an Apple iPod device, use your Xbox LIVE account to download a free update from Xbox LIVE Marketplace. Please see www.xbox.com/media for more information.

Recordings and programs may be protected by copyright. Microsoft does not authorize, support, or condone the use of its products for unauthorized copying. You may not copy, reproduce, distribute, publicly perform, or modify recordings unless authorized by the copyright owner or allowed by law.

TROUBLESHOOT

Follow these steps to troubleshoot any difficulties you may have with the Xbox 360 video game and entertainment system. If the steps in this troubleshooting section do not solve your problem, go to www.xbox.com/support. Do not take your Xbox 360 console or its accessories to your retailer for repair or service. Please visit www.xbox.com/support for troubleshooting and service information.

No Power

Confirm that you have an appropriate power source and check all connections between wall outlet and power supply, and power supply and console. The power supply light should glow green when it is working properly.

No Picture

Connect the appropriate AV cable. Turn on the TV. Select the video input on the TV (or VCR, if connected to a VCR) that displays the Xbox 360 game. Common names for video input include Input Select, AUX, Line In, Line In, Input, Source, and EXT, depending on your TV or VCR type. For more information, see your TV or VCR manual. Don't connect both the included AV cable and an HDMI AV cable to the console at the same time.

No Sound

Check the AV connection. If you're using digital audio, make sure the receiver is turned on and the output in your console's audio settings is set correctly. Don't connect both the component HD AV cable and the HDMI AV cable to the console at the same time.

Poor-Quality Sound

Clean the disc as shown in the Xbox 360 Warranty manual (Volume 2). Check the AV connection (see "Connect to Your TV and Audio System"). Play Dolby® Digital audio only on audio systems that support Dolby Digital. Select the audio output that is supported by your system or TV: stereo or Dolby® Surround for stereo speakers, mono for monaural speakers. If sound is coming from only one speaker, check that all audio cables are connected correctly. Only connect the optional audio adapter cable for audio output while the HDMI AV cable is connected.

Game, Movie, or Music Does Not Start

Play only supported discs (Xbox 360 games, audio CDs, DVD movies). Clean the disc. Insert the disc fully close the disc tray.

Power Light Flashes

The light of the console power button should glow solid green while the console is on and flash when you press the eject button. If it flashes differently during operation, follow these steps:

- Flashes red: The console is too hot and will not play games until cooled down. Place the console in a well-ventilated area away from other heat sources. Once the console cools, the flashing will stop and the Xbox 360 console can be played. For more information, see "Select a Location for the Console."
- Solid red: follow instructions onscreen to correct the problem.
- Solid red, no onscreen instructions: Internal problem that requires service. Go to www.xbox.com/support to request service.

Wireless Controller Does Not Work

Turn on the wireless controller by pressing the Xbox Guide button and connect the wireless controller to your console (see "Add Wireless Controllers").

If lights spin longer than 15 seconds when connecting:

- Move the controller closer to the console.
- Make sure the batteries are fresh.
- Keep the console and controller at least three feet away from large metal objects, such as file cabinets and refrigerators.
- Metallic decorations or stickers on the console or controller can interfere with wireless controller performance. Remove decorations and try connecting again.
- Make sure the front of the console is positioned in the direction of the controller and away from nearby walls.
- Cordless phones (2.4 GHz), wireless LANs, wireless video transmitters, microwave ovens, some mobile/cell phones, and Bluetooth headsets can interfere with the operation of the controller. Turn these off or unplug them and retry connecting.
- If nothing else works, turn off your console, remove and reinsert the AA batteries into the controller, then reconnect the controller to the console.

Can't Connect to Xbox LIVE or Home Network

If the headset isn't emitting any sound or you are unable to transmit your voice:

- Make sure the headset connector is plugged in securely.
- Try adjusting the volume using the volume control knob.
- Make sure the mute switch isn't on.
- Make sure that voice isn't turned off in the Xbox Guide.
- Check your game manual to determine whether you need to push a button while speaking.

Headset Does Not Work

If the headset isn't emitting any sound or you are unable to transmit your voice:

- Make sure the headset connector is plugged in securely.
- Try adjusting the volume using the volume control knob.
- Make sure the mute switch isn't on.
- Make sure that voice isn't turned off in the Xbox Guide.
- Check your game manual to determine whether you need to push a button while speaking.

Accessory Does Not Work

Use Xbox 360-compatible gameplay accessories that have this logo:

[IMAGE: XB360Compatible.jpg]

If an accessory is not supported by a specific game, the game may not play.

Cannot Save Game

The Xbox 360 storage device must have enough free space to save the game. Delete unwanted items from storage or attach an additional memory unit (sold separately) for more space.

Hard Drive Not Listed as a Storage Device

If your hard drive is not listed as a storage device, try the following steps, in order.

- 1 Make sure the hard drive is fully inserted into the hard drive slot. Turn the console off, then on again.
- 2 Turn the console off and remove the hard drive. Turn the console on and then off again. Reattach the hard drive.
- 3 If available, try the hard drive on another console, or try another hard drive on your console to pinpoint the problem.

NOTE

Damaged hard drives will not show up in the Xbox Guide and could harm your Xbox 360 console. Hard drives that have been crushed, immersed in liquids, or exposed to intense heat may be damaged beyond use and will not show up in your list of storage devices.

TAKE CARE OF YOUR XBOX

Cleaning

If you clean the Xbox 360 console:

- Clean the outside of the Xbox 360 console only. Make sure that no objects are inserted into ventilation openings.
- Use a dry cloth—do not use abrasive pads, detergents, scouring powders, solvents (for example, alcohol, gasoline, paint thinner, or benzene), or other liquid or aerosol cleaners.
- Do not use compressed air.
- Do not use DVD head cleaner devices.
- Do not attempt to clean connectors.
- Clean the console feet and the surface on which the Xbox 360 console rests with a dry cloth.

To clean Xbox 360 game discs or audio CDs:

- Hold discs by the edges; do not touch the disc surface with your fingers.
- Clean discs using a soft cloth, lightly wiping from the center outward.
- Do not use solvents; they can damage the disc.

Operating Environment

Operating the Xbox 360 in an environment where the external temperature can vary widely and quickly can damage the Xbox 360. When moved from to a location with a temperature difference of 20 degrees or more from the previous location, allow the Xbox 360 to come to room temperature naturally before turning it on.

Metallic objects and Stickers

Do not place metallic items or stickers near or on the Xbox 360, as they can interfere with controller, networking, and button operation.

Proper Storage of Discs

Always return discs to their storage containers when they are not in the disc drive.

Do not store discs in direct sunlight or near a heat source.

Always handle discs by their edges.

Do Not Attempt Repairs

Do not attempt to take apart, open, service, or modify the Xbox 360 console, power supply, or accessories. Doing so could present the risk of electric shock, fire, or damage to your Xbox 360 console.

Any evidence of any attempt to open and/or modify the Xbox 360 console, including any peeling, puncturing, or removal of any of the labels, will, for safety reasons, void the Limited Warranty and render the Xbox 360 console ineligible for authorized repair.

PLAY HEALTHY

IMPORTANT HEALTH WARNINGS ABOUT PLAYING VIDEO GAMES

[IMAGE: alert.jpg]

Photosensitive Seizures

A very small percentage of people may experience a seizure when exposed to certain visual images, including flashing lights or patterns that may appear in video games. Even people who have no history of seizures or epilepsy may have an undiagnosed condition that can cause these "photosensitive epileptic seizures" while watching video games.

These seizures may have a variety of symptoms, including lightheadedness, altered vision, eye or face twitching, jerking or shaking of arms or legs, disorientation, confusion, or momentary loss of awareness. Seizures may also cause loss of consciousness or convulsions that can lead to injury from falling down or striking nearby objects.

Immediately stop playing and consult a doctor if you experience any of these symptoms. Parents should watch for or ask their children about the above symptoms—children and teenagers are more likely than adults to experience these seizures. The risk of photosensitive epileptic seizures may be reduced by taking the following precautions:

- Sit farther from the TV screen.
- Use a smaller TV screen.
- Play in a well-lit room.
- Do not play when you are drowsy or fatigued.

If you or any of your relatives have a history of seizures or epilepsy, consult a doctor before playing.

Musculoskeletal Disorders

Use of game controllers, keyboards, mice, or other electronic input devices may be linked to serious injuries or disorders.

When playing video games, as with many activities, you may experience occasional discomfort in your hands, arms, shoulders, neck, or other parts of your body. However, if you experience symptoms such as persistent or recurring discomfort, pain, throbbing, aching, tingling, numbness, burning sensation, or stiffness, DO NOT IGNORE THESE WARNING SIGNS. PROMPTLY SEE A QUALIFIED HEALTH PROFESSIONAL, even if symptoms occur when you are not playing a video game. Symptoms such as these can be associated with painful and sometimes permanently disabling injuries or disorders of the nerves, muscles, tendons, blood vessels, and other parts of the body. These musculoskeletal disorders (MSDs) include carpal tunnel syndrome, tendonitis, tenosynovitis, vibration syndromes, and other conditions.

While researchers are not yet able to answer many questions about MSDs, there is general agreement that many factors may be linked to their occurrence, including medical and physical conditions, stress and how one copes with it, overall health, and how a person positions and uses their body during work and other activities (including playing a video game). Some studies suggest that the amount of time a person performs an activity may also be a factor.

Some guidelines that may help you work and play more comfortably and possibly reduce your risk of experiencing an MSD can be found in the Healthy Gaming Guide at www.xbox.com. These guidelines address topics such as:

- Positioning yourself to use comfortable, not awkward, postures.
- Keeping your hands, fingers, and other body parts relaxed.
- Taking breaks.
- Developing a healthy lifestyle.

If you have questions about how your own lifestyle, activities, or medical or physical condition may be related to MSDs, see a qualified health professional.

Hearing Loss

[IMAGE: Alert.jpg]

Extended exposure to high volumes when using a headset may result in temporary or permanent hearing loss. Some unapproved third-party headsets may produce higher sound levels than approved Xbox 360 Headsets.

Caution

[IMAGE: Alert.jpg]

Any changes or modifications made on the system not expressly approved by the manufacturer could void the user's authority to operate the equipment.

Caution

[IMAGE: Alert.jpg]

Exposure to radio frequency radiation

To comply with FCC RF exposure compliance requirements, this device must not be co-located or operating in conjunction with any other antenna or transmitter.

FCC Declaration of Conformity (DoC):

Trade Name: Microsoft Corp.

Responsible Party: Microsoft Corporation

Address: One Microsoft Way,
Redmond, WA
98052 U.S.A.

Telephone No.: (800) 4MY-XBOX

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) This device must accept any interference received, including interference that may cause undesired operation.

For Customers in Canada

This Class B digital apparatus complies with Canadian ICES-003.

This device complies with RSS 210 of Industry Canada (IC).

Operation is subject to the following two conditions: (1) this device may not cause interference, and (2) this device must accept any interference, including interference that may cause undesired operation of this device.

For Customers in Taiwan (applicable to Model 1575 radio module contained within console).

NCC Statement- For general products

低功率電波輻射性電機管理辦法

第十二條經型式認證合格之低功率射頻電機，非經許可，公司、商號或使用者均不得擅自變更頻率、加大功率或變更原設計之特性及功能。

第十四條低功率射頻電機之使用不得影響飛航安全及干擾合法通信；經發現有干擾現象時，應立即停用，並改善至無干擾時方得繼續使用。

前項合法通信，指依電信規定作業之無線電信。低功率射頻電機須忍受合法通信

或工業、科學及醫療用電波輻射性電機設備之干擾。

Caution

[IMAGE: Alert.jpg]

Exposure to radio frequency radiation

The installer of this radio equipment must ensure that the antenna is located or pointed such that it does not emit RF field in excess of Health Canada limits for the general population; consult Safety Code 6, obtainable from Health Canada's website at www.hc-sc.gc.ca/rpb.

COPYRIGHT

Information in this document, including URL and other Internet Web site references, is subject to change without notice. Unless otherwise noted, the example companies, organizations, products, domain names, e-mail addresses, logos, people, places and events depicted herein are fictitious, and no association with any real company, organization, product, domain name, e-mail address, logo, person, place or event is intended or should be inferred. Complying with all applicable copyright laws is the responsibility of the user. Without limiting the rights under copyright, no part of this document may be reproduced, stored in or introduced into a retrieval system, or transmitted in any form or by any means (electronic, mechanical, photocopying, recording, or otherwise), or for any purpose, without the express written permission of Microsoft Corporation.

Microsoft may have patents, patent applications, trademarks, copyrights, or other intellectual property rights covering subject matter in this document. Except as expressly provided in any written license agreement from Microsoft, the furnishing of this document does not give you any license to these patents, trademarks, copyrights, or other intellectual property.

© 2009 Microsoft Corporation. All rights reserved. Microsoft, Windows, Xbox, Xbox 360, Xbox LIVE, the Xbox logos, and the Xbox LIVE logo are trademarks of the Microsoft group of companies.

This product incorporates copyright protection technology that is protected by method claims of certain U.S. patents and other intellectual property rights owned by Macrovision Corporation and other rights owners. Use of this copyright protection technology must be authorized by Macrovision Corporation, and is intended for home and other limited viewing uses only unless otherwise authorized by Macrovision Corporation. Reverse engineering or disassembly is prohibited.

Manufactured under license from Dolby Laboratories. "Dolby" and the double-D symbol are trademarks of Dolby Laboratories. Confidential Unpublished Works. Copyright 1999–2007 Dolby Laboratories. All rights reserved.

HDMI, the HDMI Logo and High-Definition Multimedia Interface are trademarks or registered trademarks of HDMI Licensing LLC.

The names of actual companies and products mentioned herein may be the trademarks of their respective owners.

CUSTOMER SUPPORT

Please go to www.xbox.com/support or call Xbox Customer Support (toll-free):

- United States and Canada: 1-800-4MY-XBOX (1-800-469-9269)
- TTY users: 1-866-740-XBOX (1-866-740-9269)