





Nokia Wireless Charging Stand DT-910



9258375 / 1.0



ENGLISH: Keys and parts

1. Power supply
2. Power cable
3. Connector for power supply
4. Charging area
5. Near Field Communication (NFC) area
6. Indicator light

Only use original Nokia charging covers for your phone with this product.

Parts of the product are magnetic. Metallic materials may be attracted to the product. Do not place credit cards or other magnetic storage media near the product, because info stored on them may be erased.

The surface of this product is nickel-free.

Switch the charger on or off

Use the charger only with the supplied power supply.

Switch on

1. Connect one end of the power cable to the power supply.
2. Plug the power supply into a wall outlet.
3. Connect the other end of the power cable to the charger.

You can keep the charger plugged into wall outlet even when you're not charging your phone. The charger uses hardly any power when not charging.

Switch off

Disconnect the power supply from the charger, then unplug from the wall outlet.

Charge your phone or other device

To start charging, simply place your phone on the charger. A white indicator lights up.

When the battery is fully charged, the indicator light goes out.

It's normal for the charger and the charged phone to warm up when charging. Using the phone, for example, to stream music while charging may increase the warming.

Keep the area around the charger free of clutter. If there is something besides your phone on the charger, the phone doesn't charge, and the white indicator light blinks quickly.

Set your phone to automatically perform an action

You can set your Nokia with Windows Phone to automatically perform an action when you tap it on the Near Field Communication (NFC) area on the charger.

1. Tap the NFC area of your phone on the NFC area on the charger. The accessories app opens automatically.
2. Tap **Nokia accessories settings**, and select the action you want your phone to perform.

To start the action, tap the NFC area of your phone on the NFC area on the charger.

You can set different phones to perform a different action from the same charger, and your phone to do different things from different chargers.

Find support

When you want to learn more about how to use your device, or if you're unsure how your device should work, go to www.nokia.com/support.

Your questions may have been asked before. On the support web pages, select **Frequently asked questions**.

You can also find other useful info, such as:

- User guides
- Further details about features and technologies, and the compatibility of devices and accessories

If your issue remains unsolved, contact Nokia for repair options.

ENGLISH:

Product and safety information

Take care of your device
Handle your device, charger and accessories with care. The following suggestions help you protect your warranty coverage.

- Keep the device dry. Precipitation, humidity, and all types of liquids or moisture can contain minerals that corrode electronic circuits. If your device gets wet, allow the device to dry.
- Use the charger for intended purposes only. Improper use, or use of incompatible chargers may present a risk of fire, explosion, or other hazard. Never use a damaged charger. Only use the charger indoors.
- Do not attempt to charge a device having a damaged, cracked or open battery case or a device that is not compatible with Qi.
- Do not use or store the device in dusty or dirty areas. Moving parts and electronic components can be damaged.

- Do not store the device in high temperatures. High temperatures can shorten the life of the device, and warp or melt plastics.
- Do not store the device in cold temperatures. When the device warms to its normal temperature, moisture can form inside the device and damage electronic circuits.

- Do not attempt to open the device.
- Unauthorized modifications may damage the device and violate regulations governing radio devices.

- Do not drop, knock, or shake the device. Rough handling can break internal circuit boards and mechanics.
- Only use a soft, clean, dry cloth to clean the surface of the device.

Recycle

Always return your used electronic products, batteries, and packaging materials to dedicated collection points. This way you help prevent uncontrolled garbage disposal and promote the recycling of materials.

Implanted medical devices

Manufacturers of medical devices recommend minimum separation of 15.3 centimeters (6 inches) between a wireless device and an implanted medical device, such as a pacemaker or implanted cardioverter defibrillator, to avoid potential interference with the medical device.

Persons who have such devices should:

- Always keep the wireless device more than 15.3 centimeters (6 inches) from the medical device.
- Not carry the wireless device in a breast pocket.
- Turn the wireless device off if there is any reason to suspect that interference is taking place.
- Follow the manufacturer directions for the implanted medical device.

If you have any questions about using your wireless device with an implanted medical device, consult your health care provider.

Copyright and other notices

DECLARATION OF CONFORMITY



Hereby, NOKIA CORPORATION declares that this DT-910 product is in compliance with the essential requirements and other relevant provisions of Directive 2004/108/EC. A copy of the Declaration of Conformity can be found at www.nokia.com/global/declaration.

© 2012 Nokia. All rights reserved. Nokia, Nokia Connecting People, and the Nokia Original Accessories logo are trademarks or registered trademarks of Nokia Corporation.

Reproduction, transfer, distribution, or storage of part or all of the contents in this document in any form without the prior written permission of Nokia is prohibited. Nokia operates a policy of continuous development.

Nokia reserves the right to make changes and improvements to any of the products described in this document without prior notice. The 'Qi' symbol is a trademark of the Wireless Power Consortium.

To the maximum extent permitted by applicable law, under no circumstances shall Nokia or any of its licensors be responsible for any loss of data or income or any special, incidental, consequential or indirect damages howsoever caused. The contents of this document are provided "as is." Except as required by applicable law, no warranties of any kind, either express or implied, including, but not limited to, the implied warranties of merchantability and fitness for a particular purpose, are made in relation to the accuracy, reliability or contents of this document. Nokia reserves the right to revise this document or withdraw it at any time without prior notice.

The availability of some features may vary by region. Please contact your operator for more details. The availability of products may vary by region. For more info, contact your Nokia dealer. This device may

contain commodities, technology or software subject to export laws and regulations from the US and other countries. Diversion contrary to law is prohibited.

FCC/INDUSTRY CANADA/MEXICO NOTICE

This device complies with part 15 of the FCC rules and Industry Canada license-exempt RSS standard(s). Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. Any changes or modifications not expressly approved by Nokia could void the user's authority to operate this equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful

interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.