





### Psst...

This guide isn't all there is...

There's a user guide in your phone – it's always with you, available when needed. Check out videos, find answers to your questions, and get helpful tips. Tap **1** Nokia Care. If you're new to Windows Phone, check out the section for new Windows Phone users.

For the online user guidance, even more info, and troubleshooting help, go to www.nokia.com/support.

Check out the support videos at www.youtube.com/ NokiaSupportVideos.

For info on Microsoft Mobile Service terms and Privacy policy, go to **www.nokia.com/privacy**.

### First start-up

Your new phone comes with great features that are installed when you start your phone for the first time. Allow some minutes while your phone sets up.



## Quick Guide Nokia Lumia 735

### Contents

For your safety	4	
Keys and parts	6	
Get started	8	
Try out the touch screen	11	
Get the basics	12	
Take your friends with you	13	
Help and tips	14	I
Feature-specific information	16	
Product and safety info	16	



### For your safety

We invite you to read the instructions on this guide before using the device.

 $\bigcirc$ 

SWITCH OFF IN RESTRICTED AREAS Switch the device off when mobile phone use is not allowed or when it may cause interference or danger, for example, in aircraft, in hospitals or near medical equipment, fuel, chemicals, or blasting areas. Obey all instructions in restricted areas.



ROAD SAFETY COMES FIRST Obey all local laws. Always keep your hands free to operate the vehicle while driving. Your first

safety.

### INTERFERENCE

All wireless devices may be susceptible to interference, which could affect performance.

consideration while driving should be road



QUALIFIED SERVICE Only qualified personnel may install or repair this product.



BATTERIES, CHARGERS, AND OTHER ACCESSORIES

ACCESSORIES Use only batteries, chargers, and other accessories approved by Microsoft Mobile for use with this device. Third-party chargers that comply with the IEC/EN 62684 standard, and that can connect to your device micro USB connector, may be compatible. Do not connect incompatible products.



KEEP YOUR DEVICE DRY Your device is not water-resistant. Keep it dry.

### GLASS PARTS

CLASS PARTS The device screen is made of glass. This glass can break if the device is dropped on a hard surface or receives a substantial impact. If the glass breaks, do not touch the glass parts of the device or



attempt to remove the broken glass from the device. Stop using the device until the glass is replaced by qualified service personnel.



PROTECT YOUR HEARING To prevent possible hearing damage, do not listen at high volume levels for long periods. Exercise caution when holding your device near your ear while the loudspeaker is in use.



SAR This device meets RF exposure guidelines when used either in the normal use position against the ear or when positioned at least 1.5 centimetres (5/8 inch) away from the body. The specific maximum SAR values can be found in the Certification Information (SAR) section of this user guide. For more info, go to www.sar-tick.com.


When a carry case, belt clip or other form of device holder is used for body-worn operation, it should not contain metal and should provide at least the above-stated separation distance from the body. Note that mobile devices may be transmitting even if you are not making a voice call voice call.

## Keys and parts Earpiece Audio connector AHJ 3.5 mm Light sensor Front camera Volume keys Power/Lock key Microphone Antenna area Flash 1 2 3 4 5 6 7 8

- 9 10 Flash
- Camera
- 11 NFC area
- 12 Wireless charging area (on the wireless charging back cover)
- 13
- Loudspeaker Micro-USB connector Microphone 14
- 15

Some of the accessories mentioned in this user guide, such as charger, headset, or data cable, may be sold separately.

Avoid touching the antenna area while the antenna is in use. Contact with antennas affects the communication quality and may reduce battery life due to higher power level during operation.






### **Get started**

Before you start using your phone, remove the back cover to insert the nano-SIM card.

**Remove the back cover** Make sure the phone is switched off.

With the back of the phone facing you, place your thumb on the back of the phone next to the camera lens, and bend the cover open. Do not use any sharp tools, as they may damage the phone.






### Insert the SIM and memory card

 If the battery is in, lift it out.
 Slide the nano-SIM card into the SIM slot with the metal contact area down. **3.** If you have a memory card, slide the card into the memory card slot.

It is recommended that you use a fast microSD card from a well-known manufacturer.

• Important: Your device uses a nano-SIM card, also known as a nano-UICC card. Use of incompatible SIM cards, or use of SIM card adapters, may damage the card or the device, and may corrupt data stored on the card.



Replace the battery and back cover
1. Line up the battery contacts, and put the battery in.
2. Press the bottom edge of the back cover against the bottom edge of your phone.
3. Snap the cover into place.
4. To switch your phone on, press and hold the power key.

**Charge the battery** Plug a compatible charger into a wall outlet, and connect the micro-USB end to your phone. You can also charge your phone from a computer with a USB cable.

If the battery is completely discharged, it may take up to 20 minutes before the charging indicator is displayed.



### Try out the touch screen


To use your phone, simply tap or tap and hold the touch screen.

Swipe To, for example, open the action centre, place a finger at the top of the screen, and slide it down.

Zoom in or out Place 2 fingers on an item, such as a photo, and slide your fingers apart or together.

 Tap and hold to open a menu

 Place your finger on an item, until the menu opens.









### Get the basics

### Make a call

**1.** Tap  $\langle \rangle \in \oplus$ , type in the phone number, and tap **call**. To type in the + character, used for international calls, tap and hold **0**.

The + character only works from abroad. The + character may not work in all regions. In this case, enter the international access code directly.

2. To end the call, tap END CALL.

### Lock the keys and screen Press the power key briefly.

To unlock, press the power key, and drag the lock

screen up.

### Switch between views and apps

To switch between the start screen and the apps menu, simply swipe left or right.

To switch between open apps, press and hold  $\leftarrow$ , and choose the app you want. To close an app, tap  $\otimes$ .

### Personalise the start screen

To move a tile on the start screen, place your finger on the item for a second or two, and drag the item to a new location. To resize or unpin a tile, tap and hold the tile, and tap the arrow icon to resize or  $\bigotimes$  to unpin.

### Take your friends with you

Get in touch with your friends, family, and colleagues. The People hub is the place to manage your contact info.

 Transfer contacts

 1. On your old phone, switch Bluetooth on, and make sure it's visible to other devices.

 2. On your new phone, tap 2. Transfer my Data.

 3. Follow the instructions shown, and tap sure instructions shown, and tap

 continue.

4. On your new phone, switch Bluetooth on, and select your old phone from the list. Follow the instructions shown on both phones.

Your contacts and text messages are transferred.

Not all phones may be compatible.

Add a new contact Tap **☐ People**, swipe to contacts, and tap ↔.

Import contacts from a SIM card Tap People, swipe to contacts, and tap ••• > settings > import from SIM.



### Help and tips

Get the most out of your phone while getting the battery life you need.

If you want to save battery power, you can:

• Switch battery saver mode on

• Close data connections, such as Bluetooth or

wireless networks, when you're not using them

• Set your phone to check for new mail or other feeds less frequently

• Lower the screen brightness, and set the screen to switch off after a shorter time

• Mute unnecessary sounds, such as key tones

For more info, check the Nokia Care app in your phone.

### If your phone freezes

If your phone isn't responding, press and hold the power key for about 10 seconds. The phone vibrates and restarts. You can also take the battery out for a few seconds. Put the battery back in, and switch your phone on again. No content, such as contacts or messages, is deleted. If this doesn't help, visit www.nokia.com/support.

If your issue remains unsolved, contact your network service provider or Microsoft Mobile for repair options. Before sending your phone for repair, always back up your data, as all personal data in your phone may be deleted.

Find the answers to technical questions related to your phone, and the nearest authorized repair center addresses at www.nokia.com/support.



For the list of Mexico Repair Centers, see the leaflet included inside this sales package.





### Feature-specific information

Using services or downloading content, including free items, may cause the transfer of large amounts of data, which may result in data

Cause the transfer of large amounts of data, which may result in data costs. Use only compatible memory cards approved for use with this device. Incompatible cards may damage the card and the device and corrupt data stored on the card. Characters with accents, other marks, or some language options, take more space, and limit the number of characters that can be sent in a single message. The list of countries and territories included in the time zone settings does not imply sovereignty. To access the Windows Phone software license terms, select the software, you accept the terms. Note that by using the software, you accept the terms. If you do not accept the terms, do not use the device or software. Instead contact Microsoft Mobile or the party from which you purchased the device to determine its return policy.

### **Product and safety info**

Network services and costs You can only use your device on the LTE 800, 1800, 2600; WCDMA 850, 900, 2100; and GSM 850, 900, 1800, 1900 MHz networks. You need a subscription with a service provider. Using some features and downloading content require a network connection and may result in data costs. You may also need to subscribe to some features.

subscribe to some features. Important: 4G/LTE might not be supported by your network service provider or by the service provider you are using when traveling. In these cases, you may not be able to make or receive calls, send or receive messages or use mobile data connections. To make sure your device works seamlessly when full 4G/LTE service is not available, it is recommended that you change the highest connection speed from 4G to 3G. To do this, swipe left on the start screen, and tap **& Settings - mobile+SIM**. Switch Highest connection speed to 3G. For more info, contact your network service provider.

Make an emergency call Department: Connections in all conditions cannot be guaranteed. Never rely solely on any wireless phone for essential communications like medical emergencies. Before making the call:

Switch the phone on.
If the phone screen and keys are locked, unlock them.
Move to a place with adequate signal strength.
Press #, and tap (> 0).
Type in the official emergency number for your present location. Emergency call numbers vary by location.
Tap call.
Give the necessary info as accurately as possible. Do not end the call until given permission to do so.
You may also need to do the following:
Put a SIM card in the phone. If you don't have a SIM, tap emergency call when you get an error message about a missing SIM.
If your phone asks for a PIN code, tap emergency call.
Witch the call restrictions off in your phone, such as call barring, fixed dialing, or closed user group.
When you switch your phone on for the first time, you are asked to create your Microsoft account and ghone stoup ahone. To make an emergency call during the account and phone sug to pa eask or or call.
If more phone phone on for the first time, you are asked to create your Microsoft account and ghone setup, tap emergency call.
If more phone phone on for the first time, you are asked to create your Microsoft account and set up your phone. To make an emergency call during the account and shone setup, tap emergency call.

If the mobile network is not available, you may also try making an internet call, if you can access the internet.

Take care of your device See the in-device user guide for important instructions on how to take care of your device. Do not drop, knock, or shake the device or the battery. Rough handling can break them. Recycle



When this device has reached the end of its working life, all of its materials can be recovered as materials and energy. For info on how to recycle your old products and where to find collection sites, go to www.nokia-latinoamerica.com/reciclaje, or call the Contact Center, Recycle packaging and user guides at your local recycling scheme. When you cooperate and deliver all these materials to one of the available collection sites, you contribute in helping the environment and help to ensure the health of future generations. All electrical and electronic products and batteries may contain recycleable metals and other potentially hazardous substances and must be taken to their respective collection sites at the end of their working life. Under no circumstances should you break open a battery or other related materials. Do not dispose of these products as unsorted municipal waste, as this may cause contamination of the environment or risks to human health. All Nokia products are in compliance to the applicable industry international production standards and to all requirements defined by the competent

### government agencies. For more info on the environmental attributes of your device, see www.nokia.com/ecoprofile (in English).

About Digital Rights Management When using this device, obey all laws and respect local customs, privacy and legitimate rights of others, including copyrights. Copyright protection may prevent you from copying, modifying, or transferring photos, music, and other content.

Battery and charger info Use your device only with an original BV-T5A rechargeable battery. Charge your device with AC-20AR, AC-20E, or AC-50U charger.

Charge your device with AC-204K, AC-20E, or AC-50U charger. Charger plug type may vary. Third-party chargers that comply with the IEC/EN 62684 standard, and that can connect to your device micro USB connector, may be compatible. Microsoft Mobile may make additional battery or charger models available for this device.

Battery and charger safety Always switch the device off and unplug the charger before removing the battery. To unplug a charger or an accessory, hold and pull the plug, not the cord. When your charger is not in use, unplug it. If left unused, a fully charged battery will lose its charge over time. Always keep the battery between 15°C and 25°C (59°F and 77°F) for optimal performance. Extreme temperatures reduce the capacity and lifetime of the battery. A device with a hot or cold battery may not work temporarily.

work temporarily. Accidental short-circuiting can happen when a metallic object touches the metal strips on the battery. This may damage the battery or the other object.

Do not dispose of batteries in a fire as they may explode. Obey local regulations. Recycle when possible. Do not dispose as household waste.

regulatoris: Recycle when possible, both of dispose as notaerind waste. Do not dismantle, cut, crush, bend, puncture, or otherwise damage the battery in any way. If a battery leaks, do not let ilquid touch skin or eyes. If this happens, immediately flush the affected areas with water, or seek medical help. Do not modify, attempt to insert foreign objects into the battery, or immerse or expose it to water or other liquids. Batteries may explode if damaged. Use the battery and charger for their intended purposes only. Improper use, or use of unapproved or incompatible batteries or chargers may present a risk of fire, explosion, or other hazard, and may invalidate any approval or warranty. If you believe the battery or charger is damaged, take it to a service centre before continuing to use it. Never use a damaged battery or charger. Only use the charger indoors. Do not charge your device during a lightning storm.



### Small children

Your device and its accessories are not toys. They may contain small parts. Keep them out of the reach of small children.

### **Medical devices**

Deration of radio transmitting equipment, including wireless phones, may interfere with inadequately shielded medical devices' function. Consult a physician or the medical device's manufacturer to determine if it is adequately shielded from external radio energy.

Implanted medical devices To avoid potential interference, manufacturers of implanted medical devices recommend a minimum separation of 15.3 centimetres (6 inches) between a wireless device and the medical device. Persons who have such devices should: • Always keep the wireless device more than 15.3 centimetres (6 inches) from the medical device. • Not carry the wireless device to the ear opposite the medical device. • Suitch the wireless device off if there is any reason to suspect that interference is taking place. • Follow the manufacturer directions for the implanted medical device.

device. If you have any questions about using your wireless device with an implanted medical device, consult your health care provider.

Accessibility solutions Microsoft Mobile is committed to making mobile phones easy to use for all individuals, including those with disabilities. For more information, visit www.nokiaaccessibility.com (in English).

### Hearing

A Warning: When you use the headset, your ability to hear outside sounds may be affected. Do not use the headset where it can endanger your safety. Some wireless devices may interfere with some hearing aids.

**Nickel** The surface of this device is nickel-free.

### Vehicles

Vehicles Radio signals may affect improperly installed or inadequately shielded electronic systems in vehicles. For more info, check with the manufacturer of your vehicle or its equipment. Only qualified personnel should install the device in a vehicle. Faulty installation may be dangerous and invalidate your warranty. Check regularly that all wireless device equipment in your vehicle is mounted and operating properly. Do not store or carry flammable or explosive

materials in the same compartment as the device, its parts, or accessories. Do not place your device or accessories in the air bag deployment area.

Potentially explosive environments Switch your device off in potentially explosive environments, such as near petrol pumps. Sparks may cause an explosion or fire resulting in injury or death. Note restrictions in areas with fuel; chemical plants; or where blasting operations are in progress. Areas with a potentially explosive environment may not be clearly marked. These usually are areas where you are advised to switch your engine off, below deck on boats, chemical transfer or storage facilities, and where the air contains chemicals or particles. Check with the manufacturers of vehicles using liquefied petroleum gas (such as propane or butane) if this device can be safely used in their vicinity.

### **Certification information (SAR)** Certification information (SAR) This mobile device meets international guidelines for exposure to radio waves. Your mobile device is a radio transmitter and receiver. It is designed

Your mobile device is a radio transmitter and receiver. It is designed not to exceed the limits for exposure to radio waves (radio frequency electromagnetic fields), recommended by international guidelines from the independent scientific organization ICNIRP. These guidelines incorporate substantial safety margins that are intended to assure the protection of all persons regardless of age and health. The exposure guidelines are based on the Specific Absorption Rate (SAR), which is an expression of the amount of radio frequency (RF) power deposited in the head or body when the device is transmitting. The ICNIRP SAR limit for mobile devices is 2.0 W/kg averaged over 10 grams of tissue. SAR tests are carried out with the device in standard operating positions, transmitting at its highest certified power level, in all its frequency bands. The maximum recorded SAR values for this device are:

are:

	Maximum SAR value	Frequency bands used when Maximum SAR value was recorded
When held against the head	0.66 W/kg over 10g	WCDMA 2100 and WLAN 2450
When operated at a	0.57 W/kg over 10g	GPRS 900 and WLAN

when operated at a separation distance of 1.5 centimetres (5/8 inch) from the

2450

body



Your mobile device is also designed to meet the United States Federal Communications Commission (FCC) guidelines. FCC ratings for your device and more information on SAR can be found at **transition.fcc.gov/oet/rfsafety/sar.html**. This device meets RF exposure guidelines when used against the head or when positioned at least 1.5 centimetres (5/8 inch) away from the body. When a carry case, belt clip or other form of device holder is used for body-worn operation, it should not contain metal and should provide at least the above stated separation distance from the body. To send data or message, a good connection to the network is needed. Sending may be delayed until such a connection is available. Follow the separation distance instructions until the sending is finished. finished

Follow the separation distance instructions until the sending is finished. During general use, the SAR values are usually well below the values stated above. This is because, for purposes of system efficiency and to minimise interference on the network, the operating power of your mobile is automatically decreased when full power is not needed for the call. The lower the SAR value. Device models may have different versions and more than one value. Component and design changes may occur over time and some changes could affect SAR values. The latest available SAR information for this and other Nokia device models can be found at **www.nokia.com/sar**. The World Health Organization (WHO) has stated that current scientific information des not indicate the need for any special precautions when using mobile devices. If you are interested in reducing your exposure, they recommend you limit your usage or use a hands-free kit to keep the device awy from your head and body. For more information and explanations and discussions on RF exposure, go to the WHO website at www.wb.int/peh-emf/en.

Support messages To help you take maximum advantage of your phone and services, you may receive messages from Microsoft Mobile. The messages may contain tips and tricks and support. To provide the service described above, your mobile phone number, the serial number of your phone, and some identifiers of the mobile subscription may be sent to Microsoft Mobile when you use the phone for the first time. This information may be used as specified in the privacy policy, available at www.nokia.com.

### Care

For questions regarding your plans, billing or network please contact your operator. For questions regarding your Nokia product and warranty, please visit the support pages for your country at www.nokia.com/support.

**Electrical information of the device** 





Product	Mobile phone
Supplier	Microsoft Mobile
Model	RM-1038
Charger	AC-50U The following electrical characteristics apply for Nokia U chargers only.
Input	100-240 Vca 50-60 Hz 60-300 mA
Output	5.0 Vcc 350-1 500 mA
Rechargeable battery supplier	Microsoft Mobile
Phone power consumption	3,7 Vcc



<text><text><text><text><text><text>

responsible for any loss of data or income or any special, incidental,

responsible for any loss of data or income or any special, incidental, consequential or indirect damages howsover caused. Reproduction, transfer or distribution of part or all of the contents in this document in any form without the prior written permission of Microsoft Mobile is prohibited. Microsoft Mobile operates a policy of continuous development. Microsoft Mobile reserves the right to make changes and improvements to any of the products described in this document without prior notice. Downloading of maps, games, music and videos and uploading of mapes and videos may involve transferring large amounts of data. Your service provider may charge for the data transmission. The availability of particular products, services and features may vary by region. Please check with your local dealer for further details and availability of language options. **ECC/MECN OTICE**This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. For more info, go to transition.*fcc.gov/oelt/fsafet/if-fags.html*. Any changes or modifications not expressly approved by Microsoft Mobile could void the user's authority to operate this equipment. These limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can rediate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If the sequipment this an experienced radio/Tv technician for help. Th 02014 Microsoft Mobile. All rights reserved, Microsoft group of companies. Nokia is a registered trademarks of the Microsoft group of c

Manufactured under license from Dolby Laboratories.

This product is licensed under the MPEG-4 Visual Patent Portfolio License (i) for personal and noncommercial use in connection with information which has been encoded in compliance with the MPEG-4 Visual Standard by a consumer engaged in a personal and noncommercial activity and (ii) for use in connection with MPEG-4 video provided by a licensed video provider. No license is granted or shall be implied for any other use. Additional information, including that related to promotional, internal, and commercial uses, may be obtained from MPEG LA. LLC. See www.mpegla.com (in English). The 'Qi' symbol is a trademark of the Wireless Power Consortium.

Markets rower construction of the interference rower consolution. Markets of Mobile Oy (Ltd) has purchased the devices and services business from Nokia. The manufacturer of this product is Microsoft Mobile Oy (Ltd) or any of its affiliates, even if "Nokia Corporation" or any of its affiliates may still be visible in the sales package, documentation, or the product itself. Microsoft Mobile Oy (Ltd) provides the Manufacturer's Limited Warranty ("Warranty") for this product in accordance with the terms and conditions described in the "Manufacturer's Limited Warranty" document included in the sales package. Microsoft Mobile Oy (Ltd) shall assume and be responsible for all rights and obligations related to your Warranty. Microsoft Mobile Oy (Ltd), Keilalahdentie 2-4, FIN-02150 Espoo, Finland

Finland

However, in certain countries (People's Republic of China, USA, However, in certain countries (People's Republic of China, USA, Canada, Mexico, Russia, Brzail, Turkey), the specified local affiliates, which have been purchased by Microsoft Mobile Oy (Ltd), continue to provide the Warranty as defined in the Warranty terms included in the sales package. You can find the list of local affiliates at www.nokia.com/support in the warranty section of your product's support pages

### MANUFACTURER'S LIMITED WARRANTY

### 1. GENERAL

1. GENERAL Microsoft Mobile Oy (hereinafter "MMO") provides this Manufacturer's Limited Warranty ("Warranty") for genuine MMO product (the "Product"), which MMO has released for sale in the European Union, Iceland, Norway, Switzerland, and Turkey ("Covered Countries") since 1 November 2013.Microsoft Mobile Oy (hereinafter "MMO"), its affiliated companies, in case of Mexico, Nokia México S.A. de C.V., ("MMO") provides this Manufacturer's Limited Warranty ("Warranty") for genuine Nokia product (the "Product"), which has been released for sale in Latin America ("Covered Countries") since 1 November 2013. Nokia México S.A. de C.V. has its main offices at Guillermo Gonzáles Camarena No. 1200, Piso 15, Col. Lomas de Santa

## Fe, Deleg. Alvaro Obregón, C.P. 01210, México D.F., México. The Warranty may be enforced at the Authorized Service Centres identified herein.

identified herein. This Warranty is distinct from any statutory rights under any mandatory consumer protection laws of your country applicable to you. It is intended to grant you specific, and as the case may be, additional rights, within the limits of what is permissible under such law, and does not limit the rights you may have under applicable statutory product warrantee provisions. You may have other rights based on local laws during or after the Warranty period. These rights are not excluded by this Warranty. 2. WARRANTY 2. WARRANTY

WARRANTY
 From the date the Product is sold to an end-user for the first time, as evidenced by the original proof of purchase, MMO warrants the Product is free from defects in materials and workmanship ("Defect") as follows:
 Twenty four (24) months for the main device;(i) Twelve (12) months

for the main device; (ii) Twelve (12) months for accessories sold separately or included in

(ii) Twelve (12) months for accessories sold separately or included in the sales pack of the main device;
(iii) Twelve (12) months for accessories sold separately or included in the sales pack of the main device excluding batteries, covers, cables and chargers; and
(iii) Six (6) months for all batteries, covers, cables and chargers, unless otherwise specified in the Product user guide.
During the warranty period, MMO will, in a reasonable time, remedy the Defect free of charge by either repairing or replacing the defective Product or the defective part of it at its option provided that you have informed MMO of the Defect before the warranty period expires. When repairing or replacing your Product, MMO may use new or re-conditioned parts or products.
To the fullest extent permitted by applicable law, no repair or replacement parts or replacement Products provided under this Warranty will be covered by this Warranty for the remainder of the original warranty period or for sixty (60) days from the date of repair or replacement, whichever is longer.
The Product or all parts of your Product that MMO has replaced shall become MMO's property.
MMO does not warrant that software preinstalled by or on behalf of MMO in the Product for subsequent updates and upgrades) together MMO software related errors, MMO will make available the latest version of the MMO software for reinstallation on your Product or, if that would not be possible, another remedy, which in MMO's reasonable discretion, satisfactorily addresses the error. Some MMO software or your local section of www.nokia.com.

## Please always back up all data and content stored on your Product before taking your Product in for service since service activities will erase all data from your Product. 3. WHAT THIS WARRANTY DOES NOT COVER

MMO does not provide any warranty for the following:

MMO does not provide any warranty for the following: 1 User guides; 2 Any (i) third party software, settings, content, data, or links installed or downloaded onto your Product at any time, or (ii) MMO and third party services or enabling clients even if preinstalled by MMO (please read the terms and conditions that may accompany the services as those will define your rights and obligations); 3 Any (i) normal wear and tear, (ii) reduced charging capacity of the battery resulting from its natural end of product life, or (iii) pixel defects in your Product's display that are within the scope of industry standards; 4 SIM card and/or any cellular or other networks or system on which your Product operates; or

standards; 4 SIM card and/or any cellular or other networks or system on which your Product operates; or 5 Errors or damage caused by: (a) misuse or not using your Product in accordance with the user guide, such as if the Product has been exposed to moisture, to dampness or to extreme thermal or environmental conditions or to rapid changes in such conditions, to corrosion, to oxidation, to spillage of food or liquid or to influence from chemical products, (b) using your Product with, or connecting it to, any product, accessory, software, or service not manufactured or supplied by MMO, (c) any products combined with your Product by a third party, (d) damage or errors caused by hacking, cracking, viruses, or other malware, or by unauthorised access to services, accounts, computer systems or networks; or (e) other acts beyond MMO's reasonable control. This Warranty is not valid: 1 Outside of the Covered Countries; 2 If your Product, or the software it runs on, has been (a) opened, modified, or repaired without MMO's authorisation, or (b) repaired with unauthorised spare parts; 3 If your Product's serial number, the mobile accessory date code, or the IMEI number has been removed, erased, defaced, altered or if these are illegible in any way; 4 If you have not installed the latest software updates that are publicly available for your Product thin a reasonable time of their release; or

5 If you refuse to give possession of the Product to MMO for repair

5 If you refuse to give possession of the Product to MMU for repair and investigation. If this Warranty does not cover your Product or the issue based on which it requires service, MMO reserves the right to charge for the repair or replacement of your Product, as well as a handling fee. 4. LIMITATION OF MMO'S LIABILITY To the extent permitted by applicable law(s), MMO shall not under any circumstances be liable, either expressly or implicitly, for any

1 Damages or losses of any kind whatsoever resulting from or relating to loss of, damage to, or corruption of, content or data or the recreation or transfer thereof even if such loss, damage, or corruption was a result of a Defect in your Product; and/or 2 Loss of profit, products or functionality, business, contracts, revenues or anticipated savings, increased costs or expenses, or for any indirect, consequential or special loss or damage. To the extent permitted by applicable law, MMO's liability shall be limited to the purchase value of your Product. The limitations in this clause 4 shall not apply in case of MMO's negligence or intentional misconduct or in case of death or personal injury resulting from MMO's proven negligence. **5. OTHER IMPORTANT NOTICES**For further information on your Warranty, as well as information needed to process your varranty queries, please visit www.nokia.com. Please ensure your operator has removed any SIM-locks (or other equivalent mechanisms that may lock your Product to a specific network or operator) prior to delivering your Product to repair. Your Product may contain country specific elements, including software. The warranty services available in a particular country may be limited to the Products and country ypecific elements valiable in that country. Also, if your Product has been re-exported from its original destination to another operational. Microsoft Mobile OX. Keilalahdentie 2-4, FIN-02150 Esoo. Finland Warranty even if it would not be operational. Microsoft Mobile Oy, Keilalahdentie 2-4, FIN-02150 Espoo, Finland

### NOKIA — MANUFACTURER'S LIMITED WARRANTY

1. GENERAL Nokia Corporation ("Nokia") provides this Manufacturer's Limited Warranty ("Warranty") for genuine Nokia product (the "Product"), which Nokia has released for sale in the European Union, Iceland, Norway, Switzerland, and Turkey ("Covered Countries") since 1 November 2013. Nokia México S.A. de C.V., ("Nokia") provides this Manufacturer's Limited Warranty ("Naranty") for genuine Nokia branded product (the "Product"), which has been released for sale in Mexico ("Covered Countries") since 1 November 2013. Nokia México S.A. de C.V. has its main offices at Guillermo Gonzáles Camarena No. 1200, Piso 15, Col. Lomas de Santa Fe, Deleg. Alvaro Obregón, C.P. 01210, México D.F., México. The Warranty may be enforced at the Authorized Service Centres identified herein. This Warranty is distinct from any statutory rights under any mandatory consumer protection laws of your country applicable to you. It is intended to grant you specific, and as the case may be, additional rights, within the limits of what is permissible under such



law, and does not limit the rights you may have under applicable statutory product warrantee provisions. You may have other rights based on local laws during or after the Warranty period. These rights are not excluded by this Warranty.

are not excluded by this Warranty. 2: WARRANTY From the date the Product is sold to an end-user for the first time, as evidenced by the original proof of purchase, Nokia warrants the Product is free from defects in materials and workmanship ("Defect") as follows: (i) Twenty four (24) months for the main device;(i) Twelve (12) months for the next devices

for the main device; (ii) Twelve (12) months for accessories sold separately or included in

(i) Twenty four (24) months for the main device; (ii) Twelve (12) months for the main device;
(ii) Twelve (12) months for accessories sold separately or included in the sales pack of the main device excluding batteries, covers, cables and chargers; and
(iii) Six (6) months for all batteries, covers, cables and chargers; unless otherwise specified in the Product user guide.
During the warranty period, Nokia will, in a reasonable time, remedy the Defect free of charge by either repairing or replacing the defective Product or the defective part of it at its option provided that you have informed Nokia of the Defect before the warranty period expires. When repairing or replacing your Product, Nokia may use new or re-conditioned parts or products.
To the fullest extent permitted by applicable law, no repair or replacement will renew or extend the warranty period. Original or replacement, whichever is longer.
The Product or all parts of your Product, Nokia may usen ent, which are your sender this Warranty will be covered by this Warranty for the remainder of the original warranty period or for sixty (60) days from the date of repair or replacement, whichever is longer.
The Product or all parts of your Product that Nokia has replaced shall become Nokia's property.
Nokia does not warrant that software preinstalled by or on behalf of Nokia in the Product for subsequent updates and upgrades) (together "Nokia software") will meet your requirements, whichever is representable or will be corrected. For Nokia software or safts factorily addresses the error. Some Nokia software ney be subject to separate license terms that are available with the software or your local section of www.nokia.com.
Please always back up all data and content stored on your Product before taking your Product. **3. WHAT TINE WARRANTY DOES NOT COVER**Nokia does not provide any warranty for the following:
1. User guides;
2. Avy(i) third p

1 User guides; 2 Any (i) third party software, settings, content, data, or links installed or downloaded onto your Product at any time, or (ii) Nokia and third

party services or enabling clients even if preinstalled by Nokia (please read the terms and conditions that may accompany the services as those will define your rights and obligations); 3 Any (i) normal wear and tear, (ii) reduced charging capacity of the battery resulting from its natural end of product life, or (iii) pixel defects in your Product's display that are within the scope of industry standards:

battery resulting from its natural end of product life, or (iii) pixel defects in your Product's display that are within the scope of industry standards; 4 SIM card and/or any cellular or other networks or system on which your Product operates; or 5 Errors or damage caused by: (a) misuse or not using your Product na scordance with the user guide, such as if the Product has been exposed to moisture, to dampness or to extreme thermal or environmental conditions to to rapid changes in such conditions, to corrosion, to oxidation, to spillage of food or liquid or to influence from chemical products, (b) using your Product with, or connecting it thicd party, software, or service not manufactured or supplied by Nokia, (c) any products combined with your Product to, any product, accessory, software, or service, and, cracking, viruses, or other malware, or by unauthorised access to services, accounts, computer systems or networks; or (e) other acts beyond Nokia's reasonable control. This Warranty is not valid: 1 Outside of the Covered Countries; 2 If your Product, or the software it runs on, has been (a) opened, with unauthorised spare parts;

modified, or repaired without rooks a duthorsation, or to repaired with unauthorised spare parts; 3 If your Product's serial number, the mobile accessory date code, or the IMEI number has been removed, erased, defaced, altered or if these are illegible in any way; 4 If you have not installed the latest software updates that are publicly available for your Product within a reasonable time of their release; or or

5 If you refuse to give possession of the Product to Nokia for repair

5 if you refuse to give possession of the Product to Nokia for repair and investigation. If this Warranty does not cover your Product or the issue based on which it requires service, Nokia reserves the right to charge for the repair or replacement of your Product, as well as a handling fee. 4. LIMITATION OF NOKIA'S LIABILITY To the extent permitted by applicable law(s), Nokia shall not under any circumstances be liable, either expressly or implicitly, for any 1 Damages or losses of any kind whatsoever resulting from or relating to loss of, damage to, or corruption of, content or data or the recreation or transfer thereof even if such loss, damage, or corruption was a result of a Defect in your Product; and/or 2 Loss of profit, products or functionality, business, contracts, revenues or anticipated savings, increased costs or expenses, or for any indirect, consequential or special loss or damage. To the extent permitted by applicable law, Nokia's liability shall be limited to the purchase value of your Product.

# The limitations in this clause 4 shall not apply in case of Nokia's negligence or intentional misconduct or in case of death or personal injury resulting from Nokia's proven negligence. **J. OTHER IMPORTANT NOTICES** For further information on your Warranty, as well as information needed to process your warranty queries, please visit **www.nokia.com**. Please ensure your operator has removed any SIM-locks (or other equivalent mechanisms that may lock your Product to a specific network or operator) prior to delivering your Product for repair. Your Product may contain country specific elements available in a particular country may be limited to the Products and country specific elements available in that country. Also, if your Product has been re-exported from its original destination to another country, your Product may contain country specific elements available in that country specific elements are not considered a defect under this Warranty even if it would not be operational. Nokia Corporation, Keilalahdentie 2-4, FIN-02150 Espoo, Finland

