

# E71x User Guide

---

# FCC Draft

9210644  
Issue DRAFT

CE 0434 ⓘ

## DECLARATION OF CONFORMITY

Hereby, NOKIA CORPORATION declares that this RM-462 product is in compliance with the essential requirements and other relevant provisions of Directive 1999/5/EC. A copy of the Declaration of Conformity can be found at [http://www.nokia.com/phones/declaration\\_of\\_conformity/](http://www.nokia.com/phones/declaration_of_conformity/).

© 2008 Nokia. All rights reserved.

Nokia, Nokia Connecting People, and Navi are trademarks or registered trademarks of Nokia Corporation. Nokia tune is a sound mark of Nokia Corporation. Other product and company names mentioned herein may be trademarks or tradenames of their respective owners.

Reproduction, transfer, distribution, or storage of part or all of the contents in this document in any form without the prior written permission of Nokia is prohibited.

**symbian** This product includes software licensed from Symbian Software Ltd © 1998-2008. Symbian and Symbian OS are trademarks of Symbian Ltd.

US Patent No 5818437 and other pending patents. T9 text input software Copyright (C) 1997-2008. Tegic Communications, Inc. All rights reserved.



Java and all Java-based marks are trademarks or registered trademarks of Sun Microsystems, Inc.

**FCC Draft**

This product is licensed under the MPEG-4 Visual Patent Portfolio License (i) for personal and noncommercial use in connection with information which has been encoded in compliance with the MPEG-4 Visual Standard by a consumer engaged in a personal and noncommercial activity and (ii) for use in connection with MPEG-4 video provided by a licensed video provider. No license is granted or shall be implied for any other use. Additional information, including that related to promotional, internal, and commercial uses, may be obtained from MPEG LA, LLC. See <<http://www.mpegla.com>>.

Nokia operates a policy of ongoing development. Nokia reserves the right to make changes and improvements to any of the products described in this document without prior notice.

TO THE MAXIMUM EXTENT PERMITTED BY APPLICABLE LAW, UNDER NO CIRCUMSTANCES SHALL NOKIA OR ANY OF ITS LICENSORS BE RESPONSIBLE FOR ANY LOSS OF DATA OR INCOME OR ANY SPECIAL, INCIDENTAL, CONSEQUENTIAL OR INDIRECT DAMAGES HOWSOEVER CAUSED.

THE CONTENTS OF THIS DOCUMENT ARE PROVIDED "AS IS". EXCEPT AS REQUIRED BY APPLICABLE LAW, NO WARRANTIES OF ANY KIND, EITHER EXPRESS OR IMPLIED, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, ARE MADE IN RELATION TO THE ACCURACY, RELIABILITY OR CONTENTS OF THIS DOCUMENT. NOKIA RESERVES THE RIGHT TO REVISE THIS DOCUMENT OR WITHDRAW IT AT ANY TIME WITHOUT PRIOR NOTICE.

The availability of particular products and applications and services for these products may vary by region. Please check with your Nokia dealer for details, and availability of language options.

The third-party applications provided with your device may have been created and may be owned by persons or entities not affiliated with or related to Nokia. Nokia does not own the copyrights or intellectual property rights to the third-party applications. As such, Nokia does not take any responsibility

for end-user support, functionality of the applications, or the information in the applications or these materials. Nokia does not provide any warranty for the third-party applications.

BY USING THE APPLICATIONS YOU ACKNOWLEDGE THAT THE APPLICATIONS ARE PROVIDED AS IS WITHOUT WARRANTY OF ANY KIND, EXPRESS OR IMPLIED, TO THE MAXIMUM EXTENT PERMITTED BY APPLICABLE LAW. YOU FURTHER ACKNOWLEDGE THAT NEITHER NOKIA NOR ITS AFFILIATES MAKE ANY REPRESENTATIONS OR WARRANTIES, EXPRESS OR IMPLIED, INCLUDING BUT NOT LIMITED TO WARRANTIES OF TITLE, MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE, OR THAT THE APPLICATIONS WILL NOT INFRINGE ANY THIRD-PARTY PATENTS, COPYRIGHTS, TRADEMARKS, OR OTHER RIGHTS.

#### Export controls

This device may contain commodities, technology or software subject to export laws and regulations from the US and other countries. Diversion contrary to law is prohibited.

#### FCC/INDUSTRY CANADA NOTICE

Your device may cause TV or radio interference (for example, when using a telephone in close proximity to receiving equipment). The FCC or Industry Canada can require you to stop using your telephone if such interference cannot be eliminated. If you require assistance, contact your local service facility. This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. Any changes or modifications not expressly approved by Nokia could void the user's authority to operate this equipment.

9210644/Issue DRAFT

# FCC Draft

# Contents

---

<b>SAFETY</b> .....	6	Messaging settings.....	23
<b>Support</b> .....	8	Instant messaging.....	24
Help .....	8	Settings wizard .....	24
Nokia support and contact information ....	8	Message reader.....	25
<b>1. Get started</b> .....	8	<b>7. Yellow Pages</b> .....	25
Insert the SmartChip card and battery.....	8	<b>8. MEdia Net</b> .....	25
MicroSD card slot.....	9	Connect to MEdia Net.....	25
Charge the battery.....	10	Browse pages .....	26
Power the phone on or off.....	11	Security settings.....	27
Access codes .....	11	Cache memory .....	27
Digital rights management.....	12	Browser security.....	28
Attach the wrist strap .....	13	<b>9. MEdia Mall</b> .....	29
<b>2. Your phone</b> .....	13	<b>10.AT&amp;T Music</b> .....	29
Keys and parts .....	13	Music player .....	29
Standby mode.....	14	<b>11.My Stuff</b> .....	32
Indicators.....	14	Download files .....	32
Menu.....	15	View images.....	33
Volume control.....	16	Edit images.....	33
Keypad lock (keyguard).....	16	Print images.....	33
Antenna locations .....	16	Transfer videos from PC .....	33
Connect a compatible headset.....	17	Tones.....	34
Connect a USB data cable .....	17	Streaming links.....	34
<b>3. Call functions</b> .....	17	Presentations.....	34
Make a voice call.....	17	<b>12.Address Book</b> .....	34
Answer or decline a call .....	18	Save and manage contact information ...	34
Video Share .....	19	Add a ringing tone.....	35
<b>4. Cellular Video</b> .....	19	<b>13.Games &amp; Apps</b> .....	35
<b>5. Write text</b> .....	20	Launch a game or application.....	35
Traditional text input .....	20	Application options .....	35
Predictive text input .....	20	Download an application.....	35
<b>6. Messaging</b> .....	20	<b>14.AT&amp;T Navigator</b> .....	36
Write and send messages.....	20	<b>15.Tools</b> .....	36
Inbox.....	21	Notes.....	36
E-mail.....	22	Clock.....	37
Outbox .....	23	Camera .....	37
View messages on the SmartChip card ...	23	Recent Calls.....	38
Service commands.....	23		

FCC Draft

Calendar .....	39	Bluetooth connectivity .....	45
Flash Player .....	39	USB data cable.....	47
Calculator.....	39	File manager .....	47
Converter II.....	39	Application manager .....	47
RealPlayer .....	39	Device manager .....	48
Help .....	40	Connection manager .....	49
Recorder .....	40	WLAN wizard.....	49
Quickoffice .....	40	Speech .....	50
<b>16.Settings .....</b>	<b>41</b>	<b>17.Battery information .....</b>	<b>51</b>
Speed dial .....	41	Charging and discharging.....	51
Voicemail.....	41	Nokia battery authentication guidelines.	52
Sync .....	41	<b>Care and maintenance.....</b>	<b>53</b>
Profiles.....	41	<b>Additional safety information .....</b>	<b>54</b>
Config.....	42	<b>Index.....</b>	<b>58</b>
Voice commands.....	44		
Themes.....	44		

# FCC Draft

# SAFETY

---

Read these simple guidelines. Not following them may be dangerous or illegal. Read the complete user guide for further information.



## SWITCH ON SAFELY

Do not switch the device on when wireless phone use is prohibited or when it may cause interference or danger.



## ROAD SAFETY COMES FIRST

Obey all local laws. Always keep your hands free to operate the vehicle while driving. Your first consideration while driving should be road safety.



## INTERFERENCE

All wireless devices may be susceptible to interference, which could affect performance.



## SWITCH OFF IN RESTRICTED AREAS

Follow any restrictions. Switch the device off in aircraft, near medical equipment, fuel, chemicals, or blasting areas.



## QUALIFIED SERVICE

Only qualified personnel may install or repair this product.



## ENHANCEMENTS AND BATTERIES

Use only approved enhancements and batteries. Do not connect incompatible products.



## WATER-RESISTANCE

Your device is not water-resistant. Keep it dry.

**FCC Draft**

## ■ About your device

The wireless device described in this guide is approved for use on the UMTS 850 and 1900, EGSM 850 and 900, and GSM 1800 and 1900 networks. Contact your service provider for more information about networks.

When using the features in this device, obey all laws and respect local customs, privacy and legitimate rights of others, including copyrights.

Copyright protection may prevent some images, music, and other content from being copied, modified, or transferred.

Your device supports several methods of connectivity. Like computers, your device may be exposed to viruses and other harmful content. Exercise caution with messages, connectivity requests, browsing, and downloads. Only install and use services and other software from trustworthy sources that offer adequate security and protection against harmful software, such as applications that are Symbian Signed or have passed the Java Verified™ testing.

Consider installing antivirus and other security software on your device and any connected computer.

Your device may have preinstalled bookmarks and links for third-party internet sites. You may also access other third-party sites through your device. Third-party sites are not affiliated with Nokia, and Nokia does not endorse or assume liability for them. If you choose to access such sites, you should take precautions for security or content



Your device can only support one antivirus application. Having more than one application with antivirus functionality could affect performance and operation or cause the device to stop functioning.



**Warning:** To use any features in this device, other than the alarm clock, the device must be switched on. Do not switch the device on when wireless device use may cause interference or danger.

When connecting to any other device, read its user guide for detailed safety instructions. Do not connect incompatible products.

Remember to make back-up copies or keep a written record of all important information stored in your device.

## ■ Network services

To use the phone you must have service from a wireless service provider. Many of the features require special network features. These features are not available on all networks; other networks may require that you make specific arrangements with your service provider before you can use the network services. Your service provider can give you instructions and explain what charges will apply. Some networks may have limitations that affect how you can use network services. For instance, some networks may not support all language-dependent characters and services.

Your service provider may have requested that certain features be disabled or not activated in your device. If so, these features will not appear on your device menu. Your device may also have a special configuration such as changes in menu names, menu order, and icons. Contact your service provider for more information.

This device supports WAP 2.0 protocols (HTTP and SSL) that run on TCP/IP protocols. Some features of this device, such as web browsing, e-mail, video share, GPS navigation, instant messaging, and multimedia messaging, require network support for these technologies.

## ■ Shared memory

The following features in this device may share memory: tones, graphics, contacts, text messages, multimedia, and instant messages, e-mail, calendar, To-Do Notes, Java™ games, applications, and the Note application. Use of one or more of these features may reduce the memory available for the remaining features sharing memory. Your device may display a message that the memory is full when you try to use a shared memory feature. In this case, delete some of the information or entries stored in the shared memory features before continuing.

## ■ Enhancements, batteries, and chargers

Check the model number of any charger before use with this device. This device is intended for use when supplied with power from the AC-4 chargers.



**Warning:** Use only batteries, chargers, and enhancements approved by Nokia for use with this particular model. The use of any other types may invalidate any approval or warranty, and may be dangerous.

For availability of approved enhancements, please check with your dealer. When you disconnect the power cord of any enhancement, grasp and pull the plug, not the cord.

## Support

---

### ■ Help

Your phone has context-sensitive help. To access help when an application is open, select **Options > Help**. To switch between help and the application that is open in the background, select and hold the home key, and select from the list of open applications.

To open help from the main menu, select **Menu > Tools > Help**. Select an application to view a list of help topics and the related help text. To open an index view or keyword list, select **Options > Search**.

### ■ Nokia support and contact information

Check [www.nokia.com/support](http://www.nokia.com/support) or your local Nokia website for the latest guides, additional information, downloads, and services related to your Nokia product.

On the website, you can get information on the use of Nokia products and services. If you need to contact customer service, check the list of local Nokia Care contact centers at [www.nokia.com/customerservice](http://www.nokia.com/customerservice).

For maintenance services, check your nearest Nokia Care point at [www.nokia.com/repair](http://www.nokia.com/repair).

## 1. Get started

---

### ■ Insert the SmartChip card and battery



**Note:** Always switch the device off and disconnect the charger before removing the battery.

This phone uses BP-4L batteries.

For availability and information on using SmartChip card services, contact your SmartChip card vendor. This may be the service provider or other vendor.



1. Press the release buttons and lift the back cover off.



2. If the battery is inserted, lift the battery in the direction of the arrow to remove it.



3. Insert the SmartChip card. Make sure that the contact area on the card is facing the connectors on the device and that the bevelled corner is facing the top of the device.



4. Insert the battery. Align the contacts of the battery with the corresponding connectors on the battery compartment and insert in the direction of the arrow.



5. Close the back cover.



## ■ MicroSD card slot

Use only compatible microSDHC and microSD cards approved by Nokia for use with this device. Nokia uses approved industry standards for memory cards, but some brands may not be fully compatible with this device. Incompatible cards may damage the card and the device and corrupt data stored on the card.



Keep microSDHC and microSD cards out of the reach of small children.

You can extend the available memory with a microSDHC or microSD card with up to 8 GB memory. Optimal performance is with a 4GB microSD card. You can insert or remove a microSDHC or microSD card without switching the phone off.

To maximize the performance of your device, it is recommended that no more than 100 files are stored in any folder.

## Insert the microSD card

Note that the memory card may be supplied with the phone, and may already be inserted.



1. Open the cover of the memory card slot.
2. Insert the memory card in the slot with the contact area first. Make sure that the contact area is facing the connectors on the device.
3. Push the card in until it locks into place
4. Close the cover.



**Important:** The microSD card must be inserted in the slot with the gold-colored area facing up.

## Eject the microSD card



**Important:** Do not remove the memory card in the middle of an operation when the card is being accessed. Removing the card in the middle of an operation may damage the memory card as well as the device, and data stored on the card may be corrupted.

1. Press the power key briefly, and select Remove memory card.
2. Open the cover of the memory card slot.
3. Press the end of the memory card to release it from the memory card slot.
4. Close the cover.

After you install applications to a compatible memory card, installation files (.sis, .sisx) remain in the device memory. The files may use large amounts of memory and prevent you from storing other files. To maintain sufficient memory, use Nokia PC Suite to back up installation files to a compatible PC, then use the file manager to remove the installation files from the device memory. See "Install an application," p. 48. If the .sis file is a message attachment, delete the message from the Messaging inbox.

## ■ Charge the battery

Your battery has been precharged, but the charging levels may vary.

1. Connect the charger to a wall outlet.
2. Open the side door and connect the charger to the device. You can use your device while it is charging.
3. When the battery is fully charged, disconnect the charger from the device and close the side door. Then disconnect the charger from the wall outlet.

If the battery is completely discharged, it may take a few minutes before the charging indicator appears on the display or before any calls can be made.

The charging time depends on the charger and the battery used. Charging a BP-4L battery with the AC-4 charger takes approximately two hours if the battery is completely empty.



## ■ Power the phone on or off

Press and hold the power/end key.

If the phone asks for a PIN code, enter the PIN code, and select **OK**.

If the phone asks for the lock code, enter the lock code, and select **OK**.

## Set time and date

To set the correct time zone, time, and date, select the country you are presently in, then enter the local time and date.

Some networks have automatic updates of time and date. For information on this feature, contact your service provider.



## ■ Access codes

Select *Menu > Settings > Config. > General > Security > Phone and SIM card* to set how your phone uses the access codes.

## Lock code

The lock code helps to protect your phone against unauthorized use. You can create and change the code, and set the phone to request the code. Keep the code secret and in a safe place separate from your phone. If you forget the code and your phone is locked, your phone will require service and additional charges may apply. For more information, contact a Nokia Care point or your phone dealer.

When the device is locked, calls may be possible to the official emergency number programed into your device.

## PIN codes

The personal identification number (PIN) code or the universal personal identification number (UPIN) code (4 to 8 digits) help to protect your SmartChip card. The (U)PIN code is

usually supplied with the SmartChip card. Set the phone to request the code each time the phone is switched on.

The PIN2 code may be supplied with the SmartChip card and is required for some functions. The module PIN is required to access the information in the security module. The signing PIN is required for the digital signature. The module PIN and the signing PIN are supplied with the SmartChip card if the SmartChip card has a security module in it.

## **PUK codes**

The personal unblocking key (PUK) code or the universal personal unblocking key (UPUK) code (8 digits) are required to change a blocked PIN code and UPIN code, respectively. The PUK2 code is required to change a blocked PIN2 code.

If needed, contact your local service provider for the codes.

## **Call restriction password**

The restriction password (4 digits) is required when using call restriction. You can obtain the password from your service provider. If the password is blocked, contact your service provider.

## **■ Digital rights management**

Content owners may use different types of digital rights management (DRM) technologies to protect their intellectual property, including copyrights. This device uses various types of DRM software to access DRM-protected content. With this device you can access content protected with WMDRM 1.0 and OMA DRM 1.1. If certain DRM software fails to protect the content, content owners may ask that such DRM software's ability to access new DRM-protected content be revoked. Revocation may also prevent renewal of such DRM-protected content already in your device. Revocation of such DRM software does not affect the use of content protected with other types of DRM or the use of non-DRM-protected content.

Digital rights management (DRM) protected content comes with an associated activation key that defines your rights to use the content. If your device has WMDRM protected content, both the activation keys and the content will be lost if the device memory is formatted. You may also lose the activation keys and the content in case the files on your device get corrupted. Losing the activation keys or the content may limit your ability to use the same content on your device again. For more information, contact your service provider. Some activation keys may be connected to a specific SIM card, and the protected content can be accessed only if the SIM card is inserted in the device.

If your device has OMA DRM-protected content, to back up both the activation keys and the content, use the backup feature of Nokia PC Suite. Other transfer methods may not transfer the activation keys which need to be restored with the content for you to be able to continue the use of OMA DRM-protected content after the device memory is formatted. You may also need to restore the activation keys in case the files on your device get corrupted.

## ■ Attach the wrist strap


Thread the wrist strap as shown, and tighten it.



## 2. Your phone


### ■ Keys and parts

1. Earpiece
2. Light sensor
3. Navi™ scroll key
4. Selection key
5. Call key
6. Microphone
7. Charger connector
8. Power key
9. Selection key
10. End key
11. Backspace key
12. Enter key



#### One touch keys

1. Home key
2. Contacts key
3. Calendar key
4. E-mail key




#### Fun/Shift/Chr

1. Function key. To insert digits or characters printed at the top of keys, press and hold the function key and press the corresponding key. To enter only the characters printed at the top of keys, press the function key twice quickly.
2. Shift key. To switch between the different character cases, press the shift key.
3. Chr key. When writing text, press the chr key to insert characters not shown on the keypad.



## Side

1. Universal headset connector
2. Volume key
3. Voice commands key
4. Volume key
5. Infrared
6. Micro USB connector
7. Micro SD card slot



## ■ Standby mode

When you have switched on the phone, and it is registered to a network, the phone is in the standby mode and ready for use.

To open the list of last dialed numbers, press the call key. Scroll left to access a list of calls received and missed calls.

To use the voice commands or voice dialing, press and hold the right selection key.

To change the profile, press the power key, and select a profile.

To start a connection to the web, press and hold 0.

## Active standby

Active standby provides fast access to frequently used applications shown across the top of the main display. To select an application or event, scroll to it, and select it.

To turn active standby off (*Idle scr. theme*) or choose different applications (*Shortcuts*), select *Menu > Settings > Config. > General > Personalization > Idle screen mode*.

## Offline profile



**Important:** In the offline profile you cannot make or receive any calls, or use other features that require cellular network coverage. Calls may still be possible to the official emergency number programmed into your device. To make calls, you must first activate the phone function by changing profiles. If the device has been locked, enter the lock code.




























To activate the Offline profile, press the power key, and select *Offline*. When the Offline profile is active, the connection to the cellular network is turned off. You can listen to music using the music player when the Offline profile is active. Remember to switch off your device when wireless phone use is prohibited.

To leave the Offline profile, press the power key, and select another profile.

## ■ Indicators

**3G** – The phone is connected to a UMTS or HSDPA network

**G** – The phone is connected to a GSM network

-  – The phone is in the Offline profile and not connected to a cellular network.
-  – A memory card is inserted in the phone.
-  – You have messages in the Inbox folder in Messaging.
-  – You have new voicemail.
-  – You have new instant messages (IM).
-  – You have new e-mail in your remote mailbox.
-  – You have messages waiting to be sent in Outbox.
-  – You have missed calls.
-  – Ringing type is set to Vibrate, and Message alert tone and E-mail alert tone are set to Off.
-  – The phone keypad is locked.
-  – An alarm is active.
-  – The loudspeaker is activated.
-  – All calls to the phone are forwarded to another number.
-  or  – A headset or a loopset is connected to the phone.
-  or  or  – A GPRS or EGPRS packet data connection is active, the connection is on hold, or a connection is available.
-  or  or  – A UMTS packet data connection is active, the connection is on hold, or a connection is available.
-  or  or  – A WLAN is available, actively connected, or actively connected to an encrypted network.
-  or  – Bluetooth connectivity is switched on, or data is being transmitted using Bluetooth technology.
-  – A USB data cable connection is active.

Other indicators may also be shown.

## ■ Menu

In the menu, you can access the functions in your phone. To access the main menu, press *Menu*.

To open an application or a folder, scroll to it, and press the center scroll key.

To change the menu view, select *Menu* > **Options** > *Change Menu view* and a view type.

If you change the order of the functions in the menu, the order may differ from the default order described in this user guide.

To close an application or a folder, select **Back** and **Exit** as many times as needed to return to the standby mode, or select **Options** > *Exit*.



**Tip:** To display and switch between open applications, press and hold the home key. Scroll to an application, and select it. To close open applications, press the backspace key.

To mark or unmark an item in applications such as *Address Book* or *Messaging*, press #. To mark or unmark several consecutive items, press and hold #, and scroll up or down.

Leaving applications running in the background increases the demand on battery power and reduces the battery life.

## ■ Volume control

To adjust the earpiece or loudspeaker volume during a call or when listening to an audio file, press the volume keys. To activate or deactivate the loudspeaker during a call, select **Loudsp.** or **Handset**.



**Warning:** Do not hold the device near your ear when the loudspeaker is in use, because the volume may be extremely loud.

## ■ Keypad lock (keyguard)

The phone automatically locks the keypad in one minute. To change the time the phone automatically locks the keypad, select *Menu > Settings > Config. > General > Security > Phone and SIM card > Keypad auto lock period > User defined* and the desired time. To manually lock the keypad in the phone mode, press the left selection key and \* within 1.5 seconds.

To unlock the keypad in the phone mode, select **Unlock**, and press \* within 1.5 seconds.

To lock the keypad in the music mode, press the power/end key two times, and select *Lock keypad*. To unlock the keypad in the music mode, select **Unlock > OK**.

When the device or keypad is locked, calls may be possible to the official emergency number programed into your device.



## ■ Antenna locations

Your device has four antennas: cellular antenna, Bluetooth antenna, WLAN antenna, and GPS antenna. The antennas are integrated, and located at the upper and lower parts of your device.







**Note:** Your device may have internal antennas. As with any radio transmitting device, avoid touching the antenna area unnecessarily while the antenna is transmitting or receiving. Contact with such an antenna affects the communication quality and may cause the device to operate at a higher power level than otherwise needed and may reduce the battery life.

## ■ Connect a compatible headset

Do not connect products that create an output signal as this may cause damage to the device. Do not connect any voltage source to the Nokia Connector.

When connecting any external device or any headset, other than those approved by Nokia for use with this device, to the universal headset connector, pay special attention to volume levels.



## ■ Connect a USB data cable

To set the default USB connection mode, select *Menu > Settings > Data Cbl. > Data Cable Mode* and the desired mode. To set the default mode to be activated automatically, select *Ask on connection > No*.



# 3. Call functions

---

To adjust the volume during the call, press the volume key.

## ■ Make a voice call

1. In the standby mode, enter the phone number, including the area code. Press the backspace key to remove a number.  
For international calls, press \* twice for the international prefix (the + character replaces the international access code), and enter the country code, area code (omit the leading zero if necessary), and phone number.
2. To call the number, press the call key.
3. To end the call, or to cancel the call attempt, press the end key.

To make a call from Address Book, select *Menu > Addr. Book*, or the right selection key. Scroll to the desired name, or enter the first letters of the name, and scroll to the desired name. To call the number, press the call key.

To call a recently dialed number, press the call key in the standby mode to see a list numbers. Scroll left to see calls received or missed calls. Select a number, and press the call key.

## Voice dialing

A voice tag is added automatically to all entries in *Addr. Book*.

### Make a voice dialing call

Before using voice tags, note the following:

- Voice tags are not language-dependent. They are dependent on the speaker's voice.
- Voice tags are sensitive to background noise. Use them in a quiet environment.



**Note:** Using voice tags may be difficult in a noisy environment or during an emergency, so you should not rely solely upon voice dialing in all circumstances.

1. In the standby mode, press and hold the right selection key.

If you are using a compatible headset with the headset key, press and hold the headset key.

2. When *Speak now* is displayed, speak the voice command clearly. The phone plays the voice command of the best match. After 1.5 seconds, the phone dials the number. If the result is not the correct one, before dialing, select **Next** and another entry.

### Make a conference call

The phone supports conference calls (network service) between a maximum of six participants, including yourself. Contact your service provider for any network limitations.

1. Make a call to the first participant.
2. To make a call to another participant, select **Options** > *New call*.
3. To create the conference call when the new call is answered, select **Options** > *Conference*.

To add a new person to the conference call, repeat step 2, and select **Options** > *Conference* > *Add to conference*.

4. To end the conference call, press the end key.

### ■ Answer or decline a call

To answer a call, press the call key.

To mute the ringing tone, select **Silence**.

To reject the call, press the end key, or select **Options** > *Decline*. If you have set *Call forwarding* to *If busy*, rejecting the call forwards the call.

To send a text message as a reply to the caller instead of answering the call, select **Silence** > *Send msg*. To edit and save the text message reply, select **Menu** > *Settings* > *Config*. > *Phone* > *Call* > *Message text*.

Keep your device away from magnets or magnetic fields.

## Call waiting

During a call, to answer the waiting call, press the call key. The first call is put on hold. To switch between the two calls, select **Swap**. To end the active call, press the end key.

To activate the *Call waiting* function (network service), select *Menu > Settings > Config. > Phone > Call > Call waiting > Activate*.

## Options during a call

Many of the options that you can use during a call are network services. For availability, contact your service provider.

During a call, select **Options** and from the following:

*Transfer* – to connect a call on hold to an active call and disconnect yourself

*Send touch tones* – to send DTMF tone strings (for example, a password). Enter the DTMF string or search for it in Address Book. To enter a wait character (**w**) or a pause character (**p**), press \* repeatedly. To send the tone, select **OK**.

## ■ Video Share

Video Share allows you to share live video with another person using a Video Share capable phone. Both accounts must subscribe to the Video Share service and be in a 3G service area during the video share call.

1. During a voice call, *Video Share Ready* appears.
2. To begin sharing, select *Video Share*.

After the receiving caller accepts your invitation, the speakerphone activates and streams your camera's video.

3. To stop sharing, select **Stop**.

The speakerphone turns off and the connection continues as a voice call. You can choose to save the video clip.

Additional features may be available. If you have questions about billing or Video Share, contact your service provider. For more information, see [www.wireless.att.com](http://www.wireless.att.com).

## 4. Cellular Video

---

In the standby mode, to access to the AT&T wireless internet, select *Menu > Cellular Video*. Cellular Video (CV) provides links to a variety of content such as video clips from TV shows, news, sports, and weather. Access the wireless internet with MEdia™ Net to purchase and download music, games, graphics, multimedia, and applications to your phone.

If you have questions about billing or accessing this website, contact your service provider. For more information, see [www.wireless.att.com](http://www.wireless.att.com).

## 5. Write text

---

### ■ Traditional text input

Your device has a full keyboard. You can enter punctuation marks by pressing the corresponding key or a combination of keys.

To switch between the different character cases, press the shift key.

To insert digits or characters printed at the top of keys, press and hold the corresponding key, or press and hold the function key and press the corresponding key.

To enter only the characters printed at the top of keys, press the function key twice quickly.

To erase a character, press the backspace key. To erase several characters, press and hold the backspace key.

To insert characters that are not shown on the keypad, press the chr key.

To copy text, press and hold the shift key, and scroll to highlight the word, phrase, or line of text you want to copy. Select **Options** > *Editing options* > *Copy*. To insert the text into a document, move to the correct place and select **Options** > *Editing options* > *Paste*.

To change the writing language, or to switch off the predictive text input, select **Menu** > *Settings* > *Config.* > *General* > *Personalization* > *Language*.

### ■ Predictive text input

To activate predictive text input, select **Menu** > *Settings* > *Config.* > *General* > *Personalization* > *Language* > *Predictive text*. The indicator is shown on the display. When you start writing a word, your device suggests possible words. When the correct word is found, scroll right to confirm it. While writing, you can also scroll down to access a list of suggested words. If the desired word is on the list, scroll to it and press the scroll key. If the word you are writing is not in the dictionary of the device, the device suggests a possible word, while the word you were writing is shown above the suggested word. Scroll up to select your word. The word is added to the dictionary when you start writing the next word.

To define the settings for text input, select **Options** > *Input options* > *Settings*.

To change the writing language, select **Options** > *Input options* > *Writing language*.

## 6. Messaging

---

Before you can receive or send messages or e-mail, you must have the necessary settings and access points defined. Contact your service provider for the settings.

### ■ Write and send messages

Your device supports text messages beyond the limit for a single message. Longer messages are sent as two or more messages. Your service provider may charge accordingly. Characters

with accents or other marks, and characters from some language options, take up more space, and limit the number of characters that can be sent in a single message.

The wireless network may limit the size of MMS messages. If the inserted picture exceeds this limit, the device may make it smaller so that it can be sent by MMS.

Only devices that have compatible features can receive and display multimedia messages. The appearance of a message may vary depending on the receiving device.

1. Select **Menu > Messaging > Messages > New message** and the message type. To create a text message or multimedia message, select **Message**, or from the standby mode, select the left selection key. The message type changes automatically based on the content.



**Tip:** To change the message font size, select **Options > Font size** and the desired size.

2. In the **To:** field, enter the phone numbers or e-mail addresses of the recipients, or to select recipients from **Address Book**, press the scroll key. Separate recipients with a semicolon (;).
3. To enter the subject for a multimedia, or e-mail message, scroll down to the subject field. If the subject field is not visible for a multimedia message, select **Options > Message header fields**, mark **Subject**, and select **OK**.
4. Scroll down to the message field and enter the message content.

When you write a text message, the message length indicator shows how many characters you can enter in the message. For example, 10 (2) means that you can still add 10 characters for the text to be sent as a series of two text messages.

To insert an object, such as an image, video clip, note, or a business card, to a multimedia, or e-mail message, select **Options > Insert content**. Use the scroll key to move across the icons at the bottom of the message. Press the center selection key, or select **Select** to insert the content.

To record a new sound clip for an audio message, select **Insert audio clip > New**. To use a previously recorded sound clip, select **Insert audio clip > From My Stuff**.

5. To send the message, select **Options > Send**.

## ■ Inbox

Inbox contains received messages except e-mail messages. To read received messages, select **Menu > Messaging > Messages > Inbox** and the message.

To view the list of media objects that are included in the multimedia message, open the message, and select **Options > Objects**.



**Important:** Exercise caution when opening messages. Messages may contain malicious software or otherwise be harmful to your device or PC.

Your phone can receive various types of messages, such as operator logos, business cards, calendar entries, and ringing tones. You can save the message content to your phone.

For example, to save a received calendar entry to the calendar, select **Options > Save to Calendar**.

## Service messages

Service messages (network service) are notifications that may contain a text message or the address of a browser service.

To define whether service messages are enabled and whether the messages are downloaded automatically, select **Menu > Messaging > Messages > Options > Settings > Service message**.

## ■ E-mail

When you create a new mailbox, the name you give to the mailbox replaces *New mailbox*. You can have up to six mailboxes. Select **Menu > Messaging > Messages > More E-mail** and follow the instruction to create and connect to mailboxes.

## IMAP4 and POP3 mailboxes

Select **Menu > Messaging > Messages** and the mailbox. *Connect to mailbox?* is displayed. Select **Yes** to connect to your mailbox (network service) or **No** to view previously retrieved e-mail messages offline.

To connect to the mailbox afterwards, select **Options > Connect**. When you are online, to end the data connection to the remote mailbox, select **Options > Disconnect**.

## Retrieve and read e-mail messages



**Important:** Exercise caution when opening messages. Messages may contain malicious software or otherwise be harmful to your device or PC.

1. Select **Options > Retrieve e-mail** and whether you want to retrieve new, selected, or all messages.
2. To open an e-mail message, select it.

To view e-mail attachments, indicated with , select **Options > Attachments**. You can retrieve, open, or save attachments in supported formats.

## Delete e-mail messages

To delete an e-mail message from the phone and retain it in the remote mailbox, select **Options > Delete > Phone only**. To delete an e-mail from both the phone and the remote mailbox, select **Options > Delete > Phone and server**.

To cancel the deletion of an e-mail from both the phone and server, scroll to an e-mail that has been marked to be deleted during the next connection, and select **Options > Restore**.

## Sync mailboxes

Select **Menu > Messaging > Messages** and the sync mailbox.

To synchronize your phone with the remote mailbox, select **Options** > *Synchronization* > *Start*.

To view received messages, select *Inbox* and the message.

## ■ **Outbox**

The Outbox folder is a temporary storage place for messages that are waiting to be sent. To access the Outbox folder, select *Menu* > *Messaging* > *Messages* > *Outbox*.

To retry sending a message, scroll to the message, and select **Options** > *Send*.

To postpone sending a message, scroll to a message, and select **Options** > *Defer sending*.

## ■ **View messages on the SmartChip card**

Before you can view SmartChip messages, you need to copy them to a folder in your phone. Select *Menu* > *Messaging* > *Messages* > **Options** > *SIM messages*, mark the messages you want to copy, and select **Options** > *Copy* and the folder to which you want to copy the messages.

## ■ **Service commands**

To enter and send service commands (also known as USSD commands) such as activation commands for network services to your service provider, select *Menu* > *Messaging* > *Messages* > **Options** > *Service commands*. To send the command, select **Options** > *Send*.

## ■ **Messaging settings**

### Text message settings

To define text message settings, such as the message center and character encoding used, select *Menu* > *Messaging* > *Messages* > **Options** > *Settings* > *Text message*.

### Multimedia messaging settings

To define multimedia message settings, such as the access point to use and whether multimedia messages are retrieved automatically, select *Menu* > *Messaging* > *Messages* > **Options** > *Settings* > *Multimedia message*.

### E-mail settings

Select *Menu* > *Messaging* > *Messages* > **Options** > *Settings* > *E-mail* > *Mailboxes*, the mailbox and from the following:

*Connection settings* – to define the connection settings such as the servers and protocol used

*User settings* – to define user settings such as when messages are sent and whether to include a signature

*Retrieval settings* – to define retrieval settings such as which parts of the messages are retrieved and how many messages are retrieved

*Automatic retrieval* – to define settings for retrieving messages automatically at set intervals or when an e-mail notification is received from the server

## **Other settings**

To define whether a specified number of sent messages are saved to the Sent folder, and whether to store the messages in the phone memory or memory card, select *Menu > Messaging > Messages > Options > Settings > Other*.

## **Message reader**

The message reader reads received text and multimedia messages aloud.

To play a message, press and hold the left selection key when you receive a message.

To start reading the next message in Inbox, scroll down. To start reading the message again, scroll up. In the beginning of the message, scroll up to hear the previous message.

To pause the reading, press the left selection key briefly. To continue, press the left selection key briefly again. To end the reading, press the end key. See "Edit the voice properties," p. 50.

## **■ Instant messaging**

Instant messaging (IM, network service) allows you to converse with others and join discussion forums (IM groups) with specific topics.

For availability of IM services, pricing, and tariffs contact your service provider.

Select *Menu > Messaging > Messages > IM*.

## **■ Settings wizard**

Select *Menu > Messaging > Set. wiz*.

Settings wizard configures your device for settings based on your network operator information. To use these services, you may have to contact your service provider to activate a data connection or other services.

The availability of the different settings items in Settings wizard depends on the features of the device, SmartCard card, wireless service provider, and the availability of the data in the Settings wizard database.

If Settings wizard is not available from your service provider, it may not appear in the menu of your device.

To start the wizard, select *Start*. When you use the wizard for the first time, you are guided through the settings configuration. If there is no SmartCard card inserted, you need to select the home country of your service provider, and your service provider. If the country or service



provider suggested by the wizard is not correct, select the correct one from the list. If the settings configuration is interrupted, the settings are not defined.

To access the main view of the Settings wizard after the wizard has finished the settings configuration, select *OK*.

If you are not able to use Settings wizard, visit the Nokia phone settings web site or contact your service provider.

## ■ Message reader

Select *Menu > Messaging > Msg. reader*.

The message reader reads received text and multimedia messages aloud.

To play a message, press and hold the left selection key when you receive a message.

To start reading the next message in the inbox, scroll down. To start reading the message again, scroll up. In the beginning of the message, scroll up to hear the previous message.

To pause the reading, press the left selection key briefly. To continue, press the left selection key briefly again.

To end the reading, press the end key.

## 7. Yellow Pages

---

In the standby mode, to access to the AT&T Yellow Pages website, select *Menu > Yellow Pages*. Yellow Pages provides a directory of local and national businesses, search options, maps, and directions.

If you have questions about billing or accessing this website, contact your service provider.

## 8. MEdia Net

---

You can access various mobile internet services with your phone browser.



**Important:** Use only services that you trust and that offer adequate security and protection against harmful software.

Check the availability of these services, pricing, and instructions with your service provider.


With the phone browser you can view the services that use wireless markup language (WML) or extensible hypertext markup language (XHTML) on their pages. Appearance may vary due to screen size. You may not be able to view all details of the internet pages.

## ■ Connect to MEdia Net

Ensure that the correct configuration settings of the service are activated.

Make a connection to the AT&T mobile web service in one of the following ways:

- Select *Menu > MEdia Net*. In the standby mode, press and hold 0, or press the MEdia Net key under the left selection key.
- To select a bookmark of the service, select *Menu > MEdia Net > Options > Save as bookmark*.

The starting page is indicated with .

- To enter a new URL, select *Menu > MEdia Net > Options > Go to web address*. Enter the address of the service, and select *Go to*.


You can save page addresses as bookmarks in the phone memory.

## ■ Browse pages

After you make a connection to the service, you can start browsing its pages. The function of the phone keys may vary in different services. Follow the text guides on the phone display.

For more information, contact your service provider.

### Connection security

If the security indicator  is displayed during a connection, the data transmission between the phone and the internet gateway or server is encrypted.

The security icon does not indicate that the data transmission between the gateway and the content server (or place where the requested resource is stored) is secure. The service provider secures the data transmission between the gateway and the content server.

To view details about the connection, encryption status, and information about server authentication, select *Options > Advanced > Page info*.

### Keys and commands for browsing

To open a link, make selections, or select boxes, press the scroll key.

To go to the previous page while browsing, select **Back**. If **Back** is not available, select *Options > Navigation options > History* to view a chronological list of the pages visited during a browsing session. To select the desired page, scroll left or right, and select it. The history list is cleared each time a session is closed.

To save a bookmark while browsing, select *Options > Save as bookmark*.

To retrieve the latest content from the server, select *Options > Navigation options > Reload*.

To open the browser toolbar, scroll to an empty part of the page, and press and hold the scroll key.

To end the connection and view the browser page offline, select *Options > Advanced > Disconnect*. To stop browsing, select *Options > Exit*.

## Keypad shortcuts while browsing

- 1 – Open your bookmarks.
- 2 – Search for keywords in the current page.
- 3 – Return to the previous page.
- 5 – List all open windows.
- 8 – Show the page overview of the current page. Press 8 again to zoom in and view the desired section of the page.
- 9 – Enter a new web address.
- 0 – Go to the start page.
- \* or # – Zoom the page in or out.

## Page overview

With page overview, you can move more quickly to the desired part of a web page. Page overview may not be available on all pages.

To show the page overview of the current page, press 8. To find the desired spot on the page, scroll up or down. Press 8 again to zoom in and view the desired section of the page.

## Direct calling

While browsing, you can make a phone call, and save a name and a phone number from a page.

### Receive a bookmark

When you have received a bookmark a message is displayed. To view the bookmark, select Show.

## ■ Security settings

### Cookies

A cookie is data that a site saves in the cache memory of your phone. Cookies are saved until you clear the cache memory. See "Cache memory," p. 27.

In the standby mode, select *Menu > MEdia Net > Options > Settings > Privacy > Cookies*. To allow or prevent the phone from receiving cookies, select *Allow* or *Reject*.

## ■ Cache memory

A cache is a memory location that is used to store data temporarily. If you have tried to access or have accessed confidential information requiring passwords, empty the cache after each use. The information or services you have accessed is stored in the cache.

To empty the cache while browsing, select *Options > Clear privacy data > Cache*.

## ■ Browser security

Security features may be required for some services, such as online banking or shopping. For such connections, you need security certificates and possibly a security module, which may be available on your SmartChip card. For more information, contact your service provider.

### Security module

The security module improves security services for applications requiring a browser connection, and allows you to use a digital signature. The security module may contain certificates as well as private and public keys. The certificates are saved in the security module by the service provider.

To view or change the security module settings, select *Menu > Settings > Config.> General > Security > Security module*.

### Protected content

Protected content stores licenses used to access DRM-protected material. See "Digital rights management," p. 12. When the license store becomes full, it may be necessary to remove the licenses stored on the phone before adding new ones.

To remove all licenses stored on your phone, select *Menu > Settings > Config.> General > Security > Protected content*.

### Certificates



**FCC Draft**

**Important:** Even if the use of certificates makes the risks involved in remote connections and software installation considerably smaller, they must be used correctly in order to benefit from increased security. The existence of a certificate does not offer any protection by itself; the certificate manager must contain correct, authentic, or trusted certificates for increased security to be available. Certificates have a restricted lifetime. If "Expired certificate" or "Certificate not valid yet" is shown, even if the certificate should be valid, check that the current date and time in your device are correct.

Before changing any certificate settings, you must make sure that you really trust the owner of the certificate and that the certificate really belongs to the listed owner.

There are three kinds of certificates: server certificates, authority certificates, and user certificates. You may receive these certificates from your service provider. Authority certificates and user certificates may also be saved in the security module by the service provider.

To view the list of the authority or user certificates downloaded into your phone, select *Menu > Settings > Config.> General > Security > Certificate management* and from the available options.

## 9. MEdia Mall

---

In the standby mode, to access to the AT&T Mall website, select *Menu > MEdia Mall*. MEdia Mall provides links to content such as tones, games, graphics, videos, multimedia, and applications that may be purchased and downloaded to your phone.

If you have questions about billing or about accessing this website, contact your service provider.

## 10. AT&T Music

---

This menu provides access to the music player, music-related tools, applications, and services.

To open the music player from the standby mode, select *Menu > AT&T Music > Music Player*.

You can extend the available memory with a microSD memory card. Your device supports a microSD card with up to 8 GB memory. You can insert or remove a microSD card without switching the phone off. For more information on inserting a microSD card, see "Insert the microSD card," p. 10.

To maximize the performance of your device, it is recommended that no more than 100 files are stored in any folder.

Use only compatible microSD cards approved by Nokia for use with this device. Nokia uses approved industry standards for memory cards, but some brands may not be fully compatible with this device. Incompatible cards may damage the card and the device and corrupt data stored on the card.

### ■ Music player



**Warning:** Listen to music at a moderate level. Continuous exposure to high volume may damage your hearing. Do not hold the device near your ear when the loudspeaker is in use, because the volume may be extremely loud.

Select *Menu > My Stuff > Music* to start the music player.

You can listen to music when the *Offline* profile is activated. See "Offline profile," p. 14.

### Listen to music

In *Music*, select a category, such as *All songs* and a song.

### Playback control

To play or pause a song, press the *play/pause/stop* key.

To stop the playback, press and hold the *play/pause/stop* key.

To rewind or skip backwards, press the *rewind* key.

To fast-forward or to skip forward, press the fast-forward key.

To control the player, you can also use the scroll key.

To adjust the volume, use the volume key.

To switch random play (⏮) on, select **Options** > *Shuffle* > *On*.

To repeat a song (⏮) or all songs (⏮), select **Options** > *Repeat* > *Repeat song* or *Repeat all*.

To modify the tone of the music playback, select **Options** > *Equalizer*.

To modify the balance, loudness, or stereo widening, select **Options** > *Audio settings*.

To view a visualization during playback, select **Options** > *Start visualization*.

To return to the standby mode and leave the player in the background, press the end key. In Active standby, the currently playing song is displayed. To return to the music player, select the currently playing song.

## Music menu

To select more music to play in the *Now playing* view, select **Options** > *Go to Music menu*. To return to the *Now playing* view, select **Options** > *Go to Now playing*.

The music menu shows the music available in the phone and compatible memory card (if inserted).

To refresh the library after you have updated or moved files in the song selection, select **Options** > *Refresh library*.

After moving files, if a song has "!" in front of the title, use the refresh option to update the music player.

## Playlists

In the Music menu, select *Playlists*.

### Create a playlist

1. Select **Options** > *Create playlist*.
2. Enter a name for the playlist, and select **OK**.
3. To add songs now, select **Yes**. To show the song list under an artist title, scroll to the artist, and scroll right. To hide the song list, scroll left. Select the songs to be added, and to add the songs, select **Add**.
4. When you have made your selections, select **Done**. If a compatible memory card is inserted, the playlist is saved to the memory card.

To view details of the playlist, select **Options** > *Playlist details*.

To add more songs later, when viewing the playlist, select **Options** > *Add songs*.

To reorder songs in a playlist, scroll to the song you want to move, select **Options** > *Reorder list* > **Grab**, scroll to a new position, and select **Drop**.

## Shop Music

To go to shop music, in the *Music player*, select **Options** > *Shop Music*.

In Shop Music (network service) you can search, browse, and purchase music for downloading to your phone. You must have music shop settings and valid internet connections to use this service.

The variety and appearance of Shop Music services and settings may vary. For more information and availability of Music Shop, contact your service provider.

The settings may also be predefined in your phone. You may be able to edit the settings; select **Options** > *Settings*.

## Transfer music

You can buy music protected with WMDRM or OMA DRM from online music shops, and transfer the music to your phone.

To transfer music from a compatible PC or other compatible devices, use a compatible USB cable or Bluetooth connectivity. You cannot transfer WMDRM protected music files using Bluetooth.

To refresh the library after you have updated the song selection in your phone, in the *Music menu*, select **Options** > *Refresh Music library*.

The requirements of the PC for music purchase and transfer:

- Microsoft Windows XP operating system (or later)
- Compatible version of Windows Media Player application
- Compatible version of Nokia PC Suite

FCC Draft

## **Transfer music from PC**

You can use three different methods to transfer music:

- To use Nokia Music Manager in Nokia PC Suite, connect the compatible USB cable or activate Bluetooth connection, and select *PC Suite* as the connection mode.
- To synchronize music with Windows Media Player, connect the compatible USB cable and select *Media transfer* as the connection mode. A compatible memory card needs to be inserted in the phone. You can transfer WMDRM protected music files only using *Data transfer*.
- To view your phone on a PC as an external hard drive where you can transfer any data files, make the connection with a compatible USB cable, or with Bluetooth connectivity using PC Suite file manager.

If you are using the USB cable, select *Data transfer* as the connection mode. A compatible memory card needs to be inserted in the phone.

To change the default USB connection mode, select *Menu* > *Settings* > *Data Cbl.* > *Data Cable Mode*.



**Tip:** The method recommended for optimal transfer time is using Windows Media Player and the Media transfer connection mode.

When transferring music by inserting an old memory card with music files to the Nokia E71x, or by using the mass storage USB connection mode to transfer, the music player does not automatically display the transferred music tracks.

To view the transferred music tracks, update the music player library by selecting **Options > Refresh Music library**. This update process may take a long time. This delay only occurs with the first transfer, and the delay depends on how many music files were transferred.

Both Windows Media Player and Nokia Music Manager in Nokia PC Suite have been optimized for transferring music files. For information about transferring music with Nokia Music Manager, see the Nokia PC Suite user guide.

## Music transfer with Windows Media Player

Music synchronization functions may vary between different versions of the Windows Media Player application. For more information, see the corresponding Windows Media Player guides and helps.

## 11. My Stuff

---

Select **Menu > My Stuff**.

Use **My Stuff** to save and organize your images, video clips, music tones, streaming links, and presentations.

To copy files to phone memory or to the memory card, select the folder (such as *Images*), scroll to the file or mark the files, and select **Options > Organize > Copy to phone mem.** or **Copy to memory card**.

To set an image as a wallpaper or to be shown during a call, select *Images*, and scroll to the image. Select **Options > Use image**, **Assign to contact**, **Set as wallpaper** or **Set as call image**.

To create image or video folders and move files to them, select *Images* or *Videos*, and scroll to a file. Select **Options > Organize > New folder** and the memory, and enter a name for the folder. Mark the files you want to move to the folder, and select **Options > Organize > Move to folder** and the folder.

### ■ Download files

Select **Menu > My Stuff**, the folder for the file type you want to download, and the download function (for example, *Images > Downl. images*). The browser opens. Choose a bookmark for the site to download from.



## ■ View images

When you are viewing still images in the phone, you can view the next or previous images using the right and left scroll keys.

- To view an image in the full screen, and to return to the normal view, press 0.
- To rotate an image clockwise or counterclockwise, press 3 or 1.
- To zoom in closer press \*, to zoom out press #. Select *Back* to return the normal view.
- To move on a zoomed image, scroll up, down, left, or right.

## ■ Edit images

To edit images in *My Stuff*, scroll to the image, and select **Options** > *Edit*.

Select **Options** > *Apply effect* to crop or rotate the image; adjust the brightness, color, contrast, and resolution; and add effects, text, clip art, or a frame to the picture.

Shortcuts in the image editor:

- To view an image in the full screen, and to return to the normal view, press \*.
- To rotate an image clockwise or counterclockwise, press 3 or 1.
- To zoom in, select **Options** > *Zoom in*.

## ■ Print images

You can use the phone with a PictBridge-compatible printer using a data cable.

To print images in *My Stuff*, scroll to the image, and select **Options** > *Print*.

## ■ Transfer videos from PC

To transfer videos from a compatible PC, use a compatible USB cable or Bluetooth connectivity.

The requirements of the PC for video transfer:

- Microsoft Windows XP operating system (or later)
- Compatible version of Nokia PC Suite
- Nokia Video Manager application (add-on application to PC Suite)

To transfer videos with Nokia Video Manager, connect the compatible USB cable or activate Bluetooth connection, and select *PC Suite* as the connection mode.

To change the default USB connection mode, select *Menu* > *Settings* > *Data Cbl.* > *Data Cable Mode*.

Nokia Video Manager is optimized for transcoding and transferring video files. For information about transferring video with Nokia Video Manager, see the Nokia Video Manager help.

## ■ Tones

To download tracks or audio clips select *Menu > My Stuff > Tones > Download Tones*. The browser opens, and you can select a bookmark from which the site can download.

## ■ Streaming links

Select *Menu > My Stuff > Download videos > Options > New link* to create a new streaming link. Enter the name and Web address. Scroll to links and select **Open** to go to a link.

## ■ Presentations

With presentations, you can view svg (scalable vector graphics) files, such as cartoons and maps. These files maintain their appearance when printed or viewed with different screen sizes and resolutions. To view svg files, select the *Menu > My Stuff > Presentations*, scroll to an image, and select *Play*.

# 12. Address Book

---

## ■ Save and manage contact information

To save and manage contact information, such as names, phone numbers, and addresses, select *Menu > Addr. Book*, or press the right selection key.

To add a new contact, select *Options > New contact*. Fill in the fields you want, and select **Done**.

To view names and numbers from a SmartChip card, phone memory, and service numbers, select **Options > Settings > Contacts to display** and mark *Phone memory*, *SIM memory*, or *Service numbers*. Selecting SIM memory displays contacts saved on your SmartChip card.

To copy names and numbers from a SmartChip card to your phone or vice versa, scroll to the contact (or mark the desired contacts), and select **Options > Copy > Phone memory** or *SIM memory*.

To assign default numbers and addresses to a contact, select it, and select **Options > Defaults**. Scroll to the desired default option, and select **Assign**.

To view the list of fixed dialing numbers, select **Options > SIM numbers > Fixed dial contacts**. This setting is only shown if supported by your SmartChip card.

When fixed dialing is activated, calls may be possible to the official emergency number programed into your device.

To view information about the memory consumption of contacts, select **Options > Address Book info**.

To create a contact group so that you can send text or e-mail messages to several recipients at the same time, select *Menu > Addr. Book*. Scroll to the right, and select **Options > New**

*group*. Enter a name for the group, and select the group. Select **Options** > *Add members*. Mark the contacts you want to add to the group, and select **OK**.

## ■ Add a ringing tone

To set a ringing tone for each contact and group, select *Menu* > *Addr. Book*.

To add a ringing tone to a contact, select the contact and **Options** > *Ringing tone*, and the desired ringing tone.

To add a ringing tone to a group, scroll right to the groups list, and scroll to a contact group. Select **Options** > *Ringing tone* and the ringing tone for the group.

To remove the personal or group ringing tone, select *Default tone* as a ringing tone.

## 13. Games & Apps

---

In the standby mode, select *Menu* > *Games&Apps* to manage applications and games. These files are stored in the phone memory or an attached microSD memory card and may be arranged in folders.

For options to format or lock and unlock the memory card, see "Format a memory card," p. 47 and "Lock or unlock a memory card," p. 47.

## ■ Launch a game or application

Your phone software includes some games.

Select *Menu* > *Games&Apps*. Scroll to the desired game or application, and select *Open*.

## ■ Application options

*Update version* – to check if a new version of the application is available for download from web (network service)

*MEdia net page* – to provide further information or additional data for the application from an internet page (network service), if available

*App. access* – to restrict the application from accessing the network

## ■ Download an application

Your phone supports J2ME™ Java applications. Make sure that the application is compatible with your phone before downloading it.



**Important:** Only install and use applications and other software from sources that offer adequate security and protection against harmful software.

You can download new Java applications and games in different ways.

Use the Nokia Application Installer from PC Suite to download the applications to your phone, or select *Menu > Games&Apps > Options > Download applications*; the list of available bookmarks is shown.

For the availability of different services and pricing, contact your service provider.

## 14. AT&T Navigator

---

AT&T Navigator provides Global Positioning System (GPS) driving directions, color maps, and traffic alerts. Press the GPS key or select *Menu > AT&T GPS > AT&T Nav*.



**Tip:** To optimize the standby time for your phone, close any applications not in use.

If you have questions about billing or about accessing this website, please contact your service provider.

The Global Positioning System (GPS) is operated by the government of the United States, which is solely responsible for its accuracy and maintenance. The accuracy of location data can be affected by adjustments to GPS satellites made by the United States government and is subject to change with the United States Department of Defense civil GPS policy and the Federal Radionavigation Plan. Accuracy can also be affected by poor satellite geometry. Availability and quality of GPS signals may be affected by your location, buildings, natural obstacles, and weather conditions. The GPS receiver should only be used outdoors to allow reception of GPS signals.

Any GPS should not be used for precise location measurement, and you should never rely solely on location data from the GPS receiver and cellular radio networks for positioning or navigation.

The trip meter has limited accuracy, and rounding errors may occur. Accuracy can also be affected by availability and quality of GPS signals.

Assisted GPS (A-GPS) is used to retrieve assistance data over a packet data connection, which assists in calculating the coordinates of your current location when your device is receiving signals from satellites.

## 15. Tools

---

### ■ Notes

Select *Menu > Tools > Notes*. To write a new note, start writing. To save the note, select **Done**. You can save plain text files (.txt format) you receive to *Notes*.

## ■ Clock

Select *Menu > Tools > Clock*. To change the clock settings, and to set the time and date, select *Options > Settings*.

### Alarm clock

To set a new alarm, scroll right to *Alarms*, and select *Options > New alarm*. Enter the alarm time, select whether and when the alarm is repeated, and select *Done*.

To change AM and PM, highlight the current setting, and press any key to change from AM to PM, or from PM to AM.

To cancel an alarm, scroll to the alarm, and select *Options > Remove alarm*. To deactivate a repeated alarm, select *Options > Deactivate alarm*.

Select *Stop* to turn off the alarm.

Select *Snooze* to stop the alarm for 5 minutes, after which it resumes. You can do this a maximum of five times.

If the alarm time is reached while the device is switched off, the device switches itself on and starts sounding the alarm tone. If you select *Stop*, the device asks whether you want to activate the device for calls. Select *No* to switch off the device or *Yes* to make and receive calls. Do not select *Yes* when wireless phone use may cause interference or danger.

### World clock

To set the phone to show the time in other locations, scroll right to *World clock*. To add a location, select *Options > Add location*.

To set your current location, scroll to a location, and select *Options > Set as current location*. The location is displayed in the clock main view, and the time in your phone is changed according to the location selected. Check that the time is correct and matches your time zone.

## ■ Camera

To activate the camera, press the Camera/Video key, or select *Menu > Tools > Camera*.

### Capture an image


Your device supports an image capture resolution of up to 2048 x 1536 pixels.


To capture an image, use the display as a viewfinder and press the scroll key. The image is saved to *Images* in *My Stuff*. To return to the viewfinder, select *Back*. To delete the image, press the backspace key.


To zoom in or out before capturing an image, scroll up or down. This function is available only when the toolbar is not shown.


To focus on the subject before capturing the image, press the T key.


The toolbar provides you with shortcuts to different items and settings before and after capturing an image or recording a video. Scroll to a toolbar item and press the scroll key.


 – Switch between the video mode and the image mode.

 – Select the scene.


 – Select the flash mode (images only).


 – Activate the self-timer (images only).

 – Activate the sequence mode (images only).

 – Select a color effect.

 – Show or hide the viewfinder grid (images only).


 – Adjust the white balance.

 – Adjust the exposure compensation (images only).

The available options vary depending on the capture mode and view you are in. The settings return to the default after you close the camera.

Keep a safe distance when using the flash. Do not use the flash on people or animals at close range. Do not cover the flash while taking a picture.

To edit a photo, select *My Stuff* > *Images*. Open the photo and select **Options** > *Edit* > **Options** > *Apply effect*. Scroll through the options on the screen and select the effect you want.

 **Tip:** To turn off the camera capture sound, press and hold the # key to activate the vibrate profile.

## Record a video

To record a video, select the video mode from the toolbar. To start recording, press the scroll key.

To pause recording at any time, select *Pause*. Select *Continue* to resume recording. To stop recording, select *Stop*. The video clip is automatically saved is saved to *Video clips* in *My Stuff*. The maximum length of the video clip depends on the available memory.

To see the toolbar, press the left or right scroll key.

## Camera settings

To change camera settings for still images or video clips, select **Options** > *Settings* and the desired setting. The available options vary depending on the capture mode you are in.

## ■ Recent Calls

In the standby mode, press the call key as a shortcut to the recent calls log (a network service). Use the left and right scroll keys to scroll between missed calls, calls received, and calls made, or select *Menu* > *Tools* > *Recent calls*.



Note: The actual invoice for calls and services from your service provider may vary, depending on network features, rounding off for billing, taxes, and so forth.



Note: Some timers, including the life timer, may be reset during service or software upgrades.

## ■ Calendar

Select *Menu > Tools > Calendar*.

To add a new calendar entry, select **Options > New entry** and an entry type. *Anniversary* entries are repeated every year. *To-do* entries help you to keep a list of tasks that you need to do. Fill in the fields, and select **Done**.

Press # in month, week, or day views to automatically return to and highlight the current date.

## ■ Flash Player

To view, play, and interact with flash files made for mobile devices, select *Menu > Tools > Flash Player*. To open a folder or play a flash file, select it.

## ■ Calculator

Select *Menu > Tools > Calculator*. When entering numbers, press # to add a decimal.



Note: This calculator has limited accuracy and is designed for simple calculations.

## ■ Converter II

Select *Menu > Tools > Converter II*. You can convert measurement parameters such as *Length* from one unit to another, for example, *Yards to Meters*.

The converter has limited accuracy and rounding errors may occur.

Before you can convert currency, you need to choose a base currency (usually your domestic currency) and add exchange rates. The rate of the base currency is always 1. Select *Currency* as the measurement type, and select **Options > Currency rates**. To change the base currency, scroll to the currency, and select **Options > Set as base currency**. Add exchange rates, scroll to the currency, and enter a new rate.

After you insert all the required exchange rates, you can convert currency. In the first *Amount* field, enter the value to be converted. The other *Amount* field changes automatically.



Note: When you change base currency, you must enter new exchange rates because all previously set exchange rates are cleared.

## ■ RealPlayer

Select *Menu > Tools > RealPlayer*.

With RealPlayer, you can play media files such as video clips saved in the phone memory or memory card, or stream media files over the air by opening a streaming link. RealPlayer does not support all file formats or all the variations of file formats.

To play, select a media file or a streaming link in *Video clips*, *Download videos*, or *Recently played*.

To stream live content, you must first configure your default access point. Select *Menu > Tools > RealPlayer > Options > Settings > Streaming > Network*. Contact your service provider for more information.



**Warning:** Do not hold the device near your ear when the loudspeaker is in use, because the volume may be extremely loud.



## ■ Help

Your phone has context-sensitive help. To access help when an application is open, select **Options > Help**. To switch between help and the application that is open in the background, select and hold the home key, and select from the list of open applications.

To open help from the main menu, select *Menu > Tools > Help*. Select an application to view a list of help topics, and select the related help text. To open a keyword list, select **Options > Search**.

## ■ Recorder

The voice recorder allows you to record voice call conversations and voice memos. If you record a phone conversation, all parties hear a beeping sound during recording. Recorded files are saved in the *Tones* folder in *My Stuff*.

Select *Menu > Tools > Recorder*. To record a sound clip, select **Options > Record audio clip**, or select . To listen to the recording, select .

## ■ Quickoffice

Select *Menu > Tools > Quickoffice*.

Quickoffice consists of Quickword for Microsoft Word, Quicksheet for Microsoft Excel, Quickpoint for Microsoft PowerPoint, and Quickmanager for purchasing software. You can view Microsoft Office 2000, XP, and 2003 documents (\*.doc, \*.xls, and \*.ppt) with Quickoffice. If you have the editor version of Quickoffice, you can also edit files.

All file formats or features are not supported.

More information If you experience problems with Quickword, Quicksheet, or Quickpoint, visit <http://support.quickoffice.com> for more information. Support is also available by sending an e-mail to [sales@quickoffice.com](mailto:sales@quickoffice.com).

## Work with files

To open a file, scroll to it, and press the scroll key.



To sort files according to the type, select **Options** > *Sort by*.

To view the details of a file, select **Options** > *Details*. The details include the name, size and location of the file, and the time and date when the file was last modified.

To send files to a compatible device, select **Options** > *Send* and the sending method.

## 16. Settings

---

### ■ Speed dial

Speed dialing is a quick way to call frequently used numbers in the standby mode. You need to assign a phone number to the speed dialing keys 2 to 9 (the 1 key is reserved for the call mailbox), and set *Speed dialing* to *On*.

To assign a phone number to a speed dialing key, select *Menu* > *Settings* > *Speed dial*. Scroll to a key icon, and select **Options** > *Assign*. Select the contact and the number for the speed dial. To change the number, select **Options** > *Change*.

To set *Speed dialing* to *On*, select *Menu* > *Settings* > *Config.* > *Phone* > *Call* > *Speed dialing* > *On*.

To call a speed dialing number, press and hold the speed dialing key until the call begins.

### ■ Voicemail

To call your voice mailbox (network service), press and hold 1 in the standby mode.

To define the voicemail number if no number is set, select *Menu* > *Settings* > *Voice Mail*. Scroll to *Voice mailbox* and select *Define number*, and enter the corresponding mailbox number. To change the call mailbox number, select **Options** > *Change number*. Contact your service provider for the voice mailbox number.

### ■ Sync

Sync enables you to synchronize data such as your calendar entries, contacts, and notes with a compatible computer or a remote internet server using a Bluetooth connection.

Select *Menu* > *Settings* > *Sync*.

To create a new profile, select **Options** > *New sync profile* and enter the required settings.

To synchronize data, in the main view, mark the data to be synchronized, and select **Options** > *Synchronize*.

### ■ Profiles

In *Profiles*, you can adjust and customize the phone tones for different events, environments, or caller groups. You can see the currently selected profile at the top of the display in the standby mode. If the *Normal* profile is in use, only the current date is shown.

Select *Menu > Settings > Profiles*.

To activate the profile, select the profile and *Activate*.



**Tip:** To quickly access Profiles, press the end key and select from the menu. To quickly change to *Vibrate* profile from any other profile, in the standby mode, press and hold #.

To customize a profile, highlight the profile, select **Options > Customize**, and the desired settings.

To set the profile to be active until a certain time within the next 24 hours, select *Timed* and the time.

When using the *Offline* profile, the phone is not connected to the cellular network. If no SmartChip card is installed, to use some functions of the phone, start the phone in *Offline*.



**Important:** In the offline profile you cannot make or receive any calls, or use other features that require cellular network coverage. Calls may still be possible to the official emergency number programmed into your device. To make calls, you must first activate the phone function by changing profiles. If the device has been locked, enter the lock code.

## ■ Config.

### General

Select *Menu > Settings > Config > General* and from the following:

*Personalization* – to adjust the display, idle screen mode, tones, themes, language, voice command, and notification light settings.

- *Display* – to adjust the display brightness, font size, power saver time-out, the welcome screen note or logo, and light time-out.

The light time-out sets the backlight time-out for the display. Use the left and right scroll keys to set a time from five seconds to one minute.

- *Tones* – to select tones and volume for calls, e-mail, messages, calendar, and the clock.

*Date and time* – to set the time and date and the display format

*Enhancement* – to change the settings for an enhancement. Select an enhancement and the desired setting.

*Security* – to change the phone and SmartChip card settings, such as PIN and lock codes; view certificate details and check authenticity; and view and edit security modules

When security features that restrict calls are in use (such as call restrictions, closed user group, and fixed dialing), calls may be possible to the official emergency number programmed into your device.

*Factory config.* – to reset some of the settings to their original values. You need the lock code.

## Phone

### Call

Select *Menu* > *Settings* > *Config.* > *Phone* > *Call* and from the following:

*Send my caller ID* (network service) – to display or hide your phone number from the person whom you are calling

*Call waiting* (network service) – See "Call waiting," p. 19

*Decline call with msg. and Message text* – See "Answer or decline a call," p. 18.

*Automatic redial* – to set the phone to make a maximum of 10 attempts to connect the call after an unsuccessful call attempt

*Show call time and Summary after call* – to set the phone to display the call duration during a call and the approximate duration of the last call

*Speed dialing* – See "Speed dial," p. 41.

*Anykey answer* – to answer an incoming call by briefly pressing any key, except the left and right selection keys, volume keys, power key, and end key.

### Call forward

1. Select *Menu* > *Settings* > *Config.* > *Phone* > *Call forwarding* (network service).
2. Select which calls you want to forward, for example, *Voice calls*.
3. Select the desired option. For example, to forward voice calls when your number is busy or when you reject an incoming call, select *If busy*.
4. Select *Options* > *Activate* and the phone number to which you want to forward the calls. Several forwarding options can be active at the same time.

### Network

Select *Menu* > *Settings* > *Config.* > *Phone* > *Network* and from the following:

*Cell info display* (network service) – to set the phone to indicate when it is used in a cellular network based on microcellular network (MCN) technology and to activate cell info reception

### Connection

Select *Menu* > *Settings* > *Config.* > *Connection* and from the following:

*Bluetooth* – to switch Bluetooth on or off, and edit Bluetooth settings. See "Bluetooth connection settings," p. 45.

*Data Cable* – to edit USB settings. See "USB data cable," p. 47.

*Destinations* – to define the connection methods used for reaching a particular destination

*Data counter* – to set the data counter connection and access points.

*Data call* – to set the online time for the data call connection. The data call settings affect all access points that use a GSM data call.

*Video Share* – to set video sharing on or off, SIP profile, video saving, preferred memory, and alert note.

*SIP configuration* – to set or edit the default or existing profile.

*Configurations* – to view and delete configuration contexts. Certain functions, such as web browsing and multimedia messaging, may require configuration settings. You may receive the settings from your service provider.

*APN control* – to add new access point names.

## **Applications**

To view and edit settings of applications installed to your phone, select *Menu > Settings > Config. > Applications* and from the following:

*RealPlayer* – to set video repeat on or off and streaming proxy and access points.

*Camera* – to set camera image quality, show captured image, resolution, date or text, and memory in use. Also, to set video length, resolution, date or text, and memory in use.

*Voice recorder* – to set recording quality and memory in use.

*App. manager* – to set signed software installation, online certificate checks, and default web address.

*Recent calls* – to set the log duration of recent calls.

### ■ **Voice commands**

To select the function to use by voice command, select *Menu > Settings > Voice comm.* The voice commands for changing profiles are in the Profiles folder.

To change a voice command for an application, scroll to the application, select **Options > Change command** and enter the new name. To play the activated voice command, select **Options > Playback**.

To use voice commands, see "Voice dialing," p. 18.

### ■ **Themes**

To change the look of your phone display, activate a theme.

Select *Menu > Settings > Themes*. To see a list of the available themes, select *General*. The active theme is indicated by a check mark.

To preview a theme, scroll to the theme, and select **Options > Preview**. To activate the previewed theme, select **Set**.

The selected theme does not change the wallpaper. To change the wallpaper, select *Menu > Settings > Themes > Wallpaper > Image*. Scroll to the image you want and press **Select**.

In *Themes*, you can also set the menu view type, set a theme for the idle screen, set a custom wallpaper, personalize the look of the power saver, and select an image shown during a call.

## ■ Bluetooth connectivity

Bluetooth wireless technology enables wireless connections between electronic devices within a maximum range of 10 meters (33 feet).

This device is compliant with Bluetooth Specification 2.0 supporting the following profiles: GAP (General Access), SDAP (Service Discovery), OPP (Object Push), FTP (File Transfer), SPP (Serial Port), HSP (Headset), HFP (Hands-free), DUN (Dial-Up Network), BIP (Basic Imaging), A2DP (Advanced Audio Distribution), AVRCP (A/V Remote Control), GAVDP (Generic Audio/Video Distribution Profile), PBAP (Phone Book Access profile), SAP (SIM Access Profile), and GOEP (Generic Object Exchange). To ensure interoperability between other devices supporting Bluetooth technology, use Nokia approved enhancements for this model. Check with the manufacturers of other devices to determine their compatibility with this device.

There may be restrictions on using Bluetooth technology in some locations. Check with your local authorities or service provider.

Features using Bluetooth technology increase the demand on battery power and reduce the battery life.

Do not accept Bluetooth connections from sources you do not trust.

A Bluetooth connection is disconnected automatically after sending or receiving data.

### Bluetooth connection settings

Select *Menu* > *Settings* > *Bluetooth*.

*Bluetooth* — to switch Bluetooth connectivity on or off

*My phone's visibility* > *Shown to all* — to allow your phone to be found by other devices with Bluetooth connectivity at all times. To allow your phone to be found for a defined time period, select *Define period*. For security reasons it is advisable to use the *Hidden* setting whenever possible.

*My phone's name* — to define a name for your phone

*Remote SIM mode* — to enable the usage of the SIM card of the phone by another device (for example, a car kit) by Bluetooth technology (SIM access profile)

When the wireless device is in the remote SIM mode, you can only use a compatible connected enhancement, such as a car kit, to make or receive calls. Your wireless device will not make any calls, except to the emergency numbers programed into your device, while in this mode. To make calls from your device, you must first leave the remote SIM mode. If the device has been locked, enter the lock code to unlock it first.

### Pair and block devices


To open a list of paired devices, in the *Bluetooth* view, scroll right to the next tab.

To pair with a device, select **Options** > *New paired device*, select the device with which to pair, and exchange passcodes.



**Tip:** If you pair with a Bluetooth headset, (⌘) is shown on the display. If you move beyond the maximum range for a Bluetooth connection, and need to reconnect, make sure the phone displays "Headset Disconnected" and the indicator is not shown on the display before you pair the headset again.

To cancel pairing, scroll to the device whose pairing you want to cancel, and press the backspace key. If you want to cancel all pairings, select **Options** > *Delete all*.

To set a device to be authorized, scroll to the device, and select **Options** > *Set as authorized*. Connections between your phone and an authorized device can be made without your knowledge. Use this status only for your own devices to which others do not have access, for example, your PC or devices that belong to someone you trust.  is added next to authorized devices in the *Paired devices* view.


To block connections from a device, in the paired devices view, select the device and *Block*.

To view a list of blocked devices, scroll right to the tab *Blocked devices*. To unblock a device, scroll to the device, and select **Delete**.



**Important:** If you are unable to connect to PC Suite through Bluetooth, refer to the Nokia E71x FAQ Product Information at [www.nokiausa.com](http://www.nokiausa.com).

## Send data

1. Open the application where the item you wish to send is saved.
2. Scroll to the item you want to send, and select **Options** > *Send* > *Via Bluetooth*.
3. The phone starts to search for devices within range. Paired devices are shown with . Some devices may show only the unique device addresses. To find out the unique address of your phone, enter the code **\*#2820#** in the standby mode.

If you have searched for devices earlier, a list of devices found previously is shown. To start a new search, select *More devices*.

4. Select the device with which you want to connect.
5. If the other device requires pairing before data can be transmitted, a tone sounds and you are asked to enter a passcode. Create your own passcode and share the passcode with the owner of the other device. You do not have to memorize the passcode.

## Receive data

When you receive data using Bluetooth technology, you are asked if you want to accept the message. If you accept, the item is placed in *Inbox* in *Messages*.



## ■ USB data cable

To set the default USB connection mode, select *Menu > Settings > Data Cbl. > Data Cable Mode* and the desired mode. To set whether the default mode is activated automatically, select *Ask on connection > No*.

## ■ File manager

To browse, open, and manage files and folders in the phone memory or on a memory card, select *Menu > Settings > File mgr.*

## Back up and restore phone memory

To back up information from phone memory to the memory card or restore information from the memory card, in *File manager*, select *Options > Back up phone memory* or *Restore from mem. card*. You can only back up the phone memory and restore it to the same phone.

## Format a memory card

When a memory card is formatted, all data on the card is permanently lost. Some memory cards are supplied preformatted and others require formatting.

1. In the *File manager* view, select the memory card.
2. Select *Options > Memory card options > Format*.
3. When formatting is complete, enter a name for the memory card.

FCC Draft

## Lock or unlock a memory card

To set a password to help prevent unauthorized use, in the *File manager* view, select the memory card and *Options > Memory card password > Set*. You are asked to enter and confirm your password. The password can be up to eight characters long.

If you insert another password-protected memory card into your phone, you are prompted to enter the password of the card. To unlock the card, select *Options > Unlock memory card*.

## ■ Application manager

You can install two types of applications to your phone:

- J2ME™ applications based on Java™ technology with the extension .jad or .jar. PersonalJava™ applications cannot be installed on your phone.
- Other applications and software suitable for the Symbian operating system. The installation files have the .sis or .sisx extension. Only install software specifically designed for your phone.



**Important:** Only install and use applications and other software from trusted sources, such as applications that are Symbian Signed or have passed the Java Verified™ testing.


Installation files may be transferred to your phone from a compatible computer, downloaded during browsing, or sent to you in a multimedia message, as an e-mail attachment or by using Bluetooth. You can use Nokia Application Installer in Nokia PC Suite to install an application to your phone or a memory card.

To open *Application manager*, select *Menu > Settings > App. mgr.* Installed applications are placed in *Installed apps*.

## Install an application

The .jar file is required for installing Java applications. If it is missing, the phone may ask you to download it.

To install an application or software package:

1. Select the desired file in the Installation files folder. Applications on the memory card are indicated with .
2. Select **Options > Install**.

Alternatively, search the phone memory or the memory card, select the application, and press the scroll key to start the installation.

During the installation, the phone shows information about the progress of the installation. If you are installing an application without a digital signature or certification, the phone displays a warning. Continue installation only if you are sure of the origins and contents of the application.

Java applications may attempt to, for example, establish a data connection or send a message. To edit the permissions of an installed Java application and define which access point the application will use, select *Installed apps.*, scroll to the application, and select **Open**.

After you install applications to a compatible memory card, installation files (.sis) remain in the device memory. The files may use large amounts of memory and prevent you from storing other files. To maintain sufficient memory, use Nokia PC Suite to back up installation files to a compatible PC, then use the file manager to remove the installation files from the device memory. See "File manager," p. 47. If the .sis file is a message attachment, delete the message from the Messaging inbox.

## Remove an application

In the *Application manager* main view, select *Installed apps.*, scroll to the software package, and select **Options > Uninstall**.

## ■ Device manager

To open the device manager, select *Menu > Settings > Device mgr.*

## Update software

The current software version is displayed in the *Updates* view.





**Warning:** If you install a software update, you cannot use the device, even to make emergency calls, until the installation is completed and the device is restarted. Be sure to back up data before accepting installation of an update.

Downloading software updates may involve the transmission of large amounts of data through your service provider's network. Contact your service provider for information about data transmission charges.

Make sure that the device battery has enough power, or connect the charger before starting the update.

1. In the *Updates* view, select **Options** > *Check for updates*.

If an update is available, the phone starts downloading it.

2. After a successful download, to install the update, select **Now**. To start the installation later, select **Later**.

To start the installation process later, select **Options** > *Install update*.

If no server profile has been defined, the phone asks you to create one, or if there are several, to select from a list of servers.

Contact your service provider for server profile settings.

## Configure your phone

You may receive configuration settings from your service provider or company information management department.

To connect to a server and receive configuration settings for your phone, scroll right to *Profiles*, scroll to the server profile, and select **Options** > *Start configuration*.

To edit a server profile, scroll to the profile, and select **Options** > *Edit profile*.

Contact your service provider or company information management department for the server profile settings.

## ■ Connection manager

To view detailed information about a connection such as the bearer, status, and the amount of data sent or received, scroll to the connection and select **Open**. The details shown depend on the connection type.

## ■ WLAN wizard

Select *Menu* > *Settings* > *WLAN wiz..*

The WLAN wizard helps you to connect to a wireless LAN. To use WLAN, it must be available in the location, and your device must be connected to the WLAN.

Some places, like France, have restrictions on the use of wireless LAN. Check with your local authorities for more information.

The WLAN wizard shows the status of your wireless LAN connections and network searches in the active standby mode. To view the available options, scroll to the row showing the

status, and press the scroll key. Depending on the status, you can start the web browser using a wireless LAN connection, disconnect from a wireless LAN, search for wireless LANs, or set network scanning on and off.

When you select *Start Web browsing*, the WLAN wizard automatically creates an internet access point (IAP) for the selected wireless LAN. The IAP can also be used with other applications requiring wireless LAN connection.

If you select a secured wireless LAN network, you are asked to enter the relevant passcodes. To connect to a hidden network, you must enter the correct hidden service set identifier (SSID). To create a new access point for a hidden WLAN, select *New WLAN*.

You can also start the WLAN wizard separately to get more information on wireless LANs within range. Select *Menu > Tools > WLAN wiz.* Found networks are displayed.

Scroll to the desired network, and select *Options* and from the following:

- *Start Web browsing* or *Cont. Web browsing* using the IAP of the wireless LAN
- *Disconnect WLAN* to disconnect the active connection to the wireless LAN
- *Refresh* to update the list of available wireless LANs
- *Filter WLAN* to filter out wireless LANs in the list of found networks. The selected networks are filtered out the next time the application searches for wireless LANs.
- *Details* to view the details of the wireless LAN. If you select an active connection, the connection details are displayed.
- *Define access point* to create an internet access point but not start the web browser
- *Edit access point* to edit an existing internet access point

Always enable one of the available encryption methods to increase the security of your wireless LAN connection. Using encryption reduces the risk of unauthorized access to your data.

## ■ Speech

Select *Menu > Settings > Speech*.

With Speech, you can set the language, voice, and voice properties for the message reader.

### Edit the voice properties

To set the language for the message reader, select *Language*.

To set the speaking voice, select *Voice*. The voice is language dependent.

To set the speaking rate, select *Speed*.

To set the speaking volume, select *Volume*.

To listen to a voice, open the voice tab, select the voice, and select **Options > Play voice**.

# 17. Battery information

---

## ■ Charging and discharging

Your device is powered by a rechargeable battery. The battery intended for use with this device is the BP-4L. This device is intended for use when supplied with power from the following charger: AC-4. The battery can be charged and discharged hundreds of times, but it will eventually wear out. When the talk and standby times are noticeably shorter than normal, replace the battery. Use only Nokia approved batteries, and recharge your battery only with Nokia approved chargers designated for this device. Use only replacement batteries qualified with the device per the IEEE 1725-2006 standard. Use of other batteries or chargers may present a risk of fire, explosion, leakage, or other hazard.

If a battery is being used for the first time or if the battery has not been used for a prolonged period, it may be necessary to connect the charger, then disconnect and reconnect it to begin charging the battery. If the battery is completely discharged, it may take several minutes before the charging indicator appears on the display or before any calls can be made.

Always switch the device off and disconnect the charger before removing the battery.

Unplug the charger from the electrical plug and the device when not in use. Do not leave fully charged battery connected to a charger, since overcharging may shorten its lifetime. If left unused, a fully charged battery will lose its charge over time.

Always try to keep the battery between 15°C and 25°C (59°F and 77°F). Extreme temperatures reduce the capacity and lifetime of the battery. A device with a hot or cold battery may not work temporarily. Battery performance is particularly limited in temperatures well below freezing.

Do not short-circuit the battery. Accidental short-circuiting can occur when a metallic object such as a coin, clip, or pen causes direct connection of the positive (+) and negative (-) terminals of the battery. (These look like metal strips on the battery.) This might happen, for example, when you carry a spare battery in your pocket or purse. Short-circuiting the terminals may damage the battery or the connecting object.

Do not dispose of batteries in a fire as they may explode. Batteries may also explode if damaged. Dispose of batteries according to local regulations. Please recycle when possible. Do not dispose as household waste.

Do not dismantle, cut, open, crush, bend, deform, puncture, or shred cells or batteries. In the event of a battery leak, do not allow the liquid to come in contact with the skin or eyes. In the event of such a leak, flush your skin or eyes immediately with water, or seek medical help.

Do not modify or remanufacture, attempt to insert foreign objects into the battery or immerse or expose it to water or other liquids.

Improper battery use may result in a fire, explosion, or other hazard. If the device or battery is dropped, especially on a hard surface, and you believe the battery has been damaged, take it to a service center for inspection before continuing to use it.

Use the battery only for its intended purpose. Never use any charger or battery that is damaged. Keep your battery out of the reach of small children.


## ■ Nokia battery authentication guidelines

Always use original Nokia batteries for your safety. To check that you are getting an original Nokia battery, purchase it from an authorized Nokia dealer, and inspect the hologram label using the following steps:

Successful completion of the steps is not a total assurance of the authenticity of the battery. If you have any reason to believe that your battery is not an authentic, original Nokia battery, you should refrain from using it, and take it to the nearest authorized Nokia service point or dealer for assistance. Your authorized Nokia service point or dealer will inspect the battery for authenticity. If authenticity cannot be verified, return the battery to the place of purchase.

### Authenticate hologram

1. When you look at the hologram on the label, you should see the Nokia connecting hands symbol from one angle and the Nokia Original Enhancements logo when looking from another angle.



2. When you angle the hologram left, right, down and up, you should see 1, 2, 3 and 4 dots on each side respectively.

### What if your battery is not authentic?

If you cannot confirm that your Nokia battery with the hologram on the label is an authentic Nokia battery, please do not use the battery. Take it to the nearest authorized Nokia service point or dealer for assistance. The use of a battery that is not approved by the manufacturer may be dangerous and may result in poor performance and damage to your device and its enhancements. It may also invalidate any approval or warranty applying to the device.



To find out more about original Nokia batteries, visit [www.nokia.com/battery](http://www.nokia.com/battery).

# Care and maintenance

---

Your device is a product of superior design and craftsmanship and should be treated with care. The following suggestions will help you protect your warranty coverage.

- Keep the device dry. Precipitation, humidity, and all types of liquids or moisture can contain minerals that will corrode electronic circuits. If your device does get wet, remove the battery, and allow the device to dry completely before replacing it.
- Do not use or store the device in dusty, dirty areas. Its moving parts and electronic components can be damaged.
- Do not store the device in hot areas. High temperatures can shorten the life of electronic devices, damage batteries, and warp or melt certain plastics.
- Do not store the device in cold areas. When the device returns to its normal temperature, moisture can form inside the device and damage electronic circuit boards.
- Do not attempt to open the device other than as instructed in this guide.
- Do not drop, knock, or shake the device. Rough handling can break internal circuit boards and fine mechanics.
- Do not use harsh chemicals, cleaning solvents, or strong detergents to clean the device.
- Do not paint the device. Paint can clog the moving parts and prevent proper operation.
- Use a soft, clean, dry cloth to clean any lenses, such as camera, proximity sensor, and light sensor lenses.
- Use only the supplied or an approved replacement antenna. Unauthorized antennas, modifications, or attachments could damage the device and may violate regulations governing radio devices.
- Use chargers indoors.
- Always create a backup of data you want to keep, such as contacts and calendar notes.
- To reset the device from time to time for optimum performance, power off the device and remove the battery.

These suggestions apply equally to your device, battery, charger, or any enhancement. If any device is not working properly, take it to the nearest authorized service facility for service.



## Disposal

The crossed-out wheeled-bin symbol on your product, literature, or packaging reminds you that in the European Union all electrical and electronic products, batteries, and accumulators must be taken to separate collection at the end of their working life. Do not dispose of these products as unsorted municipal waste.

Return the products to collection to prevent possible harm to the environment or human health from uncontrolled waste disposal and to promote the sustainable reuse of material resources. Collection information is available from the product retailer, local waste authorities, national producer responsibility organizations, or your local Nokia representative. For more information, see product Eco-Declaration or country-specific information at [www.nokia.com](http://www.nokia.com).

## Additional safety information

---

### ■ Small children

Your device and its enhancements may contain small parts. Keep them out of the reach of small children.

### ■ Operating environment

This device meets RF exposure guidelines when used either in the normal use position against the ear or when positioned at least 2.2 centimeters (7/8 inches) away from the body. When a carry case, belt clip, or holder is used for body-worn operation, it should not contain metal and should position the device the above-stated distance from your body. To transmit data files or messages, this device requires a quality connection to the network. In some cases, transmission of data files or messages may be delayed until such a connection is available. Ensure the above separation distance instructions are followed until the transmission is completed.

Parts of the device are magnetic. Metallic materials may be attracted to the device. Do not place credit cards or other magnetic storage media near the device, because information stored on them may be erased.

### ■ Medical devices

Operation of any radio transmitting equipment, including wireless phones, may interfere with the functionality of inadequately protected medical devices. Consult a physician or the manufacturer of the medical device to determine if they are adequately shielded from external RF energy or if you have any questions. Switch off your device in health care facilities when any regulations posted in these areas instruct you to do so. Hospitals or health care facilities may be using equipment that could be sensitive to external RF energy.

## Implanted medical devices

Manufacturers of medical devices recommend that a minimum separation of 15.3 centimeters (6 inches) should be maintained between a wireless device and an implanted medical device, such as a pacemaker or implanted cardioverter defibrillator, to avoid potential interference with the medical device. Persons who have such devices should:

- Always keep the wireless device more than 15.3 centimeters (6 inches) from the medical device when the wireless device is turned on.
- Not carry the wireless device in a breast pocket.
- Hold the wireless device to the ear opposite the medical device to minimize the potential for interference.
- Turn the wireless device off immediately if there is any reason to suspect that interference is taking place.
- Read and follow the directions from the manufacturer of their implanted medical device.

If you have any questions about using your wireless device with an implanted medical device, consult your health care provider.

## ■ Vehicles

RF signals may affect improperly installed or inadequately shielded electronic systems in motor vehicles such as electronic fuel injection systems, electronic antiskid (antilock) braking systems, electronic speed control systems, and air bag systems. For more information, check with the manufacturer, or its representative, of your vehicle or any equipment that has been added.

Only qualified personnel should service the device or install the device in a vehicle. Faulty installation or service may be dangerous and may invalidate any warranty that may apply to the device. Check regularly that all wireless device equipment in your vehicle is mounted and operating properly. Do not store or carry flammable liquids, gases, or explosive materials in the same compartment as the device, its parts, or enhancements. For vehicles equipped with an air bag, remember that air bags inflate with great force. Do not place objects, including installed or portable wireless equipment in the area over the air bag or in the air bag deployment area. If in-vehicle wireless equipment is improperly installed and the air bag inflates, serious injury could result.

Using your device while flying in aircraft is prohibited. Switch off your device before boarding an aircraft. The use of wireless teledevices in an aircraft may be dangerous to the operation of the aircraft, disrupt the wireless telephone network, and may be illegal.

## ■ Potentially explosive environments

Switch off your device when in any area with a potentially explosive atmosphere, and obey all signs and instructions. Potentially explosive atmospheres include areas where you would normally be advised to turn off your vehicle engine. Sparks in such areas could cause an explosion or fire resulting in bodily injury or even death. Switch off the device at refueling points such as near gas pumps at service stations. Observe restrictions on the use of radio equipment in fuel depots, storage, and distribution areas; chemical plants; or where blasting

operations are in progress. Areas with a potentially explosive atmosphere are often, but not always, clearly marked. They include below deck on boats, chemical transfer or storage facilities and areas where the air contains chemicals or particles such as grain, dust, or metal powders. You should check with the manufacturers of vehicles using liquefied petroleum gas (such as propane or butane) to determine if this device can be safely used in their vicinity.

## ■ Emergency calls



**Important:** This device operates using radio signals, wireless networks, landline networks, and user-programmed functions. If your device supports voice calls over the internet (internet calls), activate both the internet calls and the cellular phone. The device will attempt to make emergency calls over both the cellular networks and through your internet call provider if both are activated. Connections in all conditions cannot be guaranteed. You should never rely solely on any wireless device for essential communications like medical emergencies.

### To make an emergency call:

1. If the device is not on, switch it on. Check for adequate signal strength. Depending on your device, you may also need to complete the following:
  - Insert a SmartChip (SIM) card if your device uses one.
  - Remove certain call restrictions you have activated in your device.
  - Change your profile from offline or flight profile mode to an active profile.
2. Press the end key as many times as needed to clear the display and ready the device for calls.
3. Enter the official emergency number for your present location. Emergency numbers vary by location.
4. Press the call key.

When making an emergency call, give all the necessary information as accurately as possible. Your wireless device may be the only means of communication at the scene of an accident. Do not end the call until given permission to do so.

## ■ Hearing aids

Some digital wireless devices may interfere with some hearing aids. If interference occurs, consult your service provider.

## ■ Certification information (SAR)

This mobile device meets guidelines for exposure to radio waves.

Your mobile device is a radio transmitter and receiver. It is designed not to exceed the limits for exposure to radio waves recommended by international guidelines. These guidelines were developed by the independent scientific organization ICNIRP and include safety margins designed to assure the protection of all persons, regardless of age and health.

The exposure guidelines for mobile devices employ a unit of measurement known as the Specific Absorption Rate or SAR. The SAR limit stated in the ICNIRP guidelines is 2.0 watts/kilogram (W/kg) averaged over 10 grams of tissue. Tests for SAR are conducted using



standard operating positions with the device transmitting at its highest certified power level in all tested frequency bands. The actual SAR level of an operating device can be below the maximum value because the device is designed to use only the power required to reach the network. That amount changes depending on a number of factors such as how close you are to a network base station. The highest SAR value under the ICNIRP guidelines for use of the device at the ear is 1.53 W/kg.

Use of device accessories and enhancements may result in different SAR values. SAR values may vary depending on national reporting and testing requirements and the network band. Additional SAR information may be provided under product information at [www.nokiausa.com](http://www.nokiausa.com).

Your mobile device is also designed to meet the requirements for exposure to radio waves established by the Federal Communications Commission (USA). These requirements set a SAR limit of 1.6 W/kg averaged over one gram of tissue. The highest SAR value reported under this standard during product certification for use at the ear is 1.41 W/kg and when properly worn on the body is 0.72 W/kg.

# FCC Draft

# Index

---

## A

- access codes
  - lock code 11
  - module PIN 12
  - PIN 11
  - PIN2 12
  - PUK 12
  - PUK2 12
  - restriction password 12
  - signing PIN 12
  - UPIN 11
  - UPUK 12
- active standby 14
- Address Book. See contacts.
- antenna 16
- assigning a number 41
- AT&T Music 29
- audio clips 34

## B

- battery
  - charging 10
- Bluetooth
  - connection settings 45
  - receiving data 46
  - sending data 46
- browser 27

## C

- cache memory 27
- calculator 39
- calendar 39
- calls
  - answering 18
  - conference call 18
  - ending 17, 19
  - forwarding 43
  - international 17
  - making 17
  - options during a call 19
  - rejecting 18
  - rejecting with text message 18
  - speed dial 41
  - swapping 19
  - voice dial 18
  - voice mailbox 41
  - waiting 19

- Cellular Video 19
- certificates 28
- contacts 34
  - memory consumption 34
- converter 39
- cookies 27

## D

- data cable 47
- data connection indicators 14
- digital rights management 12

## E

- e-mail messages
  - deleting 22
  - retrieving 22

## F

- Flash Player 39

## G

- games 35

## H

- help 8, 40

## I

- indicators 14
- instant messaging 24
- internet 25

## K

- keyguard. See keypad lock.
- keypad lock 16

## L

- listening to music 29

## M

- MEdia Mall 29
- MEdia Net 25
- media player. See RealPlayer.
- menu 15
- message reader 25

FCC Draft

- messages
  - outbox 23
  - service commands 23
  - service messages 22
  - SmartChip messages 23
- music player
  - downloading music 31
  - playlists 30
  - shop music 31
  - transferring music 31
- music. See music player.
- My Stuff 32
  - transferring videos 33

## N

- notes 36

## P

- paired devices 45
- presentations 34
- profiles 41

## Q

- Quickoffice 40

## R

- RealPlayer recorder 40
- ringing tones
  - add to contacts 35
  - add to groups 35

## S

- security
  - module 28
  - protected content 28
- services 25
- settings
  - connection 43
  - data call 43
  - messaging 23
- settings wizard 24
- songs

- transferring 31
- speech 50
- speed dial 41
- speed dialing 41
- standby mode 14
- streaming links 34
- svg files 34

## T

- themes 44
- transferring music 31
- transferring videos 33

## U

- updating software 48
- USB data cable 47

## V

- Video Share 19
- videos
  - transferring 33
- voice commands 44
- voice dialing 18
- voice recorder. See recorder
- volume 6

## W

- web
  - connection security 26
- wireless LAN 49
- wireless markup language 25
- WLAN 49
- write and send messages 20
- writing text. See text input.

## X

- XHTML 25

## Y

- Yellow Pages 25

FCC Draft

# FCC Draft