

Nokia N900 User Guide

D
R
A
F
T

Issue 1

2 Contents

Contents

Safety

About your device

6

Network services

7

Shared memory

7

Find help

Read the user guide

8

Support

8

Settings

8

Access codes

8

Prolong battery life

9

View information about your device

9

Visit maemo.nokia.com

10

Get started

Set up your device

10

Keys and parts

13

First start-up

15

Kickstand

16

Stylus

17

Use accessories

17

Introduction

Key features

18

About Maemo software

19

About your device

19

About the desktop

20

Application menu

21

Status area and status menu

22

Dashboard

24

About the touch screen

24

Text input

26

Protect your device

29

Explore Ovi

30

Personalise your device

30

Edit and personalise the desktop

30

Profile settings

31

Change the background image

32

Change the device language

32

Change themes

32

Connect your device

32

About connectivity

32

Network settings

32

Use a WLAN connection

33

Use a packet data connection

37

Active data connections

38

Disable wireless connections

38

Internet connection settings

38

Bluetooth connectivity

39

USB connections

41

Browse the web	41	Options during a call	57
About browser	41	Call timers	57
Open and browse web pages	41	Emergency calls	57
Browser toolbar	43		
Organise bookmarks	43		
Clear private data	44	Send text and instant messages	58
Connection security	44	About Conversations	58
Download files	45	Send text messages	59
Save web pages	45	Send instant messages	60
View browsing history	46	Delete messages and conversations	62
Install a plug-in or an add-on	46	Filter conversations	62
Browser settings	46	Text message and instant message settings	62
Organise your contacts	48		
Get contacts	48	Mail	63
View your contacts' availability statuses	50	About mail	63
Sort contacts	50	Read your work mail using Mail for Exchange	63
Send contact cards	51	Set up your mail	63
Add shortcuts to desktop	51	Read and send mail	66
Contacts settings	51	Organise your mail	69
Make calls	52	Synchronise with Mail for Exchange	69
About calls	52	Add the mail widget to desktop	70
Change display orientation	52	Mail settings	70
Touch screen during calls	53		
Make voice calls	53	Capture images and record video clips	74
Make internet calls	55	Camera	74
Make internet video calls	56	Capture images	74
		Record video clips	76
		Camera settings	77
		View images with Photos	79

4 **Contents**

Share your images and video clips	82	Use utilities	104
Play music and video clips	84	Update software and install applications	107
About Media player	84	About Application manager	107
File formats	85	Install additional applications	107
Add the media widget to desktop	85	Add catalogues	108
Search for media files	85	Check for updates	109
View MAFW plug-ins	85	Update software	109
Play music with Media player	85		
Use the FM transmitter	87	Play games	111
Play video clips with Media player	88	Blocks	111
Listen to internet radio with Media player	89	Chess	111
Play music from media server	90	Mahjong	112
Find and view locations	91	Marbles	113
Positioning (GPS)	91	Install other games	113
Ovi Maps for mobile	92		
Manage time	96	Settings	113
View the time and set alarms	96	Personalisation settings	113
View and manage your calendar	97	Connectivity settings	116
Use utilities and manage data	99	General settings	119
Synchronise and transfer content from another device	99	Third party application settings	119
Back up and restore data	101		
Manage files	101	Tips and troubleshooting	120
Memory	102	Basic tips for using your device	120
Clear device data and restore settings	103	Advanced tips for using your device	120
		Shortcuts	121
		Troubleshooting	123

Product and safety information	125
Index	132

D
R
A
F
T

6 Safety

Safety

Read these simple guidelines. Not following them may be dangerous or illegal. Read the complete user guide for further information.

SWITCH ON SAFELY



Do not switch the device on when wireless phone use is prohibited or when it may cause interference or danger.

ROAD SAFETY COMES FIRST



Obey all local laws. Always keep your hands free to operate the vehicle while driving. Your first consideration while driving should be road safety.

INTERFERENCE



All wireless devices may be susceptible to interference, which could affect performance.

SWITCH OFF IN RESTRICTED AREAS



Follow any restrictions. Switch the device off in aircraft, near medical equipment, fuel, chemicals, or blasting areas.

QUALIFIED SERVICE



Only qualified personnel may install or repair this product.

ACCESSORIES AND BATTERIES



Use only approved accessories and batteries. Do not connect incompatible products.

WATER-RESISTANCE



Your device is not water-resistant. Keep it dry.

About your device

The wireless device described in this guide is approved for use on the (E)GSM 850, 900, 1800, 1900, and UMTS 900, 1700, 2100 networks. Contact your service provider for more information about networks.

Your device may have preinstalled bookmarks and links for third-party internet sites and may allow you to access third-party sites. These are not affiliated with Nokia, and Nokia does not endorse or assume liability for them. If you access such sites, take precautions for security or content.

Warning:

To use any features in this device, other than the alarm clock, the device must be switched on. Do not switch the device on when wireless device use may cause interference or danger.

When using this device, obey all laws and respect local customs, privacy and legitimate rights of others, including copyrights. Copyright protection may prevent some images, music, and other content from being copied, modified, or transferred.

Make back-up copies or keep a written record of all important information stored in your device.

When connecting to any other device, read its user guide for detailed safety instructions. Do not connect incompatible products.

The images in this guide may differ from your device display.

Refer to the user guide for other important information about your device.

Network services

To use the device you must have service from a wireless service provider. Some features are not available on all networks; other features may require that you make specific arrangements with your service provider to use them.

Network services involve transmission of data. Check with your service provider for details about fees in your home

network and when roaming on other networks. Your service provider can explain what charges will apply. Some networks may have limitations that affect how you can use some features of this device requiring network support such as support for specific technologies like WAP 2.0 protocols (HTTP and SSL) that run on TCP/IP protocols and language-dependent characters.

Your service provider may have requested that certain features be disabled or not activated in your device. If so, these features will not appear on your device menu. Your device may also have customized items such as menu names, menu order, and icons.

Shared memory

The following features in this device may share memory: bookmarks; image, audio, and video files; notes, sketch, and other files; contacts; e-mail messages; and applications. Use of one or more of these features may reduce the memory available for the remaining features. If your device displays a message that the memory is full, delete some of the information stored in the shared memory.

8 Find help

Find help

Read the user guide

>To find more support, read the complete user guide.

Read the online user guide

Select  > User Guide.

Read the in-device user guide

- 1 Select  > File manager and Documents > User guides.
- 2 Select the index file of your preferred language.

The in-device user guide is stored in the internal mass memory of your device. When you install system software updates, the information in the user guide may not be up to date.

Tip: You can add a shortcut to the user guide to the desktop, to make it easier to access the guide later. To do this, open the user guide, and from the toolbar, select  > Add shortcut to desktop.

Support

When you want to learn more about how to use your product or you are unsure how your device should function, go to www.nokia.com/support, or using a mobile device, www.nokia.mobi/support, or, in your device, select  > User Guide.

If this does not resolve your issue, do one of the following:

- Restart the device: switch off the device, and remove the battery. After about a minute, replace the battery, and switch on the device.
- Restore the original factory settings.
- Update your device software.

If your issue remains unsolved, contact Nokia for repair options. Go to www.nokia.com/repair, or in Latin America, www.nokia-latinoamerica.com/centrosdeservicio. Before sending your device for repair, always back up the data in your device.

Settings

Your device normally has GPRS, streaming, and mobile internet settings automatically configured, based on your network service provider. You may have settings from your network service provider already installed in your device.

To change the general settings in your device, such as language, desktop, display, and keypad lock settings, go to  > Settings.

Access codes

If you forget any of the access codes, contact your service provider.

Personal identification number (PIN) code — This code protects your SIM card against unauthorised use. The PIN

code (4-8 digits) is usually supplied with the SIM card. After three consecutive incorrect PIN code entries, the code is blocked, and you need the PUK code to unblock it.

Personal Unblocking Key (PUK) code — This code (8 digits) is required to change a blocked PIN code. If the code is not supplied with the SIM card, contact your service provider.

Lock code — The lock code helps you to protect your device against unauthorised use. The preset code is 12345. You can create and change the code, and set the device to request the code. Keep the new code secret and in a safe place separate from your device. If you forget the lock code and your device is locked, you must take the device to a Nokia authorised service facility and additional charges may apply. To unlock the device, the software must be reloaded, and all data you have saved in the device, may be lost.

Prolong battery life

Many features in your device increase the demand on battery power and reduce the battery lifetime. To save battery power, note the following:

- Deactivate Bluetooth technology when you do not need it. Applications that use Bluetooth technology should be closed when not needed.
- Features that use wireless LAN (WLAN), or allowing such features to run in the background while using other features, increase the demand on battery power. WLAN on your device scans available networks as often as specified in WLAN settings and connects automatically to

the networks that have been used before. To further reduce battery consumption, you can specify that your device does not scan, or scans less often, for available networks in the background.

- The backlight of the display increases the demand on battery power. In the display settings, you can adjust the display brightness and change the length of the time-out period, after which the backlight switches off. You can also activate the power saving mode to set the device to consume less power when the display backlight is on. To modify display settings, select  > **Settings and Display**.
- Leaving applications running in the background increases the demand on battery power.

View information about your device

Select  > **Settings and About product**.

The available information includes:

- Device model
- Platform name and release
- Software version
- WLAN MAC address
- Bluetooth address
- IMEI address
- Applicable licences
- Other important information about your device

10 Get started

Visit maemo.nokia.com

You can find the latest tools, background images, and applications to personalise your device, and view the Maemo experience at maemo.nokia.com. To access this web site, select the Maemo shortcut on the desktop or the Maemo bookmark in the web browser.

Get started

Set up your device

Insert the SIM card and battery

Section metadata

Keywords: [insert the SIM card](#), [insert the battery](#)


Always switch the device off and disconnect the charger before removing the battery.

Important: To prevent damage to the SIM card, always remove the battery before you insert or remove the card.

- 1 To prevent the battery from coming loose, place the device so that the back cover is facing up.
- 2 Place your finger in the grip, and lift the back cover up. You do not need to press a button to release the back cover.




- 3 To release the SIM card holder, slide the holder to the left (1), and lift the right end of the holder up (2). Make sure that the bevelled corner on the card is facing up, and that the contact area on the card is facing the connectors on the device (3). Close the holder (4), and slide it to the right to lock it into place (5).



- 4 Align the contacts of the battery with the corresponding connectors on the battery compartment, and insert the battery in the direction of the arrow.



- 5 To replace the back cover, direct the locking catch toward its slot, and press down until the cover locks into place.



Insert the memory card

Section metadata

Keywords: insert the memory card



Use only compatible MicroSD cards approved by Nokia for use with this device. Nokia uses approved industry standards for memory cards, but some brands may not be fully compatible with this device. Incompatible cards may damage the card and the device and corrupt data stored on the card.

The memory card can be safely inserted or removed even when the device is switched on. When you open the back cover, the device cannot access the memory card, to protect the data on the card. When you replace the back cover, the memory card is accessible again.


A memory card may be already inserted in the device. If not, do the following:

- 1 To prevent the battery from coming loose, place the device so that the back cover is facing up.
- 2 Place your finger in the grip, and lift the back cover up. You do not need to press any button to release the back cover.


12 Get started



3 To release the memory card holder, slide the holder towards the battery (1), and lift up the end of the holder (2). Insert a compatible memory card into the holder (3). Make sure the contact area on the card is facing the connectors on the device. Close the holder (4), and slide it back to lock it into place (5).



4 Replace the back cover. Keep the device facing down when replacing the cover. Make sure the cover is properly closed.




Charge the battery

Section metadata

Keywords: battery, charging

Your battery has been partially charged at the factory. If the device indicates a low charge, do the following:

Charge the battery using the charger



- 1 Connect the charger to a wall outlet.
- 2 Connect the charger to the micro USB connector of the device.
- 3 When the device indicates a full charge, disconnect the charger from the device, then from the wall outlet.

The notification light blinks when the device is charging. The notification light stays lit when the battery is fully charged.

You do not need to charge the battery for a specific length of time, and you can use the device while it is charging. If the battery is completely discharged, it may take several minutes before the notification light starts blinking or before any calls can be made.

Charge the battery using the USB cable

You can charge your device using a compatible USB device, for example a computer, when a wall outlet is not available. You can also transfer data while charging the device.

- 1 Connect a compatible USB cable between a compatible USB device and your device.

Depending on the type of device that is used for charging, it may take a while for charging to start.

- 2 If your device is switched on, USB mode options are displayed. Select **Mass storage mode** or **PC Suite mode** to make sure that your device receives enough power from USB charging.

The notification light blinks when the device is charging. The notification light stays lit when the battery is fully charged.

If the battery is completely discharged, allow some time for charging before using your device.

If your device is on and you have many applications running, the device can consume more power than it receives from USB charging. Close some of the applications and data connections, or use the charger that came with the device.


Keys and parts

Keys and parts (front)

Section metadata

Keywords: keys, parts

14 Get started



- 1 Power key
- 2 Light sensor
- 3 Secondary camera lens
- 4 Proximity sensor
- 5 Earpiece
- 6 Notification light
- 7 Touch screen
- 8 Physical keyboard


To ensure proper functionality of the touch screen, remove the protective film from the device display.

Do not cover the area left of the touch screen with, for example, protective film or tape.



Keys and parts (back) Section metadata

Keywords: keys, parts




- 1 Lens cover
- 2 Camera flash
- 3 Camera lens
- 4 Kickstand

Keys and parts (top)


Section metadata

Keywords: keys, parts



- 1 Zoom/Volume key
- 2 Power key
- 3 Capture key
- 4 Infrared port

None of the pre-installed applications of your device use the infrared port, but it enables the development of third party applications requiring an infrared port. The infrared port is not IrDA compatible.



- 1 Stereo speaker
- 2 Micro USB connector
- 3 Wrist strap eyelet
- 4 Stereo speaker
- 5 Lock switch
- 6 Nokia AV Connector (3.5 mm)
- 7 Microphone
- 8 Stylus

Keys and parts (sides)

Section metadata

Keywords: keys, parts, connectors

First start-up
Switch the device on
Section metadata

Keywords: switch the device on, switch the device off

- 1 Press the power key.

16 Get started



- 2 If the device asks for a PIN code or lock code, enter it, and select **Done**. The preset lock code is 12345. If you forget the code and your device is locked, your device requires service. Additional charges may apply, and all your personal data may be deleted. For more information, contact a Nokia Care point or your device dealer.

Switch the device off

Press the power key, and select **Switch off!**.

Tip: You can also switch the device off by pressing and holding the power key.

Start-up wizard

- 1 Switch the device on. A welcome note is briefly displayed, and the start-up wizard opens.

- 2 The language, region, time and date settings are displayed. Define the following:

Language — Slide your finger up or down to scroll through the list, and select the language.

Region — Slide your finger up or down to scroll through the list, and select the region.

Time — Define the time format by moving the slider to **24 hrs** or **12 hrs**, and move the hands of the clock to the correct time with your finger. If you are using the 12-hour clock, move the slider to **AM** or **PM**.

Date — Set the current date. To do this, slide your finger up or down on the day, month, and year columns.

- 3 To accept and save the settings, select **Save**.

Kickstand


Section metadata

Keywords:

kickstand

The kickstand is on the back of the device, and when placed on a flat surface, can be used when you watch, for example, video clips.

Open the kickstand



Stylus

Section metadata

Keywords: Stylus

Some activities, such as sketching, may be easier to do with a stylus than with your finger.



Important: Use only a stylus approved by Nokia for use with this device. Using any other stylus may invalidate any

warranty applying to the device and may damage the touch screen. Avoid scratching the touch screen. Never use an actual pen or pencil or other sharp objects to write on the touch screen.

Use accessories

Headset

Section metadata

Keywords: headset

You can connect a compatible headset or compatible headphones to your device. Nokia headsets with music controls can also be used, but the device does not support the music controls.



Warning:

When you use the headset, your ability to hear outside sounds may be affected. Do not use the headset where it can endanger your safety.

18 Introduction

Do not connect products that create an output signal as this may cause damage to the device. Do not connect any voltage source to the Nokia AV Connector.

When connecting any external device or any headset, other than those approved by Nokia for use with this device, to the Nokia AV Connector, pay special attention to volume levels.

Wrist strap

Section metadata

Keywords:

wrist strap

- 1 Remove the back cover.
- 2 Hook a strap behind the clamp and close the back cover.



Introduction

Key features

With your new Nokia N900, you can keep track of your calls and mail messages, browse the web, and switch instantly between open applications and ongoing conversations. Some of the key features are highlighted here:



View web pages with full-screen browsing.



Use the Media player application to listen to your music, view videos, or tune in to your favourite internet radio stations.



Use the Calendar application to stay up-to-date and plan your meetings.



Manage your friends' details with the Contacts application.



Use the Phone application to make a voice, internet, or internet video call to a friend.



Use the Maps application to find points of interest.



Use the Camera application to capture images and record video clips, then upload directly to the web to share with friends or the online community.



Read and reply to your mail while on the move.



Use the Conversations application to exchange text messages or start instant messaging (IM) conversations with your IM contacts.



Use the Application manager application to check the available updates for applications and download them to your device.



Find popular applications, themes, and wallpapers from the Ovi Store.

With Maemo software, it is possible to develop your own applications for your device. To do this, you can use the Maemo Software Development Kit (Maemo SDK). For more information on what Maemo software is and how to develop applications, see maemo.nokia.com.

About your device

Antenna locations

Section metadata

Keywords: antenna

Your device may have internal and external antennas. Avoid touching the antenna area unnecessarily while the antenna is transmitting or receiving. Contact with antennas affects the communication quality and may cause a higher power level during operation and may reduce the battery life.



Cellular antenna

About Maemo software

This device uses Maemo 5 software on Linux. The software is built for computer-like performance, enabling the running of multiple applications at the same time, and delivering a wide range of activities ranging from web browsing to video recording. Your device supports Maemo Update, which allows updating the operating system and applications over a WLAN or packet data connection.



Bluetooth and WLAN antenna



GPS antenna

Control volume

Adjust the volume

Use the volume keys.

Tip: You can view the current volume setting, and also adjust the volume, from the status menu. Tap the status area to open the menu. Use the volume slider  to adjust the volume.

Mute sounds

Drag the volume slider in the status menu all the way to the left.

Adjust call and message tone volumes

Select  > Settings and Profiles.

Notification light

The notification light can indicate the status of your device. For example, it can inform you about the battery charging status, and tell you if you have missed a phone call or received, for example, a mail or text message.

You can activate or deactivate the notification light for each notification type by modifying the notification light settings.

The colours of the notification light indicate the following:



- Application triggered notification light (received text message, instant message, or mail)
- Secondary camera active (internet video call)
- Battery charging
- Battery full

About the desktop

The desktop is displayed when you switch on the device. It offers quick access to different features of your device. You can have up to four desktops. The desktops can be personalised to have different widgets, bookmarks,

background images, and shortcuts to applications and contacts.

The desktop contains the following:



- 1 Application menu
- 2 Status area
- 3 Your network service provider (if a SIM card is inserted)
- 4 Widgets
- 5 Shortcuts
- 6 Browser bookmarks

Switch between desktops

Swipe left or right.



Search for contacts

Start entering a name, using the physical keyboard.

Open the virtual keypad to make a call

On the desktop, using the physical keyboard, start entering a phone number. To enter the first number, press and then the desired number. After entering the first number, you can use either the physical keyboard or the virtual keypad to enter more numbers.

Application menu

The application menu displays the available applications.

Select



Open an application

Select the application you want to open.

Close an application

Select . All unsaved changes and selections are cancelled.

Status area and status menu

Status area



The status area informs of the current status of items that are relevant across the device. The current time, and battery and signal strength are displayed. In addition, the status area may indicate your internet connection status, available updates, or your active profile.

Status area indicators

General indicators

	A clock alarm is active.
	The state of device battery, and possible charging status.
	The device is connected to a compatible USB device for charging, but the device is not receiving enough power.
	The current signal strength.
	Software updates or additional applications are available.
	The Silent profile is active.

Connectivity indicators

	The current network.
	Synchronisation is in progress.
	A USB connection is active.
	A packet data connection is active (network service).
	A wireless LAN connection is active.

	An ad-hoc wireless LAN connection is active.
	Bluetooth connectivity is active.
	A Bluetooth connection with one or more Bluetooth devices is active.
	SIM card not available (card not inserted or PIN code not entered).
	The Offline mode is active.

GPS indicators

	The GPS function is active.
	The GPS function is inactive.

Content sharing indicators

	Sharing is ongoing.
	Sharing is pending and needs your attention.
	Sharing is blocked.

Call indicator

	A phone call is active.
---	-------------------------

Availability status indicators

	Online
	Busy

If the availability status is offline, no indicator is shown in the status area.

Sound indicators


	Your device is connected to wired or Bluetooth headphones.
	Your device is connected to a wired or Bluetooth headset.
	The FM transmitter is activated.

If a third party application adds an icon to the status area, it is placed after the default icons.

Open the status menu

Tap the status area.

The status menu displays, for example, the remaining battery life, device volume, and Bluetooth connection status. To change the displayed status, select the respective status menu item.



Dashboard

The applications that are currently running can be seen on the dashboard. The dashboard also displays the notifications that you have received but have not opened yet, for example, text and mail messages, as well as missed calls.



Open the dashboard

When you open an application, the  icon changes to the dashboard icon . Select  to open the dashboard. The

application remains open, and you can return to the application by selecting it.

Tip: You can now open another application by selecting . The previously opened application is left running in the background.

Switch between applications

When several applications are open, select  and the application you want to switch to.

Respond to a notification

- 1 When you receive, for example, a new mail, instant message, or text message, a notification is briefly displayed. You can view the message by selecting the notification. If you do not select the notification while it is displayed, the notification remains on the dashboard. To indicate this, the  icon blinks and then stays lit.
- 2 To view the notification on the dashboard, select .

About the touch screen

Touch screen actions

Section metadata

Keywords:

Tap

To select or open an application or other element on the touch screen, tap it once with your finger.

Select


In this user documentation, opening applications or items by tapping them once is called 'selecting'. If you need to select several items in a sequence, the display texts to select are separated by arrows, for example  > Phone.

Select and hold

In many applications, you can open a context-sensitive pop-up menu by selecting and holding. To do this, place your finger on the item, until the pop-up menu opens.

Drag

Dragging can be used, for example, to scroll up or down a list. To drag, place your finger on the screen, and slide it across the screen.

**Swipe**

Swiping can be used, for example, to switch between images in the Photos application. To swipe, slide your finger quickly left or right on the screen.

**Touch screen backlight****Turn the touch screen backlight on**

The touch screen backlight is turned off after a period of inactivity. To turn the backlight on, tap the screen. If the screen and keys are locked, use the lock switch to unlock them.

Touch screen actions in applications**Open the application menu**

Tap the title bar of the currently open application.

26 Introduction



Close a dialog

Tap outside the dialog. All changes and selections are cancelled.

Text input


Use the physical keyboard

To use the physical keyboard, slide the touch screen up. When you use the physical keyboard, the virtual keyboard is disabled.

D
R
A



In addition to the character keys, the physical keyboard contains the following keys:



1 Sym/Ctrl key
2 key
3 Shift key

T

- 4 Space key
- 5 Enter key
- 6 Backspace key

Enter text

Press the keys on the keyboard.

Switch between character cases

Press the shift key. To enter only upper or lower case letters, press the shift key twice. To return to normal mode, press the shift key again.

Enter a number, additional character, or common symbol

Press and hold , and then press the key that has the character printed at the top of it. To enter only the characters printed at the top of keys, press  twice to lock the mode. To return to normal mode, press  again.

Enter a character not found from the keyboard

Press and hold , and then press the sym key.

Use word completion

You can also use the word completion feature. The word candidates are displayed in the text input area. To select a word candidate, press the right arrow key.

Add an accent to a character

- 1 To enter, for example, â, press and hold , and then press the sym key.
- 2 Tap the accent (^) on the touch screen.
- 3 Press the letter to which you want the accent to be added. To only add the accent, tap the accent twice.

Use the virtual keyboard

To use the virtual keyboard, make sure the physical keyboard is closed, and select a text entry field, the web address field of the browser, for example. The virtual keyboard needs to be activated before you can use it.

Activate the virtual keyboard

Select  > Settings and Text input.

Select the **Use virtual keyboard** check box.

Switch between upper or lower case characters

Select .

Add an accent to a letter

Select , then , and then the accent (for example, ^) from the list. Then select  and the letter to which you want the accent to be added. To only enter the accent, tap the accent twice.

Cut, copy, or paste text

Select  and the desired option.

Insert a line break

Select .

Delete a character

Select .

Switch between input languages

Select  and the language. You must have the languages defined in the text input settings.

Close the virtual keyboard

Select .

Switch between input methods

To switch between the virtual keyboard and the physical keyboard, slide the touch screen up or down.

Switch virtual keyboard layout

The virtual keyboard can provide character sets for two different input languages at the same time, for example, the Russian and Latin character sets. To define the input languages, modify the text input settings.

Switch between input languages

Press and hold the ctrl key, and then press the space key.

Text input settings

Select  > Settings and Text input.

Select from the following:

Hardware keyboard layout — Define the character set used in the physical keyboard. Changing this setting may lead to the physical keys not matching the hardware keyboard layout.

Use virtual keyboard — Activate the virtual keyboard.

Word completion — Enable word completion.

Auto-capitalisation — Enable auto-capitalisation, to capitalise the first letter of sentences automatically when entering text.

Insert space after word — Insert a space after each accepted word completion.

1st language — Select the first language. To select a dictionary to use for the first language, select **Dictionary** and the dictionary language.

2nd language — Select the second language. To select a dictionary to use for the second language, select **Dictionary** and the dictionary language. When you switch to the secondary language, the current dictionary for the word completion feature is also changed.

Use dual dictionaries — Use both language dictionaries at the same time.

Word completion and dictionaries

If word completion is activated, the device suggests suitable endings for the words that you start writing. Word completion is based on a built-in dictionary. When you enter characters, the device searches its dictionary for words starting with these characters.

You can select to use dual dictionaries to allow the device to search from the dictionary of the second language if it cannot find a suitable word in the first language dictionary.

The dictionary can learn new words automatically from the text you have entered. Text entered in password fields is not saved in the dictionary.

Activate word completion and use dual dictionaries

Select  > Settings and Text input.

Accept a suggested word

Select the suggested word. When using the physical keyboard, press the right arrow key.

Reject a suggested word

Continue writing the word. With each character, the device updates its suggestion to suit the characters you have entered.

Protect your device

Lock your device

To prevent unauthorised use of your device, change the lock code, and set the device to automatically lock after a certain length of time.

Briefly press the power key, and select **Secure device**.

Unlock your device

Enter the lock code, and select **Done**.

Set the length of the time-out period

Select  > Settings and Device lock > Autolock, and select the length of time.

Change the lock code

- 1 Select  > Settings and Device lock > Change lock code.
- 2 Enter the current code once, and the new code twice. The default lock code is 12345.

If you tap outside the dialog at any time, the device lock code is not changed.

Keep the new lock code secret and in a safe place, separate from your device.

30 Personalise your device

If you forget the lock code and your device is locked, you must take the device to a Nokia authorised service facility and additional charges may apply. To unlock the device, the software must be reloaded, and all data you have saved in the device, may be lost.

Lock touch screen and keys

Locking the touch screen and keys prevents accidental keypresses.

To lock or unlock the touch screen and keys, slide the lock switch.

Explore Ovi

Visit Ovi

Section metadata

Keywords: Ovi

 Ovi contains services provided by Nokia. With Ovi, you can create a mail account, share your images and video clips with friends and family, plan trips and view locations on a map, download games, applications, video clips, and tones to your device, and purchase music. The available services may vary by region, and not all languages are supported.

To access Ovi services, go to www.ovi.com, and register your own Nokia account.

For more information on how to use the services, see the support pages of each service.

About Ovi Store

Section metadata

Keywords: Ovi Store

 In Ovi Store, you can download mobile games, applications, videos, images, themes, and ringing tones to your device. Some items are free of charge; others you need to pay for with your credit card or in your phone bill. The availability of payment methods depends on your country of residence and your network service provider. Ovi Store offers content that is compatible with your mobile device and relevant to your tastes and location.

Personalise your device

Edit and personalise the desktop

Open the desktop menu

Tap the desktop, and select  > Desktop menu.

Personalise the desktop

Select from the following:

Add shortcut — Add an application shortcut to the desktop.

Add contact — Add a contact to the desktop.

Add bookmark — Add a web bookmark to the desktop.

Add widget — Add a widget, such as Agenda or Location, to the desktop.

Change background — Change the background image.

There are preinstalled background images in the device, but you can use any image stored in the device, on an inserted memory card, or in a paired or shared device.

Manage views — Set which desktops are in use.

Themes — Select a theme for your desktop.

Rearrange items on the desktop


Drag widgets, bookmarks, contacts, or shortcuts.

Move an item from one desktop to another

Drag the item to the left or right until you reach the desired desktop.

Remove items from the desktop

Select  on the widget, bookmark, contact, or shortcut.



Profile settings

Select  > Settings and Profiles.

Set the device to vibrate when in the Silent or General profile

Select Vibrate.

Select the ringing tone and message alert tones

Select Ringing tone, SMS alert, IM tone, or E-mail alert and the desired tone.

Add a new ringing tone or message alert tone

Select the tone type, More, the desired tone, and Done.

Select the volume level of tones

Select System sounds, Key sounds, or Touch screen sounds and the desired volume level.

32 Connect your device

Adjust the volume of tones

Drag the slider right or left.

Change the background image

You can select a different background image for each desktop of your device.

- 1 Swipe left or right to select the desired desktop.
- 2 Tap the desktop, and select  > Desktop menu > Change background.
- 3 Select More.
- 4 Browse to the image, and select Done.

The background image of the current desktop is changed. To change the background image of another desktop, go to the desired desktop.

Change the device language

- 1 Select  > Settings and Language & region.
- 2 Select Device language and the desired language.
- 3 Restart the device.

Change themes

A theme is a set of matching background images, one for each desktop.

- 1 Select  > Settings and Themes.
- 2 Select a theme from the list.

Connect your device

About connectivity

Your device offers several options to connect to the internet or to another compatible device, PC, or Mac. The available connection methods are wireless LAN (WLAN) connection and a packet data connection. Using a WLAN connection, you can connect to the internet without a SIM card inserted.

You can enable automatic transfers between WLAN and packet data connections, to keep your device constantly online. You can also set your device to ask which connection to use. When you connect to the internet for the first time using a packet data connection, the device prompts you to select whether you want to allow automatic transfer without further confirmation.

You can also connect to a PC or other compatible device using Bluetooth wireless technology, or by using a USB data cable.

Network settings

Your device can automatically switch between GSM and 3G networks.

In the status area, the current network is indicated with the following icons:

2G	GSM
2.5G	EDGE
3G	3G

3.5G HSPA

To modify network settings, select  > **Settings** and **Phone** > **Network**.

Select the service provider's network

By default, your device selects the network automatically. To select the network manually, select **Manual** and a network.

Select network mode

Select which network to use. If you select **Dual**, the device uses the GSM or 3G network automatically, according to the network availability, parameters, and the roaming agreements between network service providers. For further information, contact your network service provider.

You cannot change the network mode, if a packet data connection is active. Disconnect the packet data connection or switch to a wireless LAN (WLAN) connection before changing the network mode.

Roaming is based on specific roaming agreements between your network service provider and other network service providers, to enable you to use network services outside your home network, for example when travelling abroad.

Define data roaming settings

Always ask is selected by default. A connection is only attempted when a confirmation note is accepted. If you select

Always allow, all packet data connections abroad are handled as in the home network.

For further information and roaming costs, contact your network service provider.

View transferred data details

Select **Home network data counter**. To clear the details and reset the counter, select **Clear**.

Use a WLAN connection

You can use a wireless LAN (WLAN) data connection to connect to the internet. Only one connection to one wireless LAN can be active at a time, but several applications can use the same internet access point.

About WLAN

To use a wireless LAN (WLAN) connection, it must be available in the location, and your device must be connected to the WLAN. Some WLANs are protected, and you need an access key from the service provider to connect to them.

There might be some restrictions for WLAN use in some countries. Check with your local authorities for more information.

Features that use WLAN, or that are allowed to run in the background while using other features, increase the demand on battery power and reduce the battery life.

34 Connect your device

Your device supports the following WLAN features:

- IEEE 802.11b/g standard
- Operation at 2.4 GHz
- Wired equivalent privacy (WEP) with keys up to 128 bits, and Wi-Fi protected access (WPA2-Enterprise) authentication method. These functions can be used only if they are supported by the network.

Important: Always enable one of the available encryption methods to increase the security of your wireless LAN connection. Using encryption reduces the risk of unauthorised access to your data.

Operating modes

There are two operating modes in WLAN: infrastructure and ad hoc.

The infrastructure operating mode allows two kinds of communication: wireless devices are connected to each other through a WLAN access point device, or wireless devices are connected to a wired LAN through a WLAN access point device.

In the ad hoc operating mode, devices can send and receive data directly with each other.

Create a WLAN connection

- 1 Select  > Settings and Internet connections > Connections > New > Next.

2 Enter a descriptive name for the connection, and select **Next**.

3 The device asks if you want to scan for available WLANs. Select **Yes**, and select the WLAN from the Select connection dialog. If a WLAN is hidden, it is indicated as hidden in the dialog. You can select a hidden WLAN as any other WLAN connection, if you know the network name (SSID), and enter it manually.

To enter the values manually, select **No**, and define the following:

Network name (SSID) — Enter the name of the WLAN. If you create an ad hoc network, ensure that the name of the network is unique. When you connect to the internet over a WLAN, the connection is based on this information. If the field is dimmed and cannot be edited, the scanned SSID contains characters that are not in the standard UTF-8 character sets.

Network is hidden — Select whether the name of the WLAN is hidden, that is, the network is configured not to broadcast its name (SSID). If you select this option, your device actively searches for hidden WLANs when you attempt to establish an internet connection.

Network mode — Select **Ad hoc** or **Infrastructure**. The infrastructure mode is used with internet connections.

Security method — Select the same security method that is used by your WLAN access point.

If you operate your own WLAN access point, always enable one of the available encryption methods to increase the security of your wireless network. Using encryption reduces the risk of unauthorised access to your data.

Available WLANs

After the WLAN scan, all available WLANs are displayed with the following information:

- Connection type, indicated with  (general) or  (ad hoc)
- Name
- If the WLAN is already saved in your device,  is displayed
- WLAN signal strength, indicated with 
- Encryption method used, indicated with  (WPA),  (WEP), or  (none)

Security settings

Select  > Settings and Internet connections > Connections.

In the connection setup dialogs, enter the encryption keys, depending on the WLAN connection in question. For stronger security, it is recommended that you use the WPA method, if possible.

WEP authentication

Enter the wireless equivalent privacy (WEP) key. You can define more than one WEP key, and you can also select the default key, if that is required by your WLAN.

WPA authentication

Enter the Wi-Fi protected access (WPA) preshared key. The key length must be between 8 and 63 characters. Only ASCII characters are allowed.

WPA with EAP type

To define the extensible authentication protocol (EAP) type, select from the following:

TLS (transport layer security) authentication — Select the client certificate used for authentication.

PEAP (protected extensible authentication protocol) authentication or **TTLS** (tunneled transport layer security) — Select an authentication method used inside PEAP or TTLS and an optional client certificate.

For MSCHAPv2, define a user name and a password. Select the **Prompt password at every login** check box, if you want your password to be always requested when a connection is created. For GTC, enter your user name. You are prompted for a response upon connection creation. The client certificates are optional. For more information, contact your internet service provider.

36 Connect your device

Define advanced settings

Select  > **Settings and Internet connections** > **Connections**. Select the connection and **Edit**. In the last dialog, select **Advanced**.

WLAN proxy settings

Enable proxies

- 1 Select **Use proxy**.
- 2 Enter the IP address of the proxy server, or the host name. The format of a domain name can be `proxy.company.com`.
- 3 Enter the number of the proxy port.

Bypass proxies

If you have domains for which the use of proxies should be bypassed, select **Do not use proxy for**, and enter the domain names for which the proxy is not needed.

Enable automatic proxies

To obtain the IP addresses automatically from the internet service provider, select the **Automatic configuration** check box, and enter the web address of the server in the **Web address** field.

IP address settings

Open the **IP Addresses** tab.

IP address

- 1 To obtain the IP address for the device automatically from the server, select **Auto-retrieve IP address**.
- 2 If you want to enter the values manually, contact your internet service provider for the correct values and for further information.

DNS address

Domain name service (DNS) is an internet service that translates domain names such as `www.nokia.com` into IP addresses, such as `192.100.124.195`.

- 1 To obtain the DNS address automatically from the server, select **Auto-retrieve DNS**.
- 2 If you want to enter the values manually, enter the IP addresses of the primary and secondary domain name servers, if required by your internet service provider.

Other WLAN settings

Open the **Other** tab, and define the following:

WLAN transmission power — Select how much power the device outputs during a WLAN connection. The default value is 100 mW.

Power saving — Select the power saving level of WLAN connections.

Ad hoc channel — Select a channel for ad hoc WLAN connections.

To only support authentication according to the WPA2 protocol for WLAN connections, select **WPA2-only mode**.

The available options vary according to the selected connection type.

Modify EAP settings

The EAP settings are only visible for WLAN connections that use the EAP authentication protocol.

Enter user name manually

If the user name differs from the user name provided by the certificate, select the **Use manual user name** check box, and enter the user name in the **Manual user name** field.

Require client authentication

If you want the EAP server to require your device to be authenticated, select the **Require client authentication** check box.

Use a packet data connection

About packet data

Your device supports packet data connections (network service), such as GPRS in the GSM network. In 3G networks, data connections remain active during voice calls.

To establish a data connection, an access point is required. To check what access point types are required for particular

services, and for availability and subscription to packet data connection services, contact your network service provider.

Fast downloading and uploading

High-speed packet access (HSPA, also called 3.5G) is a network service in 3G networks that provides high-speed data downloads and uploads. When HSPA support in the device is activated and the device is connected to a 3G network that supports HSPA, downloading and uploading data such as mail and web pages using a packet data connection may be faster.

3.5G in the status area indicates an active HSPA connection.

For availability and subscription to data connection services and the related costs, contact your network service provider.

Packet data settings

Packet data settings are usually set automatically by the device, based on your SIM card. If you need to modify the settings, contact your service provider for details, and do the following:

- 1 Select  > **Settings**.
- 2 Select **Internet connections** > **Connections**.
- 3 Select the internet connection provided by your network service provider, and select **Edit**. Enter the new details.

To enter the password every time you make a connection, select the **Prompt password at every login** check box.

Advanced settings

Advanced packet data settings are modified in the same way as WLAN settings.

Active data connections

In the status area, the active data connections are indicated with the following icons:

-  A packet data connection is active.
- or
-  A wireless LAN (WLAN) connection is active.

Note: The actual invoice for calls and services from your service provider may vary, depending on network features, rounding off for billing, taxes, and so forth.

Close connections

Select the status area and a connection, and close the connection.

Disable wireless connections

Disable connections

Briefly press the power key, and select **Offline mode**.

Enable connections

Briefly press the power key, and select **Normal mode**.

Important: In the Offline mode you cannot make or receive any calls, or use other features that wireless network or Bluetooth connection. Calls may still be possible to the official emergency number programmed into your device. To use the features, you must first set the device back to normal mode. If the device has been locked, enter the lock code.

Internet connection settings

You can select which connections are used automatically, define how often connections are scanned for in the background, and set the device to switch to a saved WLAN connection when available.

Select  > **Settings and Internet connections** > **Connect automatically**.

Select a connection

Select whether you want to use a wireless LAN (WLAN) connection, a packet data connection, or whichever connection is available.

To select a connection each time you connect to the network, select **Always ask**.

Define the frequency of automatic connection attempts

Select **Search interval**. The default value is 10 minutes.

Switch to a WLAN when available

If you want your device to use a saved WLAN connection instead of a packet data connection when such a WLAN is available, select **Switch to WLAN when available**.

Bluetooth connectivity

About Bluetooth connectivity

With Bluetooth connectivity, you can make a wireless connection to other compatible devices, such as mobile phones, computers, headsets, and car kits.

You can use the connection to send images, video clips, music and sound clips, and notes, and transfer files from your compatible PC.

Since devices with Bluetooth wireless technology communicate using radio waves, they do not need to be in direct line-of-sight. However, they must be within 10 metres (33 feet) of each other, although the connection may be subject to interference from obstructions such as walls or from other electronic devices.

This device is compliant with Bluetooth Specification 2.1 + EDR supporting the following profiles: General Access Profile, File Transfer Profile, Object Push Profile, Generic Object Exchange Profile, Headset Profile, Hands Free Profile, Advanced Audio Distribution Profile, and Audio/Video Remote Control Profile. To ensure interoperability between other devices supporting Bluetooth technology, use Nokia

approved accessories for this model. Check with the manufacturers of other devices to determine their compatibility with this device.

Features using Bluetooth technology increase the demand on battery power and reduce the battery life.

Bluetooth settings

Select  > **Settings and Bluetooth**.

Select from the following:

Bluetooth on — Activate Bluetooth connectivity.

Visible — Allow your device to be found by other devices. If your device is hidden (not visible), it can only be connected to by a previously paired device.

My device's name — Enter a name for your device. This name is visible to other Bluetooth devices.

Tip: When searching for devices, some devices may show only the device address (IMEI address). To find the address of your device, select  > **Phone and** , and enter *#06#.

Pair devices

Devices with Bluetooth 2.1 and Secure Simple Pairing (SSP) ability are paired automatically. Ensure that both devices display the same passcode.

40 Connect your device

Pair with Bluetooth 2.0 or older devices

- 1 Your device proposes a passcode automatically. You can also create your own passcode (1 to 16 digits), and agree with the owner of the other device to use the same code. The passcode is only used once.
- 2 Select  > **Settings and Bluetooth**.
- 3 Select **Devices** > **New**.

Your device lists the Bluetooth devices that are within range and not hidden. The devices are indicated with the following icons:

	Computer
	Mobile device
	Audio or video device
	Other device

- 4 Select the device, and enter the passcode. The same passcode must be entered in the other device.
- 5 To authorise the device to connect to your device without your knowledge, select **Set as trusted device**. Use this status only for your own devices, such as your compatible headset or PC, or devices that belong to someone you trust.
- 6 Select **Pair**.

Cancel the pairing

Tap outside the dialog.

Do not pair with or accept connection requests from unknown devices. This helps to protect your device from harmful content.

Devices with no display, such as headsets, are connected automatically after pairing.

Send data using Bluetooth connectivity

Several Bluetooth connections can be active at the same time. For example, if you are connected to a compatible headset, you can also transfer files to another compatible device.

- 1 Open the application where the item you want to send is stored, and select the item.
- 2 Select **Share** or , depending on the view you are in.
- 3 Select **Send via Bluetooth**.
- 4 Select the device to which you want to connect.
- 5 If the other device requires pairing before data can be transmitted, a tone sounds, and you are asked to enter a passcode. The same passcode must be entered in both devices.

Receive data using Bluetooth connectivity

When you receive data using Bluetooth connectivity, a tone sounds, and you are asked if you want to accept the data.

Select **Save**, and define a file name and location for the data.

USB connections

USB

- 1 Connect your device to a compatible device with a USB data cable.
- 2 Select the USB mode. You can set the device to interact with Nokia PC Suite on your compatible PC or to appear as a mass storage drive in a PC, Mac, or other device.
- 3 To view or change the USB mode, or to disconnect the device, open the status area menu.

In the status area,  indicates an active connection.

Use your device as a modem

You can use your device as a modem, to connect your computer to the internet.

- 1 Connect your device to your computer, using the USB data cable.
- 2 Select **PC Suite mode**.
- 3 From PC Suite, select **Connect to the Internet**.

The connection may not be displayed on your device. The device data counter is updated after you disconnect. When connected, you can use your computer to monitor the amount of data sent and received.

You can only establish an internet connection using a cellular network, and may not be able to use some of the other

communication features when the device is used as a modem.

Browse the web

About browser

With the Maemo browser, you can view hypertext markup language (HTML) web pages on the internet. You can also view web pages that are designed specifically for mobile devices. These pages use extensible hypertext markup language (XHTML).

Select  > Web.

To browse the web, you must have an internet access point configured in your device.

Important: Use only services that you trust and that offer adequate security and protection against harmful software.

Open and browse web pages

Select  > Web, and enter the address in the address bar, or select a bookmark.

You can also view web pages in portrait orientation. To activate portrait browsing, press **Ctrl + Shift + 0**.

42 Browse the web


Use normal mode

Normal mode is active when you open a web page. In normal mode, you can move around a web page by dragging in the desired direction. You can also select check boxes and links, and enter text by selecting a text box and starting to write.

Use hover mode

To move the cursor on the web page, as if using a normal mouse, activate hover mode. For example, you can display information on a map by hovering the cursor over a location. To activate this mode, drag from the left of the touch screen onto the screen.  is displayed.

To select an item when hover mode is activated, press the space or shift key.



Use selection mode

To select text and images, as if using a normal mouse, activate selection mode. When hover mode is activated,

select  is displayed. To deactivate selection mode, select .

By default, web pages open in full screen mode. To exit full screen mode, select .


Tip: Use the stylus to open links more easily.

Zoom specific parts of a web page

Double-tap the desired part. To go back, double-tap again.

Zoom a whole web page

Draw a circle clockwise to zoom in or anticlockwise to zoom out.



Reload a page


Open the menu, and select Reload.

Stop loading a page

Select .

Browse recently visited pages

To access the recent browsing history, drag your finger from the right of the touch screen onto the screen, or press the backspace key. You can also select  to open the previous web page.



Search for text on a web page

- 1 Open the menu, and select **Find on page**.
- 2 Enter the desired text in the search field.

To hide the search bar, select  from the toolbar.

Browser toolbar

The browser toolbar helps you select frequently used functions of the browser. The toolbar is displayed in normal screen mode and hidden in full screen mode.

Select  > **Web**. To switch from full screen mode to normal mode, tap the screen, and select .

From the toolbar, select from the following:

-  — Open and edit bookmarks.
-  — Add a bookmark, add a shortcut to the desktop, or subscribe to an RSS feed.
-  — Stop loading content.
-  — Go to the previous web page.
-  — Switch from normal to full screen mode.

Organise bookmarks

Add a bookmark

- 1 Select  > **Web**.
- 2 Go to the web page for which you want to add a bookmark.
- 3 From the toolbar, select  > **Add to bookmarks**.

You can change the name of the bookmark and select where to save the bookmark.

Add browser shortcuts to desktop

With browser shortcuts, you can quickly access bookmarked web pages.

- 1 Select  > Web.
- 2 Go to a page you want to add a shortcut to.
- 3 From the toolbar, select  > Add shortcut to desktop.

Import bookmarks

You can import bookmarks to your device from other devices and computers.

- 1 To export an HTML file containing bookmarks from another browser to your device, use the relevant function of that browser.
- 2 Transfer the exported file from the other browser to your device. You can use mail, copy to a memory card, or use a USB data cable, for example.
- 3 Select  > Web, open the menu, and select Import bookmarks and the file.

The imported bookmarks are added to My bookmarks > Imported bookmarks.

Clear private data

A cache is a memory location that is used to store data temporarily. If you have tried to access or have accessed confidential information requiring passwords, empty the

cache after each use. The information or services you have accessed are stored in the cache.

- 1 Select  > Web, and go to a web page.
- 2 Open the menu, and select Options > Clear private data.
- 3 Select from the following:

Browsing history — Clear the browsing history of web pages and links you have opened and web addresses you have entered using the application toolbar.

Cache — Clear the memory cache. The memory cache is automatically cleared whenever you close the browser application.

Cookies — Clear all cookies.

Saved passwords — Clear all passwords you have saved for authentication purposes and web forms.

Authenticated sessions — Clear all authenticated sessions.

Geolocation permissions — Clear all permissions and bans you have given for web sites to use your position information.

Connection security

Data transmission between your device and a web server is encrypted if the secure server information banner is displayed. The security information includes the address of the website and the verification.

View security information for a website

Open the menu, and select **Details**.

Security certificates may be required for some services, such as banking services. You are notified if the identity of the server is not authentic or if you do not have the correct security certificate in your device.

Important: Even if the use of certificates makes the risks involved in remote connections and software installation considerably smaller, they must be used correctly in order to benefit from increased security. The existence of a certificate does not offer any protection by itself; the certificate manager must contain correct, authentic, or trusted certificates for increased security to be available. Certificates have a restricted lifetime. If "Expired certificate" or "Certificate not valid yet" is shown, even if the certificate should be valid, check that the current date and time in your device are correct.

Before changing any certificate settings, you must make sure that you really trust the owner of the certificate and that the certificate really belongs to the listed owner.

Download files

Important: Only install and use applications and other software from sources that you trust. Applications from untrusted sources may include malicious software that can

access data stored in your device, cause financial harm, or damage your device.

- 1 Select  > **Web**, and go to a web page that contains download links.
- 2 Select a link that points to the file that you want to download.
- 3 Select from the following:

Open with — Open the file in the appropriate application.

Save to device — Save the file to your device.

After a file transfer from an internet server starts, the name and size of the file and the progress of the download is displayed. Closing the dialog does not interrupt active downloads.

During the download, you can do the following:

Pause — Pause the download.

Resume — Continue the download. You may not be able to resume all paused files, because not all servers support it.

Delete — Cancel and delete the download.

Save web pages

You can save web pages to your device, to view them offline.

- 1 Go to the web page you want to save.
- 2 Open the menu, and select **Save page as**.

46 Browse the web

- 3 Enter a name, select where to save the page, and select if you want to also save the images.
- 4 Select **Save**.

View browsing history

You can view and visit your most recently visited web pages. The browsing history contains the web pages you have visited in the current browser window. The complete browsing history contains all the web pages you have visited in the past seven days.

Select  > Web.

- 1 Go to a web page.
- 2 Drag your finger from the right of the touch screen onto the screen, or press the backspace key.
- 3 Select a web page from the recent history, or select **Complete browsing history** and the desired date and web page.

Tip: To open the previous web page, from the toolbar, select .

Install a plug-in or an add-on

You can install plug-ins and XPI based add-ons (extensions) for the browser.

Important: Only install and use applications and other software from sources that you trust. Applications from untrusted sources may include malicious software that can

access data stored in your device, cause financial harm, or damage your device.

Install, update, or uninstall a plug-in

Install, update, and uninstall plug-ins using the Application manager.

Install an add-on

On a web page, activate a link referring to an installation file.

Update or uninstall an add-on

- 1 Select  > Web, and go to a web page.
- 2 Open the menu, and select **Options > Add-ons**.
- 3 Select the installation file and the desired option.

You can disable or enable add-ons and plug-ins. You may need to restart the browser.

Browser settings

Adjust view

You can change the way web pages are displayed in the browser.

- 1 Select  > Web, and go to a web page.
- 2 Open the menu, and select **Options > Adjust view**.
- 3 Select from the following:

Show images — To load and display all images, select **Always**. To display loaded images only, select **Already in cache**. To never load or display images, select **Never**.

Text size — Define the text size. To display the browser-defined text size, select **Normal**. To display 150% or 200% larger text, select **Large** or **Very large**.

Encoding — Text characters may not display correctly on web pages with different languages. To make a web page more readable, select the encoding that best matches the language of the web page.

Web settings

Select  > **Web**, and go to a web page.

Open the menu, and select **Options** > **Settings** and from the following:

Browser

Memory cache size — Define the amount of RAM you want to use as a cache.

Use increase and decrease keys for — Select to use the zoom/volume keys for zooming or controlling volume.

Open in full screen — Switch to full screen mode when a new window is opened.

Auto focus address field — Enter text directly in the web address field when you use the physical keyboard.

Enable rotation — Activate portrait browsing. When activated, you can view web pages in portrait orientation, when you turn your device.

Content

Enable password saving — Save passwords for web forms, on website sign in pages, for example. When this option is not selected, passwords are not filled in and you cannot save passwords. Clearing this checkbox does not delete previously saved passwords.

Open pop-ups — To allow all pop-up windows, select **Always**. To only allow pop-up windows that you open by selecting a link, select **Only requested**. To block all pop-up windows, select **Never**.

Accept cookies — A cookie is data that a site saves in the cache memory of your device. Cookies contain information about your visits to websites. They help to identify you upon subsequent visits and retain information when you move between web pages. To accept the use of cookies, select **Always**. To be prompted before a cookie is stored, select **Ask first**. To prevent cookies from being stored, select **Never**.

Geolocation — Define if you want to show your position information at street, district, or city level, or not to show it at all.

Enable JavaScript — JavaScript is used on many websites. Websites may have malicious scripts and it can be safer not to run them. Some websites may not work at all without JavaScript enabled.

48 Organise your contacts

Allow JavaScript pausing — Suspend the use of Flash and JavaScript whenever the browser window is open in the background.

It is recommended that you do not save passwords or use other similar features in web services or sites where you store personal data or content. This is especially important if unauthorised access to such web services or sites could cause you financial harm.

Organise your contacts

Get contacts

Add and edit contacts

When you open Contacts for the first time, the Get contacts dialog opens. You can import contacts from your SIM card, mobile device, or other device.

Select  > Contacts. A list of all your stored contacts and their possible availability status, status message, and avatar image is displayed.

Add a new contact

- 1 Open the menu, and select **New contact**.
- 2 Enter the contact's first name and last name. Only one name field is required.
- 3 Enter a phone number. To define whether it is a home or work number, mobile or landline number, or fax number, select **Mobile**.

- 4 Enter a mail address. To define whether it is a home or work mail address, select **E-mail**.
- 5 To add an avatar image, select the placeholder image. Select a default avatar, or to use a different image, select **Browse**.
- 6 To add more details, select **Add field**. You can add details about, for example, addresses, birthdays, business details, mail addresses, nicknames, notes, phone numbers, SIP user names, titles, and websites.

You can also manually add contact user names for different internet services. If you set up your own account, the contacts are automatically imported from the server.

Edit a contact

- 1 Select the contact, open the menu, and select **Edit**.
- 2 Edit the contact's details.

To add more details about the contact, select **Add field**. To remove details, select **Delete fields**. Select the details you want to delete and **Delete**. You cannot remove the first name, last name, or gender field.

Merge a contact

If you have duplicate contacts, do the following:

- 1 Select the contact, open the menu, and select **Merge contact**.
- 2 Select the contact to merge with.

If the contact details have contradicting information or the merging was not successful, select the desired details and **Save**.

Delete a contact

- 1 Open the menu, and select **Delete contacts**.
- 2 Select the contacts to delete and **Delete**.
- 3 Confirm the deletion.

The contacts are also deleted from all possible services.

Import and export contacts

You can import contact information from another device, IM accounts, a SIM card, or from a compatible file.

Import contacts

- 1 Select  > **Contacts**, open the menu, and select **Get contacts**.
- 2 Select from the following:

Synchronise from other device — Synchronise existing contacts from another device.

Import contacts from new account — Modify or create an IM account. When an IM account is created, the contacts of that account are imported.

Copy from SIM card — Copy all contacts from your SIM card.

Import contacts — Import contacts from a file stored in your device.

You can import contacts from files that have the .vcf file extension.

Export contacts

- 1 Select  > **Contacts**, open the menu, and select **Export**. Select **Next**.
- 2 Select **All contacts** or **Selected contacts**, and select **Next**.
If you selected **Selected contacts**, select the contacts you want to export, and then select **Done**.
- 3 Select the export file format, and select **Next**.
- 4 Define the folder name for the exported contacts, select a location for the folder, and select **Next**.
- 5 Select **Finish**.

Import a Mail for Exchange contact

You can import the details of Mail for Exchange contacts to your device contacts list. You need to have a Mail for Exchange account set up in your device.

Select  > **Contacts**.

- 1 Open the menu, and select **Get contacts** > **Import Mail Exch. contacts**.
- 2 Enter a name, and select **Search**.
- 3 Select **Import**.

50 Organise your contacts

Add and edit My information

My information is a view that contains your own contact details. You can also access your IM accounts or mail from this view.

Select  > Contacts, open the menu, and select My information.

Add My information manually

- 1 Enter your first name, last name, phone number, and mail address. Only one name field is required.

Your phone number is automatically imported from your SIM card if it is available. Other details, such as for internet call or chat services that you have set up an account for, may also be automatically imported. You cannot edit imported details.

- 2 To add an avatar manually, or change an automatically imported avatar, select the placeholder image. Select a default avatar, or to use a different image, select **Browse**.

Your avatar is automatically downloaded from the IM service. If you have more than one service set up, the avatar is picked randomly.

- 3 To add more details about yourself, select **Add field**.
- 4 Select **Save**.

In the My information view, the availability icon shows your availability status, status icon, and status message. To access the availability settings, select the icon.

Edit My information

- 1 Open the **My information** menu, and select **Edit**.
- 2 Edit the fields as necessary, and select **Save**.

Synchronise your contacts

- 1 Select  > Contacts.
- 2 Open the menu, and select **Get contacts** > **Synchronise from other device** > **Next**.
- 3 Select whether you want to transfer data from other Bluetooth devices, or to set up synchronisation to keep data updated on both devices. Select **Next**.
- 4 Select **Select device** and the desired device from the list.
- 5 Enter the identification number of the device you want to transfer data with, and select **Pair**.

View your contacts' availability statuses

The availability status of your contacts is indicated by one of the following:

	Online
	Busy
	Away
	Offline

Sort contacts

- 1 Select  > Contacts, and open the menu.
- 2 Select from the following:

ABC — Sort the contact list alphabetically.

Availability — Sort the list by availability status. Your contacts are listed by availability first, then in alphabetical order.

Recent — Sort the list according to recent activity. The contacts you have recently communicated with are listed first.

View groups

Open the menu, and select **Groups**.

View communication history

Select a contact, open the menu, and select **Communication history**.

Send contact cards

You can send contact cards in a text message or mail, or through Bluetooth connectivity.

Send a contact card

- 1 Select  > **Contacts**.
- 2 Select the contact whose contact card you want to send. To send your own information, open the menu, select **My information**.
- 3 Open the menu, and select **Send contact card**.
- 4 Select the method to use to send the contact card.

- 5 Select the contact you want to send the card to, and select **Send**.

Send a contact detail

- 1 Select  > **Contacts**.
- 2 Select the contact whose contact detail you want to send, open the menu, and select **Send contact detail**.
- 3 Select the contact detail you want to send.
- 4 Select the method to use to send the contact detail.
- 5 Select the contact you want to send the detail to, and select **Send**.

Add shortcuts to desktop

You can add shortcuts to contacts on the desktop. To open a list of available contact methods, select a contact.

Add a shortcut

Select  > **Contacts**, select the contact you want to add the shortcut for, open the menu, and select **Create shortcut**.

You can only create one shortcut for a contact.

Contacts settings

Select  > **Contacts**.

Open the menu, and select **Settings** and from the following:

52 Make calls

Display names — Define how names are displayed. By default, First name Last name is used.

Display video calling option — Allow video calling directly from the contacts list entry.

Display SMS only for Mobile numbers — Show text message options for mobile phone numbers, but not for landline phone numbers.

Delete all contacts from device — Delete all contacts on the device. The contacts are removed from the device, but they can still be found on the server.

Voice-mail number — Define the voice mailbox phone number.

Make calls

About calls

You can make voice calls and internet calls with your device. You can also make internet video calls.

Select  > Phone.

You can see your recent calls in the Phone main view. The calls are indicated with the following icons:

-  Dialled call
-  Received call
-  Missed call

Tip: You can make a call to a person saved in Contacts using the physical keyboard. On the desktop, start entering the name of the person to open Contacts. Select the contact from the proposed matches, and select .

You can also enter a phone number on the desktop using the physical keyboard. Press and hold  and enter the number. In the virtual keypad view, select .

Change display orientation

You can set the Phone application to be in portrait or landscape mode, or to change automatically to portrait or landscape according to the orientation in which you hold the device. You can also set the device to open the Phone application when you turn the device to portrait orientation, if on the desktop.

Select  > Phone, open the Phone menu, and select Turning control.

Select display orientation

Select Display orientation > Portrait, Landscape, or Automatic.

If you select Automatic, the orientation changes according to the orientation in which you hold the device.

Set the Phone application to open when you turn the device, if on the desktop

Select the Launch by turning check box.

Touch screen during calls

Your device has a proximity sensor. To extend battery life and prevent accidental selections, the touch screen is disabled automatically during calls, when you place the device next to your ear.



Do not cover the proximity sensor, for example, with protective film or tape.

Make voice calls

Make a call

Select  > Phone.

Tip: You can also set the Phone application to open from the desktop when you turn your device to portrait orientation. To activate this feature, open the **Phone** menu, and select **Turning control**.

Hold your device correctly during a call.



Select a recipient from the contacts list

Select **Select contact** and the contact.

To search for a contact, use the physical keyboard to start entering the first characters of the name, and select from the proposed matches. If you have saved several numbers for a contact, select the desired number from the list.

If you hold the device in portrait orientation, you can use the initial character icons on the right side of the display to find your contact.

Select a recipient from the recent calls list

The recent calls are listed in the Phone main view. Select a contact from the list to make the call.

54 Make calls

Enter the phone number manually

Select  and the cellular call type. Enter the phone number, including the area code.

Enter an international phone number

Select * twice to enter the + character (which replaces the international access code), and enter the country code, area code (omit the leading zero if necessary), and phone number.

Make the call

Select .

End the call

Select .

Cancel the call attempt

Select .

Tip: To add a contact card to the desktop, select **Contacts** and a contact, open the menu, and select **Create shortcut**.

Answer a call

Select . If the incoming call has been diverted from another phone number,  is displayed.

Reject a call

Select .

End an active call

Select .

Mute the ringing tone

Select .

Answer another call during a call

If call waiting (network service) is activated, select  to answer a new incoming call. The first call is put on hold.

Make a conference call

Select  > **Phone**.

Conference calls (network service) can only be made over cellular networks and can have a maximum of three participants (including yourself).

Call the first participant

Enter a participant's phone number, or select a contact from your contacts list.

Add an additional participant

Open the menu, and select **New call to contact** or **New call to number**.

Start the conference

Open the menu, and select **Start conference call**.

Talk to a participant in private

Select the participant and  **Private**. This splits the conference call into two separate calls. To end one of the calls, select the call and **End**. To continue the conference call, open the menu, and select **Start conference call**.

End the conference call

Select **End**.

Send DTMF tones

You can send dual-tone multifrequency (DTMF) tones during an active call to control your voice mailbox or other automated phone services.

During a call, select  and enter the DTMF sequence.

You can also enter the tone sequence using the keyboard.

Make internet calls

Internet calls

Internet calls are based on the voice over internet protocol (VoIP) that allows you to make and receive calls over the internet. To use this feature, you must have an active network connection (WLAN or packet data) and a registered internet call account with an internet call service provider, and your availability status must be **On** to allow you to receive calls.

Internet call services may not support emergency calls. Contact your internet call service provider for further details.

Create and edit call accounts

With call accounts, you can use internet call or instant messaging services.

Select  > **Phone**.

Create a call account

- 1 Open the **Phone** menu, and select **Accounts > New**.
- 2 Select a service and **Register new account**.
- 3 Enter the user details.

You can also create accounts in the Conversations application.

Sign in to an existing call account

- 1 Open the **Phone** menu, and select **Accounts > New** and a service.
- 2 Enter your user details, and select **Sign in**.

When an existing account is activated, your contacts are automatically retrieved from the account server, and added to your contacts list.

Edit an account

Select an account, and edit your user name, password, or screen name.

Enable or disable an account

Select an account, and select or clear the **Enabled** checkbox.

56 Make calls

Save account settings

Select **Save**.

Make an internet call

- 1 Select  > **Phone**.
- 2 Connect your device to an internet connection, and select a VoIP service account. Your availability status changes to **Online**.
- 3 Select **Select contact** and a contact.
- 4 To end the call, select .

You can also make an internet call from the **Contacts** application.

Answer an internet call

Select .

Make internet video calls

About internet video calls

To make an internet video call (network service), you need to be in the coverage of a 3G network, or use a wireless LAN (WLAN) internet connection. You also need to have a VoIP account.

For availability and subscription to internet video call services, contact your service provider. While talking, real-time, two-way video is streamed between you and the recipient of the call, if the recipient has a compatible device.

You can broadcast a live video stream using the device camera.

Internet video calls can only be made between two parties, can only be made to compatible mobile devices or ISDN clients, and cannot be made while another voice, video, or data call is active. Internet video calls are only made in landscape mode.

Answer a video call

Select .

Make an internet video call

Select  > **Phone**.

Select a recipient from the contacts list

Select **Select contact** and the contact.

Make the internet video call

Select . During the voice call, open the menu, and select **Turn on video**.

The secondary camera is used for internet video calls.

End the internet video call, or cancel a call attempt

Select .

Options during a call

Options during an active call

Open the menu, and select from the following:

New call to number — Call another number to start a conference call.

New call to contact — Call a contact to start a conference call.

Hold call — Put the call on hold.

Turn on video — Activate video sending.

Options during a call that is on hold

To put a call on hold, open the menu, select **Hold call**.

Open the menu, and select from the following:

New call to number — Call another number to start a conference call.

New call to contact — Call a contact to start a conference call.

Activate call — Activate the call.

Mute the microphone

Select . To unmute, select .

Activate the loudspeaker

Select .

Send DTMF tones

Select .

End the call

Select .

The available options may vary, depending on the call mode.

Call timers

You can view the duration of received and dialled calls. The duration of voice and internet calls is displayed separately.

Select  > Phone. Open the menu, and select **Call timers**.

Clear call timers

Select **Clear timers**. Both voice and internet call timers are cleared.

Emergency calls

Before making an emergency call, switch the device on, and check for adequate signal strength. If the screen and keys are locked, slide the lock switch on the side of the device to unlock them.

Important: This device operates using radio signals, wireless networks, landline networks, and user-programmed functions. Emergency calls can be made using the cellular

58 Send text and instant messages

phone. It is not possible to make an emergency call using voice calls over the internet (internet calls). Connections in all conditions cannot be guaranteed. You should never rely solely on any wireless device for essential communications like medical emergencies.

Make an emergency call

- 1 Select  > Phone.
- 2 Select  and the cellular call type.
- 3 Enter the official emergency number for your present location.
- 4 Select  to start the call.

Make an emergency call without entering PIN, PUK, or lock code

- 1 When the device asks for the code, enter the emergency number for your present location. The  Emergency call icon appears.
- 2 Select  Emergency call to make the call. After the emergency call, you need to enter the required PIN, PUK, or lock code to be able to use other device functions.

When making an emergency call, give all the necessary information as accurately as possible. Your wireless device may be the only means of communication at the scene of an accident. Do not end the call until given permission to do so.

Send text and instant messages

About Conversations

Select  > Conversations.

In Conversations, you can send text messages and instant messages.

The services share the main view, where text message and instant message conversations are listed. Select a conversation to see the messages in it.

You can send instant messages to one contact, or have a group conversation with several participants.

You can see your recent messages in the Conversations main view. The messages are indicated with the following icons:



You have one or more unread text messages in the conversation.



You have replied to this text message (the latest message in the conversation is sent by you).



You have one or more pending text messages in the conversation.



You have one or more failed text messages in the conversation.



You have one or more unread instant messages in the conversation.




You have replied to this instant message (the latest message in the conversation is sent by you).

Tip: To call a contact from the conversations main view, select and hold a conversation, and from the pop-up menu, select **Open contact card** and the call type.

Tip: To copy text from a received or sent text or instant message, activate selection mode. Drag from the left of the touch screen onto the screen, and select .

Drag your finger on the text to select, and, to copy the text, press **ctrl + C**.

To copy an entire text or instant message, select and hold the message, and from the pop-up menu, select **Copy**.



Send text messages

Send a text message

- 1 Select  > Conversations.
- 2 Select **New SMS**.

3 To add a recipient, select **To** and a contact, or enter a phone number.

4 Write your message in the message body.

To add a smiley, select the desired smiley.

5 Select **Send**.

Text messages are displayed in the main view as a conversations list.

Your device supports text messages beyond the limit for a single message. Longer messages are sent as two or more messages. Your service provider may charge accordingly. Characters with accents, other marks, or some language options take more space, and limit the number of characters that can be sent in a single message.

Forward a text message

- 1 Select  > Conversations.
- 2 Select the conversation and then the text message.
- 3 Select **Forward**.

Send a contact card

- 1 Select  > Contacts and a contact.
- 2 Open the menu, and select from the following:

Send contact card — Send all the contact details.

Send contact detail — Send a specific contact detail only.

60 Send text and instant messages

- 3 Select whether the card is sent as a text message, using Bluetooth connectivity, or as a mail message.
- 4 Select the message recipient, or enter a phone number.
- 5 Select **Send**.

Save a received contact card

- 1 Select  > **Conversations**.
- 2 Open the conversation with the received text message, and select the contact card link.
- 3 Select if you want to save the contact card as a new contact or update existing contact card information.

Send instant messages

Create and sign in to an instant messaging account

To send instant messages, you must create an instant messaging account.

Select  > **Conversations**, open the **Conversations** menu, and select **Accounts**.

Create an instant messaging account

- 1 Select **New**.
- 2 Select a service and **Register new account**.
- 3 Enter your user details. Depending on the service, you may have to set up an account using a web browser. Follow the instructions.

Sign in to an existing instant messaging account

- 1 Select **New** and a service.
- 2 Enter your user details, and select **Sign in**.

When an existing account is activated, your contacts are automatically fetched from the account server and added to your contacts list.

Send an instant message

- 1 Select  > **Conversations**.
- 2 Select **New IM** and a contact, or open the menu, select **Send IM to**, and enter an instant messaging address.
- 3 Write your message in the message editor. You cannot use the enter key to move to the next row (if you press the enter key, the message is sent). To add a smiley, select the desired smiley.
- 4 Select .

Start a group conversation

Some instant messaging (IM) services support group conversations. In a group conversation, you can have an IM conversation among several participants.

- 1 Select  > **Conversations**.
- 2 To start a conversation with the first participant, open the menu, select **Send IM to**, and enter an instant messaging address.

- 3 Select **Use account** and an instant messaging account supporting group conversations.
- 4 To invite additional participants to the conversation, open the menu, and select **Invite**.

Open the menu, and select from the following:

Participants — View conversation participants.
Set topic — Set a topic for a group conversation.
Leave — Leave a group conversation.

Participate in a chat room conversation

You can receive and send chat room messages if you have been invited to a chat room. To join a chat room, you can also enter the address of the room.

Select  > **Conversations**.

Respond to a chat room invitation

If you are invited to a chat room, a notification is displayed. To join the chat room, select the notification and **Yes**.

Join a chat room

- 1 Open the **Conversations** menu, and select **Join chat room**.
- 2 Enter the address of the chat room.
- 3 Select an account, and **Join**.

Save and view instant messaging history

Your instant messaging history is saved automatically.

To view your instant messaging history, select  > **Conversations** and a conversation.

Change your avatar

An avatar is a small image that you can use to represent yourself when sending instant messages.

- 1 Select  > **Conversations**.
- 2 Open the menu, and select **Accounts** and the account for which you want to change the avatar image.
- 3 Select the avatar placeholder and the desired avatar, or select **Browse** to browse your device memory for images.
- 4 To save the avatar, select **Save**.

You can also change your avatar in the account settings.

Change availability status

Tap the status area to open the status menu, and select **Availability** and from the following:

Online, Busy, or Offline — Set your availability status.
Type your status message — Enter your availability status message.
My location — Define your current location.

62 Send text and instant messages

New status — Add a new availability profile. With availability profiles, you can modify your availability separately for each account.

Account settings

Select  > Conversations, open the **Conversations** menu, and select Accounts.

Select an account, and define the following:

User name and **Password** — Enter your user name and password.

Screen name — Enter your screen name.

Avatar — Select an avatar image.

Edit personal info — Edit your personal information.

Enabled — Activate or deactivate the account.

Delete messages and conversations

Select  > Conversations.

Delete a text message

- 1 Select a conversation and a text message.
- 2 Select Delete.

Delete all messages in one conversation

- 1 Open the conversation.
- 2 Open the menu, and select Clear conversation.

Delete conversations

- 1 Open the menu, and select **Delete conversations**.
- 2 Select the desired conversation or conversations and Delete.

Filter conversations

Select  > Conversations.

To find a conversation with a specific recipient, start entering the recipient's name using the keyboard. Conversations with recipients starting with the entered characters are displayed in the conversations list view.

Text message and instant message settings

Select  > Conversations.

Open the **Conversations** menu, and select **Settings** and from the following:

Receive SMS delivery reports — Select whether to receive text message delivery reports.

SMS centre number — Use the text message centre number stored on your SIM card, or define another number.

Smileys theme — Select a theme for smileys.

IM theme — Select a theme for the conversations view.

Mail

About mail

You can access your personal mail accounts from your device, using Nokia Messaging. You can synchronise your mail from a single mailbox (default mailbox) or multiple mailboxes. Nokia Messaging enables push-synchronising to regular IMAP mail servers, such as Yahoo or Gmail.

You can also access your work mail, using Mail for Exchange. You can read and reply to mails, view and edit compatible attachments, and manage your calendar and contact information.

Read your work mail using Mail for Exchange

With Mail for Exchange, you can receive your work mail to your device. You can read and reply to your mails, view and edit compatible attachments, view calendar information, receive and respond to meeting invitations, and view, add, and edit contact information.

Mail for Exchange can be set up only if your company has Microsoft Exchange server. In addition, your company's IT administrator must have activated Microsoft Exchange ActiveSync for your account.

ActiveSync

Use of the Mail for Exchange is limited to over-the-air synchronisation of PIM information between the Nokia device and the authorised Microsoft Exchange server.

Before starting to set up Mail for Exchange, ensure that you have the following:

- A corporate mail address
- Your Exchange server name (contact your company's IT department)
- Your network domain name (contact your company's IT department)
- Your office network password

Depending on your company's Exchange server configuration, you may need to enter other information in addition to those listed. If you do not know the correct information, contact your company's IT department.

With Mail for Exchange, the use of the lock code may be mandatory. The default lock code of your device is 12345, but your company's IT administrator may have set a different one for you to use.

Set up your mail

Set up a Nokia Messaging account

You can have only one Nokia Messaging account set up in your device.

- 1 Select  > E-mail.
- 2 Open the menu, and select New account
- 3 Define the following:

Region — Select your country or region.

To search for a region, start entering the region name using the keyboard.

Service provider — Select **Nokia Messaging**.

E-mail address and Password — Enter your mail address and password. This is mandatory information.

- 4 Select **Finish**.

Set up your other mail

To send and receive mail messages, you must have an active network connection and a mail account with a mail service provider. For the correct settings, contact your mail service provider.

Using mail services (for instance, retrieving messages automatically) may involve transmission of large amounts of data. Contact your network service provider for information about data transmission charges.

- 1 Select  > **E-mail**.

- 2 Open the menu, and select **New account**.

- 3 For account details, define the following:

Region — Select your country or region.

To search for a region, start entering the region name using the keyboard.

Service provider — Select your mail service provider. If your mail service provider is not listed, select **Other**.

To search for a service provider, start entering the service provider name using the keyboard.

Account title — Enter a title for the account.

Tip: To search for a region or service provider, start entering the search term using the keyboard. The search bar becomes visible. Matching regions or service providers are displayed.

- 4 For user details, define the following:

Name — Enter your name. This name is displayed in the sender field of sent messages.

User name and Password — Enter your user name and password for the mail service. They are needed when you log into your mailbox. If you leave the password field empty, you are prompted for a password when you try to connect to your mailbox on the mail server.

E-mail address — Enter your mail address. It must contain the @ character. Replies to your messages are sent to this address.

- 5 If you selected **Other** as the mail service provider, define the following settings for incoming mail:

Account type — Select the mail protocol (POP3 or IMAP4) recommended by your mail service provider. IMAP4 is more modern and typically enables more functionality. Some functionality may be restricted with POP3.

You cannot change this setting after you save the account settings or exit the wizard.

Incoming server — Enter the host name or IP address of the POP3 or IMAP4 server that receives your mail.

Secure authentication — Set the system to use secure authentication.

If you do not use secure connections, it is strongly recommended that you enable secure authentication. For information on the supported methods, contact your mail service provider.

Secure connection — Define the security setting for incoming messages.

If you access your mail over a wireless LAN (WLAN), it is strongly recommended that you use secure connections. For information on the supported secure connections, contact your mail service provider.

Tip: Usually, the incoming mailbox servers (POP3 or IMAP4) are provided by your mail service provider, and the outgoing mail server (SMTP) is provided by your internet service provider. If these service providers are different, you may have different passwords and security settings for incoming and outgoing messages.

6 Simple mail transfer protocol (SMTP) servers are used when sending mail. To send mail, you must define the SMTP host name or IP address that you obtain from the mail service provider of the connection you use.

If you selected **Other** as the mail service provider, define the following settings for outgoing mail:

Outgoing server — Enter the host name or IP address of the server that sends your mail.

Secure authentication — Set the system to use secure authentication.

Secure connection — Define the security setting for outgoing messages.

Use connection-specific SMTP servers — Use connection-specific SMTP servers for sending mail. To modify connection-specific SMTP server settings, select **Edit SMTP servers**.

Tip: The settings for outgoing mail (SMTP) usually either use a user name and a password, or are specific to a connection. Without an SMTP user name and password, your internet service provider may prevent you from sending mail for security reasons.

7 To complete the mail account setup, select **Finish**.

Set up a Mail for Exchange account

To use Mail for Exchange, you need a Mail for Exchange account.

To set up an account:

1 Select  > **E-mail**, open the menu, and select **New account**.

2 Define the following:

Region — Select your country or region.

To search for a region, start entering the region name using the keyboard.

Service provider — Select **Mail for Exchange**.

3 Enter your mail address, user name, password, and domain.

4 Define the following:

Server — Enter the server address.

Port — Enter the port number for the Mail for Exchange server connection. The field is prefilled with the standard HTTPS Mail for Exchange port number.

Secure connection — Use a secure connection.

5 On the **Synchronisation content** page of the wizard, define the following:

E-mail — Enable mail synchronisation.

Calendar and tasks — Enable calendar and task synchronisation.

Contacts — Enable contact synchronisation.

First synchronisation — If you have enabled contact synchronisation, you need to select if you want to remove all local contacts when the device synchronises for the first time. **Keep items on device** is selected by default.

6 To modify advanced settings, select **Advanced settings**.7 Select **Finish**.**Read and send mail****Retrieve and read mail messages**

Select  > **E-mail**.

Your device can automatically retrieve the mail messages sent to you.

Retrieve mail messages manually

- 1 Open the menu, and select **Send & receive**. The messages are retrieved for all accounts. If you want to receive messages only from a specific account, select the desired account, open the menu, and select **Send & receive**. When retrieving mail, all messages in the Outbox folder are sent.
- 2 To retrieve the contents of a selected message, select the message header.

Read a mail message

Select the header of the message. To display images in the mail message, select .

If new mail messages are received while the mail application is closed, a notification is displayed. To open a new message, select the notification.

Reply to a received mail message

Select  to reply to the sender, or  to reply to all (the sender and the other recipients of the mail message).

Respond to a meeting invitation

Select **Accept**, **Tentative**, or **Decline**. Accepted and tentatively accepted meetings are saved in your calendar as events.

You can only receive meeting invitations via Mail for Exchange.

Forward a received mail message

Select .

Mark a mail message as read or unread

Open the menu, and select **Mark as read** or **Mark as unread**.

Move to previous or following mail message

Select  or .

Search for a mail message

In a mail folder, using the physical keyboard, start entering a search term. If a message title or the name of a sender or

recipient matches the search term, the message is displayed in a list.

Add the mail sender to your contacts list

Open the menu, and select **Add to Contacts**.

Delete a mail message

Select .

Create and send mail messages

- 1 Select  > **E-mail**.
- 2 Select **New message**.
- 3 Enter a mail address, or select recipients from the contacts list.
To separate multiple recipients, add a semicolon (:) or a comma (,). Use the **Cc** field to send a copy, or the **Bcc** field to send a blind copy to other recipients. If the **Cc** or **Bcc** field is not visible, open the menu, and select **Show Cc** or **Show Bcc**.

Tip: To search for recipients' mail addresses by their names, enter a recipient's name, open the menu, and select **Check names**.

- 4 Enter the subject, and write the message. To change the font, size, and colour of text in the message, select the icons from the toolbar.
- 5 Select .

Message settings

You can define a priority level for your mail message, and define whether the message is sent as formatted text (HTML) or plain text.

When writing a message, open the menu, and select **Message settings**.

Define the priority level

Select **Low**, **Normal** (default), or **High**.

Define the text format

Select **Formatted text** (default) or **Plain text**.

Add, save, and delete attachments

Select  > **E-mail**.

You can add attachments to a mail message you are writing, and remove added attachments.

Add an attachment

Open the menu, and select **Add attachment**.

Delete an attachment

Open the menu, and select **Remove attachments**.

You can open and save attachments from a received mail message.

Open an attachment

Select the attachment.

Save an attachment

Open the menu, and select **Save attachments**. Enter a name, select where to save the attachment, and **Save**.

Create a mail signature

- 1 Select  > **E-mail**.
- 2 Select **Edit account** and the desired account.
- 3 Select **Signature**.
- 4 Select the **Use signature** check box.
- 5 Enter your signature, and select **Save**.

The signature is added to the end of the body text of all messages you send using this account. You can edit and delete the signature before you send the mail message.

Tips for creating mail messages

Select  > **E-mail**.

Insert an image to the body of a mail message

Select .

Copy text from a mail message

- 1 Tap the message at the point from where you want to start copying.

- 2 Press and hold the shift key, and use the arrow keys to select text.
- 3 Press **ctrl + C** to copy the text, and **ctrl + V** to paste it to another location.

Organise your mail

Organise mail messages and attachments

Select  > E-mail.

Move messages from one folder to another

You can move messages to another mail folder, or to a folder in the device memory or on a memory card.

- 1 Select the folder, open the menu, and select **Move message**.
- 2 Select the messages that you want to move and **Move**.
- 3 Select the folder where you want to move the messages. To create a new folder, select **New**.

Search within a mail message

- 1 Select  > E-mail.
- 2 Open a mail message.
- 3 Open the menu, and select **Find in message**. The search bar is displayed.
- 4 Enter the search terms in the search bar, and press enter. Matching terms are highlighted.

Delete mail messages

To delete a mail message, select the message and .

For POP3 accounts, if you have activated the **Leave messages on server** option in the incoming mail settings, the message is only deleted from your device. If you deactivate the option and want to delete the message from the server, select the message and **Delete**.

For IMAP4 accounts, the messages you delete are always deleted from the server.

Synchronise with Mail for Exchange

Synchronisation takes place automatically in intervals that you have defined when setting up the Mail for Exchange account. You can also start the synchronisation manually at any time.

Only the content that you have defined when setting up the account is synchronised. If you want to synchronise more content, modify the Mail for Exchange settings.

Start the synchronisation manually

From the status menu, select **Mail for Exchange > Synchronise manually**.

If you have synchronised your calendar using Nokia PC Suite before, you may have duplicate calendar entries in your device.

Remove duplicate calendar entries

- 1 In the Mail for Exchange settings, deactivate calendar synchronisation.

If you do not deactivate calendar synchronisation before removing your calendar entries from your device, the entries are also removed from the server during the next synchronisation, and they cannot be synchronised back to your device.

- 2 Remove all calendar entries from your device.
- 3 In the Mail for Exchange settings, activate calendar synchronisation. The calendar is synchronised from the server back to your device during the next synchronisation.

Add the mail widget to desktop

You can add the mail widget to the device desktop. The widget shows if you have received mail, and displays the number of unread mail messages.

Tap the desktop, and select  > Desktop menu > Add widget > E-mail.

Mail settings

Mail account settings

Select  > E-mail.

Open the E-mail menu, and select Edit account and an account. Ensure that you are not connected to the mailbox.

Tip: To search for an account, start entering the account title.

For the correct settings, contact your mail service provider.

Account details

Account title — Enter a title for the account.

Leave messages on server — For POP3 accounts only. Set the device to leave a copy of retrieved messages on the server.

User details

Name — Enter the name to display as the sender in messages.

User name and Password — Enter your user name and password for the mail service.

E-mail address — Enter your mail address.

Settings for incoming mail

Incoming server — Enter the host name or IP address of the POP3 or IMAP4 server that receives your mail.

Secure authentication — Set the system to use secure authentication.

Secure connection — Define the security setting for incoming messages. Follow the instructions from your mail service provider.

Port — Enter the port number. Follow the instructions from your mail service provider.

Settings for outgoing mail

Outgoing server — Enter the host name or IP address of the SMTP server that sends your mail.

Secure authentication — Set the system to use secure authentication.

User name and Password — Enter your user name and password for the SMTP server.

Secure connection — Define the security setting for outgoing messages.

Port — Enter the port number. Follow the instructions from your mail service provider.

Use connection-specific SMTP servers — Use connection-specific SMTP servers for sending mail messages. To edit SMTP server settings, select **Edit SMTP servers**.

Mail settings

Select  > E-mail, open the **E-mail** menu, and select **Settings**.

Define the following:

Default account — Define which account is the default account. The first account created is set as default.

New message format — Select the format of new mail messages. The default value is Formatted text (HTML).

Incoming notifications — Show a notification when you receive mail.

Automatically add to Contacts — Add message recipients automatically to Contacts.

Update automatically — Set the device to retrieve messages automatically.

Update when connected via — Define which connection type is used to retrieve mail automatically.

Update interval — Define how often messages are retrieved. The default value is 15 minutes.

Nokia Messaging settings

Select  > E-mail and Edit account > **Nokia Messaging**.

View user details

Select **Service info**. You cannot edit these fields.

Modify Nokia Messaging settings

Select **Synchronisation** and from the following:

Days — Select the days on which you want the synchronisation to be done.

Hours — Select the time during which you want the synchronisation to be done on the selected days.

Sync while roaming — Select this option if you want synchronisation to be done when you are roaming outside your home network.

Disable sync when — Define a level of battery power at which you want synchronisation to stop.

Send and receive — Define the synchronisation interval.

Sync inbox — Select this option if you want your Inbox to be synchronised.

Download size — Select if you want to download only the mail message header, partial message, or full message.

Remove items older than — Select a time period after which mail messages are deleted from the device.

Sync drafts — Select this option if you want the mail messages in your Drafts folder to be synchronised.

Sync sent items — Select this option if you want the mail messages in your Sent items folder to be synchronised.

Add or modify mailboxes

- 1 Select **Nokia Messaging: Mailboxes**.
- 2 To add a new mailbox, select **Add new mailbox**. The title of each mailbox is retrieved from the Nokia Messaging Server. Select a mailbox.
- 3 To modify a mailbox, select the mailbox and from the following:

Mailbox name — Modify the mailbox name.

Mark messages as read on server — Select this option if you want the read status of your mails to be synchronised to the server.

My name — Modify your name.

Password — Modify your password.

E-mail address — Your mail address. You cannot modify this field.

Use signature — To use a signature, select the check box and **Signature**. Enter the signature, and select **Done**.

Mail for Exchange settings

Select  > **E-mail**. Open the menu, and select **Edit account** > **Mail for Exchange**.

View synchronisation details

Select **Details**. The number of items that were added, updated, or deleted in the last synchronisation are displayed.

To modify Mail for Exchange settings, select **Settings** and from the following:

Synchronisation schedule

Peak start time and **Peak end time** — Select a start and end time for the peak period.

Peak days — Select the days of the week when you want the peak times to apply. You must select at least one day.

Peak schedule — Select a synchronisation interval for peak periods. If you select **Always on**, new received messages and other changes on the server are pushed into the device without delay.

Off-peak schedule — Select a synchronisation interval for off-peak periods.

Connection

Server — Edit the address of the Exchange server.
Port — Edit the port number for the Exchange server connection.
Secure connection — Use a secure connection.
Conflict resolution — Define which item is kept if it has been edited on both the device and server since the last synchronisation.

Credentials

User name — Edit your Exchange server user name.
Password — Edit your Exchange server password.
Domain — Edit your domain on the Exchange server.

E-mail

Synchronise e-mail — Enable mail synchronisation.
E-mail address — Edit your mail address.
Account title — Edit the account title.
Signature — Use a signature in the mail messages sent from your Mail for Exchange account.
Synchronise messages back — Define how old messages are synchronised from the server.
When sending e-mail — Define if outgoing messages are sent immediately or only at the next synchronisation.

Calendar and tasks

Synchronise calendar and tasks — Enable calendar and task synchronisation.
Calendar — Define which calendar is used for Mail for Exchange.
Synchronise calendar back — Define how old calendar events and tasks are synchronised with the server.
Synchronise completed tasks — Include completed tasks in the synchronisation.

Contacts

Synchronise contacts — Enable contact synchronisation.
First synchronisation — Define whether all local contacts are removed when the device synchronises with the server for the first time.

Resynchronisation

Full resynchronisation — Start full resynchronisation.

The available options may vary.

Configure connection specific SMTP servers

Configuring connection specific SMTP servers enables the mail application to connect to an SMTP server and send mails when you are roaming between connections of different mail service providers.

74 Capture images and record video clips

- 1 If you want to use connection specific SMTP servers,  > E-mail, open the menu, and select Edit account.
- 2 Select the desired account.
- 3 Select Use connection-specific SMTP servers.
- 4 To edit SMTP servers, select Edit SMTP servers. Make the changes, and select Save.

Capture images and record video clips

Your device supports an image capture resolution of 2576x1921 pixels (5 megapixels). The image resolution in this guide may appear different.

Camera

Activate the camera

Open the lens cover. If the camera is active in the background, and the lens cover is open, press the capture key to activate the camera.

Capture images

Image indicators

The indicators in the camera viewfinder area display the current camera settings. The indicators in image mode are the following:



- 1 Close
- 2 Scene mode in use (for example, Automatic)
- 3 Capture settings ()
- 4 Flash mode in use (for example, Automatic)
- 5 Photos ()
- 6 Zoom level (hidden at the default zoom level)
- 7 Autofocus crosshair (, not shown in all image modes)
- 8 Image counter (estimated number of images you can capture using the current settings and available memory)
- 9 Memory in use (for example, Internal storage)
- 10 Image resolution (for example,)
- 11 White balance (for example,). Only visible if set to other than Automatic.
- 12 Exposure (for example,). Only visible if set to other than 0.
- 13 ISO sensitivity (for example,). Only visible if set to other than Automatic.

14 Geotag ( if geotagging is enabled). The icon blinks when the coordinates for the location are being retrieved.

Capture an image

When capturing an image, note the following:

- Use both hands to keep the camera still.
- The quality of a digitally zoomed image is lower than that of a non-zoomed image.
- The camera goes into battery saving mode if you perform no actions for about a minute. To continue capturing images, activate the touch screen.

Keep a safe distance when using the flash. Do not use the flash on people or animals at close range. Do not cover the flash while taking a picture.

- 1 To activate the camera, open the lens cover. If the camera is active in the background, and the lens cover is open, press the capture key to activate the camera.
- 2 To switch from video mode to image mode, select .
- 3 To lock the focus on an object, press the capture key halfway down. A green locked focus indicator is displayed. If the focus was not locked, a red focus indicator is displayed. Release the capture key, and press it halfway down again. You can also capture an image without locking the focus.

4 To capture an image, press the capture key all the way down. Do not move the device before the image is saved.

Zoom in or out

Use the volume keys.

Switch between normal and full screen mode

Tap the viewfinder area.

Geotag images and video clips

If you have enabled geotagging, the device saves geotag information such as country, city, and suburb, of every image and video clip you capture or record.

You need an internet connection to be able to add geotag information to your files.

It may take several minutes to obtain the geotag information. The availability and quality of GPS signals may be affected by your location, buildings, natural obstacles, and weather conditions. Your geotag information is not saved anywhere else than your device. If you share a file that includes geotag information, also the geotag information is shared, and your location may be visible to third parties viewing the file.

Enable geotagging

When you activate the camera for the first time, the device asks you whether you want to enable geotagging. To enable geotagging later, do the following:

76 Capture images and record video clips

- 1 Select  > Camera.
- 2 Open the Camera menu, and select Geotagging.
- 3 Select the Enable geotagging check box and Done.

After capturing an image

After you have captured an image, the post-capture view is displayed. In this view, you can, for example, delete the image or edit the tags of the image.

If you have selected **Show captured image** > **No** in the general camera settings, the camera returns to the pre-capture view, and the post-capture view is not displayed. In this case, you can edit the image in Photos.

In the post-capture view, if the image you captured is successfully geotagged, the country, city, and suburb geotags are displayed. If the geotags are not readily available at the moment of capture, the device tries to retrieve the geotags.

Acquiring geotags is displayed.

After capturing an image, select from the following:

-  — Return to the pre-capture view.
-  — Edit image tags and geotags.
-  — Share your image with others.
-  — Delete the image.
-  — Open the Photos application.

You cannot zoom images in the post-capture view.

Record video clips

Video indicators

The indicators in the camera viewfinder area display the current camera settings. The indicators in video mode are the following:



- 1 Close
- 2 Scene mode in use (for example,  **Automatic video**)
- 3 Sound recording (for example,  sound recording deactivated)
- 4 Capture settings ()
- 5 Media player ()
- 6 Zoom level (hidden at the default zoom level)
- 7 Autofocus crosshair ()
- 8 Time remaining. Estimated total video recording time, using the current settings and available memory.
- 9 Memory in use (for example, )
- 10 Video resolution (for example, )

- 11 White balance (for example, ). Only visible if set to other than **Automatic**.
- 12 Exposure (for example, ). Only visible if set to other than 0.
- 13 Geotag (, visible if geotagging is enabled). The icon blinks when the coordinates for the location are being retrieved.

Record a video clip

Start recording

- 1 To activate the camera, open the lens cover. If the camera is active in the background, and the lens cover is open, to activate the camera, press the capture key.
- 2 To switch from image mode to video mode, select .
- 3 To lock the focus on an object, press the capture key halfway down. A green locked focus indicator is displayed. If the focus was not locked, a red focus indicator is displayed. Release the capture key, and press it halfway down again. You can also record a video clip without locking the focus.
- 4 To start recording, press the capture key all the way down.

The elapsed recording time is displayed in red.

Stop recording

Press the capture key.

Switch between normal and full screen mode

Tap the viewfinder area.

After recording a video clip

After you have recorded a video clip, the post-recording view is displayed. In this view, you can, for example, delete the video clip or edit tags.

If you have selected **Show captured video** > **No** in the general camera settings, the camera returns to the pre-recording view, and the post-recording view is not displayed.

In the post-recording view, select from the following:

-  — Return to the pre-recording view.
-  — Edit video clip tags and geotags.
-  — Share your video clip with others.
-  — Delete the video clip.
-  — Open Media player, and play the video clip.

Camera settings

Scene modes

When you activate the camera, the last used scene mode is in use.

Select  > Camera and .

Select from the following:

78 Capture images and record video clips

 **Automatic** — The default image scene mode. Capture images in a variety of situations.

 **Night** — Capture images in low light conditions. The image may take longer to be processed.

 **Macro** — Focus on close up objects. The images may be susceptible to noticeable camera shake.

 **Landscape** — Capture landscape images with clear outlines, colours, and contrast.

 **Portrait** — Capture portraits of people, in good lighting conditions.

 **Action** — Capture fast moving objects, using a short exposure time. You can capture successive images rapidly. The auto-focus crosshair is not displayed.

 **Automatic video** — The default video scene mode. Record video clips in a variety of situations.

 **Night video** — Record video clips in low light conditions. Fewer frames per second (FPS) are recorded than in automatic video scene mode. The video clip may take longer to be processed.

Image settings

If you change the scene mode, the white balance, exposure, and ISO sensitivity settings are reset to defaults. The image resolution remains the same.

- 1 Select  > Camera and .
- 2 Select from the following:

White balance — Select the current lighting conditions. Colours are reproduced more accurately.

Exposure — Adjust the exposure compensation. If you are capturing a dark subject against a very light background, such as snow, adjust the exposure to +1 or to +2 to compensate for the brightness of the background. For light subjects against a dark background, use -1 or -2.

ISO sensitivity — Adjust the light sensitivity. Increase the light sensitivity in low light conditions, to avoid underexposed and out of focus images. Increasing the light sensitivity may also increase the image noise.

Resolution — Select the image resolution.

Video settings

- 1 Select  > Camera.
- 2 Select  to switch from image mode to video mode, if necessary.
- 3 Select  and from the following:

White balance — Select the current lighting conditions. Colours are reproduced more accurately.

Exposure — Adjust the exposure compensation. If you are filming a dark subject against a very light background, such as snow, adjust the exposure to +1 or to +2 to compensate for the brightness of the background. For light subjects against a dark background, use -1 or -2.

Resolution — Select the video resolution. Higher resolution video clips have a larger file size.

Flash settings

Keep a safe distance when using the flash. Do not use the flash on people or animals at close range. Do not cover the flash while taking a picture.

If you change the scene mode, the flash settings are reset to defaults.

- 1 Select  > Camera and .
- 2 Select from the following:

 **Automatic** — The flash is used automatically, if the lighting conditions require it.

 **Always on** — The flash is always used. Captured images may be overexposed.

 **Red eye reduction** — A pre-flash is used, to reduce the red eye effect.

 **Always off** — The flash is not used. Captured images may be underexposed and out of focus.

General settings

Select  > Camera and .

Select from the following:

Memory in use — Select **Internal storage** or a memory card, if inserted. In the internal storage, the files are stored in the Camera folder. On the memory card, the files are stored in a folder named DCIM (Digital Camera Images). When you connect your device to a PC, both folders are displayed as DCIM folders in the PC, which allows your PC to identify your device as a camera.

Creator name — Enter a name that is automatically inserted into the metadata of your captured images or recorded video clips.

Show captured image — Define how long images are displayed after being captured. If you do not want the image to be displayed at all, select **No**. This setting is available if image mode is in use.

Show captured video — Define how long video clips are displayed after being recorded. If you do not want the video to be displayed at all, select **No**. This setting is available if video mode is in use.

Restore default camera settings

To restore the camera settings to the default values, open the menu, and select **Restore settings**.

View images with Photos

View images

With Photos, you can view images as thumbnails in a grid, or full images individually. You can zoom, pan, and edit images and image tags. You can also view slide shows, use a TV-out

80 Capture images and record video clips

cable to view images on a TV, and share images with your friends.

View images in a grid

Select and hold the image to share, delete, mark or unmark as favourite, or view image details.

In the grid view, you can view and browse through multiple images inside one folder or filter set. The images are displayed as thumbnails. Small icons on the thumbnails indicate metadata, such as tags.



View an image in full screen mode

Select the image from the grid.

View images as a slide show

In full screen mode, select . To stop the slide show, tap anywhere on the display.

To view images on a TV screen, connect a compatible TV-out cable to your device.

TV-out settings

- 1 Select  > **Settings and TV out**.
- 2 Select **PAL** (default, used in Europe, for example) or **NTSC** (used in North America, for example).
- 3 Select **Save**.

Sort images

Select  > **Photos**, and open the menu.

Sort images by date

Select **Filter by date**, and select whether to view images from a certain day or period of time.

Sort images by tags

Select **Filter by tags**, and select terms that should be in the metadata of the images you want to view.

Sort images by folders

- 1 Select **Filter by folder**.
- 2 Select from the following:

Camera default folder — View the folder where the Camera application saves captured images.

Custom folder — Select the folder you want to view.

All images — View all images that are found in the device or on a memory card, if available.

Modify images

Select  > Photos.

Open an image for editing

- 1 Select the image you want to modify from the grid. The image is displayed in full screen mode.
- 2 Tap the image.



Select from the following:

-  — Rotate an image.
-  — Crop an image.
-  — Delete an image.
-  — Share an image.
-  or  — Undo or redo an action.

Use other editing options

Open the menu, and select **Edit image**. You can, for example, resize an image, flip an image horizontally or vertically, or adjust the brightness and contrast settings.

Edit tags

You can create new tags, edit previously created tags, add or edit location information, or remove tags from images.

Select  > Photos.

- 1 Select the image that you want to edit.
- 2 In normal screen mode, select .
- 3 You can also edit multiple images' tags in grid view mode. Open the menu, and select **Edit images' tags** and the images that you want to edit.
- 4 Select the desired tags from the cloud and **Done**.

Edit location information

Select **Geotags**. Geotag items must be selected individually.

Create a new tag

Select **New**, enter a tag name, and select **Done**.

Photos settings

- 1 Select  > Photos.
- 2 Open the menu, and select **Settings**.

82 Capture images and record video clips

3 Define the following:

Sort — By default, the thumbnails are in chronological order, starting with the oldest image. You can also sort images by name.

Slideshow — Define the pace of slide shows.

Group images by month

To view images separated with month titles in the grid view, select **Group by month**.

Display metadata indicators

To see small metadata icons on the images that have metadata attached to them, select **Display metadata indicators**.

The options available for editing may vary.

Share your images and video clips

About sharing content

You can share your content, for example, images or video clips, by uploading them to internet services, such as Ovi by Nokia or Flickr. To share, you must have a working internet connection and an existing sharing account.

Create a sharing account

To be able to send your content to different services, you need a sharing account. If you do not have an account, when trying

to share, the device prompts you to create an account first. Follow the instructions on the display.

To create a new sharing account in advance, do the following:

- 1 Select  > **Settings and Sharing accounts** > **New**.
- 2 Select the service.
- 3 Enter the user name and password, and select **Validate**. Depending on the service, you may have to set up an account using a web browser. Follow the instructions on the display.

Share items

- 1 Select the items you want to share and **Share via service**.
- 2 Enter a title and description, and select **Share**. You can edit the tags, select which sharing account to use, or modify the sharing options.

When sharing multiple items, to edit the metadata of an individual image, tap the thumbnail of the image.

The changes you make to files when sharing will not affect the metadata of the actual content.

Tags

When sharing content, you can see possible metadata indicators as small icons on the images' thumbnails.

 — Title, description or tags are assigned to the image.

 — The file contains GPS coordinates or information of the file creator. If the metadata is not yet selected to be removed,  is displayed.

Edit tags

Select Tags.

Share items using Bluetooth connectivity

- 1 Select the items you want to send and **Send via Bluetooth**.
- 2 Select the device to which you want to send the items. You may need to pair with the device first.

Send items using mail

Select the items you want to send, and select **Send via E-mail**.

Sharing settings

When sharing content, select **Options** and from the following:

Image size — Define the image size.

Metadata — Define which content details are sent with the content.

Privacy — Define who can see the content in your Flickr account.

Album — Select the album for the content.

The settings available for editing may vary.

View sharing status

After selecting **Share**, the content is moved to the upload queue. In the status area, the status of the current upload is indicated with the following icons:



Sharing is ongoing.



Sharing is pending because there is no connection available. Open the status area menu, and select the icon to try establishing a connection, or cancel the sharing.



Sharing is blocked because an error has occurred. Open the status area menu, and select the icon to see more detailed information of the error, and retry or cancel the sharing.

When the upload is complete, the icon is removed from the status area.

Edit your sharing accounts

Select  > **Settings and Sharing accounts**. Select an account.

Ovi

Change the password

Enter the new password, and select **Save**.

84 Play music and video clips

Remove the account

Select **Delete**.

If you are editing the account details using your device, you cannot change your user name.

Flickr

Edit account details

Select **Edit**, and follow the instructions. Return to the account editing dialog, and select **Validate**.

Remove the account

Select **Delete**.


You can only edit your Flickr account details using the browser.

Play music and video clips

About Media player

With Media player, you can listen to music and other audio files stored in your device or on a compatible memory card (if inserted) and audio streams from the internet. You can also play video clips or streamed video clips from the internet, and stream content from available media servers.

Select  > **Media player**.



Listen to music

Select .

Play video clips

Select .

Listen to internet radio

Select .

Shuffle between all songs

Select .

Browse media servers

Select the media server (). To see all servers, if there are more than four servers available, select  **More**.

File formats

Select  > Media player.

The supported video file formats are 3GP, MOV, AVI, MP4, WMV, and ASF. Streaming performance depends on the bandwidth availability.

The supported audio file formats are MP3, AAC, WMA, M4A, AMR, AWB, and WAV.

The supported playlist formats are M3U, PLS, ASX, WAX, WVV, and WPL.

Media player does not necessarily support all features of a file format or all the variations of file formats.

Add the media widget to desktop

You can add the media widget to the device desktop. With the widget, you can control audio playback (music or internet radio), and display the media player's Now playing view.

Tap the desktop, and select  > Desktop menu > Add widget > Media player.

Search for media files

Select  > Media player.

In views that list media files, start entering search terms using the keyboard. The search bar becomes visible. Matching files are displayed.

View MAFW plug-ins

You can view Media Application Framework (MAFW) plug-ins that have been installed for the Media player.

Select  > Media player.

Open the menu, and select Plug-ins and a plug-in.

Use the Application manager to install, update, or uninstall plug-ins.

Play music with Media player

Play music

Select  > Media player and Music.

Play a song

Select .

Pause playback

Select . You can also use the space key on the physical keyboard.

Stop playback

Select .

Play the next or previous song

Select  or . You can also use the arrow keys on the physical keyboard.

86 Play music and video clips

Repeat the currently playing song

Select .

Fast-forward or rewind

Select and hold  or .

Shuffle

Select .

Adjust the volume

To open and close the volume controls, select . Use the slider or volume keys to adjust the volume.

Browse the music library

Select  > Media player and Music.

Browse the music library

Open the menu, and select All albums, All songs, Genres, Artists, or Playlists.
[Editorial Note: Edited by: EM Date created: 02.02.2010 Comment type: word_choice Change: required Btw, this list could be replaced with 'the desired option'.]

Access the Now playing view

Select .

Switch between the current song and current playlist view in the Now playing view

Select the album art image.

Set a song as your ringing tone

In a view that lists songs (for example **[Editorial Note: Edited by: EM Date created: 02.02.2010 Comment type: word_choice Change: required "for example" -> ""]**), select and hold a song, and from the pop-up menu, select Set as ringing tone.

In the Now playing view, you can access the FM transmitter, save the playlist, or clear the current playlist from the menu.

If you close and reopen the Media player application, the last selected view is used.

View playlists

The Media player library contains a default set of automatic playlists. The contents of the playlists are updated each time they are opened. You cannot edit or delete automatic playlists.

Select  > Media player and Music. Open the menu, and select Playlists and the desired option.

Add songs to current playlists

Select  > Media player and Music.

Add a song to the current playlist

Select and hold a song, and from the pop-up menu, select **Add to now playing**.

The selected song is added to the Now playing list.

Add all songs in a library view to the current playlist

In a library view, select an artist, album, genre, or playlist, open the menu, and select **Add songs to now playing**.

All songs in the current library view are added to the Now playing list.

Remove a song from the current playlist

When viewing the current playlist in the Now playing view, select and hold a song, and from the pop-up menu, select **Delete from now playing**.

Clear the current playlist before adding new songs

In the Now playing view, open the menu, and select **Clear now playing**.

The playback is stopped and the previous view is displayed.

Save playlists

- 1 Select  > **Media player** and .
- 2 To save the items in the Now playing view as a playlist, select **Save playlist**.

- 3 Enter a name for the playlist, and select **Save**. If you want to replace an existing playlist, enter the exact name of the playlist to replace.

Shuffle songs

With the shuffle feature, you can listen to songs from the Now playing view or playlists in a random order.

Select  > **Media player**.

Shuffle songs

Select .

Stop shuffling

Select .

Use the FM transmitter

About the FM transmitter

With the FM transmitter, you can play songs in your device using a compatible FM receiver, such as a car radio or a home stereo system.

The operating distance of the FM transmitter is up to a maximum of 3 metres (10 feet). The transmission may be subject to interference due to obstructions, such as walls, other electronic devices, or from public radio stations. The FM transmitter may cause interference to nearby FM receivers operating on the same frequency. To avoid interference,

88 Play music and video clips

always search for a free FM frequency on the receiver before using the FM transmitter.

The operating frequency of the transmitter ranges from 88.1 to 107.9 MHz.

If the transmitter is not transmitting anything for one minute, it switches off automatically.

The FM transmitter cannot be used while the headset or TV-out cable is connected.

Play music using the FM transmitter

- 1 Select  > Media player.
- 2 Select a song to play, open the menu, and select FM transmitter.
- 3 To activate the FM transmitter, select FM transmitter on.
- 4 To select the frequency, select Frequency.

Calls are not broadcast using the FM transmitter. Playback is paused for the duration of the calls. The FM transmitter cannot be used during USB charging.

FM transmitter settings

- 1 Select  > Settings and FM transmitter.
- 2 To activate the FM transmitter, select FM transmitter on.
- 3 To select the frequency, select Frequency.

Play video clips with Media player

Play video clips

Select  > Media player and Video.

Play a video clip

Select .

Fast-forward or rewind

Select and hold  or .

Adjust the volume

To open or close the volume controls, select . Use the slider or the volume keys to adjust the volume.

Delete a video clip

Select .

Browse the video library

The video library contains video clips recorded with the device camera, transferred from your PC, or downloaded from the web, and bookmarked video streams.

- 1 Select  > Media player and Video.
- 2 Open the menu, and filter the view by date or category.

Add, edit, and remove video bookmarks

Add a video bookmark

- 1 Use the web browser to go to a web page containing video stream. The stream opens in the media player.
- 2 When the stream is playing, to save it as a bookmark, select .
- 3 Enter the name and web address of the bookmark, and select **Save**.

Edit or remove a bookmark

Select **Video > Video bookmarks**, select and hold the bookmark to open a pop-up menu, and select **Edit** or **Delete**.


Use TV-out to play video clips on your TV

Set the used television system

- 1 Select  > **Settings and TV out**.
- 2 Select **PAL** (default, used in Europe, for example) or **NTSC** (used in North America, for example).
- 3 Select **Save**.

Play video clips on a TV

- 1 Connect a compatible TV-out cable to your device.



- 2 Select **Media player > Video** and a video clip.

You can make and answer calls when connected to the TV.

Play video clips from the internet

- 1 Select  > **Media player**.
- 2 To play video clips streamed from the internet, select **Video** and a bookmark, or, when browsing the internet, select a video clip.

Listen to internet radio with Media player

Listen to internet radio

With Internet radio, you can listen to internet radio stations or other compatible audio streams. The Internet radio application supports MP3 and WMA files, and M3U, PLS, and WPL playlists. Some playlist file formats, such as ASX and WAX, are supported only partially.

- 1 Select  > **Media player**.

90 Play music and video clips**Listen to a radio station**

Select Internet radio and the desired station from the list.

Pause playback

Select .

Stop listening

Select .

Listen to the next or previous radio station

Select  or .

Adjust the volume

To open and close the volume controls, select . Use the slider or the volume keys to adjust the volume.

Add internet radio stations

Internet radio can include one or more web links to radio streams.

- 1 Select  > Media player and Internet radio.
- 2 Open the menu, select Add radio bookmark, and enter the web address of the station. If you are already listening to a station, the details are automatically provided.
- 3 To save the station, select Save. The radio station is added to the Internet radio stations view.

Play music from media server**About media servers**

With media servers, you can store and share your media files, that is, images, video and audio clips, and other types of multimedia.

Select  > Media player.

Universal Plug and Play (UPnP) technology allows devices to connect to each other, and simplifies communication and the sharing of data and media in the home. Media servers are available for most operating systems and many hardware platforms.

Your device functions as a UPnP client and can auto-detect media servers that are connected to the same local network as your device and are configured accordingly.

The Media player application provides access to media servers in the wireless environment. The available servers are displayed at the bottom of the main Media player view. You cannot delete the servers from the main Media player view nor delete media from them.

Browse media servers

Select  > Media player.

After scanning the wireless network, discovered media servers are displayed at the bottom of the main Media player view. If there are more than four servers available, to see all servers, select  More.

When you select a server, the root directory of the server is loaded and displayed. You can browse the servers and their content.

Find and view locations

Positioning (GPS)

About GPS

Section metadata

Keywords: GPS

The Global Positioning System (GPS) is operated by the government of the United States, which is solely responsible for its accuracy and maintenance. The accuracy of location data can be affected by adjustments to GPS satellites made by the United States government and is subject to change with the United States Department of Defense civil GPS policy and the Federal Radionavigation Plan. Accuracy can also be affected by poor satellite geometry. Availability and quality of GPS signals may be affected by your location, buildings, natural obstacles, and weather conditions. GPS signals may not be available inside buildings or underground and may be impaired by materials such as concrete and metal.

GPS should not be used for precise location measurement, and you should never rely solely on location data from the GPS receiver and cellular radio networks for positioning or navigation.

The trip meter has limited accuracy, and rounding errors may occur. Accuracy can also be affected by availability and quality of GPS signals.

The coordinates in the GPS are expressed using the international WGS-84 coordinate system. The availability of the coordinates may vary by region.

Assisted GPS (A-GPS)

Your device also supports assisted GPS (A-GPS).

A-GPS requires network support.

Assisted GPS (A-GPS) is used to retrieve assistance data over a packet data connection, which assists in calculating the coordinates of your current location when your device is receiving signals from satellites.

When you activate A-GPS, your device receives useful satellite information from an assistance data server over the cellular network. With the help of assisted data, your device can obtain the GPS position more quickly.

Your device is preconfigured to use the Nokia A-GPS service, if no service provider-specific A-GPS settings are available. The assistance data is retrieved from the Nokia A-GPS service server only when needed.

You must have an internet access point defined in the device to retrieve assistance data from the Nokia A-GPS service over a packet data connection. You can define the access point for

92 Find and view locations

A-GPS in network positioning settings. A wireless LAN (WLAN) access point cannot be used for this service. Only a packet data internet access point can be used. Your device asks you to select the internet access point when GPS is used for the first time.

Hold your device correctly

When using the GPS receiver, ensure you do not cover the antenna with your hand.



Establishing a GPS connection may take from a couple of seconds to several minutes. Establishing a GPS connection in a vehicle may take longer.

The GPS receiver draws its power from the device battery. Using the GPS receiver may drain the battery faster.

Position requests

You may receive a request from a network service to receive your position information. Service providers may offer information on local topics, such as weather or traffic conditions, based on the location of your device.

When you receive a position request, the service that is making the request is displayed. To allow your position information to be sent, select **Accept**. To deny the request, select **Reject**.

Location settings

Select > Settings and Location.

GPS settings

Select from the following:

Enable — Activate the internal GPS receiver in your device. The GPS receiver is automatically activated when an application that uses GPS data is opened.

GPS device — Select the GPS receiver to use.

Pair new device — Pair an external GPS receiver with your device. Select the GPS receiver from the list of found devices.

Network positioning settings

Select from the following:

Enable — Activate the network-based positioning service (including A-GPS).

Location server — Enter the location server address.

Ovi Maps for mobile

About Maps

Section metadata

Keywords: maps

Select  > Maps.

With Maps, you can see your current location on the map, browse maps of different cities and countries, search for places, and plan routes from one location to another.

When you open Maps, you may need to select an internet access point used to stream map data.

When you browse to a new area on the map, map data is streamed from the internet. Some maps may be available in your device or on a memory card.

Tip: To avoid data transfer costs, you can also use Maps without an internet connection, and browse the maps that are saved in your device or memory card.

Note: Downloading content such as maps, satellite images, voice files, guides or traffic information may involve transmission of large amounts of data (network service).

Almost all digital cartography is inaccurate and incomplete to some extent. Never rely solely on the cartography that you download for use in this device.

View the map**Section metadata****Keywords:** view the map

When the GPS connection is active,  shows your current location on the map.

Move on the map

Drag the map with your finger or stylus.

View your current location

Select .

Zoom the map


Select + or -, or select  and the country, state, city, or street view.

View a route to a location

Select the location information box and **Route to**. Maps creates a route from your current position, if available.

Map elements**Section metadata****Keywords:** map elements

94 Find and view locations



- 1 Selected location
- 2 Location information
- 3 Compass
- 4 Zoom icons

Modify the map**Section metadata****Keywords:** modify the map

Change the look of the map to suit your needs.

Select  > Maps and from the following:

Map view — In the standard map view, details such as street names or motorway numbers, are easy to read.

Satellite — For a detailed view, use satellite images.

Terrain — View at a glance the ground type and altitude, for example, when you are travelling off-road.

3D View — For a more realistic view, change the perspective of the map.

3D Landmarks — Display prominent buildings and attractions on the map.

Night Mode — Dim the colours of the map. When travelling at night, the map is easier to read in this mode.

Tips — Display tips on how to use Maps.

Search for a place**Section metadata****Keywords:** search for a place

You can find specific addresses and types of business, such as restaurants or hotels.

- 1 Select  > Places.
- 2 Start entering the search terms in the search field. You can select from the suggested matches.
- 3 Select .

The location is displayed on the map. If more than one search result is available, to view the other search results on the map, select or .

View the search results list

In the map view, select . To return to the map view, tap outside the active area.

Plan routes

Section metadata

Keywords: plan routes

You can create walking or driving routes, view them on the map, and get turn-by-turn directions.

Create and view a route

- 1 Select > Routing.

Maps automatically sets your current location as the starting point, if available.

- 2 If you want to set the starting point manually, enter the search terms in the search field and select .
- 3 To add the desired location to the route point list, in the map view, select . To view more search results, select .
- 4 To search for the destination, in the route point list, enter the search terms in the search field , and select .

- 5 To add more route points, in the route point list, select . Enter the search terms in the search field, and select .

The route can include up to four route points.

- 6 Select **View Route**. To consecutively view the route points on the map, select or .

Tip: To select route points from the map, in the route point list, select .

View the route directions

When viewing the route, select .

Clear the route

When viewing the route, select > Clear map.

Modify the settings for a route

The route settings affect the route directions and the way the route is displayed on the map.

- 1 Select > Routing.
- 2 Select or .
- 3 Select the desired option.

To return to the map view, tap outside the active area.

General settings

Section metadata

96 Manage time

Keywords: general settings

Use metric or imperial units

Select  > Maps > More > Metric units or Imperial units.

Use the 12 or 24 hour clock

Select  > Maps > More > 12 hour or 24 hour.

Manage time

View the time and set alarms

Select  > Clock.

You can view your local time and time zone information, set and edit alarms, or modify date, time and regional settings.

Add and edit alarms

Add alarms

- 1 Select  > Clock and .
- 2 Enter the time for the alarm. You can create an alarm that repeats on set days. You can also add a title.
- 3 Select Save.

Edit alarms

- 1 Select  > Clock and .
- 2 Select the alarm you want to edit.

- 3 Edit the title and time of the alarm, select the days on which the alarm is to be repeated, and activate or deactivate the alarm.

- 4 Select Save.

Turn off a sounding alarm

Select Stop.

Turn off the alarm for a certain period

Select Snooze.

If your device is switched off when a clock alarm is due, your device switches itself on and starts sounding the alarm tone.

View world clock

You can view the current time in different locations. The first clock is the local time, and it opens the date and time settings.

Add a new world clock

- 1 Select  > Clock and .
- 2 Select New World clock.
- 3 Drag the map to the desired time zone, or select  to search for a city.

Clock settings

Alarm settings

- 1 Select  > Clock, and open the menu.
- 2 Select Alarm settings.

- 3 Select the tone for the alarm clock and the time after which the alarm sounds again when you set it to snooze.
- 4 Select **Save**.

View and manage your calendar

View your calendar

Select  > Calendar, and open the menu.

Select Month, Week, or Agenda.

With the calendar, you can do the following:

- Create events, tasks, and notes for different purposes such as work, home, or hobbies. The items you enter in different calendars appear in different colours.
- Create new calendars, and delete unnecessary calendars. However, your device has two calendars that cannot be deleted. The private calendar only exists in your device and cannot be synchronised. The device main calendar is used with PC Suite, for example. It is also possible to add calendars provided by third parties.
- Hide calendars without removing your events and tasks. For example, you can hide your work calendar during your holiday. When a calendar is hidden, its alarms are deactivated.

Tip: If you add birthdays to your contact cards, the birthdays are collected into a birthday calendar. The alarm is deactivated by default for the birthdays, so you must edit them if you want to be reminded.

View the events of a day

In the Month or Week view, select the day.

Tip: To move to the previous or following day, swipe left or right. In the Month and Week views, you can move to the previous or following month or week in the same way.

View notes

Select **Go to notes**.

View all tasks

Select **Go to tasks**.

Add and edit calendars

You can create different calendars for home, work, and hobbies, for example.

Select  > Calendar, and open the menu.

Select **Settings > Edit calendars**.

Add a calendar

Select **New**, and follow the instructions of the Calendar wizard. Add the title and colour of the calendar, and select whether the calendar is displayed.

Edit a calendar

Open the calendar you want to edit, and edit the details.

Add and edit calendar notes

Select  > Calendar, open the menu, and select **Go to notes**.

Add a note

Select **New note**, and write the note.

To change the calendar, select **Calendar**.

Edit a note

Open the note, and edit the content.

To change the calendar, select **Calendar**.

Add and edit tasks

You can keep track of your schedule by creating task reminders for yourself. After the task has been completed, you can mark the task as done.

Select  > Calendar, open the menu, and select **Go to tasks**.

Add a task

Select **New task**, add the title and date, select which calendar to use, and set the alarm.

Edit a task

Open the task, and edit the details.

Mark a task as done

Select **Done**.

Add and edit events

You can reserve time in your calendar for events such as appointments and meetings. You can also add reminders for birthdays, anniversaries, and other events.

If you add a birthday to your contact cards, the birthdays are automatically collected to a birthday calendar.

Select  > Calendar.

Add an event

- 1 Go to the desired date, and select **New event**.
- 2 Add the details of the event. You can set the event to repeat regularly, set an alarm, and select which calendar to use.
- 3 Select **Save**.

Tip: To add an event quickly, select **Month**, **Week**, or **Agenda**, and start entering text using the physical keyboard. The **New event** dialog opens, and you can edit the rest of the information.

Edit or remove an event

- 1 Go to the date of the event.
- 2 Select the desired event, open the menu, and select **Edit event** or **Delete event**.

Import events to calendar

You can import downloaded or local files with the .ics file extension to your calendar.

Tap a file that has the .ics file extension, and select a calendar from the list.

To import the content to a new calendar, select **Create new calendar**.

Synchronise your calendar with another device

You can synchronise your calendars with other compatible devices. You can use an existing calendar or create a new calendar for the events, tasks, and notes.

When calendar events are synchronised, the calendar in the other device may have more complex settings for repeating events. In this case, the repeating events are shown in the device, but the possibility to edit repeating events may be restricted.

Add the agenda widget to desktop

You can add the agenda widget to the device desktop. With the widget, you can quickly view your upcoming calendar events.

Tap the desktop, and select  > Desktop menu > Add widget > Calendar.

Calendar settings

Select  > Calendar, and open the menu.

Select **Settings** and from the following:

Edit calendars — Add and edit calendars.

Alarm tone — Change the alarm tone. To add your own alarm tone, select **More**.

Delete items — Define the period after which your calendar events and tasks are removed.

First day of week — Change the first day of the week.

Hide done tasks — Hide your completed tasks.

Use utilities and manage data

Synchronise and transfer content from another device

Synchronise content

Synchronise with a compatible device for the first time

If you want to synchronise using Nokia PC Suite, you need to start the synchronisation from the PC. Otherwise, do the following:

- 1 Select  > Settings and Transfer & sync > Next > **Synchronise data**.
- 2 Select the device with which to synchronise data. You may need to pair with the device.
- 3 Select the content to include in the synchronisation. If you synchronise calendar entries, select the calendar to use.

100 Use utilities and manage data

4 Select **Finish** to start the synchronisation.

The length of time needed to complete the synchronisation depends on the amount of data to be transferred.

After synchronisation, the created synchronisation profile is saved in the Transfer & sync main view. You can later synchronise data using the same settings.

Synchronise again

Select the desired synchronisation profile from the list, and select **Sync**.

Handle synchronisation conflicts

If an item to be synchronised has been edited in both devices, the device attempts to merge the changes automatically. If this is not possible, there is a synchronisation conflict. Select the version to save.

Transfer data

Transfer data for the first time

- 1 Select  > Settings and Transfer & sync > Next.
- 2 Select **Retrieve data** or **Send data**.
- 3 Select the device with which to transfer data. You may need to pair with the device.
- 4 Select the content to include in the data transfer.
- 5 Select **Finish** to start the data transfer.

After a data transfer, the created transfer profile is saved in the Transfer & sync main view. You can later transfer data using the same settings.

Transfer content again

To transfer content again, select the desired data transfer profile from the list, and start the transfer.

Manage transfer profiles

Select  > Settings and Transfer & sync.

In the Transfer & sync main view, you can see the data transfer profiles you have created. You can modify, delete, or create new transfer profiles.

Modify transfer details

- 1 Select the transfer profile from the list.
- 2 Select **Content**.
- 3 Select the content to include in the data transfer, and select **Done**.

Create a new transfer profile

Select **New**. A data transfer wizard opens, and you can start a new data transfer. The profile is saved in the Transfer & sync main view.

Delete a transfer profile

Select the transfer profile from the list, and select **Delete**.

Deleting a transfer profile does not delete content from the device.

Back up and restore data

About backups

You can back up data to the device mass memory or a compatible memory card, and if necessary, restore the data to the device. The backup appears as a folder on the device mass memory or memory card. You can also secure the backup with a password.

You can back up the following:

Communication and Calendar — Mail and chat messages and accounts, text messages, contacts in the Contacts application, calendar events, clock alarms, and alarm settings

Bookmarks — Bookmarks from web browsers

Settings — All application configurations

Application list — A list of the applications installed in your device

Create a new backup

- 1 Select  > Backup and New backup.
- 2 Enter a descriptive name, define the desired location of the backup, and select **Proceed**.
- 3 Select the data types you want to back up.

- 4 If you want to protect the backup with a password, select the **Protect with password** check box, enter the password twice, and select **Done**.

Restore a backup

- 1 Select  > Backup.
- 2 Select the desired backup and **Restore**.
- 3 Select the data types to restore.
- 4 Confirm that you want to restore the data. If the backup is password-protected, enter the password, and select **OK**.
- 5 If your device contains a newer version of the files than the backup you are restoring, the device asks you to confirm if you want to save the backed up version, or cancel data restore. Select from the following:

Yes — The device overwrites the current version with the backed up file.

Yes to all — The device overwrites all conflicting files without further confirmation.

No — The version on the device is not replaced.

Manage files

About File manager

Select  > File manager.

With File manager, you can move, copy, rename, delete, open, and share files and folders.

102 Use utilities and manage data

View files and folders

Select  > File manager.

To view detailed information about a file or folder, select and hold the item, and from the pop-up menu, select **Details**.

Stored files are compressed to save memory.

You cannot modify read-only files or folders.

If you use a USB data cable to connect your device to your computer, you can view files and folders after setting the computer operating system to display hidden folders. In Microsoft Windows, folders are named, for example, .documents, .images, or .videos.

Edit files and folders

- 1 Select  > File manager.
- 2 Select the folder containing the file or folder you want to edit.
- 3 Open the **File manager** menu, and select from the following:

New folder — Create a new folder.

Move — Move a file or folder.

Copy — Copy a file or folder.

Delete — Delete a file or folder.

Share — Share a file or folder.

Sort — Sort files and folders.

Memory usage — View memory usage. To view memory details, select **Details**.

- 4 To rename a file or folder, select and hold the item, and from the pop-up menu, select **Rename**.

Memory

About memory

Your device has an inbuilt mass memory with a capacity of 32 GB, some of which is reserved for the device software, and not available for use when connected to a PC.

In addition to the device mass memory, your device has an external microSD memory card slot, and it supports memory cards with a capacity of up to 16 GB. You can insert and remove a memory card when the device is switched on, if the memory card is not being used by an application.

Use only compatible MicroSD cards approved by Nokia for use with this device. Nokia uses approved industry standards for memory cards, but some brands may not be fully compatible with this device. Incompatible cards may damage the card and the device and corrupt data stored on the card.

If the device memory becomes corrupted, you may need to format the device storage and re-install the operating system.

Manage memory cards

With File manager, you can create new folders, view memory usage, or manage information on the memory card.

Select  > File manager.

- 1 Select the desired memory card from the list.
- 2 Open the **File manager** menu, and select the desired action.

Format your memory card

Select and hold the memory card, and from the pop-up menu, select **Format**.

View memory consumption

You can view the amount of available memory in the device memory or on the memory card, and the amount of memory available for installing applications.

Select  > **Settings and Memory**.

To view the memory consumption in more detail, select **Details**.

To increase the amount of available memory, use File manager or other applications to delete data.

Increase available memory

Many features of the device use memory to store data. The device notifies you if the amount of available memory is low.

View how much memory is available

Select  > **Settings and Memory**.

Increase the available memory

Move data to a compatible memory card (if available) or to a compatible computer. To remove data you no longer need, use File manager, or open the respective application.

You can remove the following:

- Images and video clips. Back up the files to a compatible computer.
- Saved web pages
- Messages in Conversations
- Retrieved mail messages in the mailboxes
- Contact information
- Calendar notes
- Applications shown in Application manager that you do not need
- Installation files (.deb or .install) of applications you have installed. Transfer the installation files to a compatible computer.

Clear device data and restore settings

Clear device data

When you clear data from your device, the data is permanently deleted.

1 Select  > **Settings**.

104 Use utilities and manage data

- 2 Open the **Settings** menu, and select **Clear device** > **Yes**.
- 3 Enter the lock code of the device, and select **Done** to clear the device data.

The following data is deleted:

- Browser user data: bookmarks, user history, passwords, and cookies
- Contacts
- Calendar entries
- Home shortcuts
- Mail messages, accounts, and their passwords
- Instant messaging and internet call accounts
- Connectivity settings, connections, and their passwords
- Location information
- Documents: document favourites; and images, audio, and video files
- Settings for text input methods, and user dictionaries
- Game scores
- All user settings, including touch screen, display brightness, and volume settings
- Profiles

The following data is not affected:

- Applications that you installed

- Memory card contents

Restore the original settings

You can restore all device settings to their default values. This does not affect content or shortcuts you have created, security codes, passwords, the device language, or game scores. Also, it does not affect the contents of the device mass memory.

- 1 Select  > **Settings**.
- 2 Open the **Settings** menu, and select **Restore original settings** and **Yes**.
- 3 Enter the lock code of the device, and select **Done**.

Use utilities

Subscribe to RSS feeds

Read news feeds and blogs

With the RSS feed reader, you can read news feeds and blogs from all over the world and content published on different web sites.

Select  > **RSS**.

Open a feed

Select the feed you want to open.

Open the **RSS** menu, and select from the following:

Sort — Sort feed contents by date or name.

Manage folders — Organise, create, rename, or delete folders.

Clear image cache — Clear all details from the image cache.

Settings — Modify RSS feed reader settings.

Select from the following:

 — Refresh the view.

 — Add a new feed.

 — View feed details.

 — Delete.

 — Show or hide the folder structure.

 — Search for posts in your feeds. Enter keywords in the field, and select .

Add the RSS widget to desktop

You can add the RSS widget to the device desktop. With the widget, you can view the latest posts to your news feeds.

Tap the desktop, and select  > Desktop menu > Add widget > RSS.

View PDFs

With the PDF reader, you can view documents in the portable document format (PDF).

Select  > PDF reader.

Open the **PDF reader** menu, and select from the following:

Open — Open a document.

Save as — Save a document.

Details — View the details of a document.

Select from the following:

 — Go to the first page of the document.

 — Go to the last page of the document.

 — Go to the previous page of the document.

 — Go to the next page of the document.

 — Zoom in.

 — Zoom out.

 — Switch from normal to full screen mode.

Write notes

With the Notes application, you can create and save short notes. Files with the .txt (plain ASCII text with no formatting) and .note.html (formatted text) file extensions are supported. The full HTML file format is not supported.

Select  > Notes.

Open the **Notes** menu, and select from the following:

New — Add a new note.

Open — Open an existing note.

Save — Save a note.

106 Use utilities and manage data

Settings — Change the text alignment or file format.

Font — Change the font style or formatting.

Undo or Redo — Undo or redo an action.

Make calculations

- 1 Select  > **Calculator**.
- 2 Make calculations. To use more complex calculator functions, open the menu, and select **Scientific**.
- 3 To clear the display, open the **Calculator** menu, and select **Clear till roll**.

Manage certificates

Certificates are used when creating secure connections in, for example, web browser and mail. You can install, view, and delete certificates.

Certificates are used to authenticate the server or the user. Do not add new certificates unless you have verified that they are genuine. Adding arbitrary certificates may decrease the security of your encrypted connections.

User certificates are typically provided to you by your service provider or company IT department.

Select  > **Settings and Certificate manager**.

Draw sketches

Select  > **Sketch**.

To draw simple images, start drawing on the screen with your finger or with the stylus. All sketches are saved in the PNG file format.

Open the **Sketch** menu, and select from the following:

New — Start a new sketch.

Open — Open an existing sketch.

Save — Save a sketch.

Canvas size — Modify the canvas size.

Crop — Crop a sketch.

Details — View details of a sketch.

Drawing tools

Select from the following:

 — Draw freehand.

 — Draw straight lines.

 — Draw a rectangle.

 — Draw an ellipse or a circle.

 — Erase a line or shape. Select one of the four brush sizes from the toolbar, and draw over the area you want to erase.

To change the brush size or colour, select the respective selector icon from the toolbar.

Open X Terminal

X Terminal is an advanced application, with which you can use your device through a command line interface.

Select  > X Terminal.

Update software and install applications

About Application manager

Select  > App manager.

Application manager allows you to install new applications and other extensions from application catalogues (repositories). You can also list, update, and uninstall packages.

Important: Only install and use applications and other software from sources that you trust. Applications from untrusted sources may include malicious software that can access data stored in your device, cause financial harm, or damage your device.

About application packages and catalogues

Application manager works with packages that are generally contained in application catalogues, that you can access over a network connection.

An application package is a set of files. It can contain an application that you open from the Applications folder, a

plug-in for the desktop, a new theme, or other kinds of add-ons.

A catalogue is a set of packages. It can include different kinds of software combined as application packages. Certain packages can be shared by many applications. For the software to install successfully, the whole catalogue is needed. A list of available packages is saved in the device.

On some websites, you can install an application directly by selecting a link to a file with the .install file extension. Application manager opens, and installs the application. If a new catalogue is needed for the application, Application manager also offers to add it automatically.

View log

You can use the log to view event details and to diagnose unusual behaviour in the Application manager. The content of the log is deleted when you close the application.

Open the **Application manager** menu, and select **Log**.

Save the log

Select **Save as**, enter a name for the log, and define where you want to save it. The log is saved as a text file.

Install additional applications

Browse, search, and install applications

Select  > App manager and  Download.

108 Update software and install applications

Browse applications

Select a category to browse a list of installable application packages. If there are only a few packages available, the category list is not displayed.

The package list contains the name, version, and size of each package. When you select a package, a short description of its contents is displayed, and you can install, search, or view details of the package.

Search for an application

Using the physical keyboard, start entering a search word. Applications starting with the entered characters are displayed.

View application details

Select the application and **Details**.

Install an application

Select the application and **Continue**.

Show installed applications

Select  > **App manager** and  **Uninstall**.

You can search, sort, and view applications and their details in the same way as when browsing installable applications.

Uninstall applications

1 Select  > **App manager** and  **Uninstall**.

2 Select an application and **Uninstall**.

Once confirmed and started, the uninstallation process cannot be cancelled.

Add catalogues

View, install, and edit catalogues

You can view, install, edit, and delete catalogues. It may not be possible to edit or delete preinstalled catalogues.

Select  > **App manager**.

View available catalogues

Open the **Application manager** menu, and select **Application catalogues**. A list of catalogues is displayed. If refreshing a catalogue fails, select the catalogue name to view the details.

Install a catalogue

You can only install a catalogue's packages if the catalogue is installed on your device. If you select an .install file, for example, from a website, and the catalogue needed to fulfil all dependencies is not installed on your device, you are prompted to install the catalogue. If you cancel the installation, you will not be able to install any of the packages.

1 Open the **Application manager** menu, and select **Application catalogues > New**.

- 2 Define the catalogue name.
- 3 Define the web address, distribution, and components details, provided by the catalogue owner.
- 4 To enable or disable a catalogue, clear or select the **Disabled** check box. If you disable a catalogue, the device does not search for updates or software packages from it.
- 5 Select **Save**.

Edit a catalogue

You can edit the information of each catalogue. You can also disable a catalogue to hide its packages in the Application manager.

Certain essential catalogues only allow you to enable or disable the catalogue, you cannot edit any other information.

- 1 Open the **Application manager** menu, and select **Application catalogues** and the catalogue.
- 2 Edit the details.
- 3 To enable or disable a catalogue, clear or select the **Disabled** check box.

Restore application packages

If needed, you can replace the existing application packages with backup files you have previously created.

- 1 Select  > **App manager**.

- 2 Open the **Application manager** menu, and select **Restore applications**.
- 3 Select the applications to restore and **Yes**.

The applications are retrieved from catalogues, using a network connection.

Check for updates

To see a list of installed application packages that can be updated, select  > **App manager** and  **Update**. The list contains the name, version, and size of each package. When you select a package, a short description of its contents is displayed.

You can select the packages you want to update or update all available packages. You can also sort update packages in the same way as when browsing installable applications, or view application details.

To prevent any possible loss of data, back up your data before installing operating system updates.

Update software

Software updates may include new features and enhanced functions that were not available at the time of purchase of your device. Updating the software may also improve the device performance. You can update the software in your device with Application manager or with Nokia Software Updater.

110 Update software and install applications

Automatic software updates

When new software updates are available for the operating system or for Nokia or third party applications, or when there are additional applications available for your device,  is displayed in the status area.

It is recommended that you install software updates as they may contain important bug fixes and other updates. If you dismiss the suggested updates, you can later install them from the Application manager.

Downloading software updates may involve the transmission of large amounts of data (network service).

Make sure that the device battery has enough power, or connect the charger before starting the update.

Install software updates

- 1 Select the status area and **New updates**.
- 2 Select **Update all**, or select the packages to install and **Continue**.
- 3 Confirm the installation.

Install additional applications

- 1 Select the status area and **New releases**.
- 2 To open a web page with details of an additional application, select **Download**.

Check the version number of the software on your device

Select  > **Settings** and **About product**. Or, select  > **Phone** and  and enter *#0000#.

Most software updates can be installed with the Application manager. However, an update using Nokia Software Updater may sometimes be necessary. In this case, you receive a notification that a software update is available via Nokia Software Updater.

Software updates using your PC

Nokia Software Updater is a PC application that enables you to update your device software. To update your device software, you need a compatible PC, broadband internet access, and a compatible USB data cable to connect your device to the PC.

To get more information, to check the release notes for the latest software versions, and to download the Nokia Software Updater application, see www.nokia.com/softwareupdate, or in Latin America, www.nokia-latinoamerica.com/nsu.

Update the device software with the Nokia Software Updater

- 1 Download and install the Nokia Software Updater application to your PC.
- 2 Connect your device to the PC using a USB data cable, and open the Nokia Software Updater application. The Nokia

Software Updater application guides you to back up your files, update the software, and restore your files.

Play games

Blocks

The objective of the game is to move and rotate the falling blocks so that the rows are complete. When a row is complete, it disappears and the blocks above that row fall down one row.

Play Blocks

- 1 Select  and **Blocks**.
- 2 Select from the following:

Block speed — Define how fast the blocks fall down.

Starting density — Define the number of blocks that are randomly placed when the game starts.

Starting height — Define the number of rows at the bottom of the screen when the game starts.

- 3 Select **Play**.

Rotate a block

Tap the block, or press enter on the physical keyboard.

Move a block

Drag the block to the desired direction, or use the arrow keys on the physical keyboard.

Pause a game

Select **Exit to menu**.

Resume a paused game

Select **Continue**.

Restart a game

Select **Restart**.

The game is over when the game field is full of blocks, and the next falling block cannot fit.

Chess

Play Chess

- 1 Select  and **Chess**.
- 2 Select from the following:

Player 1 — Select black or white game pieces for the first player.

Opponent — Select the skill level of the computer opponent, or select **Player 2** for a two-player game.

Sound effects — Enable sound effects.

Show legal moves — See all possible legal moves when moving a chess piece.

- 3 Select **Play**.

To move a game piece, drag the piece to the desired location.

112 Play games

When you have successfully moved a pawn to your opponent's side of the game board, you can promote your pawn to queen, rook, knight, or bishop, according to standard chess rules.

When the chess game ends, you can return to the game and undo your last moves.

Undo or redo a move

Select  or .

Pause a game

Select .

Resume a paused game

Select Continue.

Restart a game

Select Restart.

Save a game

Open the menu, and select Save.

Open a saved game

Open the menu, and select Open and the desired game.

Mahjong

The objective of the game is to find matching pairs of game pieces and clear the whole board as fast as possible. You must

find a pair of identical game pieces that are free to move, that is, no other game piece is covering them, or lying to the left and right of them.

Play Mahjong

- 1 Select  and Mahjong.
- 2 To define the layout of the board, select Board.
- 3 To enable sound effects, select Sound effects.
- 4 Select Play.

When you find a matching pair, tap each game piece with the stylus to remove them from the board. When you successfully clear the board of game pieces, you win the game.

Undo or redo a move

Select  or .

Get a hint

Select . If you use a hint, the elapsed game time increases by 30 seconds.

Shuffle game pieces

Select . If you shuffle the remaining game pieces, the elapsed game time increases by 60 seconds.

Pause a game

Select .

Resume a paused game

Select **Continue**.

Restart a game

Select **Restart**.

View the best times

Select **Best times**. For each game level, you can view the best time and the date when it was achieved.

Marbles

The objective of the game is to match the marbles in the game area with the pattern and colour displayed on the right side of the screen.

Play Marbles

- 1 Select  and **Marbles**.
- 2 To define the number of allowed moves on each game level, select **Difficulty** level.
- 3 To enable sound effects, select **Sound effects**.
- 4 Select **Play**.

To move a marble, select it, and drag it with the stylus. You can move marbles horizontally and vertically. Once a marble is moving, it only stops when it bumps into a wall or another marble.

The lower right side of the game board contains the open chapters and levels. You can play any of the levels in the current chapter. When you complete all levels in a chapter, you can move on to the next one.

Undo a move

Select .

Pause a game

Select .

Resume a paused game

Select **Continue**.

Restart the current game level

Select **Restart**.

Install other games

In addition to the games that are pre-installed in your device, other games are available for you to install and play. You can search for and install new games using the Application manager.

Settings**Personalisation settings****Change themes**

A theme is a set of matching background images, one for each desktop.

114 Settings

- 1 Select  > Settings and Themes.
- 2 Select a theme from the list.

Profile settings

Select  > Settings and Profiles.

Set the device to vibrate when in the Silent or General profile

Select Vibrate.

Select the ringing tone and message alert tones

Select Ringing tone, SMS alert, IM tone, or E-mail alert and the desired tone.

Add a new ringing tone or message alert tone

Select the tone type, More, the desired tone, and Done.

Select the volume level of tones

Select System sounds, Key sounds, or Touch screen sounds and the desired volume level.

Adjust the volume of tones

Drag the slider right or left.

Date and time settings

Select  > Settings and Date and time.

Define date and time settings

- 1 To display the time in the 24 hour format, select 24-hr clock.
- 2 To update the date and time automatically, select Update automatically.

Set the date and time manually

- 1 Make sure the Update automatically check box is not selected.
- 2 Select Time zone, and select the desired time zone. To search for cities, select .
- 3 Select Date, and set the current day, month, and year.
- 4 Select Time, and set the current hour and minutes.

Language and regional settings

The language setting determines the language of the user interface and how the date and time are displayed. The regional setting determines how numbers and currencies are displayed.

Define language and regional settings

- 1 Select  > Settings and Language & region.
- 2 Define the device language and regional settings.
- 3 Save the settings, after which the device restarts.

Display settings

Select  > Settings and Display.

Define the following:

Brightness — Drag the slider right or left to change the brightness of the display. The display brightness is also affected by the ambient lighting conditions measured with the light sensor.

Backlight time-out — Select the period of inactivity, after which the display is turned off to save power.

Lock screen automatically — Set the device to automatically lock the touch screen and keys after a defined period of inactivity.

Display stays lit when charging — Set the display to always remain on when the device is charging.

Touch screen vibration — Set the display to give a short vibration feedback when touched.

Power saving mode — Set the device to consume less power when the display backlight is on.

Tip: To save the battery and increase the device operation time, select a low brightness level and a short time-out period.

Notification light settings

The device notification light can act as a status indicator for device and application-specific events. You can, for example, set the notification light to indicate that the device is switched on when the display is off.

Select  > **Settings and Notification light**, and select when to use the notification light.

Tip: To save the battery and increase the device operation time, deactivate the notification light.

Text input settings

Select  > **Settings and Text input**.

Select from the following:

Hardware keyboard layout — Define the character set used in the physical keyboard. Changing this setting may lead to the physical keys not matching the hardware keyboard layout.

Use virtual keyboard — Activate the virtual keyboard.

Word completion — Enable word completion.

Auto-capitalisation — Enable auto-capitalisation, to capitalise the first letter of sentences automatically when entering text.

Insert space after word — Insert a space after each accepted word completion.

1st language — Select the first language. To select a dictionary to use for the first language, select **Dictionary** and the dictionary language.

2nd language — Select the second language. To select a dictionary to use for the second language, select **Dictionary** and the dictionary language. When you switch to

116 Settings

the secondary language, the current dictionary for the word completion feature is also changed.

Use dual dictionaries — Use both language dictionaries at the same time.

Connectivity settings

Bluetooth settings

Select  > Settings and Bluetooth.

Select from the following:

Bluetooth on — Activate Bluetooth connectivity.

Visible — Allow your device to be found by other devices. If your device is hidden (not visible), it can only be connected to by a previously paired device.

My device's name — Enter a name for your device. This name is visible to other Bluetooth devices.

Tip: When searching for devices, some devices may show only the device address (IMEI address). To find the address of your device, select  > Phone and , and enter *#06#.

Location settings

Select  > Settings and Location.

GPS settings

Select from the following:

Enable — Activate the internal GPS receiver in your device. The GPS receiver is automatically activated when an application that uses GPS data is opened.

GPS device — Select the GPS receiver to use.

Pair new device — Pair an external GPS receiver with your device. Select the GPS receiver from the list of found devices.

Network positioning settings

Select from the following:

Enable — Activate the network-based positioning service (including A-GPS).

Location server — Enter the location server address.

FM transmitter settings

- 1 Select  > Settings and FM transmitter.
- 2 To activate the FM transmitter, select **FM transmitter on**.
- 3 To select the frequency, select **Frequency**.

Edit your sharing accounts

Select  > Settings and Sharing accounts. Select an account.

Ovi

Change the password

Enter the new password, and select **Save**.

Remove the account

Select **Delete**.

If you are editing the account details using your device, you cannot change your user name.

Flickr

Edit account details

Select **Edit**, and follow the instructions. Return to the account editing dialog, and select **Validate**.

Remove the account

Select **Delete**.

You can only edit your Flickr account details using the browser.

Internet connection settings

You can select which connections are used automatically, define how often connections are scanned for in the background, and set the device to switch to a saved WLAN connection when available.

Select  > **Settings and Internet connections** > **Connect automatically**.

Select a connection

Select whether you want to use a wireless LAN (WLAN) connection, a packet data connection, or whichever connection is available.

To select a connection each time you connect to the network, select **Always ask**.

Define the frequency of automatic connection attempts

Select **Search interval**. The default value is 10 minutes.

Switch to a WLAN when available

If you want your device to use a saved WLAN connection instead of a packet data connection when such a WLAN is available, select **Switch to WLAN when available**.

Modify phone settings

Call settings

Select  > **Settings and Phone** > **Call**.

Define the following:

Send my caller ID — Set your phone number to be visible to the recipient.

Call waiting — Activate the call waiting service.

Call forwarding — Define the phone number to which the incoming calls are forwarded if you do not answer. To forward calls to a specific phone number or to a contact from your contacts list, select **Forward to** or **Select contact**.

Network settings

Your device can automatically switch between GSM and 3G networks.

In the status area, the current network is indicated with the following icons:

2G	GSM
2.5G	EDGE
3G	3G
3.5G	HSPA

To modify network settings, select  > **Settings** and **Phone** > **Network**.

Select the service provider's network

By default, your device selects the network automatically. To select the network manually, select **Manual** and a network.

Select network mode

Select which network to use. If you select **Dual**, the device uses the GSM or 3G network automatically, according to the network availability, parameters, and the roaming agreements between network service providers. For further information, contact your network service provider.

You cannot change the network mode, if a packet data connection is active. Disconnect the packet data connection or switch to a wireless LAN (WLAN) connection before changing the network mode.

Roaming is based on specific roaming agreements between your network service provider and other network service providers, to enable you to use network services outside your home network, for example when travelling abroad.

Define data roaming settings

Always ask is selected by default. A connection is only attempted when a confirmation note is accepted. If you select **Always allow**, all packet data connections abroad are handled as in the home network.

For further information and roaming costs, contact your network service provider.

View transferred data details

Select **Home network data counter**. To clear the details and reset the counter, select **Clear**.

SIM card settings

Select  > **Settings and Phone** > **SIM card**.

Select from the following:

PIN code request — Set the device to request the PIN code when the device is switched on.

PIN code — Set the PIN code.

General settings

Device lock settings

Select  > Settings and Device lock.

Define the following:

Autolock — Select the length of time, after which the device is locked if not used.

Change lock code — Enter the current lock code (12345 by default) and the new code twice.

View memory consumption

You can view the amount of available memory in the device memory or on the memory card, and the amount of memory available for installing applications.

Select  > Settings and Memory.

To view the memory consumption in more detail, select Details.

To increase the amount of available memory, use File manager or other applications to delete data.

TV-out settings

- 1 Select  > Settings and TV out.
- 2 Select PAL (default, used in Europe, for example) or NTSC (used in North America, for example).
- 3 Select Save.

Calibrate the screen

Select  > Settings and Screen calibration, and follow the instructions.

View information about your device

Select  > Settings and About product.

The available information includes:

- Device model
- Platform name and release
- Software version
- WLAN MAC address
- Bluetooth address
- IMEI address
- Applicable licences
- Other important information about your device

Third party application settings

When you install additional applications, the applications may automatically add an applet icon to the Settings folder. By default, the icons are added to the Extras group.

Select  > Settings and the application, and define the desired settings.

Tips and troubleshooting

Basic tips for using your device

Lock your device

Press the power key twice.

Go to the desktop

Select and hold .

Search for a contact

On the desktop, using the physical keyboard, start entering a name.

Open the virtual keypad to make a call

On the desktop, using the physical keyboard, start entering a phone number. To enter a number, press and hold  and then press the key that has the number printed at the top of it.

Silence an incoming call

Turn the device face down.

Snooze an alarm

Turn the device face down.

Advanced tips for using your device

Open a contact card from a conversation

Select the avatar of the person. This is useful, for example, if you want to call a friend you have just had a text message conversation with.

Search for an application

Select  Using the physical keyboard, start entering the application name. Select the application from the proposed matches.

Open a web link in a new window

Press and hold the ctrl key, and then select the link.

Use the keyboard to scroll up or down on a web page

To scroll down, press the space key. To scroll up, press and hold the shift key, and then press the space key.

Zoom in or out a mail message, image, web page, or camera

Use the volume keys.

For web pages, zooming with volume keys must be activated in the web settings.


View the previous or following day, week, or month in the Calendar application

1 Select  > Calendar, and open the menu.

- 2 Select Month or Week. To view a particular day, select the day in the Month or Week view.
- 3 Swipe left or right in the selected view.

Copy text from a web page, text message, or instant message

- 1 To activate selection mode, drag your finger from the left of the touch screen onto the screen, and select .



- 2 Drag your finger on the text to select.
- 3 Press **ctrl + C**.

Copy text from a text input field, mail message, or note

- 1 Tap the text at the point where you want to start selecting.
- 2 Press and hold the shift key, and to select the text, use the arrow keys on the physical keyboard.
- 3 Press **ctrl + C**.

View the current song and current playlist in the Media player application

Select  > Media player and 

Format your memory card

Select  > File manager, select and hold the memory card, and from the pop-up menu, select **Format**.

Shortcuts

Here are some of the available keyboard shortcuts in your device. Shortcuts can make the use of applications more efficient.

General shortcuts

Ctrl + C	Copy text.
Ctrl + V	Paste text.
Ctrl + X	Cut text.
Ctrl + A	Select all.
Ctrl + O	Open (if available).
Ctrl + N	Create a new item (if available).
Ctrl + S	Save (if available).

122 Tips and troubleshooting

Ctrl + Z	Undo (if available).
Ctrl + Y	Redo (if available).
Ctrl + F	Open search bar (if available).
Ctrl + Right arrow	Move the insertion point to the end of the word.
Ctrl + Left arrow	Move the insertion point to the beginning of the word.
Ctrl + Backspace	Open the dashboard.
Ctrl + Shift + P	Take a screenshot of the current display. To view the screenshot, open the Photos application.
Ctrl + Shift + X	Open X Terminal.
Ctrl + Space	Switch between input languages (virtual keyboard character set and dictionary).

Web browser shortcuts

Ctrl + N	Open a new window.
Ctrl + R	Reload the page.
Ctrl + B	Open a bookmark.
Ctrl + D	Add a bookmark.

Ctrl + L	Move the cursor to the web address field.
Backspace	Go to the previous web page.
Space	Scroll down on a web page.
Shift + Space	Scroll up on a web page.
Shift + Up arrow	Scroll to the top of a web page.
Shift + Down arrow	Scroll to the bottom of a web page.
Ctrl + Shift + O	Activate or deactivate automatic display rotation when browsing the web. When activated, the display switches to portrait mode when you turn your device to portrait orientation.

Mail shortcuts

Ctrl + Enter	Send a message.
Ctrl + R	Reply to a message.

Media player shortcuts

Left arrow	Skip to the previous song, video clip, or internet radio station.
------------	---

Right arrow	Skip to the next song, video clip, or internet radio station.
Space	Pause or resume playback.

RSS Reader shortcut

Ctrl + R	Refresh the feed.
----------	-------------------

X Terminal shortcut

Ctrl + I	Autocomplete the command, if there is only one option, or show all available options. Corresponds to the tab icon in the X Terminal application.
----------	--

Troubleshooting

Q: What is my password for the PIN or PUK codes?

A: If you forget a PIN or PUK code, or if you have not received such a code, contact your network service provider.

For information about passwords, contact your access point provider, for example, a commercial internet service provider (ISP) or network service provider.

Q: What should I do if I start my device for the first time and nothing appears on the display?

A: Make sure that the battery is inserted properly, the power cord is attached to the device, and the power is switched on. Try to restart the device. If this does not help, contact your device dealer.

Q: Why can't my device establish a GPS connection?

A: Establishing a GPS connection may take from a couple of seconds to several minutes. Establishing a GPS connection in a vehicle may take longer. If you are indoors, go outdoors to receive a better signal. If you are outdoors, move to a more open space. Ensure that your hand does not cover the GPS antenna of your device. If the weather conditions are bad, the signal strength may be affected. Some vehicles have tinted (athermic) windows, which may block the satellite signals.

Q: Why can't I find my friend's device while using Bluetooth connectivity?

A: Check that both devices are compatible, have activated Bluetooth connectivity, and are not in hidden mode. Check also that the distance between the two devices is not over 10 metres (33 feet) and that there are no walls or other obstructions between the devices.

124 Tips and troubleshooting

Q: How can I close a Bluetooth connection?

A: To close an active Bluetooth connection, select the status area and **Bluetooth > Devices**, and select the device and **Edit > Disconnect**. If another device is connected to your device, you can also close the connection from the other device.

To deactivate Bluetooth connectivity, select the status area and **Bluetooth**, and clear the **Bluetooth** on check box.

Q: Why can't I see a wireless LAN (WLAN) access point even though I know I'm within its range?

A: The WLAN access point may use a hidden service set identifier (SSID). You can only access networks that use a hidden SSID if you know the correct SSID, and have created a WLAN internet access point for the network on your device.

Q: How do I deactivate the wireless LAN (WLAN) on my device?

A: Select the status area and **Internet connection**, and disconnect the WLAN connection.

Q: How can I send MMS messages?

A: You cannot send or receive multimedia messages (MMS) with your device, but you can send your multimedia files through mail or Bluetooth connectivity, or upload them to internet services, such as Nokia Ovi or Flickr.

Q: How do I know which software version is used in my device?

A: Select  > **Settings and About product**.

Q: How do I find my WLAN MAC address?

A: Select  > **Settings and About product**.

Q: How can I create a new profile in my device?

A: You cannot create new profiles, but you can edit the existing profiles (general and silent). Select  > **Settings and Profiles**.

Q: I had used Nokia PC Suite to synchronise my calendar. When I synchronised my calendar using Mail for Exchange, I had duplicate calendar entries. How do I remove the duplicates?

- 1 In the Mail for Exchange settings, deactivate calendar synchronisation.

If you do not deactivate calendar synchronisation before removing your calendar entries from your device, the entries are also removed from the server during the next synchronisation, and they cannot be synchronised back to your device.

- 2 Remove all calendar entries from your device.
- 3 In the Mail for Exchange settings, activate calendar synchronisation. The calendar is synchronised from the server back to your device during the next synchronisation.

Product and safety information

Open source software notice

This product includes certain free/open source software.

The exact terms of the licenses, disclaimers, acknowledgements and notices are provided to you in the product. You may obtain the source code of the relevant free and open source software at <http://www.maemo.org/>. Alternatively, Nokia offers to provide such source code to you on a CD-ROM for a charge covering the cost of performing such distribution, such as the cost of media, shipping and handling, upon written request to Nokia at:

Maemo Source Code Requests

Nokia Corporation

P.O.Box 407

FI-00045 Nokia Group

Finland

This offer is valid for a period of three (3) years from the date of the distribution of this product by Nokia.

This software is based in part on the work of the Independent JPEG Group.

The Graphics Interchange Format® is the Copyright property of CompuServe Incorporated. GIF(sm) is a Service Mark property of CompuServe Incorporated.

Adobe® Flash® Player. Copyright (c) 1996 - 2007 Adobe Systems Incorporated. All Rights Reserved. Protected by U.S. Patent 6,879,327; Patents Pending in the United States and other countries. Adobe and Flash are either trademarks or registered trademarks in the United States and/or other countries.

This product includes software developed by following copyrightholders:

- Computing Services at Carnegie Mellon University (<http://www.cmu.edu/computing/>)
- Tommi Komulainen (Tommi.Komulainen@iki.fi)
- The OpenSSL Project for use in the OpenSSL Toolkit (<http://www.openssl.org>)
- Pedro Roque Marques
- Eric Rosenquist, Srata Software Limited
- The XFree86 Project, Inc (<http://www.xfree86.org>) and its contributors
- Paul mackerras (paulus@samba.org)
- Purdue Research Foundation
- OpenEvidence Project for use in the OpenEvidence Toolkit (<http://www.openevidence.org/>)
- Eric Young (easy@cryptsoft.com)
- Tim Hudson (tjh@cryptsoft.com)

126 Product and safety information

Copyright (c) 1996 NVIDIA, Corp. NVIDIA design patents pending in the U.S. and foreign countries.

NVIDIA, CORP. MAKES NO REPRESENTATION ABOUT THE SUITABILITY OF THIS SOURCE CODE FOR ANY PURPOSE. IT IS PROVIDED "AS IS" WITHOUT EXPRESS OR IMPLIED WARRANTY OF ANY KIND. NVIDIA, CORP. DISCLAIMS ALL WARRANTIES WITH REGARD TO THIS SOURCE CODE, INCLUDING ALL IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE. IN NO EVENT SHALL NVIDIA, CORP. BE LIABLE FOR ANY SPECIAL, INDIRECT, INCIDENTAL, OR CONSEQUENTIAL DAMAGES, OR ANY DAMAGES WHATSOEVER RESULTING FROM LOSS OF USE, DATA OR PROFITS, WHETHER IN AN ACTION OF CONTRACT, NEGLIGENCE OR OTHER TORTIOUS ACTION, ARISING OUT OF OR IN CONNECTION WITH THE USE OR PERFORMANCE OF THIS SOURCE CODE.

Accessories

Warning:

Use only batteries, chargers, and accessories approved by Nokia for use with this particular model. The use of any other types may invalidate any approval or warranty, and may be dangerous. In particular, use of unapproved chargers or batteries may present a risk of fire, explosion, leakage, or other hazard.

For availability of approved accessories, please check with your dealer. When you disconnect the power cord of any accessory, grasp and pull the plug, not the cord.

Battery

Battery and charger information

Your device is powered by a rechargeable battery. The battery intended for use with this device is BL-5J. Nokia may make additional battery models available for this device. This device is intended for use when supplied with power from the following chargers: AC-10. The exact charger model number may vary depending on the type of plug. The plug variant is identified by one of the following: E, EB, X, AR, U, A, C, K, or UB.

The battery can be charged and discharged hundreds of times, but it will eventually wear out. When the talk and standby times are noticeably shorter than normal, replace the battery. Use only Nokia approved batteries, and recharge your battery only with Nokia approved chargers designated for this device.

If a battery is being used for the first time or if the battery has not been used for a prolonged period, it may be necessary to connect the charger, then disconnect and reconnect it to begin charging the battery. If the battery is completely discharged, it may take several minutes before the charging indicator appears on the display or before any calls can be made.

Safe removal. Always switch the device off and disconnect the charger before removing the battery.

Proper charging. Unplug the charger from the electrical plug and the device when not in use. Do not leave a fully charged battery connected to a charger, since overcharging may shorten its lifetime. If left unused, a fully charged battery will lose its charge over time.

Avoid extreme temperatures. Always try to keep the battery between 15°C and 25°C (59°F and 77°F). Extreme temperatures reduce the capacity and lifetime of the battery. A device with a hot or cold battery may not work temporarily. Battery performance is particularly limited in temperatures well below freezing.

Do not short-circuit. Accidental short-circuiting can occur when a metallic object such as a coin, clip, or pen causes direct connection of the positive (+) and negative (-) terminals of the battery. (These look like metal strips on the battery.) This might happen, for example, when you carry a spare battery in your pocket or purse. Short-circuiting the terminals may damage the battery or the connecting object.

Disposal. Do not dispose of batteries in a fire as they may explode. Dispose of batteries according to local regulations. Please recycle when possible. Do not dispose as household waste.

Leak. Do not dismantle, cut, open, crush, bend, puncture, or shred cells or batteries. In the event of a battery leak, prevent battery liquid contact with skin or eyes. If this happens, flush the affected areas immediately with water, or seek medical help.

Damage. Do not modify, remanufacture, attempt to insert foreign objects into the battery, or immerse or expose it to water or other liquids. Batteries may explode if damaged.

Correct use. Use the battery only for its intended purpose. Improper battery use may result in a fire, explosion, or other hazard. If the device or battery is dropped, especially

on a hard surface, and you believe the battery has been damaged, take it to a service centre for inspection before continuing to use it. Never use any charger or battery that is damaged. Keep your battery out of the reach of small children.

Nokia battery authentication guidelines

Always use original Nokia batteries for your safety. To check that you are getting an original Nokia battery, purchase it from a Nokia authorised service centre or dealer, and inspect the hologram label using the following steps:

Authenticate hologram

- 1 When you look at the hologram on the label, you should see the Nokia connecting hands symbol from one angle and the Nokia Original Enhancements logo when looking from another angle.



- 2 When you angle the hologram left, right, down and up, you should see 1, 2, 3 and 4 dots on each side respectively.



Successful completion of the steps is not a total assurance of the authenticity of the battery. If you cannot confirm authenticity or if you have any reason to believe that your Nokia battery with the hologram on the label is not an authentic Nokia battery, you should refrain from using it, and take it to the nearest Nokia authorised service centre or dealer for assistance.

For additional information, refer to the warranty and reference leaflet included with your Nokia device.

Taking care of your device

Your device is a product of superior design and craftsmanship and should be treated with care. The following suggestions will help you protect your warranty coverage.

- Do not use or store the device in dusty, dirty areas. Its moving parts and electronic components can be damaged.
- Do not store the device in high or cold temperature. High temperatures can shorten the life of electronic devices, damage batteries, and warp or melt certain plastics. When the device warms to its normal temperature from a cold temperature, moisture can form inside the device and damage electronic circuit boards.
- Do not attempt to open the device other than as instructed in this guide.
- Do not drop, knock, or shake the device. Rough handling can break internal circuit boards and fine mechanics.

128 Product and safety information

- Do not use harsh chemicals, cleaning solvents, or strong detergents to clean the device. Only use a soft, clean, dry cloth to clean the surface of the device.
- Do not paint the device. Paint can clog the moving parts and prevent proper operation.
- Use only the supplied or an approved replacement antenna. Unauthorised antennas, modifications, or attachments could damage the device and may violate regulations governing radio devices.
- Use chargers indoors.
- Backup all data you want to keep, such as contacts and calendar notes.
- To reset the device from time to time for optimum performance, power off the device and remove the battery.

These suggestions apply equally to your device, battery, charger, or any accessory.

Recycle

Always return your used electronic products, batteries, and packaging materials to dedicated collection points. This way you help prevent uncontrolled waste disposal and promote the recycling of materials. Check product environmental information and how to recycle your Nokia products at www.nokia.com/werecycle, or nokia.mobi/werecycle.

Additional safety information

Small children

Your device and its accessories are not toys. They may contain small parts. Keep them out of the reach of small children.

Operating environment

This device meets RF exposure guidelines in the normal use position at the ear or at least 2.2 centimetres (7/8 inch) away from the body. Any carry case, belt clip, or holder for body-worn operation should not contain metal and should position the device the above-stated distance from your body.

To send data files or messages requires a quality connection to the network. Data files or messages may be delayed until such a connection is available. Follow the separation distance instructions until the transmission is completed.

Parts of the device are magnetic. Metallic materials may be attracted to the device. Do not place credit cards or other magnetic storage media near the device, because information stored on them may be erased. Your device contains sensors that use magnets. External magnets may affect the operation of the device.

Medical devices

Operation of radio transmitting equipment, including wireless phones, may interfere with the function of inadequately protected medical devices. Consult a physician or the manufacturer of the medical device to determine whether they are adequately shielded from external RF energy. Switch off your device when regulations posted instruct you to do so. Hospitals or health care facilities may use equipment sensitive to external RF energy.

Implanted medical devices

Manufacturers of medical devices recommend a minimum separation of 15.3 centimetres (6 inches) between a wireless device and an implanted medical device, such as a pacemaker or implanted cardioverter defibrillator, to avoid potential interference with the medical device. Persons who have such devices should:

- Always keep the wireless device more than 15.3 centimetres (6 inches) from the medical device.
- Not carry the wireless device in a breast pocket.
- Hold the wireless device to the ear opposite the medical device.
- Turn the wireless device off if there is any reason to suspect that interference is taking place.
- Follow the manufacturer directions for the implanted medical device.

If you have any questions about using your wireless device with an implanted medical device, consult your health care provider.

Hearing aids

Some digital wireless devices may interfere with some hearing aids.

Your mobile device model complies with FCC rules governing hearing aid compatibility. These require a M3 microphone or higher value. Your device M-value is shown on the box. A higher M-value generally indicates that a device model has a lower RF emissions level,

which may improve the likelihood that the device will operate with certain hearing aids. Some hearing aids are more immune than others to interference. Please consult your hearing health professional to determine whether your hearing aid will work with this device. More information on accessibility can be found at www.nokiaaccessibility.com.

Vehicles

RF signals may affect improperly installed or inadequately shielded electronic systems in motor vehicles such as electronic fuel injection, electronic antilock braking, electronic speed control, and air bag systems. For more information, check with the manufacturer of your vehicle or its equipment.

Only qualified personnel should service the device or install the device in a vehicle. Faulty installation or service may be dangerous and may invalidate your warranty. Check regularly that all wireless device equipment in your vehicle is mounted and operating properly. Do not store or carry flammable liquids, gases, or explosive materials in the same compartment as the device, its parts, or accessories. Remember that air bags inflate with great force. Do not place your device or accessories in the air bag deployment area.

Switch off your device before boarding an aircraft. The use of wireless teledevices in an aircraft may be dangerous to the operation of the aircraft and may be illegal.

Potentially explosive environments

Switch off your device in any area with a potentially explosive atmosphere. Obey all posted instructions. Sparks in such areas could cause an explosion or fire resulting in bodily injury or death. Switch off the device at refuelling points such as near gas pumps at service stations. Observe restrictions in fuel depots, storage, and distribution areas; chemical plants; or where blasting operations are in progress. Areas with a potentially explosive atmosphere are often, but not always, clearly marked. They include areas where you would be advised to turn off your vehicle engine, below deck on boats, chemical transfer or storage facilities and where the air contains chemicals or particles such as grain, dust, or metal powders. You should check with the manufacturers of vehicles using liquefied petroleum gas (such as propane or butane) to determine if this device can be safely used in their vicinity.

The surface of this device is nickel-free.

Emergency calls

Before making an emergency call, switch the device on, and check for adequate signal strength. If the screen and keys are locked, slide the lock switch on the side of the device to unlock them.

Important: This device operates using radio signals, wireless networks, landline networks, and user-programmed functions. Emergency calls can be made using the cellular phone. It is not possible to make an emergency call using voice calls over the internet (internet calls). Connections in all conditions cannot be guaranteed. You should never rely solely on any wireless device for essential communications like medical emergencies.

Make an emergency call

- 1 Select  > Phone.
- 2 Select  and the cellular call type.
- 3 Enter the official emergency number for your present location.
- 4 Select  to start the call.

Make an emergency call without entering PIN, PUK, or lock code

- 1 When the device asks for the code, enter the emergency number for your present location. The  Emergency call icon appears.
- 2 Select  Emergency call to make the call. After the emergency call, you need to enter the required PIN, PUK, or lock code to be able to use other device functions.

When making an emergency call, give all the necessary information as accurately as possible. Your wireless device may be the only means of communication at the scene of an accident. Do not end the call until given permission to do so.

Certification information (SAR)

This mobile device meets guidelines for exposure to radio waves.

Your mobile device is a radio transmitter and receiver. It is designed not to exceed the limits for exposure to radio waves recommended by international guidelines. These guidelines were developed by the independent scientific organisation ICNIRP and include

130 Product and safety information

safety margins designed to assure the protection of all persons, regardless of age and health.

The exposure guidelines for mobile devices employ a unit of measurement known as the Specific Absorption Rate or SAR. The SAR limit stated in the ICNIRP guidelines is 2.0 watts/kilogram (W/kg) averaged over 10 grams of tissue. Tests for SAR are conducted using standard operating positions with the device transmitting at its highest certified power level in all tested frequency bands. The actual SAR level of an operating device can be below the maximum value because the device is designed to use only the power required to reach the network. That amount changes depending on a number of factors such as how close you are to a network base station.

The highest SAR value under the ICNIRP guidelines for use of the device at the ear is 0.61 W/kg.

Use of device accessories may result in different SAR values. SAR values may vary depending on national reporting and testing requirements and the network band. Additional SAR information may be provided under product information at www.nokia.com.

Your mobile device is also designed to meet the requirements for exposure to radio waves established by the Federal Communications Commission (USA) and Industry Canada. These requirements set a SAR limit of 1.6 W/kg averaged over one gram of tissue. The highest SAR value reported under this standard during product certification for use at the ear is 0.79 W/kg and when properly worn on the body is 1.03 W/kg.

DECLARATION OF CONFORMITY

CE 0434 !

Hereby, NOKIA CORPORATION declares that this RX-51 product is in compliance with the essential requirements and other relevant provisions of Directive 1999/5/EC. A copy of the Declaration of Conformity can be found at http://www.nokia.com/phones/declaration_of_conformity/.

Nokia, Nokia Connecting People, Nseries, N900 and Ovi are trademarks or registered trademarks of Nokia Corporation. Nokia tune is a sound mark of Nokia Corporation. Other product and company names mentioned herein may be trademarks or tradenames of their respective owners.

Reproduction, transfer, distribution, or storage of part or all of the contents in this document in any form without the prior written permission of Nokia is prohibited. Nokia operates a policy of continuous development. Nokia reserves the right to make changes and improvements to any of the products described in this document without prior notice.

Portions of the Nokia Maps software are ©1996-2009 The FreeType Project. All rights reserved.

This product is licensed under the MPEG-4 Visual Patent Portfolio License (i) for personal and noncommercial use in connection with information which has been encoded in compliance with the MPEG-4 Visual Standard by a consumer engaged in a personal and noncommercial activity and (ii) for use in connection with MPEG-4 video provided by a licensed video provider. No license is granted or shall be implied for any other use. Additional information, including that related to promotional, internal, and commercial uses, may be obtained from MPEG LA, LLC. See <http://www.mpegl4.com>.

TO THE MAXIMUM EXTENT PERMITTED BY APPLICABLE LAW, UNDER NO CIRCUMSTANCES SHALL NOKIA OR ANY OF ITS LICENSORS BE RESPONSIBLE FOR ANY LOSS OF DATA OR INCOME OR ANY SPECIAL, INCIDENTAL, CONSEQUENTIAL OR INDIRECT DAMAGES HOWSOEVER CAUSED.

THE CONTENTS OF THIS DOCUMENT ARE PROVIDED "AS IS". EXCEPT AS REQUIRED BY APPLICABLE LAW, NO WARRANTIES OF ANY KIND, EITHER EXPRESS OR IMPLIED, INCLUDING,

BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, ARE MADE IN RELATION TO THE ACCURACY, RELIABILITY OR CONTENTS OF THIS DOCUMENT. NOKIA RESERVES THE RIGHT TO REVISE THIS DOCUMENT OR WITHDRAW IT AT ANY TIME WITHOUT PRIOR NOTICE.

Reverse engineering of software in the device is prohibited to the extent permitted by applicable law. Insofar as this user guide contains any limitations on Nokia's representations, warranties, damages and liabilities, such limitations shall likewise limit any representations, warranties, damages and liabilities of Nokia's licensors. The availability of particular products and applications and services for these products may vary by region. Please check with your Nokia dealer for details and availability of language options. This device may contain commodities, technology or software subject to export laws and regulations from the US and other countries. Diversion contrary to law is prohibited.

FCC/INDUSTRY CANADA NOTICE

Your device may cause TV or radio interference (for example, when using a telephone in close proximity to receiving equipment). The FCC or Industry Canada can require you to stop using your telephone if such interference cannot be eliminated. If you require assistance, contact your local service facility. This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. Any changes or modifications not expressly approved by Nokia could void the user's authority to operate this equipment.

© 2010 Nokia. All rights reserved.

/Issue 1 EN

Index**Symbols/Numbers**

92, 116

A

A-GPS (assisted GPS)	91
access codes	8
accounts	55, 60, 62, 82
alarm clock	96
answering calls	54
antennas	19
applications	21, 107, 108, 109
attachments	68
availability status	50, 61
avatar	61

B

background image	32
backing up data	101
battery	9
— charging	12
— inserting	10
blogs	104, 105
Bluetooth	39, 40, 83, 116
bookmarks	43, 89

browser	41, 44, 45, 46
— bookmarks	43, 44
— browsing pages	41
— cache memory	44
— downloads	45
— security	44
— settings	47
— toolbar	43
business cards	59, 60

C

cable connection	41
calculator	106
calendar	97, 98, 99
calls	52, 57
— answering	54
— making	53
— settings	52, 117
camera	
— capturing images	75, 76
— flash	79
— image mode	75, 78
— indicators	74, 76
— location information	75
— scenes	77
— settings	78, 79
— video mode	76, 77, 78
certificates	106

chat services (IM)	55, 60, 61, 62
clock	96
conference calls	54
connectivity	32, 34, 38, 117
connectors	15
contacts	49, 50, 51, 59, 60
— adding	48
— editing	48
— sending	51
— settings	51
— synchronising	50
conversations	58, 62

D

data connections	
— cable	41
— internet access	41
date and time	114
desktop	20, 30
device	
— locking	119
dictionary	29
display settings	114, 119
DTMF tones	55

E

e-mail	
See <i>mail</i>	

E
EAP (Extensible Authentication Protocol) 35, 37

F
File manager 101, 102
Flickr 83, 116
FM transmitter 87, 88, 116

G
games 111, 112, 113
geotagging 75, 81
GPS (global positioning system) 91, 92, 116

H
headset 17
HSPA (high-speed packet access) 37

I
IM (instant messaging) 55, 60, 61, 62
images 79, 80, 81
indicators 22, 74, 76
installing applications 107
internet calls 55, 56
internet connection 32
internet radio 89, 90

K
keyguard 30
keypad lock 30
keys 13, 14, 15
kickstand 16

L
language settings 32, 114
location information 92, 116
lock code 8, 15, 29
logs 107

M
mail 63, 68
— accounts 64, 70
— attachments 68
— creating 67
— deleting 69
— folders 69
— message settings 68
— Nokia Messaging 71
— reading 66
— retrieving 66
— searching 69
— sending 67
— settings 71, 73
— setup 64
Mail for Exchange 63, 65, 69, 72

M
Maps 92
— browsing 93
— display elements 93
— finding locations 94
— modifying views 94
— route planning 95
— settings 95

media 90
media player 84, 85, 89, 90
— internet radio 89, 90
— music 85, 86, 87
— playlists 86, 87
— video clips 88, 89
memory 102, 103
— consumption rate 103, 119
memory card 11, 102, 103, 119
messages 62
— settings 62
modem 41
music 85, 86, 87
My information 50

N
navigation tools 92, 116
See also *Maps*
network settings 32, 118
news 105

news feeds	104
Nokia account	83, 116
Nokia Messaging	63, 71
Nokia support information	8
notes	98, 105
notification light	20, 115

0	
Ovi	30, 83, 116
Ovi Store	30

P	
packet data connection	37, 38
pairing devices	39
PDF reader	105
Photos	81
physical keyboard	26
PIN code	8, 15
playlists	86, 87
positioning information	92, 116
powering device on/off	15
profiles	31, 114
proximity sensor	53
proxy settings	36
PUK codes	8

R	
recording	
— video	77
regional settings	114
restoring data	101, 109
restoring settings	79, 104
ringing tones	86
roaming	32, 118
RSS	104, 105

S	
screen settings	114, 119
searching	
— mail	69
security	
— settings	35
settings	
— calendar	99
— calls	117
— clock	96
— connectivity	36
— display	114
— IM (instant messaging)	62
— mail	71
— messages	62
— network	32, 118
— packet data	37, 38
— restoring	104

— video	78
— WLAN	35, 36, 37
sharing	82, 83
shortcuts	121
signature	68
SIM card	118
— inserting	10
sketch	106
slide show	79, 80
software updates	110
songs	85, 87
support	8
switching device on/off	15
synchronisation	69, 99, 100

T	
tags	81, 82
text input	26, 27, 28, 115
text messages	59
— settings	62
themes	32, 113
time and date	114
timers	57
tones	31, 114
touch screen	24, 53
transferring	
— data	99, 100
troubleshooting	123

turning device on/off	15	WPA security	35
TV-out	80, 89, 119	wrist strap	18

U

updates	
— applications	109
— device software	110
USB cable connection	41
USB charging	12

V

video	
— recording	77
video calls	56
video clips	77, 78, 88, 89
virtual keyboard	27
VoIP	
See <i>internet calls</i>	
volume control	20

W

web connection	32
See also <i>browser</i>	
WEP security	35
widgets	70, 85, 99, 105
WLAN (wireless local area network)	33, 34, 36, 37, 38
word completion	29

D
R
A
F
T