



# Operators Manual for the P25 Base Tech III Base/Repeater Station



October 2008  
Version 5.0  
680-090-2042



## Introduction

We thank you for choosing the Midland P25 Base Tech III Base/Repeater Station to meet your communication needs. Properly used, this product will give you many years of reliable service. To get the most out of your purchase, be sure to carefully read this manual before operating the radio.

The overall operation of this radio depends entirely on how it has been programmed. If it is not functioning as desired, please check the programming first.

### **This manual covers up to firmware version 71BS241**

If you should need Midland Technical Support, please call 1-816-462-0463 or [lmrservice@midlandradio.com](mailto:lmrservice@midlandradio.com)

Other useful Midland numbers;

Main Line- 816-241-8500

Main Fax- 816-241-5713

LMR Sales- 816-462-0462

Credit Dept- 816-462-0464

Technical Support and Engineering Fax- 816-241-3272

Warranty Service- 816-462-0438

We welcome any comments on how we may improve our products to better server our customers.

---

**WARNING:** The antenna(s) used for this transmitter must be fixed-mounted on outdoor permanent structures with a separation distance of at least 6 meters from all persons during normal operation. The peak conducted output power at each antenna terminal must not exceed 250 Watts and the peak radiated output power must not exceed 1000 Watts EIPR. Users and installers must ensure that FCC requirements for satisfying RF exposure compliance are met. (See FCC Rules Part 1, Sections 1307 and 1310)

**NOTICE:** The AMBE+2™ voice coding Technology embodied in this product is protected by intellectual property rights including patent rights, copyrights and trade secrets of Digital Voice Systems, Inc. This voice coding Technology is licensed solely for use within this Communications Equipment. The user of this Technology is explicitly prohibited from attempting to extract, remove, decompile, reverse engineer or disassemble the Object Code, or in any other way convert the Object Code into a human readable form. U.S. Patents Nos. #5,870,405, #5,826,222, #5,754,974 #5,701,390, #5,715,365, #5,649,050, #5,630,011, #5,581,656, #5,517,511, #5,491,772, #5,247,579, #5,226,084 and #5,195,166.

## Table of Contents

	Page
1. LCD Display	4
2. LED Display	4
3. Key Controls	5
4. Programming	6
5. Control Knob	6
6. Channel Selection	7
7. P25 Calling Selection	8
8. P25 PTT Mode	9
9. P25 Conventional Messages	10
10. P25 Squelch Adjustment	16
11. Talk Group ID Alias	16
12. Key lock	17
13. Manual CWID Start/Stop	18
14. DTMF Encode	18
15. Analog Channel Data	19
16. P25 Channel Data	19
17. Bar Graph/Channel Display	20
18. LCD Backlight Toggle	20
19. Changing TX Power	21
20. Caller ID	21
21. Emergency Call Reception	22
22. Repeat Mode	22
23. Base Mode	23
24. Remote Control	23
25. P25 Test Mode	24
26. Adjustment Mode	26
27. Key Test	28
28. Displaying Firmware Version	29
29. Displaying Serial Number	29
30. Displaying Program Software Ver	30
31. Data Check	30
32. Error Messages	31
33. Firmware Error Detection	31
34. RS232 Error Detection	31
35. DSP Error Detection	32
36. Option Port Pinout	33

## 1. LCD DISPLAY

1.1 LCD display consists of 4 x 20 characters as shown.

Line 1: The Incoming RSSI with 10 steps

Line 2: The output power levels with 10 steps

Line 3: The left 4 letters show channel numbers. The middle 8 letters shows the channel name (if not programmed, it will be blank).

The right 4 letters displays the status of the radio as described below.

a. RX mode: M= Mix, both analog and digital can be received

D= Only digital can be received.

b. TX mode: D=PTT digital transmission A=PTT analog transmission

c. Monitor mode: = Monitor off

S= Selective squelch

d. P-25 squelch: N= Normal squelch

S= Selective squelch


e. Low Voltage Icon:  = Low Voltage state (*Icon flashes with ALM LED*)

f. Key lock mode:  =Key lock (*Not displayed if in Low Voltage alarm*)

g. Shift mode:  SHIFT KEY ICON (reverts to normal within 2 seconds)

Line 4: The left 2 letters show GPC (GROUP CALL), AC (ALL CALL), IC (INDIVIDUAL CALL).

The right 18 letters displays the GROUP NAME, INDIVIDUAL NUMBERS, ETC.



## 2. LED DISPLAY

The Midland Base Tech III has 5 LED's

From left to right;

**DIGI**= The LED is on when receiving a digital signal

**REP**= The LED is on when in repeat mode.

*(The BASE TECH III can be programmed for,*

*SIMPLEX -SEMIDUPLEX - DUPLEX- REPEATER on a per channel basis.)*

**ALM**= The LED flashes when an error on either TX or RX occurs

**TX**= The LED is on when in Transmit

**BUSY**= The LED is on when receiving a signal.

### 3. KEY CONTROLS

#### 3.1 Key entry *without* SHIFT key

0-9: channel numbers and individual call address (*target address*)

A: P-25 calls (*Group Call, All Call, and Individual Call*)

B: The beginning and the end of individual call number

C: No function

D= P-25 mode (*analog or digital TX*)

\*= Cancel channel number, individual number

#= Ending channel number, individual number

CH= Channel number entry, depress CH, then 0-9 for channels

F (*Scan*) = P25 Conventional Control Messages (*SBC*)

MON= monitor ON or OFF

Rotary knob: Volume, Squelch, Back Light Dimmer and Timer

#### 3.2 Key entry *following* SHIFT key

0= P-25 test mode start and finish

1=back light ON/OFF

2=TX power Hi/LOW

3=Talkaround ON/OFF

4=No function

5=No function

6=No function

7=Indicates Analog channel data

8=Key lock ON/OFF

9=No function

A=Manual CWID send key

B=Programmed CWID Start/Stop key

C= No function

D= No function

\*= Indicating P-25 data (*while depressed*)

#= DTMF Entry

CH= Toggle Bar-Graph or TX RX Frequencies

F (*Scan*) = SBC (Conventional Control Messages) Mode / Emergency Call

MON = P-25 squelch normal or selective and analog MONITOR modes.



## 4. PROGRAMMING

The Midland Base Tech III must be programmed with Windows 2000, XP or Vista operating system.

The 91-1480CD software and 91-1303B programming cable are required to program the radio and are available through your Midland dealer or LMR Sales Department.

*Note: During actual data transfer the radio will not operate but should be complete within 30 seconds or less.*

## 5. CONTROL KNOB

### 5.1 VOLUME

Rotate the knob to change the volume level.

The volume level varies from 0 to 34. If the local speaker is active, the audible beep level will change as the knob is rotated.

Figure 3 shows the Volume at level 12




Figure 3

## 5.2 SQUELCH CONTROL

Push the rotary knob once to select the squelch level and then turn the knob to vary the level from 0 to 15. 0 is open squelch.

Figure-4 shows the Squelch at level 6




Figure 4

## 5.3 LCD BACKLIGHT DIMMER

Push the rotary knob twice to select the dimmer level and then turn the knob to select a level from 0 to 15, 0 is the darkest.

Figure-5 shows the Dimmer at level 5




Figure 5

## 5.4 LCD BACKLIGHT TIMER

Push the rotary knob three times to adjust the Backlight Timer. The Time varies from 0 to 30 seconds. This function is inactive when the Backlight has been turned on with SHIFT + 1 (Backlight ON/OFF).

Figure-6 shows the Backlight Timer set for 15 seconds




Figure 6

## 6. CHANNEL SELECTION

The Midland Base Tech III has capability of up to 500 channels.

Press CH, and then enter the channel number.

Example-1 CH-8; Press CH + 0 + 0 + 8 or CH +8 + #

Example-2 CH-500; Press CH + 5 + 0 + 0

## 7. P-25 CALLING SELECTION (*Digital Base Mode Only*)

Press and release A repeatedly to scroll through the menu

Radio displays GPC 00001= Group 1 Call, GPC everygroup= All Call,

IDC----- = Individual Call

Figure-7 Shows Talk Group Identification (*TGID*), Group 1 Call

Figure-8 shows an All Call (*everygroup*), to everygroup on the same NAC

Figure-9 Shows an Individual Call, to and individual unit ID on the same NAC.

(Refer to Section 11, Figure 11 and 12 for ID entry).




Figure 7




Figure 8




Figure 9



### 7.1 INDIVIDUAL CALL ENTRY (*Digital Base Mode Only*)

Press and release A repeatedly until IDC----- is displayed.

Press B, and enter the numerical Unit ID.

To deleted a digit, Press the star ( \* ) key

Press B or # to complete entry.

Figure-10 shows entry start, when B is pressed

Figure-11 shows completed entry, 1 + 2 + 3 + 4 + 5 + B



Figure 10



Figure 11

### 8. P-25 PTT MODE

Press D to select PTT (*Push-To-Talk*), mode.

When the display shows **PTT is Analog**, the radio transmits in analog mode.

When the display shows **PTT is Digital**, the radio transmits in digital mode.

Figure-12 Shows Analog

Figure-13 Shows Digital




Figure 12




Figure 13

## 9. P25 CONVENTIONAL CONTROL SIGNALLING (SBC) (*Digital Base Mode Only*)

***Please note: SBC functions are selectable in the Programming Software. The Base Tech III has been developed to work with any P25 radio under the TIA specifications. However not all subscriber radios have the capability of these functions.***

### 9.1 EMERGENCY MODE TX-

*Press and hold the F key to send an EMERGENCY call. (Note: The radio will transmit on the **programmed** EMERGENCY channel not necessarily the channel that appears on the display.)*

**Reboot the radio to clear the Emergency Alert.**

### EMERGENCY MODE RX-

To clear a received Emergency call, *Press and release F* twice.

**Press F to enter the SBC mode.**

### Key functions after entering menu selection;

*Press A for the next and B for the previous menu item.*

**C** stops transmission (The radio transmits the SBC 4 times until acknowledged.)

**D** moves the cursor between items within the selection.

\* deletes the last digit.

**#** transmits the selected SBC mode.

***Please Note: When the radio is in SBC mode, it can receive Group calls, All Call and Individual calls but no source address (caller unit ID), is displayed.***

***Emergency calls can be received when in SBC mode but the radio gives priority to Radio Inhibit. Both Emergency and Radio Inhibit are ignored when in SBC transmitting mode.***

The radio will revert to normal operation if no key is pressed for 10 seconds.

## 9.2 CALL ALERT-

**To send a Call Alert**, Press F then Press A or B until the selection is displayed, then *enter the target ID* of the radio to alert and Press #. If the target radio has received the Call Alert the display should show “ACK” (acknowledgement).

Figure 14 displays a Call Alert ACK




Figure 14

## 9.3 RADIO CHECK-

The dispatcher can send a message to a subscriber unit requesting a response from the radio (for example, to check if it is in operation).

**To initiate a Radio Check**, Press F then Press A or B until the selection is displayed, then *enter the target ID* of the radio to alert and Press #. If the target radio has received the Call Alert the display should show “ACK” (acknowledgement).

Figure 15 shows Radio Check Display.




Figure 15

#### 9.4 RADIO INHIBIT-

This function is used to disable a subscriber unit (Mobile or Portable). The subscriber unit cannot be turned on at all until an Uninhibit Command is sent. The password must match the password entered in the BTIII program for inhibit to occur.

**To Inhibit a radio,** Press F then Press A or B until the selection is displayed then enter the target radio's ID. Press D and enter the programmed password, then Press #. The target radio will be totally disabled. If the target radio has received the Call Alert the display should show "ACK" (acknowledgement). Figure 16 shows the Radio Inhibit entry display.




Figure 16

#### 9.5 RADIO UNINHIBIT-

Used to enable a subscriber unit that has been disabled, the password must match the password entered in the BTIII program.

**To Uninhibit a radio,** Press F then Press A or B until the selection is displayed and enter the target radio's ID, enter the password and then Press #. The target radio will be returned to normal operation. The target radio should send an ACK if successful. Figure 17 shows the Radio Uninhibit entry mode.




Figure 17

### 9.6 STATUS UPDATE-

Used to send user status. The status numbers relates to an actual message list. Indicates the User status (0-255) and Unit status (0-255).

**To send a Status Update**, Press F then Press A or B until the selection is displayed and *enter the target radio ID*. Then Press D and *enter the User (USR), message number*, Press D again and *enter the Unit number*, then Press #. If the target radio has received the Call Alert the display should show “ACK” (acknowledgement). Figure 18 shows Status Update ready to be sent to 366.




Figure 18

### 9.7 STATUS REQUEST-

Is used to request the status of another unit. After the request is sent the target unit should respond with the current status. In the example below USR: 2, means the number 2 status message.

**To send a Status Request**, Press F then Press A or B until the selection is displayed and *enter the target radio ID* then Press #. The target unit should respond with the message number, unit ID and ACK.

Figure 19 shows Status Request received from 366.




Figure 19

### 9.9 PREDEFINED MESSAGES-

Is used to send a predefined system message.

**To send a Predefined Message**, Press F then Press A or B until the selection is displayed, then *enter the target radio ID*, Press D and enter a message number and Press #. The target radio should send and ACK if successful.

Figure 20 shows message 2 ready to be sent to 366.




Figure 20

### 9.10 RADIO MONITOR-

Used to key up a target radio from 10 to 60 seconds and monitor the transmit audio.

**To monitor a radio**, Press F then Press A or B until the selection is displayed, then *enter the target radio ID*, Press D and enter 1 (10sec), 2 (30sec), or 3 (60sec).

Figure 21 shows Radio Monitor request to 366 to transmit for 30 seconds.




Figure 21

### 9.11 TELEPHONE-

Used to initiate a telephone interconnect request on the RF subsystem.

Press F then Press A or B until the selection is displayed, then *enter the complete telephone number* including country and area code. (max. 16 digits), then Press #.

Figure 22 shows the Midland Radio Corporation telephone number.




Figure 22

### 9.12 SBC LOG-

To toggle the SBC LOG ON, Press SHIFT+F, to turn the LOG OFF Press F.

When the SBC LOG is entered, the last SBC call is displayed. Press B to scroll to the previous records and Press A to scroll to the end of the list.

The radio will store up to 99 log entries. When more than 99 entries are made the oldest log will be deleted.

**Note: When the radio is reset or reprogrammed, all logs are deleted.**

Figure 23 shows the fifth entry of the SBC Log.



Figure 23

## 10. P-25 SQUELCH ADJUSTMENT

Press SHIFT + MON to choose the P-25 squelch mode.

*Normal SQL*= If NAC is the same, the receiver will unmute

*Selective SQL*= If NAC and GROUP is the same, the receiver will unmute

Figure-24 Shows Normal SQ

Figure-25 Shows Selective SQ




Figure 24




Figure 25

## 11. TALKGROUP ALIAS ID

When GPC is selected with the “A” key, the TGID alias is indicated as programmed (*Max 8 characters*)

Figure-26 shows POLICE for the TGID alias.





Figure 26



## 12. KEY-LOCK

Press SHIFT+8 to enable and disable the Key-lock. This symbol

 shows on the LCD. Key-Lock and Key-Unlock icon is displayed for 2 seconds and then reverts to show the TGID.

The PTT, MON and SHIFT key are not locked

If PTT, MON and SHIFT needs to be locked, select DISABLE in the programming software. If the station is to be remotely controlled it is recommended to leave PTT enabled, Remote PTT will not work when PTT is locked.

To release key lock, Press SHIFT+ 8 again.

Figure-27 shows key locked

Figure-28 shows key unlocked




Figure 27




Figure 28

### 13. MANUAL CWID START AND STOP

*Press SHIFT + A* to manually send the programmed CWID.

**CAUTION: THE TRANSMITTER WILL ENERGIZE IMMEDIATELY WHEN “A” IS PRESSED!**

To turn OFF CWID, *Press SHIFT + HOLD B* for 2 seconds  
(This disables both programmed and manual CWID)

To return to normal operation, either reboot the radio or

*Press SHIFT+ HOLD B* for 2 seconds

*(CWID must be enabled in programming to use these functions).*

Figure 29 shows CWID Sending

Figure 30 shows CWID function stop

Figure 31 shows CWID function start




Figure 29




Figure 30




Figure 31

### 14. DTMF ENCODE

*Press SHIFT + #* and then enter 0-9, \* or # to transmit DTMF.

The DTMF modulation level will be the same as the CWID level.

Figure 32 displays DTMF Encode mode.




Figure 32

### 15. ANALOG CHANNEL DATA

Press SHIFT+7 to scroll through the data. 7 must be depressed to scroll.

- 1) Rx width (*narrow/wide/4kHz*)
- 2) TX width (*narrow/wide/4KHz*)
- 3) Base mode (*Simplex/Semi-duplex/Duplex/Repeater*)
- 4) Rx CTCSS/DCS, CTCSS and DCS are used in Rx
- 5) TX CTCSS/DCS, CTCSS and DCS are used in TX
- 6) TX RX Modulation type either PM or FM (*PM is the default*)

**(The INFORMATION DISPLAY selection in the 91-1480CD MISCELLANOUS MENU must be set to ENABLE to display this information.)**

Figure-33 Displays indicates a narrow channel during scroll.




Figure 33

### 16. P-25 CHANNEL DATA

Press SHIFT+ \* to scroll through the data, \* must be depressed to scroll.

- |                                      |                         |
|--------------------------------------|-------------------------|
| 1/ Unit ID ( <i>source address</i> ) | 8/ Radio Inhibit RCV    |
| 2/ RX NAC                            | 9/ Radio Un-inhibit RCV |
| 3/ TX-NAC                            | 10/ Status Update RCV   |
| 4/ TGID                              | 11/ Status Request RCV  |
| 5/Emergency Alarm RCV                | 12/ Short Message RCV   |
| 6/Call Alert RCV                     | 13/ Radio Monitor RCV   |
| 7/ Radio Check RCV                   |                         |

These functions may be enabled and disabled in the programming software's "MISCELLANEOUS/ INFORMATION DISPLAY" section.

Figure 34 Shows the Unit ID




Figure 34

### 17. BAR GRAPH/CHANNEL DISPLAY

Press SHIFT + CH to eliminate the channel name/bar graph and display the frequencies for TX and RX.

Press SHIFT + CH to toggle back.

Figure-35 Displays the frequencies instead of channel name.

The 1<sup>st</sup> and 2<sup>nd</sup> character on line 1 indicates Receive Channel

The 3<sup>rd</sup> character indicates Wide band

The 4<sup>th</sup> character indicates Simplex mode.

The modes of operation are: "S" = Simplex, "H" = Semi duplex; "D" = Duplex and "R" = Repeat Line 2, "TXN" indicates TX is Narrow band.




Figure 35

### 18. LCD BACKLIGHT TOGGLE

By Default, the Backlight illuminates for 5 seconds after any keypress then goes out. Press SHIFT +1 for the backlight to stay on. Press SHIFT+ 1 again to return to default operation.

Figure-36 Indicates the backlight is ON.

See section 8 for backlight timer settings.




Figure 36

## 19. CHANGING TX POWER

Press SHIFT+2 to select High or Low TX power. ► Indicates high power.

If the radio is programmed for Hi power, the radio can be changed to low power with this function. If the radio is programmed for low power, it cannot be switched to HI power with this function.

The Figure-37 Displays the Hi power symbol.




Figure 37

## 20. CALLER ID

In Simplex mode the Midland Base Tech III display indicates the source Unit ID or Individual ID.

Figure-38 Displays the source ID as 00000366 in group call mode.

Figure-39 Displays the source ID in Individual Call mode.




Figure 38




Figure 39

## 21. EMERGENCY CALL RECEPTION

The 4th line of the LCD shows the Emergency ALM when an emergency call is received. The LCD back light flashes and the audible tone heard from the speaker can be increased or decreased with the volume control. Figure-39 below displays the Emergency Caller's ID 00000366.




Figure 40

## 22. REPEAT MODE

### 22.1 ANALOG

If the received CTCSS/DCS matches the programmed CTCSS/DCS, the radio transmits the programmed carrier frequency and CTCSS/DCS. Hang time is programmable (0-9.9sec), through the “Miscellaneous” tab of the 91-1480CD software.

### 22.2 DIGITAL

#### **Matching NAC (Network Access Code);**

If the programmed NAC matches the received NAC it allows the radio to repeat. The programmed NAC and TGID (Talk Group Identification), is transmitted.

#### **\$F7F in RX NAC**

If the RX NAC is \$F7F, all incoming signals are repeated with the same NAC and TGID as received.

#### **\$F7F in RX NAC w/ Through OFF;**

If the RX NAC is \$F7F, receives all incoming signals and transmits the programmed NAC and TGID.

*Note: Hang time is programmable (0-9.9 seconds), through the “Miscellaneous” tab of the Base Tech III (91-1480-CD) software.*

### 22.3 MIXED

In Mixed mode, the radio receives both Analog and Digital signals automatically. Individual channel programming can be combined as described in a) and b) above. If the radio receives analog, it transmits analog, if it receives digital, it transmits digital.

## 23. BASE MODE

### 23.1 ANALOG

If the received CTCSS/DCS matches the programmed CTCSS/DCS, the radio's receiver will open. The MON key may be pressed to bypass any tone signaling.

### 23.2 DIGITAL

#### **Matching NAC (Network Access Code);**

If the programmed NAC/TGID matches the received NAC/TGID, the receiver will open. Pressing SHIFT + MON switches between Selective SQL and Normal SQL mode.

#### **\$F7E in RX NAC**

If the NAC is set for \$F7E, the radio should receive any incoming NAC.

### 23.3 MIXED

In Mixed mode, the radio receives both Analog and Digital signal automatically.

Channel programming can be combined as described in 23.1 and 23.2 above on an individual channel.

## 24. REMOTE CONTROL

The BASE TECH III can be controlled remotely by pulling pin 24 of the EXT OPTION 25 pin D-sub connector to a low level. Local operation is restored when pin 24 goes HI.

In the Remote Mode only channels 1-16 can be controlled. Also when in Remote Mode Front Panel MON and Channel Selection is disabled.

Refer to the chart on page 33 for Channel control pin outs and other related information.

Figure-41 below shows CH -1 in remote control mode. The 3rd line shows E001 instead of C001 (*EXXX means remote, CXXX is Local Mode*)

RX			
TX			▶
E001	TAC 2	MD	⊗N
GPC 0001			

Figure 41

## 25. P-25 TEST MODE

Press **SHIFT+ 0** to put the radio into test mode. Then press the following numbers for the test you wish to perform.

- 1) Standard transmitter “Test Pattern”
- 2) Standard transmitter “Symbol Rate” pattern
- 3) Standard transmitter “Low Deviation” pattern
- 4) Standard transmitter “C4FM Modulation” Fidelity pattern
- 5) Standard “Tone Test”

- Sends the Standard Tone Test Pattern in TX mode.

- Indicates BER (Bit Error Rate) in RX mode.

Figure-42 Displays that the radio is in the “P25 Test Mode” and “Test Pattern”

Figure-43 Displays Symbol Rate

Figure-44 Displays Low Deviation

Figure-45 Displays C4FM Modulation

Figure-46 Displays TX Tone Test

Figure-47 Displays RX Tone Test and BER of 5%




Figure 42




Figure 43



**<P25 Test Mode>**  
**Low Deviation** ▶  
**C001** **MD**  **N**

Figure 44

**<P25 Test Mode>**  
**C4FM Modulation** ▶  
**C001** **MD**  **N**

Figure 45

**<P25 Test Mode>**  
**Tone Test** ▶  
**C001** **MD**  **N**

Figure 46

**<P25 Test Mode>**  
**Tone Test** ▶  
**C001** **MD**  **N**  
**Error Rate** **5%**

Figure 47

## 26. ADJUSTMENT MODES

While Grounding TP-2 on the analog logic board, switch the radio on.

*(See the Midland Base Tech III Service Manual for the TP-2 location)*

Press # to change selections.

Press A (Up) and B (Down) to adjust the level.

-RX 0 dBm Out      =Rx 0 dBm output level adjustment *(At pins 20 & 21 on the EXT OPTION 25 pin D-sub connector).*

-RX FX828 MOD-1   =Deviation level adjustment for “Repeat” mode (analog)

-TX DIGITAL DEV   =Deviation level adjustment (digital)

- TX ANALOG DEVI =Deviation level adjustment (analog)

-TX TONE DEVI      =CWID Deviation level adjustment

**(The CWID level must be adjusted before it will send any code)**

You must reboot the radio to return to normal operation

Figure-48 Displays RX wide 0dbm out

Figure-49 Displays RX MOD-1, Modulation adjustment for repeat mode

Figure-50 displays TX MOD-Digital

Figure-51 displays TX MOD-Analog (TXW for Wide and TXN for narrow) whatever the current channel is programmed for.

Figure-52 displays TX TONE DEVI, This is the CWID level adjustment.

<b>RXWH</b>	<b>&lt;Adjust&gt;</b>
<b>TXW</b>	<b>RX 0dbm Out</b>
<b>C001</b>	<b>25 / 31 MA</b>

Figure 48

<b>RXWH</b>	<b>&lt;Adjust&gt;</b>
<b>TXW</b>	<b>RX FX828 MOD1</b>
<b>C001</b>	<b>0 / 31 MA</b>

Figure 49

<b>RXWH</b>	<b>&lt;Adjust&gt;</b>
<b>TXW</b>	<b>DIGITAL DEVI</b>
<b>C001</b>	<b>27 / 31 MD</b>

Figure 50

<b>RXWS</b>	<b>&lt;Adjust&gt;</b>
<b>TXW</b>	<b>ANALOG DEVI</b>
<b>C001</b>	<b>19 / 31 MA</b>

Figure 51

<b>RXWH</b>	<b>&lt;Adjust&gt;</b>
<b>TXW</b>	<b>TONE DEVI</b>
<b>C001</b>	<b>27 / 31 MA</b>

Figure 52

## 27. KEY TEST

*Press and Hold C, switch on the radio.*

Then depress any key to test.

Figure-53 shows initial display

Figure-54 shows CH key depressed.

Figure-55 shows rotary switch turn clockwise

Figure-56 shows rotary switch turn counter-clockwise

*If no key is pressed for 5 seconds, the radio reboots to normal operation.*




Figure 53




Figure 54




Figure 55




Figure 56

## 28. DISPLAYING THE FIRWARE VERSIONS

Both the radio and DSP firmware versions are indicated on the LCD after the radio switches on for 2 seconds, **unless a “Starting Message” has been programmed.**

Figure-57 Displays Radio and DSP Firmware versions




Figure 57

Figure-58 Shows the programmable starting message “Your Message Here”.



Figure 58

## 29. DISPLAYING THE SERIAL NUMBER

*Press and Hold D, turn on* the radio, the serial number is indicated. (max 8 digits).  
When the D key is released, the radio will reboot in the normal mode.

Figure-59 shows KY0000329 serial number



Figure 59

### 30. DISPLAYING THE PROGRAMMING SOFTWARE VERSION

Press and Hold A, and turn on the radio, the programming software version is indicated. When the A key is released, the radio will reboot in the normal mode  
Figure-60 shows V-0.2.3195 version




Figure 60

### 31. DATA CHECK

The Midland Base Tech III has a self diagnostic function. All data in the EEROM is checked every time the radio is switched on. If the data is not properly stored, the radio automatically turns to programming mode  
Figure-61 shows ERROM Data error




Figure 61

### 32. ERROR MESSAGES

If there is a problem with the RX PLL, TX PLL or PA, then the ALM LED flashes on and indicates which section has the issue.

Figure-49 displays a RX PLL error, Note this may be displayed in REM mode if the remote channel lines are open or a channel is selected remotely that is not programmed. (*EXXX will be displayed instead of CXXX, where XXX is the channel number.*)

Figure-62 displays a RX PLL error

Figure-63 displays a TX PLL error

Figure-64 displays a PA error




Figure 62




Figure 63




Figure 64

### 33. FIRMWARE ERROR DETECTION

When the radio itself detects a malfunction, the main CPU will restart automatically.

### 34. RS232 ERROR DETECTION

If the communications between PC and the radio have trouble, the following messages are shown on the LCD.

- Overrun error
- Framing error
- Parity error
- Unknown command
- Data unmatched
- Send error
- Answer timeout
- Receive timeout

### 35. DSP ERROR DETECTION

When there is a problem with the DSP, the following message may be shown on the display. Please check that the DSP board is installed correctly, and the correct firmware version is displayed at startup.

Figure-65 shows DSP failure

Figure-66 shows DSP not ready

Figure-67 shows DSP serial error



Figure 65




Figure 66




Figure 67



### 36. Option Port Pinout

25 pin D-sub connector for remote control is provided on the rear panel of Base Tech III. The functions of each pin are as follows:

<b>Pin No.</b>	<b>Name</b>	<b>Description</b>	<b>I/O</b>	<b>Levels</b>	<b>Comments</b>
1	CH0	LSB external binary channel selection	I	0-+3.3VDC	0000 is channel 1
2	CH1	External binary channel selection	I	0-+3.3VDC	
3	CH2	External binary channel selection	I	0-+3.3VDC	
4	CH3	MSB External binary channel selection	I	0-+3.3VDC	1111 is channel 16
5	Unassigned				
6	REM MON	Remote Monitor	I	0-+3.3VDC	+3.3V=Monitor On
7	GND	Ground			
8	Unassigned				
9	REM D/A	Remote Digital Analog select		0V – 3.3V	+3.3V = Analog 0V = Digital
10	DEM OUT	Discriminator audio out	O	≈330mVrms 1KHz @ ±3KHz	C4FM on DIGITAL MODE
11	BUSY	Channel busy indication	O	0-+3.3VDC	+3.3V=busy
12	RSSI	Receive signal strength indicator	O	0-+2.5VDC analog	
13	MOD1	External audio modulation input	I	≈50mVrms 1KHz for ±3KHz	
14	GND	Ground			
15	PTT	Push to talk	I	0-+3.3VDC	0V=transmit
16	MOD2	External modulation input	I	≈400mVrms 1KHz for ±3KHz	After limiter and filtering /LOW FREQ i.e. External CTCSS/DCS IN
17	SIMP	Simplex mode selected	O	0-+3.3VDC	0V=simplex
18	ERR	Alarm indication	O	0-+3.3VDC	Duty Cycle Determines which alarm
19	DECODE	Decode valid indication	O	0-+3.3VDC	5V=valid signaling
20	RX AUD1	Buffered receive audio	O	≈700mVrms 1KHz @ ±3KHz	1 & 2 Can produce 0 dBm into
21	RX AUD2	Buffered receive audio	O	≈700mVrms 1KHz @ ±3KHz	600 ohm input
22	TX OUT		O		
23	EXT PW/SW	External power switch	I	0-Open source	0V=ONf
24	REMOTE	External channel selection mode	I	0-+3.3VDC	0V=external
25	+12V		O	12 vdc	800mA Max out

**NOTE: Pins 1-4, 6 and 9 are only available when pin 24 (Remote Mode) is at 0V. See page 23 for more information on display indications**



5900 PARRETTA DRIVE • KANSAS CITY • MISSOURI • 64120  
PHONE: (816) 241-8500 • FAX: (816) 241-5713

[www.midlandradio.com](http://www.midlandradio.com)