


Monster Digital ,Inc.
2655 Park Center Drive Suite C. Simi Valley 93065 USA
360 WIFI Camera
CAMVI-0360-A

User's Manual


Description of appearance and keys



1. LCD display screen
2. Shutter key
3. Power/Mode
4. Wifi key
5. Busy indicator (red)
6. Charging indicator (blue)
7. WIFI indicator (red)
8. Lens
9. Gear adjusting triangle nut
10. Interface lid (USB, HDMI)
11. Speaker

Use your WIFI camera


1. First insert a micro SD or micro SDHC card, as shown in the right figure:




A high-speed card of Class 6 or above is recommended, and a Class 10 card is needed for video recording in professional mode.

Be sure to turn off the video camera before a card is inserted or taken out.

2. Power on/off

Power on: Press and hold Power key  for about 2 seconds and release it, accompanied by a sound of the buzzer, the LCD screen will be started (video recording mode is started by default), and the working indicator in red/Busy indicator will be normally on.

Power saving mode: The device will enter power saving mode when it is in an idle state for one minute (default setting of the system) without any operation, LCD display will be turned off automatically. And it can be activated by pressing any key after it is turned off.

Power off: Press and hold Power key  for about 3 seconds and release it, accompanied by a sound of the buzzer, the LCD screen will be shut down.

The device will be turned off automatically when it is in power saving mode for 3 minutes (default setting of the system) without any operation, "Goodbye" will be displayed on the LCD screen when it is turned off.


3. Charging the camera

An external chargeable lithium battery is used in this device, and its installation is as shown in the figure below:

Open the cover of the battery:

Mount the battery as per the correct marks for positive and negative poles;

Then put on the cover of the battery;




In power-off state, connect the device to the USB interface of the computer with a USB cable for charging. The charging indicator will be in blue in charging. It takes at least 4 hours to complete charging due to current limit of the USB interface of the computer. After charging is completed, charging indicator will be off.

4. Switch of functional modes


This video camera has three modes: video recording mode, driving mode and photographing mode.

After power is on, modes can be switched by pressing Power/Mode key, or through APP.


Video recording mode: As illustrated below, press Shutter key to start video recording, accompanied with a sound from the buzzer. In video recording, Busy indicator will be flashing in red all the time, and LCD timer will start timing. To stop video recording, press this key again.



Driving mode: In driving mode, video will be recorded in a cycled way, with a passage of video being recorded for three minutes by default. When the card is full, the file recorded earliest will be deleted automatically so that video recording can continue. As illustrated below, press Shutter key to start video recording, accompanied with a sound from the buzzer. In video recording, Busy indicator will be flashing in red all the time, and LCD timer will start timing. To stop video recording, press this key again.




Photographing mode: After switching to photographing mode, press Photograph key to take a photo, accompanied with a sound from the buzzer, and Busy indicator will be flashing in red all the time in photographing. After photographing, the timer will count in a decreasing way.




5. Menu operation:


After power is on, hold WIFI key for 2 seconds to activate the menu:



Menu in photographing mode



Menu in setting mode

Press Power key  to switch between menu in photographing mode and that in setting mode;

Press WIFI key and move the cursor to select on the menu


Press Shutter key to confirm;

Hold WIFI key to cancel setting or exit from the menu;

6. Application of watch-type remote controller:

1. Definition of keys on the watch-type remote controller:

Keys of the remote controller are illustrated as below:




- 1. Power key
- 2. Video recording key
- 3. Photographing key
- 4. Key indicator (red)
- 5. Watch band
- 6. Watch buckle


2. Use of watch-type remote controller:

Use the watch-type remote controller to for operations of power on, video recording, photographing, and power off within a range of 30m without operating on the camera, and just press one key to realize corresponding functions.

Remarks: Press any key, the two indicators on two sides will be on in red simultaneously.

3. Turn on or off the camera with the watch-type remote controller

Power on: Hold  key till indicator is off and release, the camera will be turned on and the buzzer will sound.


Power off: Press  and release it, the camera will be turned off and the buzzer will sound.

4. Replacement of battery of watch-type remote controller

When electrical quantity in the remote controller is low and the battery needs to be replaced, open the battery door with a coin carefully, and avoid its appearance being damaged.


II. Connecting the device to an HDTV

Connect the video camera to a HDTV with a HD cable as illustrated below. After power is on, display signals in the video camera will be output to the HDTV automatically, and HD videos and photos can be browsed in the HD TV.




Note: Stop video recording or playing before connecting or pulling off the HDMI cable.

III. Illustrated use of accessories:





5. Selfie stick




Applications (Android and Apple systems supported)


I. How to acquire APP installation program?

1. For android system, search for SYMAX360 in Play store and acquire the installation program, and install it as per the prompt, or scan the QR code  on the color box for installation.

2. For Apple system, search for SYMAX360 in Apple store and acquire the installation program, and install it as per the prompt, or scan the QR code  on the color box for installation.

II. Application of APP programs

1. Install SYMAX360 application program on the mobile phone or the tablet (available from the supplier or the internet), and an  icon will be displayed on the screen.

2. Insert the card into the video camera and turn it on, press Wi-Fi key to activate Wi-Fi, and a prompting word of Wi-Fi signals will be displayed on the screen;
3. Turn on Wi-Fi on the mobile phone or the tablet, search for P1800-xxxxxx, the name of wireless AP signal, input the wifi password : 1234567890, then connect it till the system shows that connection is successful;
4. Click the icon  of application program on the mobile phone or the tablet, and you can see the preview screen transmitted by the video camera on the mobile phone or the tablet directly, and then you can perform relevant operations.

Note:

1. Before taking photos or downloading pictures on mobile phone or tablet terminal, insert a TF card into the video camera;
2. After connecting the mobile phone or computer terminal to the video camera normally, Wi-Fi indicator will be normally on.

Applications on the personal computer:

This video camera is for plug and play, in power-on state, connect the device to the computer with the USB cable, it will be switched to movable hard drive mode automatically.

The icon of movable drive will appear on the window of "My Computer". The photos you take will be saved in I:\jpg folder in the movable drive (I is the movable drive of this device), video files you take will be saved in I:\video and car-borne files you take will be saved in I:\CAR folder.

Note: If the function of movable hard drive is used in Windows 2000 or windows system of higher version, drivers cannot be installed.

Technical parameters

Image sensor	8.0 million pixels (CMOS)	
Functional mode	Video recording and photographing	
Lens	F2.0 f=1.1mm	
Video resolution	1920*1440P (30fps)、 1440*1080P (30fps)	
Photo resolution	3840*2160、 3072*1728、 2560*1440	
File format	Video	H.264 (MOV)
	Picture	JPG
Storage medium	TF card (max. 32GB supported)	
USB interface	High-speed USB 2.0 interface	
Power source	External lithium battery 1000mAh	

FCC Notice:

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference. (2) This device must accept any interference received, including interference that may cause undesired operation.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

WARNING: Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

RF Exposure

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable condition without restriction.

IC Notice:

This device complies with Canada Industry licence-exempt RSS standard(s). Operation is subject to the following two conditions:

(1) this device may not cause interference; and

(2) this device must accept any interference. Including interference that may cause undesired operation of the device.

Avis d'Industrie Canada

Le présent appareil est conforme aux CNR d'industrie Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes:

- 1) l'appareil ne doit pas produire de brouillage; et
- 2) l'utilisateur de l'appareil doit accepter le brouillage radioélectrique subi même si le brouillage est susceptible d'empêcher le fonctionnement normal de l'appareil.



CAUTION CAUTION

RISK OF EXPLOSION IF BATTERY IS REPLACED BY AN INCORRECT TYPE.
DISPOSE OF USED BATTERIES ACCORDING TO THE INSTRUCTIONS



Electric and electronic equipment and included batteries contains materials, components and substances that can be hazardous to your health and the environment, if the waste material (discarded electric and electronic equipment and batteries) is not handled correctly.

Electric and electronic equipment and batteries is marked with the crossed out trash can symbol, seen below. This symbol signifies that electric and electronic equipment and batteries should not be disposed of with other household waste, but should be disposed of separately.

As the end user it is important that you submit your used batteries to the appropriate and designated facility. In this manner you make sure that the batteries are recycled in accordance with legislature and will not harm the environment.

All cities have established collection points, where electric and electronic equipment and batteries can either be submitted free of charge at recycling stations and other collection sites, or be collected from the households. Additional information is available at the technical department of your city.