

Manual

Operating the Nuclear Doorbell

To turn your Nuclear Doorbell on you will need to remove the isolator tabs (the plastic strips that stop batteries connecting and completing a circuit) from the button and the main unit.

Once you have done this, the Nuclear Doorbell will be activated and every time a visitor presses the button one of three randomly selected phrases will play.

NB the main unit of your Nuclear Doorbell can be stood-up using the metal stand or hung on the wall from its back plate. The button can be screwed into or stuck onto the wall.

Battery information:

The Doorbell button requires 1*12V 23A battery. Unscrew battery compartment to replace batteries.

The main unit will require fresh batteries every 3 or 4 months .After 3 months' use, please check the battery strength by pressing the button.

Batteries precaution

1. Use only fresh batteries of the required size and recommended type.
2. Do not mix old and new batteries, different types of battery: standard, alkaline, or rechargeable, or rechargeable batteries of different capacities.
3. Never leave dead or weak batteries in the unit.
4. If you do not plan to use the unit for several weeks, remove the batteries. Batteries can leak chemicals that can destroy electronic parts.
5. If the unit does not appear to be working correctly replace the batteries.
6. Dispose of batteries properly and promptly. Do not burn or bury. Recycle wherever possible.
7. Non-rechargeable batteries are not to be recharged. Rechargeable batteries are to be removed from the unit before being charged.
8. Rechargeable batteries are only to be charged under adult supervision.
9. The supply terminals are not to be short-circuited.
10. Packaging should be kept as it contains important information.

The consumer has a significant role to play in reducing the impact of waste electrical and electronic equipment on the environment, through re-using or recycling such equipment.

Some of the components used in electrical and electronic equipment may contain hazardous substances that can damage the environment and present a risk to human health if not properly disposed of.

The crossed out wheelee-bin symbol on this product is to remind you that Waste electrical and electronic products should not be disposed of with house hold waste. If you are unable to re-use or recycle your product it should be disposed of at a civic amenity site.

FCC NOTE: THE MANUFACTURER IS NOT RESPONSIBLE FOR ANY RADIO OR TV INTERFERENCE CAUSED BY UNAUTHORIZED MODIFICATIONS TO THIS EQUIPMENT. SUCH MODIFICATIONS COULD VOID THE USER'S AUTHORITY TO OPERATE THE EQUIPMENT.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: 1. This device may not cause harmful interference, and 2. This device must accept any interference received, including interference that may cause undesired operation