- 1 Open the phone, then touch **II** Phone (if your phone is locked, touch **Emergency Call**).
- 2 Enter the emergency number.
- 3 Touch Call to call the emergency number.

Note: Your mobile device can use AGPS satellite signals to help emergency services find you ("LOCATION SERVICES (GPS & AGPS)" on page 35).

COOL DOWN

In very limited circumstances, such as where your phone has been exposed to extreme heat, you may see "Cool Down" messages. To avoid possible damage to your battery and phone, you should follow these instructions until the phone is within its recommended temperature range. When your phone is in "Cool Down" mode, only emergency calls can be made.

"hy

MOTOROLACONE

CONTACTS


:: OBLONUSS

contacts like you've never had before

Keep each friend's email, phone number, and even address all in your **Contacts** for quick access.

QUICK START: CONTACTS

From the home screen, touch **S** Phone > Contacts



 To create a contact, touch & Phone > Contacts > Menu > New contact, choose where you want to store the contact, then enter details (to close the display keyboard, touch Back **5**).

Contacts shows the contacts from your Google™ account, which you can open from any computer at <u>contacts.google.com</u> (or open your contacts within <u>mail.google.com</u>). To stop synchronizing with your account, touch **I Dialer** > Contacts > Menu => Accounts, touch your Google account, then uncheck Sync Contacts.

- To call, text, or email a contact, touch I Phone
 > Contacts, touch the contact, then touch ((call),
 (text), or ((email)).
- To edit or delete a contact, touch Phone
 Contacts, touch the contact, then touch Menu

FAVORITES

For quick access to a favorite contact, open the contact, then touch the star next to their name. To show your favorites, touch **[1] Phone** and touch **Favorites** at the top.

To add a shortcut to your favorites, touch and hold a blank spot on your home screen, then touch **Folders** > **Starred contacts**. You can also add a shortcut for an individual contact: Touch and hold a blank spot on your home screen, then choose **Shortcuts** > **Contact**.

STORAGE & TRANSFER

:: 0310181638

MOTOROLACON

When you create a new contact, your phone asks if you want to store it in your Google™ account, phone memory, or SIM card. Contacts in all three places appear in your **Contacts** list, but if you change phones:

- Contacts in your Google™ account can download when you log into your Google account on a new Android™ device. You can open these contacts from any computer at <u>contacts.google.com</u>.
- Contacts on your SIM card can load to a new device when you insert your SIM card.
- Contacts in your phone memory stay in your old phone, unless you export them.

To import or export contacts between your phone memory and a SIM or memory card, touch **13 Phone** > **Contacts**, then touch Menu **> Import/Export**.

ES.

MESSAGING


sometimes it's best to text or email ...

Send and receive text with photos or other attachments, in quick text messages or full emails.

STRICTED

QUICK START: TEXT MESSAGING

From the home screen, touch 🔀 Messaging.



Tip: To see more messages, flick or drag up.

To create a text message, touch Messaging > New message. For options like attaching files, touch Menu . You want the server of the server o

To **open** text messages, touch **Messaging**, then touch the sender's name.

When you see in the status bar at the top of your screen, flick down the status bar and touch the new message to open it.

- To respond to a text message, just open it and enter your response in the text box at the bottom.
- To forward, copy, and more, touch Messaging, touch the sender's name, then touch and hold the message.

ATTACHMENTS

To send a file in a text message, touch Messaging > New message, then touch Menu > Attach.

When you open a message with an attachment, touch **Download** to download it. Touch the downloaded attachment to open it, then touch it again to save it, share it, and more.

Tip: To send and receive large attachments faster, use "WI-FI NETWORKS" on page 25.

EMAIL

Accounts & sync > Add account. For details, contact the account provider.

To set up standard email accounts (not Gmail™ or Microsoft[™] Exchange), touch **O** > **P Email** and follow the wizard. To add more standard accounts, open 🙋 Email and touch Menu 🚍 > Accounts > Menu => Add account. For details, contact the account provider.

To open email, touch 🖸 > 🤷 Email or 🖄 Gmail. Touch a message to open it.

Tip: Touch Menu 🚍 for options like Refresh or Search.

To create an email, touch 🖸 > 🧖 Email or 🖄 Gmail, then touch Menu => Compose.

Tip: Touch Menu 🚍 for options, like Attach or Add Cc/Bcc.

Gmail synchronizes with your Google[™] account mail, which you can open from any computer at mail.google.com. To stop synchronizing with your account, touch Menu => Settings > Accounts & sync, touch your Google account, then uncheck Sync Gmail.

VOICEMAIL

When you have a new voicemail, oo shows in the status touch **W Phone** then touch and hold **1**. 100 MOLOUM

If you need to change your voicemail number, in the home screen touch Menu => Settings > Call settings > Voicemail settings. For your voicemail number or other details, contact your service provider.

Fest

TEXT ENTRY

keys when you need them

When you enter text, like in a message or search, you have keyboard options.

QUICK START: TEXT ENTRY

To change the keyboard, touch and hold a blank spot in a text box. A menu opens, where you can choose Input method > Multi-touch keyboard or Swype.

Note: Swype is not available in all regions. Your keyboard might change depending on what you're entering.

Swype lets you drag your finger over the letters of a word, in one continuous motion.




To enter a word, just trace a path through the letters. To capitalize, go above the keypad. For double letters, circle the letter.

RICTED

To **move the cursor**, touch and hold a word you entered. This opens a magnifier where you can drag the cursor.

- To copy and paste, double-tap a word to highlight it (if needed, drag the ends of the highlight). Then touch and hold a blank spot for the copy and paste menu.
- To add a word to your dictionary, double-tap the word to highlight it. Then touch and hold a blank spot to open the menu where you can add the word.
- To enter the small number or symbol at the top of a key, touch and hold the key.
 - To enter several numbers or symbols, touch SYM.
- If Swype doesn't know a word, touch individual letters to enter it. Swype remembers, so next time you can just drag over the letters.

Multi-touch keyboard lets you enter letters by touching them one at a time.



TEXT ENTRY DICTIONARY

Your phone's dictionary stores special words or names to recognize when you enter them.

To open your dictionary, from the home screen touch Menu => Settings > Language & keyboard > User dictionary.

- To add a word, touch Menu => Add.
- To edit or delete a word, touch and hold it.

SCHEDULE

helping you stay in control

Your **Calendar** events can synchronize with your Google™ account, and the **Clock** can wake you up!

QUICK START: SCHEDULE

From the home screen, touch $\boxed{O} > \boxed{31}$ Calendar.

Z.



To create an event, touch **○** > <u>31</u> Calendar > Menu **=** > More > New event, then enter details (to close the display keyboard, touch Back **○**).

Calendar synchronizes with your Google account calendar, which you can open from any computer at calendar.google.com (or open your calendar within mail.google.com). To stop synchronizing with your account, touch Menu => Settings > Accounts & sync, touch your Google account, then uncheck Sync Calendar.

To edit or delete an event, touch 31 Calendar, touch the event to open it, then touch Menu
 > Edit event or Delete event.

ALARM CLOCK

To set an alarm (like to wake up), touch \bigcirc > \bigcirc Clock, then touch the \bigcirc alarm.

- To add an alarm, touch Add alarm, then enter alarm details.
- To change an alarm, touch the time.
- To set a snooze period, in the Alarm Clock list touch Menu => Settings > Snooze duration.

When an alarm sounds, touch **Dismiss** to turn it off or **Snooze** to delay it. To cancel a snoozed alarm, drag down the status bar bar and touch the alarm name.

DATE & TIME

To set the date, time, time zone, and formats, touch Menu => Settings > Date & time.

E SZ

WEB

surf the web with your phone

Open **Browser** or just touch Search \bigcirc to find a page, then bookmark it, send it, or just explore.

QUICK START: WEB

From the home screen, touch 🖸 > 🚱 Browser.



• To enter a **website address** in the browser or your home screen, just touch Search Q.

• To **zoom** in or out, pinch two fingers together or apart.

TRICTED

NOTOROLACON

 To send the website address in a message, touch Menu > More > Share page.



2

Note: Your phone automatically uses your mobile phone network to connect to the web. Your service provider may charge to surf the web or download data. If you can't connect, contact your service provider.

Tip: You can connect to the web with "WI-FI NETWORKS" on page 25.

DOWNLOADS

:: 0310181838

To download files in your browser, touch a file link or touch and hold a picture to choose **Save image**.

To show the files you downloaded, touch **○** > **▶ Downloads**. Touch and hold an item to open it, see details, or remove it from the list.

You can download "APPS" on page 5.