

EN



MOTOROLA

MOTOROLA XT535

LIFE.  POWERED.



MOTOROLA CONFIDENTIAL RESTRICTED :: MOTOROLA CONFIDENTIAL RESTRICTED :: MOTOROLA CONFIDENTIAL RESTRICTED ::

FCC SUBMISSION

Jan. 12. 2012

MOTOROLA CONFIDENTIAL RESTRICTED :: MOTOROLA CONFIDENTIAL RESTRICTED :: MOTOROLA CONFIDENTIAL RESTRICTED ::

CONTROLLED COPY

CONGRATULATIONS

MOTOROLA XT535

Your MOTOROLA **XT535** helps you seamlessly manage your “Office” and “Outdoor” lifestyles.

- **Lifeproof:** Your phone is water-resistant, dustproof, and has a scratch-resistant screen, because accidents happen.
- **Dashboard:** Easy access to all your favorite Outdoor apps, like **Camera**, **Compass**, and a pedometer, see “**DASHBOARD**” on page 12.
- **MotoSwitch:** MotoSwitch is a dynamic interface that gives you seamless access to content that is relevant to you. For details, see “**MOTOSWITCH**” on page 13.
- **Extended battery life:** So you have longer to use your phone outdoors.

Note: Certain apps and features may not be available in all countries.

Caution: Before assembling, charging, or using your phone for the first time, please read the important safety, regulatory and legal information provided with your product.

SAR

This product meets the applicable limit for exposure to radio waves (known as SAR) of 2.0 W/kg (ICNIRP). The limits and guidelines

include a substantial safety margin designed to assure the safety of all persons, regardless of age and health. The highest SAR values measured for this device are listed in the regulatory information packaged with your product.

Note: When using the product while worn on your body, either use an approved accessory such as a holster or maintain a distance of 2.5 cm (1 inch) from the body to ensure compliance with SAR requirements. Note that the product may be transmitting even if you are not making a phone call.

WANT MORE?

More help, more accessories, more free stuff. We're here to help.

Jan. 12, 2012

- **Updates:** Phone updates, PC software, user's guides, online help, and more at www.motorola.com/support.
- **Accessories:** Find more for your phone at www.motorola.com/products.
- **Social:** The latest news, tips & tricks, videos, and so much more—join us on:



YouTube™ www.youtube.com/motorola




Facebook™ www.facebook.com/motorola



Twitter www.twitter.com/motomobile

YOUR PHONE

the important keys & connectors





Note: To help protect your phone, always make sure that the battery cover and any connector covers are closed and secure.

CONTENTS

LET'S GO	6
HOME SCREEN & APPS	10
PERSONALIZE	17
CALLS	18
CONTACTS	21
MESSAGING	23
TEXT ENTRY	26
SCHEDULE	28
WEB	30
LOCATION	32
PHOTOS & VIDEOS	33
MUSIC	35
MEDIA	37
BLUETOOTH™, WI-FI, & CABLE CONNECTIONS	38
SECURITY	41
TROUBLESHOOTING	42
SAFETY, REGULATORY & LEGAL	43

LET'S GO

let's get you up and running

ASSEMBLE & CHARGE

1 Cover off



2 SIM in



3 microSD in (may already be inserted)



4 Battery in



5 Cover on



6 Charge up



Caution: Please read “ **BATTERY USE & SAFETY** ” on page 43.

SET UP & GO

Note: This phone supports apps and services that use a lot of data, so make sure your data plan meets your needs. Contact your service provider for details.


When you turn on your new phone, you can create or enter a Google™ account so that you can download apps, use Gmail™, and much more:

- 1 Press and hold Power  to turn on your phone.
- 2 Touch the Android™ image to begin setup.
- 3 Touch a button to **Create** a Google account, **Sign in** with one you have, or **Skip**.

Power Key



You can log into your account from a computer at accounts.google.com.

- 4 When your phone confirms the account, it shows account sync options.
 - To change whether your phone shows the Google account's contacts, Gmail™, and calendar, touch the Google account name.
 - To add another account, touch **Add account**. For details, see “ **EMAIL** ” on page 24.
 - To exit setup, touch Home .

If your phone cannot connect, touch Menu (☰) > **WLAN settings** to change mobile network settings.

RUGGED

Your MOTOROLA **XT535** stands up to water, dust and life. Now your investment is safe and protected from life's little challenges, like that sudden rain shower and other everyday mishaps.


Of course, your phone isn't indestructible, so to avoid damage from natural elements, such as water, sand, and dust intrusion, always make sure that the battery door cover and connector covers are closed and secure.


If your phone gets wet and/or dirty:

- Wipe with a soft cloth and shake to remove excess water from the entire phone, especially the display screen, speaker, and microphone ports.
- Allow your phone to air-dry for at least 1 hour before using it again.
- Always make sure to clean all dirt and debris from the battery door cover/seals and connector covers.

Note: Your phone is not designed to float, or work underwater.

SLEEP & WAKE UP

Your screen sleeps when you hold it to your ear during a call, or when it is inactive. To change the sleep delay, touch Menu  > **Settings** > **Display** > **Screen timeout**.

To **unlock** the screen, drag  to the outer circle.




KEYS

Use your phone's keys to navigate and open options at any time.

Press the volume keys to change the ringer volume (in the home screen), or the earpiece volume (during a call).

Touch Home  to return to the home screen.

Touch and hold Home  to see your recent apps.





Volume Keys


HOME SCREEN & APPS


a few essentials


QUICK START: HOME SCREEN

You'll see the home screen when you turn on the phone or touch Home  from a menu:




- To open shortcuts or widgets, **touch** them. Touch Home  to return to the home screen.


When you open shortcuts or widgets, touch Menu  for options.


- To move or delete shortcuts or widgets, **touch and hold** them until you feel a vibration, then drag it to another spot, another panel, or  at the top.

In lists like **Contacts**, touch and hold list items for options.



- To add shortcuts, widgets, or wallpaper, touch and hold an empty spot until you see the menu. You can also add a folder to organize your shortcuts.
- To show more panels, **drag** or **flick** right or left. Touch Home  to show panel thumbnails.


In lists like **Contacts**, drag or flick to scroll.

To change your ringtone, display brightness, and more, touch Menu  > **Settings** > **Sound** or **Display**. For details, see "**PERSONALIZE**" on page 17.

Tip: From the home screen, touch Menu  > **Themes** to design different home screens for **Work**, **Home**, or **Weekend**. Your changes are stored in each profile.

DASHBOARD

You can access the outdoor apps on your phone, with the dashboard, just touch  >  **DashBoard**.




Drag or flick to see other apps.


Start/Stop/Save pedometer record.

To change app that is shown.

Shortcuts

Your dashboard shows apps, like **Camera**, **Compass**, and **FM Radio**. You can also see a pedometer that reports your runtime, steps, and calories burned—it's the ideal fitness companion.

Note: To set the pedometer, touch Menu  > **Settings** > **Height and Weight**, then enter your details.

To view or share your records, touch Menu  > **My Record** or **Share**.

MOTOSWITCH

Jump right to your favorite apps from the lock screen!

To set up your lock screen apps:



Your favorites.

Touch & hold between the two rings to show your most used apps at the bottom.

Drag to scroll.


Most used apps. Drag an app to the outer ring to add it to your favorites.


To **go to a favorite app** from the lock screen, drag the app towards the lock icon .





Note: For toggle apps, such as **Bluetooth** or **Flight Mode**, the screen will remain locked.

APPS

To show your **app menu**, touch .


- To scroll, flick up or down.
- To open an app, touch it.
- To close the app menu, touch Back .

Tip: To show the last eight apps you opened, touch and hold Home .

To **download** new apps from Android Market™, touch  >  **Market**. Touch Search  to find an app, or touch **Downloads** to show or reinstall the apps you downloaded. To download apps from websites, you need to change your security settings: Touch Menu  > **Settings** > **Applications** > **Unknown sources**.

Tip: Choose your apps and updates carefully, from trusted sites like  **Market**, as some may impact your phone's performance—see "**CHOOSE CAREFULLY**" on page 15.


Note: When installing an app, make sure you read the alerts that tell you what information the app will access. If you don't want the app to have access to this information, cancel the installation.

To **move or uninstall** your apps, touch Menu  > **Settings** > **Applications** > **Manage applications**. Touch an app in the list to show details and options.

On your computer, you can browse and manage apps for all your devices powered by Android™ at market.android.com.

CHOOSE CAREFULLY


Apps are great. There's something for everyone. Play, communicate, work, or have fun. But remember, choose your apps carefully. Here are a few tips:

- To help prevent spyware, phishing, or viruses from affecting your phone or privacy, use apps from trusted sites, like  **Market**.
- In **Market**, check the apps' ratings and comments before installing.
- If you doubt the safety of an app, don't install it.
- Like all apps, downloaded apps will use up memory, data, battery, and processing power—some more than others. For example, a simple battery level widget will use less than a streaming music player app. After installing an app, if you're not happy with how much memory, data, battery or processing power it's using, uninstall it. You can always install it again later.
- Just like web browsing, you may want to monitor childrens' access to apps to help prevent exposure to inappropriate content.

- Certain apps may not provide completely accurate information. Take care, especially when it comes to personal health.

PHONE STATUS & NOTIFICATIONS

In the status bar at the top of your screen, the right side shows phone status. The left side shows new messages or events (for details, flick the bar down).




	network strength		battery strength
	new voicemail		new text message
	Bluetooth™ on		Bluetooth connected
	Wi-Fi connected		airplane mode
	USB connected		alarm set
	silent ringer		silent ringer, vibrate on
	mute call		speakerphone

PERSONALIZE

add your personal touch


QUICK START: PERSONALIZE

From the home screen, touch Menu  > **Settings** > **Sound** or **Display**.



Choose separate volume settings for incoming calls, media, alarms, and notifications.

Call & Message Notifications




Turn on or off menu animations.

CALLS

it's good to talk


QUICK START: CALLS

From the home screen, touch .



Open a list, then touch an entry to call.

Shows matching numbers, flick down to see more.



Call.

Hang up.

Start a conference call.


Tip: For quick access to contacts, see "**FAVORITES**" on page 21.


CONFERENCE CALLS

To start a conference call, call the first number. After they answer, touch **Add call** and call the next number. When the next number answers, touch **Merge calls**. To remove individual callers, touch **Manage**.

CALL WAITING

If you are on a call and a new call arrives:

- With call waiting on, you can drag  to the right to answer the new call and put the old call on hold. Then, touch **Swap** to switch between calls, or **Merge calls** to combine them.
- With call waiting off, the new caller gets the busy tone.

To turn on call waiting, touch Menu  > **Settings** > **Call settings** > **Additional settings** > **Call waiting**.


COOL DOWN

In very limited circumstances, such as where your phone has been exposed to extreme heat, you may see “Cool Down” messages. To avoid possible damage to your battery and phone, you should follow these instructions until the phone is within its recommended temperature range. When your phone is in “Cool Down” mode, only emergency calls can be made.

EMERGENCY CALLS

Note: Your service provider programs one or more emergency phone numbers that you can call under any circumstances, even when your phone is locked.

Emergency numbers vary by country. Your pre-programmed emergency number(s) may not work in all locations, and sometimes an emergency call cannot be placed due to network, environmental, or interference issues.


- 1 Touch  (if your phone is locked, then touch **Emergency Call**).
- 2 Enter the emergency number.
- 3 Touch **Call** to call the emergency number.


Note: Your phone can use location based services (GPS and AGPS) to help emergency services find you. See "Location Services" in your legal and safety information.

CONTACTS

contacts like you've never had before


QUICK START: CONTACTS

From the home screen, touch  **Contacts**.




Switch to the dialer, recent calls, favorites or groups.

Drag or flick to scroll.

Touch  to search, create, and more.

FAVORITES

For quick access to a favorite contact, open the contact, then touch the star next to their name. To show your favorites, touch  and touch **Favorites** at the top.



To add a shortcut to your favorites, touch and hold a blank spot on your home screen, then touch **Folders** > **Starred contacts**. You can also add a shortcut for an

individual contact: Touch and hold a blank spot on your home screen, then choose **Shortcuts** > **Contact**.

STORAGE & TRANSFER

When you create a new contact, your phone asks if you want to store it in your Google™ account, phone memory, or SIM card. Contacts in all three places appear in your **Contacts** list, but if you change phones:


- Contacts in your Google™ account can download when you log into your Google account on a new Android™ device. You can open these contacts from any computer at contacts.google.com.
- Contacts on your SIM card can load to a new device when you insert your SIM card.
- Contacts in your phone memory stay in your old phone, unless you export them.


To import or export contacts between your phone memory and a SIM or memory card, touch  **Contacts**, then touch Menu  > **Import/Export**.

MESSAGING

sometimes it's best to text or email...

QUICK START: TEXT MESSAGING

From the home screen, touch  **Messaging**.



Drag or flick to scroll.






Touch  to change settings and more.




Tip: To see more messages, flick or drag up.

EMAIL

- To **set up Google** or **Corporate** (Microsoft™ Exchange server) accounts, touch


Menu  > **Settings** > **Accounts & sync** > **Add account**. For details, contact the account provider.


To set up standard email accounts (not Gmail™ or Microsoft™ Exchange), touch  >  **Email** and follow the wizard. To add more standard accounts, open  **Email** and touch Menu  > **Accounts** > Menu  > **Add account**. For details, contact the account provider.

- To **open** email, touch  >  **Email** or  **Gmail**. Touch a message to open it.



Tip: Touch Menu  for options like **Refresh** or **Search**.


- To **create** an email, touch  >  **Email** or  **Gmail**, then touch Menu  > **Compose**.

Tip: Touch Menu  for options, like **Attach** or **Add Cc/Bcc**.

Gmail synchronizes with your Google™ account mail, which you can open from any computer at mail.google.com. To stop synchronizing with your account, touch Menu  > **Settings** > **Accounts & sync**, touch your Google account, then uncheck **Sync Gmail**.

VOICEMAIL

When you have a new voicemail,  shows in the status bar at the top of your screen. To hear voicemails, touch  then touch and hold **1**.

If you need to change your voicemail number, in the home screen touch Menu  > **Settings** > **Call settings** > **Voicemail settings**. For your voicemail number or other details, contact your service provider.

Jan. 12. 2012

TEXT ENTRY


keys when you need them

QUICK START: TEXT ENTRY

To **change the keyboard**, touch and hold a blank spot in a text box. A menu opens, where you can choose **Input Method** > **Android keyboard** or **Swype**.

Note: **Swype** is not available in all regions. Your keyboard might change depending on what you're entering.

Swype lets you drag your finger over the letters of a word, in one continuous motion.




To enter a word, just trace a path through the letters.

To capitalize, go above the keyboard.

For double letters, circle the letter.

Android keyboard lets you enter letters by touching them one at a time.




Touch and hold an empty spot to open a menu.

Delete

Symbols/Numbers

TEXT ENTRY DICTIONARY

Your phone's dictionary stores special words or names to recognize when you enter them.


To open your dictionary, from the home screen touch Menu  > **Settings** > **Language & keyboard** > **User dictionary**.


- To **add** a word, touch Menu  > **Add**.
- To **edit** or **delete** a word, touch and hold it.

SCHEDULE

helping you stay in control

QUICK START: SCHEDULE


From the home screen, touch  >  **Calendar**.






Color indicates events.


Drag or flick to scroll.



Touch  to choose the calendar view. Choose **More** to create an event or change settings.

ALARM CLOCK

To set an alarm (like to wake up), touch  >  **Clock**, then touch the  alarm.

- To turn an alarm **on** or **off**, touch  next to it.
- To **add** an alarm, touch **Add alarm**, then enter alarm details.
- To **change** an alarm, touch the time.

- To set a **snooze** period, in the **Alarm Clock** list touch Menu (☰) > **Settings** > **Snooze duration**.

When an alarm sounds, touch **Dismiss** to turn it off or **Snooze** to delay it. To cancel a snoozed alarm, drag down the status bar and touch the alarm name.

DATE & TIME

To set the date, time, time zone, and formats, touch Menu (☰) > **Settings** > **Date & time**.





Jan. 12. 2012

WEB

surf the web with your phone

QUICK START: WEB

From the home screen, touch  >  **Browser.**




Connection

Mobile Network: 

Wi-Fi: 

Enter a web page URL.



Drag or flick to scroll.

Touch  to open bookmarks, windows, and more.

Note: Your phone automatically uses your mobile phone network to connect to the web. Your service provider may charge to surf the web or download data. If you can't connect, contact your service provider.

DOWNLOADS

To download files in your browser, touch a file link or touch and hold a picture to choose **Save image**.

To show the files you downloaded, touch  >  **Downloads**. Touch and hold an item to open it, see details, or remove it from the list.



You can download "**APPS**" on page 14.


Jan. 12. 2012


LOCATION

where you are, and where you're going

QUICK START: LOCATION

From the home screen, touch  >  **Maps**.




 Show your location.

 Show layers on the map.

 Find nearby places.

 Drag or flick to scroll.

Touch to open, then touch  to add to **Starred Places**.

Touch  to get directions, open your starred places, windows, and more.


Google Maps™ offers powerful, user-friendly mapping technology and local business information—including business locations, contact information, and driving directions.

PHOTOS & VIDEOS

see it, capture it, share it!

QUICK START: PHOTOS & VIDEOS

From the home screen, touch  >  **Camera**.



Tip: For the clearest photos and videos, clean the lens with a soft, dry cloth.

VIEW & SHARE PHOTOS & VIDEOS

From the home screen, touch  >  **My Gallery**.

Flick left and right to show folders. Touch a folder to show its photos or videos, then touch a thumbnail image to open, share, or delete it.


Tip: From the viewfinder, you can touch the thumbnail in the bottom left to open your last photo or video.

- To **zoom** in, touch the screen with two fingers and then drag them apart. To zoom out, drag your fingers together.



- To **send** or **post** the photo or video, touch **Menu > Share**.

To use a Bluetooth or cable connection, see "**BLUETOOTH™, WI-FI, & CABLE CONNECTIONS**" on page 38.



- To **delete** the photo or video, touch **Menu > Delete**.
- To **set** a photo as your wallpaper or a contact photo, touch **Menu > More > Set as**.
- To **crop** or **rotate** a photo, touch **Menu > More**.
- To **play** a video, touch .


Tip: Turn the phone sideways for a widescreen view.

MUSIC


when music is what you need...



QUICK START: MUSIC





From the home screen, touch  >  **Music**, then choose a song to play it:



- To adjust **volume**, use the volume keys.

- When a song is playing, you touch Menu  to add it to a **playlist** or use it as a **ringtone**.

To edit, delete, or rename playlists, touch  >  **Music** touch the **Playlists** tab, then touch and hold the playlist name.

- To **hide** the player and use other apps, touch Home . Your music keeps playing. To return to the player, flick down the status bar and touch .
- To **stop** the player, touch .
- Before a **flight**, turn off network and wireless connections so that you can keep listening to music: Press and hold Power/Lock key  > **Airplane mode**.

Note: When you select airplane mode, all wireless services are disabled. You can then turn Wi-Fi and/or Bluetooth back on, if permitted by your airline. Other wireless voice and data services (such as calls and text messages) remain off in airplane mode.

Emergency calls to your region's emergency number can still be made.



You can use your phone's 3.5mm headset jack to connect wired headphones, or go wireless with a Bluetooth headset in "**BLUETOOTH™, WI-FI, & CABLE CONNECTIONS**" on page 38.


To listen to FM **radio** stations, Plug in a 3.5mm HJS headset and touch  >  **FM Radio**. Your phone uses the headset wire as the radio antenna.


MEDIA

view and share...

QUICK START: MEDIA

From the home screen, touch  >  **MediaSee**.



- Touch Menu  to **Select a Media Player** or the **Upload/Download Manager**.
- Touch and hold a thumbnail, then touch **Push to**, **Upload** or **Information** to send to an online media server or display details.


BLUETOOTH™, WI-FI, & CABLE CONNECTIONS

home, office, or hotspot

QUICK START: CONNECTIONS

Note: Due to French regulatory restrictions regarding possible interference, do not use Bluetooth in France when outdoors.

From the home screen, touch Menu  > **Settings** > **Wireless & networks**, then **Bluetooth settings** or **WLAN settings**.




Turn Bluetooth power on & scan, or turn off.

Change your phone's Bluetooth device name.

Re-scan.


Connect a device found by the scan.



Turn WLAN power on & scan, or turn off.

Connect a network found by the scan.

- To connect **Bluetooth devices**, touch Menu (☰) > **Settings** > **Wireless & networks** > **Bluetooth settings** > **Scan for devices** (or **Bluetooth**, if it is off). Touch a device that your phone found, to connect it.
- To connect **Wi-Fi networks**, touch Menu (☰) > **Settings** > **Wireless & networks** > **WLAN settings** (then touch **WLAN**, if it is off). Touch a network that your phone found, to connect it.
- To use a **cable connection**, connect your phone's micro USB port to a standard USB port on your computer, then use a computer program to transfer files to and from your phone's memory card. Your phone supports microSD cards up to 32GB.

On your phone, flick down the status bar and touch  to enable your phone's memory card.

You can download your phone's driver files from www.motorola.com/support.

- To make your phone a **hotspot** that other devices can use to connect to the Internet, touch Menu (☰) > **Settings** > **Wireless & networks** > **Tethering & portable hotspot**. Then, choose to enable **USB tethering** or **Portable WLAN hotspot**.

Note: Keep it secure. To protect your phone and hotspot from unauthorized access, it is strongly recommended that you set up hotspot **Security (WPA2 is the most secure)**, including password.

WI-FI MODES

For those who like to get a bit more technical, your phone supports the following Wi-Fi modes:

802.11b, g, n.




SECURITY

help keep your phone safe

QUICK START: SECURITY

From the home screen, touch Menu  > **Settings** > **Location & security**.




Set a lock pattern, PIN, or password required to wake up the screen.

Choose a number code required to turn on your phone.

Show password letters and numbers when you enter them (rather than ***).

RESET


To reset your phone to factory settings and erase all the data on your phone, touch Menu  > **Settings** > **Privacy** > **Factory data reset** > **Reset phone**.

Warning: All downloaded apps and user data on your phone will be deleted.

TROUBLESHOOTING

we're here to help

CRASH RECOVERY

In the unlikely event that your phone stops responding to touches and key presses, try a quick reset. Press and hold Power , then touch **Restart**, or remove the back cover and battery (“**ASSEMBLE & CHARGE**” on page 6), then replace and turn on your phone as usual.

SERVICE & REPAIRS

If you have questions or need assistance, we're here to help.

Go to www.motorola.com/support, where you can select from a number of customer care options. You can also contact the Motorola Customer Support Center at 1-800-331-6456 (United States), 1-888-390-6456 (TTY/TDD United States for hearing impaired), or 1-800-461-4575 (Canada).