


3. Subway Map

The phone provides the nationwide subway route map. The information is subject to change depending on the circumstances.

View Route Map

You can view the nationwide subway routes.

Press **[Left]** ▶ Press **[5]** ▶ Press **[3]** ▶ Press **[1]**




- Press **[Left]** to select a line and view the map in a specific area you have selected.
- Press **[Right]** to search a route.
(See Search Route for details.)

Search Route

You can search a subway route.

Press **[Left]** ▶ Press **[5]** ▶ Press **[3]** ▶ Press **[2]**




- You can find the number of transfers required and the estimated travel time. (The estimated travel time includes the distance between stations and the transfer time (approx. 5min). It is an estimation, and can be different from the actual time.)
- Press **[Left]** to save the route in 'My Route'. Press **[Right]** to check the route with minimum number of transfers or with the shortest distance.

My Route

You can check your saved routes.

Press **[Left]** ▶ Press **[5]** ▶ Press **[3]** ▶ Press **[3]**



- Press **[Left]** to save the route searched with 'View Route Map' or 'Search Route'.
- Press **[Left]** to delete a route or delete all routes.

Station Info.

Select a subway station and press **[Home]** to find first/last train timetable, exit info and transfer info.

Press **[Left]** ▶ Press **[5]** ▶ Press **[3]** ▶ Press **[4]**

Lost Property Office

Telephone numbers of the lost property offices are displayed.

Press **[Left]** ▶ Press **[5]** ▶ Press **[3]** ▶ Press **[5]**

Settings

You can set the frequently searched area.

Press **[Left]** ▶ Press **[5]** ▶ Press **[3]** ▶ Press **[6]**

Help

Guide to use the buttons when the subway map is displayed.

Press **[Left]** ▶ Press **[5]** ▶ Press **[3]** ▶ Press **[7]**

4. Dictionary

You can search words by using English-Korean/Korean-English dictionaries.

Before using the dictionary

• Downloading via PC-Sync Program

- 1) Go to Motorola homepage (www.mymotorola.co.kr), download PC-Sync, and install it to PC.
- 2) Run PC-Sync program and click [E-Document > Dictionary]
- 3) If you select [Put E-Dictionary into Cell Phone] after clicking [E-Dictionary] from [E-Document > Dictionary] program, the e-dictionary database are saved in the phone.

• Downloading via USB Mass Storage

- 1) Go to Motorola homepage (www.mymotorola.co.kr), download e-dictionary-related database.
- 2) If you copy a downloaded file to DIC folder of a USB Mass Storage after connecting the mobile phone to PC, e-dictionary database are saved in the phone. (USB Mass Storage, see p.142)

• When searching words in English-Korean/Korean-English dictionary, if you press **Left**, you can view list, view English-Korean/Korean-English dictionary, view previous word, my vocabulary, and add to my vocabulary.

• Press **Left** when you are on English-Korean/Korean-English page, you can change the screen to English-Korean/Korean-English search screen.

• You can use an e-dictionary menu if there are e-dictionary database.

English-Korean

If you enter English word in the box, the related words are displayed.

Press **Left** ▶ Press **5** ▶ Press **4** ▶ Press **1**



- ➔ After selecting a desired word, you can check the word by pressing **Move OK**.
- ➔ Upon checking the word, you can perform Tap.Move/Tap Clear by pressing **Right**. When moving the tap, you can select desired word by using **Move OK** or **Left**. If you press **Move OK**, you can move to selected word.
- ➔ You can check the previous words by pressing **Left**.

Korean-English

If you enter Korean word in the box, the related words are displayed.

Press **Left** ▶ Press **5** ▶ Press **4** ▶ Press **2**

- ➔ After selecting a desired word, you can check the word by pressing **Move OK**.
- ➔ Upon checking the word, you can perform Tap.Move/Tap Clear by pressing **Right**. When moving the tap, you can select desired word by using **Move OK** or **Left**. If you press **Move OK**, you can move to selected word.
- ➔ You can check the previous words by pressing **Left**.

My Vocabulary

You can save the words searched from dictionary.

Press **Left** ▶ Press **5** ▶ Press **4** ▶ Press **3**

- ➔ When searching words via dictionary, you can save them into My Word List in order by pressing **Left** and selecting Add to Word List.
- ➔ You can save up to 1,000 words per folder.
- ➔ Press **Left** to use various functions including Set/Clear Study, Delete, Move Words, Sort (in English/Korean spelling order, by date), Manage Folder(rename folder, lock folder), Delete All in Folder, and Select All in Folder.
- ➔ Press **Right** to select the words and press **Left** to use the functions such as Set/Clear Study, Delete, Move and Clear All.

My History

You can save, check and manage up to 100 searched words for each Korean-English/English-Korean dictionary.

Press **Left** ▶ Press **5** ▶ Press **4** ▶ Press **4**

- ➔ If a capacity is exceeded its space, older words will be deleted first.

Settings


You can set automatic word save setting/released and font (type) and size.

Press **Left** ▶ Press **5** ▶ Press **4** ▶ Press **5**

5. File Viewer

You can view files stored in internal/external memory.

Press **Left** ▶ Press **5** ▶ Press **5**



Note

- The image displayed on the phone can be different from that shown on PC, and some of figures may be omitted.
- Some images or text may not be displayed depending on the file type or size..


Left	Help	1	Press-Previous page Press & Hold-Start page
Right	Rotate screen	2	Set to screen
Volume key	Zoom	3	Press-Next page Press & Hold-End page
Home	Hide/Show menu	*	Previous file
Back	Previous screen	#	Next file

- You can view image files (JPG, BMP, PNG, GIF, WMF, EMF) and document files (PDF, Text, HTML, Word, Excel, Power Point).
- To use the file viewer, you should save files in the internal memory with PC Sync program.
- For external memory, the external memory card (Micro-SD) must be mounted on the phone. (USB Mass Storage, see p.142)
 - You can download PC Sync program from the Motorola homepage (www.mymotorola.co.kr).
- Select a file in the list and press **Left**. You can use Delete, File name/Information, Sort by time, Sort by name, Sort by type, Sort by size, Delete all, and bluetooth.

6. E-book

You can read the text file on the phone. See 'Help' for further information.

Press **Left** ▶ Press **5** ▶ Press **6**



- The phone provides the space of upto 200 E-books, with maximum 1024K per an E-book file. The number of files to be stored in the phone varies depending on the file size.
- You can use Go To, Search word, Search dictionary, Display and Help by pressing **Left**.



Note

- The E-dictionary program must installed in the phone or external memory. For more information see Dictionary Guide. (Dictionary, see p. 136)


Button description

Volume key	Move page	*	Start page
Home	Move line	#	End page

7. Stopwatch

You can use the phone as a stopwatch.

Press **Left** ▶ Press **5** ▶ Press **7**



- You can record upto 20 lap times with the lap time function.
- The stop watch continues even if you close the folder.

Button description


Home	Start/Pause/Resume
Right	Reset (Previous screen)
Left	During counting: Lap time

8. Astro/Yoga/Acupress

You can check your astrology, get information on Yoga and acupress to maintain your health.

1 Astrology

Press **⏮** (Left) ▶ Press **5** ▶ Press **8** ▶ Press **1**



3) Hwatu Cards

- You can see your luck with the Hwatu card.
- For more details, refer to Help.

4) Horoscopes

- You can see your luck of the lifetime, week or month with your Horoscope.

5) Blood Type Fortune

- You can see your characteristics and material harmony based on your blood type.

6) Biorhythm

- Your monthly, weekly and daily biorhythms are provided with physical, emotional and intelligent index with interpretation.
- Press **⏮** to check monthly, weekly biorhythm.
- You can check the daily biorhythm by selecting on the weekly biorhythm displayed.

7) Lucky Number

- Press and press again to receive 6 lucky numbers.

8) User Settings

- Enter your exact date of birth to view the exact information.

1) My Fortune

- Enter your date of birth to check your luck.
- After you have entered for the first time, the date of birth is automatically changed to the initial setting.

2) Tarot Cards

- You can see your luck with the Tarot card which is traditional European card games.
- For more details, refer to Help.

2 Yoga

Press **⏮** (Left) ▶ Press **5** ▶ Press **8** ▶ Press **2**



- 13 Yoga movements including Get shaped-Basic posture are described.
- Press to change the content.
- Press to check the order of figures.
- Press **⏮** (Left) to view description on each Yoga movement.

3 Acupressure Guide

Press **⏮** (Left) ▶ Press **5** ▶ Press **8** ▶ Press **3**



- 12 points on the body are displayed including hand, foot, and acupuncture points.
- Press to change the content.
- Press to check the figures.
- Press **⏮** (Left) to view description on each the massage method for each body part.

9. USB Mass Storage

You can transmit various contents and MP3 files between the phone and PC via the 5PIN USB data cable.

Press  (Left) ► Press  ► Press 

1 Check USB Mass Storage

- Check if an external memory card (Micro-SD) is mounted on the phone.
- Visit Motorola homepage (www.mymotorola.co.kr) and download the USB driver program.
- Connect the 5PIN USB data cable to the USB port of PC, and connect the other end to the charging connector of the mobile phone.
 - Do not forcefully remove the 5PIN USB data cable rather than releasing connection on the PC.
(The mobile phone can be switched off.)



Note

- The MP3 files downloaded to the USB mass storage in the mobile phone cannot be played in other mobile phone.
- You can find the MP3 files stored in the USB mass storage in "June Contents Box".
(June Contents Box, see p.105)
- You cannot play the MP3 files or contents if you rename or delete the default folder name of the USB mass storage.

2 Mounting external memory card (Micro-SD)



1 Remove the battery cover as shown in the figure.

2 Mount the external memory (Micro-SD) as shown in the figure.

- Be sure that the external memory is mounted to the correct direction, or the slot can be damaged.
- Icon is displayed on the standby screen when the external memory is mounted properly.

※ Slide the external memory to the outside when removing the external memory card. (Micro-SD)

You can mount and dismount the external memory card.
(The external memory card is not included in the product package.)

- Do not turn off the phone while using the data stored in the external memory card.
 - The data in the card can be erased.
- Insert the external memory card and restart it, if you first use the card or if there is an error on the card.
- Keep the external memory card in the safe place.
 - Do not give impact or bend the card.
 - Keep the card away from hot and humid place, the place with corrosive material or the place with magnetic wave or static electricity.



Note

- When using the external memory card, you can only use some certain functions and other functions are restricted.
- End the USB mass storage before you remove the external memory card.
 - A critical system error or defect may occur.
- Motorola takes no responsibility on loss or damage of data caused due to negligence or mishandling of the user.
- This product supports upto 4GB capacity of Micro-SD.

MEMO

Handwriting practice area with 10 horizontal dotted lines on a light green background.



09
Organizer

01 Morning call/Alarms	146
02 Calendar	148
03 Scheduler	149
04 Memo	150
05 Diary	151
06 Calculator	152
07 World Time	154

1. Morning call/Alarm

The phone provides bell or vibrates at the designated time.

Easy Alarm

When the time reaches to the period user have set, the alarm rings once.


Press (Left) ▶ Press ▶ Press

Note

- If an alarm is on, is displayed on the screen and when it is off, icon is no longer displayed on the screen.
- If the phone is set to 'Vibrate' or 'Etiquette mode', the phone vibrates instead of rings. (The phone rings for morning call.)
- When alarms set to the same time, operate in the following priority order: (Easy Alarm → Morning Call → My Alarm 1~5)
- You can turn off the alarm by opening/closing the folder when alarm rings.
 - You can also turn off the alarm by pressing (Volume key), (Camera), (NATE), (Hold), (Right).
- If you set the morning call to repeat more than once, you must press (Right) to turn off the morning call. (Morning Call, see p.147)

Press (Left) ▶ Press ▶ Press

▶ 간편알람 선택 후 버튼 누름



- If the designated timer for easy alarm expires, the alarm rings once.
 - After alarm rings once, it automatically turns off.
- You can set time by 1~999min.

Morning Call

You can set the repeat count and cycle for morning call at the required time.

Press (Left) ▶ Press ▶ Press ▶ Press

▶ Press after selecting Morning Call



- You can set alarm at the desired day of a week by selecting a day with (Right) and setting the desired time in the cycle field.
- If a morning call sounded with one or more repeat times previously set, you can set Morning Call Standby function by pressing .
 - If the repeat time set is ended or you do not press (Right), the internal and external screens are waiting for Morning Call.


- Even if you open or close the folder or press (Volume key), and (Camera) the phone is set to Morning Call Standby and the morning call is sounded at the time of repeat previously set.
- If you press (Right) upon Morning Call sounding, Morning Call of the day will be cleared regardless of a repeat time previously set.

My Alarm

You can set the Alarm to ring at a desired time.

Press (Left) ▶ Press ▶ Press ▶ Press


▶ Press after selecting My Alarm



- You can set an alarm to be sounded at a desired time by setting a time and interval.
- You can enter maximum 20 Korean characters and 40 English character for memo, a message content will be displayed when an alarm is sounded.
- You can set alarm at the desired day of a week by selecting a day with (Right) and setting the desired time in the cycle field.

2. Calendar

If you set and save a schedule, alarm rings on a corresponding date and displays the stored content.



Press **[Left]** ▶ Press **[MNO 6]** ▶ Press **[LSD ABC 2]**

- You can select New Schedule, New Things To-do, New Anniversary Date, New D-day, and New Meeting Planner by pressing **[Right]** at a desired date.
(You can add 180 items for schedule, things to do and anniversary date, 30 items for d-day and 50 items for meeting planner.)
- If you select 'Calendar top/bottom' or '3 Months top/bottom' in 'Set Standby', the current month is displayed with the scheduled dates in different color.
- When schedules set to the same time, alarm operate in the following priority order:
– D-day → Anniversary → Schedule → Meeting Planner
- Schedule start up page is the monthy calendar.
– Press **[Left]** to find the schedules by Day/Month/Year.
- Press **[Left]** to use Month, Week, Go to a date, Delete, Delete by day or month, and Delete all.
– When setting View by week, select a day of a week and press **[MNO OK]** to check the daily schedule.

Menu description

- New schedule :** The phone provides the alarm and displays memo in accordance with the alarm cycle until the cycle is expired.
- New to-do :** The to-do item is displayed as a block from the start date to the end date.
- New anniversary :** The phone provides the alarm and dispys memo at the designated anniversary.
- New D-day :** Days remaining to or passed from a specific day is displayed on the standby screen.
The alarm rings on the designated date.
- New meeting planner :** If you enter a time, the times of major cities of the world are displayed. The alarm rings and the memo appears until the end date of the selected period.

3. Scheduler

You can view or add schedule you have entered in.

Schedule

Press **[Left]** ▶ Press **[MNO 6]** ▶ Press **[LSD ABC 3]** ▶ Press **[LSD ABC 1]**



- Press **[Left]** to use View by month, Delete or Delete all.
- Press **[Right]** to add a new schedule.

To-do

Press **[Left]** ▶ Press **[MNO 6]** ▶ Press **[LSD ABC 3]** ▶ Press **[LSD ABC 2]**

- Press **[Left]** to use View by month, Delete or Delete all.
- Press **[Right]** to add a new to-do.

Anniversary

Press **[Left]** ▶ Press **[MNO 6]** ▶ Press **[LSD ABC 3]** ▶ Press **[LSD ABC 3]**

- Press **[Left]** to use View by month, Delete or Delete all.
- Press **[Right]** to add a new schedule.

3. Scheduler (Cont'd)

You can view or add schedule you have entered in.

D-day

Press (Left) ▶ Press ▶ Press ▶ Press

- Press (Left) to use View by month, Delete or Delete all.
- Press (Right) to add a new d-day.
- If you select the calculation by date for D-day setting, D-day will be indicated from a current date based on the date entered. If you select the calculation by a certain date, entering remaining dates or passing dates based on the date entered will indicate D-day.

Meeting Planner


Press (Left) ▶ Press ▶ Press ▶ Press

- Press (Left) to use View by month, Delete or Delete all.
- Press (Right) to add a new meeting plan.

4. Memo

You can store upto 50 memos in the phone.

Press (Left) ▶ Press ▶ Press



- Press (Right) to add a new meeting plan.
- You can enter a memo of upto 48 Korean letters or 96 English letters.
- When checking a written memo, you can edit it by pressing .
- Press (Left) on the list to delete, protect/lock or delete all.


5. Diary

You can write the photo diary or diet diary on the phone.

Photo Diary

You can write and manage diary with the photos.

Press (Left) ▶ Press ▶ Press ▶ Press



1 Write Diary

- The photos used in the photo diary are not deleted even if the same photos are deleted from 'Photo Album'.
- You can store upto 180 photo diaries and cannot duplicate diaries on the same date.
- You cannot use photos saved in the external memory.

2 Read Diary

- You can check, delete, or edit the stored photo diary.

3 Settings

- You can set font color and diary background.


5. Diary (Cont'd)

You can write the photo diary or diet diary on the phone.

Diet Diary

Set goals for weightloss, this can help from this function or diet.

Press **[Left]** ▶ Press **[MNO 6]** ▶ Press **[5 JKL]** ▶ Press **[Z LIO ABC]**



1 My Diet Diary

How to Record My Body Info

Press **[Left]** to select a desired date on the calendar and press **[MNO 6]** to record.

Press **[Right]** to Input the body info.

—You can check standard weight, B.M.I., and B.M.R.

How to Record Food Log

Press **[MNO 6]** to select the food, press **[Right]** to find out the total calories.

Press **[Left]** to select [User Input] or [Add Food].



Note

- When searching dates on the calendar, you can search daily/monthly/yearly/records by pressing **[Left]**.
- Dates indicating that body and meal records are kept on the calendar are displayed in color, and you can check their contents on the bottom of the screen.

2 My Food Log

- The records are displayed.
- Press **[MNO 6]** to check the monthly record.
- Press **[Right]** to add a record.
- Press **[Left]** to view/delete/delete all of diet records lists and graphs.


3 My Body History

- The records are displayed.
- Press **[MNO 6]** to check the monthly record.
- Press **[Right]** to add a record.
- Press **[Left]** to view/delete/delete all of diet records lists and graphs.

6. Calculator

You can make simple calculation with the phone.

Press **[Left]** ▶ Press **[MNO 6]** ▶ Press **[MNO 6]**



- ➔ Press **[Right]** to make the calculation again.
- ➔ When entering numbers or symbols, press **[Left/Right]** to delete a character, press and hold to delete all.
- ➔ You can use the operators several times in a calculation.

Operators

