




MOTOMANUAL

W385
CDMA
English

motorola.com

HELLOMOTO

Introducing your new Motorola W385 CDMA wireless phone. Here's a quick anatomy lesson.



Home Screen




② Press the center key  to open the **Main Menu**.

① Press and hold the power key  for a few seconds, or until the display lights up, to turn on your phone.

Main Menu



③ Press the navigation key  left/right to highlight a menu option, then down to highlight a suboption.

④ Press the center key  to select.

FOR POSITION ONLY

Motorola, Inc.
Consumer Advocacy Office
1307 East Algonquin Road
Schaumburg, IL 60196

www.hellomoto.com

Certain mobile phone features are dependent on the capabilities and settings of your service provider's network. Additionally, certain features may not be activated by your service provider, and/or the provider's network settings may limit the feature's functionality. Always contact your service provider about feature availability and functionality. All features, functionality, and other product specifications, as well as the information contained in this user's guide are based upon the latest available information and are believed to be accurate at the time of printing. Motorola reserves the right to change or modify any information or specifications without notice or obligation.

MOTOROLA and the Stylized M Logo are registered in the US Patent & Trademark Office. Windows is a registered trademark of Microsoft Corporation. All other product or service names are the property of their respective owners.

© Motorola, Inc., 2007.

Caution: Changes or modifications made in the radio phone, not expressly approved by Motorola, will void the user's authority to operate the equipment.

Software Copyright Notice

The Motorola products described in this manual may include copyrighted Motorola and third-party software stored in semiconductor memories or other media. Laws in the United States and other countries preserve for Motorola and third-party software providers certain exclusive rights for copyrighted software, such as the exclusive rights to distribute or reproduce the copyrighted software. Accordingly, any copyrighted software contained in the Motorola products may not be modified, reverse-engineered, distributed, or reproduced in any manner to the extent allowed by law. Furthermore, the purchase of the Motorola products shall not be deemed to grant either directly or by implication, estoppel, or otherwise, any license under the copyrights, patents, or patent applications of Motorola or any third-party software provider, except for the normal, non-exclusive, royalty-free license to use that arises by operation of law in the sale of a product.

Manual Number: -0

contents

menu map	6	send a multimedia message	18	change lock code	36
Use and Care	8	receive a multimedia message	20	lock & unlock phone	37
essentials	9	download pictures	21	customize	39
about this guide	9	Bluetooth connections	21	conserve battery	
battery	10	cable connections	24	charge	39
turn it on & off	12	TTY operation	24	sounds settings	39
make a call	12	basics	26	get ringtones	41
answer a call	13	home screen	26	talking phone settings	41
store a phone number	13	enter text	29	answer options	42
call a stored phone number	13	adjust volume	34	wallpaper	42
see your phone number	14	change sound settings	34	screen saver	43
main attractions	15	external display	34	backlight	44
record & play voice records	15	handsfree speaker	34	brightness	44
take a photo	16	standalone mode	36	clock format	44
				AGPS & your location	45
				AGPS limitations & tips	46

calls	47
redial a number	47
automatic redial	47
recent calls	48
return unanswered calls	49
speed dial	49
emergency calls	50
AGPS during an emergency call	50
voicemail	51
in-call options	52
other features	53
advanced calling	53
messages	54
contacts	55
personalizing	59
call times & data volumes	66
handsfree	68

Bluetooth wireless connections	68
network	70
personal organizer	71
security	72
fun & games	72
service & repairs	74
Specific Absorption Rate Data	75
Safety and General Information	79
Industry Canada Notice to Users	84
FCC Notice To Users	85
Motorola Limited Warranty for the United States and Canada	86

Hearing Aid Compatibility with Mobile Phones	90
Information from the World Health Organization	91
California Perchlorate Label	93
Smart Practices While Driving	94
index	96

menu map

main menu



GET IT NOW*

- Music & Tones
- Picture
- Games
- News & Info
- Tools on the Go
- Extras



MESSAGING

- New Message
- Inbox
- Sent
- Drafts
- Voicemail
- E-mail*
- Mobile IM*
- Chat*



CONTACTS

- New Contact
- Contact List
- Groups
- Speed Dials



RECENT CALLS

- Missed
- Received
- Dialed
- All
- View Timers



SETTINGS & TOOLS

- (see next page)

* Wireless web services required

This is the standard main menu layout.
Your phone's menu may be different.

settings menu

My Account*

- Balance
- Usage
- Payments
- My Plan
- My Features
- Change VM PW
- Find Store
- FAQs

Tools

- Voice Commands
- Calendar
- Alarm Clock
- World Clock
- Notepad
- Calculator

Bluetooth

- Add New Device

Sounds Settings

- Master Volume
- Call Sounds
- Alert Sounds
- Keypad Volume
- Service Alerts
- Power On/Off
- Alarm Sounds
- Talking Phone

Display Settings

- Banner
- Backlight
- Brightness
- Wallpaper
- Screensaver
- Display Themes
- Alert Lights
- Clock Format

Phone Settings

- Standalone Mode
- Shortcut Key
- Language
- Location
- Security
- System Select
- NAM Select
- Text Input

Call Settings

- Answer Options
- Auto Retry
- TTY Mode
- One Touch Dial
- Voice Privacy
- Call Restrictions
- DTMF Tones

Memory

- Save Options**
- Phone Memory
- Card Memory**

Phone Info

- My Number
- SW Version
- Icon Glossary
- Software Update

** available only when optional memory card installed

* requires Mobile Web service

Use and Care

To care for your Motorola phone, please keep it away from:



liquids of any kind

Don't expose your phone to water, rain, extreme humidity, sweat, or other moisture.



extreme heat or cold

Avoid temperatures below -10°C/14°F or above 45°C/113°F.



microwaves

Don't try to dry your phone in a microwave oven.



dust and dirt

Don't expose your phone to dust, dirt, sand, food, or other inappropriate materials.



cleaning solutions

To clean your phone, use only a dry soft cloth. Don't use alcohol or other cleaning solutions.



the ground

Don't drop your phone.

essentials

CAUTION: Before using the phone for the first time, read the *Important Safety and Legal Information* included in the gray-edged pages at the back of this guide.

about this guide

This guide shows how to locate a menu feature as follows:

Find it: MENU (◉) ▶ RECENT CALLS ▾ Received

This means that, from the home screen:

- 1 Press the *center key* (◉) to open the menu.
- 2 Press the *navigation key* (◉) left or right to scroll to 'RECENT CALLS'.
- 3 Press the navigation key (◉) down to scroll to **Received**, and press the center key (◉) to select it.
- 4 Press **CLR** to return to the previous menu, or **HOME** to return to the home screen.

symbols



This means a feature is network/subscription dependent and may not be available in all areas. Contact your service provider for more information.

symbols



This means a feature requires an optional accessory.

battery

battery tips

Battery life depends on the network, signal strength, temperature, features, and accessories you use.

- Always use Motorola Original batteries and chargers. The warranty does not cover damage caused by non-Motorola batteries and/or chargers.
- New batteries or batteries stored for a long time may take more time to charge.



- When charging your battery, keep it near room temperature.

When storing your battery, keep it uncharged in a cool, dark, dry place.

- Never expose batteries to temperatures below -10°C (14°F) or above 45°C (113°F). Always take your phone with you when you leave your vehicle.
- It is normal for batteries to gradually wear down and require longer charging times. If you notice a change in your battery life, it is probably time to purchase a new battery.





Contact your local recycling center for proper battery disposal.

Warning: Never dispose of batteries in a fire because they may explode.


Before using your phone, read the battery safety information in the "Safety and General Information" section included in this guide.

install the battery



charge the battery

New batteries are not fully charged. Plug the battery charger into your phone and an electrical outlet. Your phone might take several seconds to start charging the battery.



If your phone is charging while powered off, it displays **Charge Complete** when finished.

If your phone is powered on while charging, it displays a temporary charge complete

message, and the battery symbol stops flashing.


Tip: Relax, you can't overcharge your battery. It will perform best after you fully charge and discharge it a few times.

You can charge your battery by connecting a cable from your phone's mini-USB port to a USB port on a computer. Both your phone and the computer must be turned on, and your computer must have the correct software drivers installed. Cables and software drivers are available in Motorola Original data kits, sold separately.




turn it on & off

1 Open your phone.


2 Press and hold  for a few seconds or until the display turns on.




The phone may require several seconds to turn on. If prompted, enter your four-digit unlock code (the last four digits of your phone number or **1234**) and press **OK** to unlock the phone.

To turn off your phone, press and hold  for a few seconds.

make a call


Enter a phone number and press  to make a call.

To "hang up," close the flip or press .

Tip: Closing the flip also ends the call, unless you are using the speakerphone feature (see page 34).

answer a call

When your phone rings and/or vibrates, just open the flip or press  to answer.


To “hang up,” press .


Tip: Closing the flip also ends the call, unless you are using the speakerphone feature (see page 34).

store a phone number

You can store a phone number in **Contacts**:

- 1 Enter a phone number in the home screen.
- 2 Press **Save**.

Press the left soft key to select **Create New**, then press **OK** (.

- 3 Enter a name and other details for the phone number. To select a highlighted item, press the center key (.
- 4 Press **Save** to store the number.


To edit or delete a **Contacts** entry, see page 56.

Tip: You can set your phone to display a picture for each caller or set it to play a ringtone for a specific caller each time they call you (see “assign picture to entry” on page 56 and “assign ringtone to entry” on page 57).

call a stored phone number

Find it: MENU () >  **CONTACTS** ▾ **Contact List**

- 1 Scroll to the **Contacts** entry.

2 Press  to call the entry.

Tip: Find it fast! Press **Contacts** (the right soft key) from the home screen to see your **Contacts** list.

see your phone number

From the home screen, press  .

Tip: Want to see your phone number while you're on a call? Press **Options**, then **Phone Info** ▾ **My Number** ▾ **MDN**

main attractions

You can do much more with your phone than make and receive calls!

record & play voice records

You can create a voice record that you can play back later as a reminder for yourself.


create voice record


Find it: MENU (•◉•) ▶  GET IT NOW

▼ Music & Tones ▼ My Sounds

- 1 Scroll to **Record New** and press **OK** (•◉•).
- 2 Press **OK** (•◉•) to begin recording, then **STOP** (•◉•) when finished.

The voice record is automatically saved and displayed in the **MY SOUNDS** list. You can now select **Play**, **SEND** (•◉•), or **Options**.

Tip: To create a voice record quickly, press and hold the voice key (on the right side of the phone), then press **OK** (•◉•) to begin recording. Press **STOP** (•◉•) when finished. Press **Save** to save the voice record, **SEND** (•◉•) to send it in a message, or **Erase** to delete it. Press  to exit.

Tip: After you create a voice record, you can give it a new name. In the **MY SOUNDS** listing, your phone displays an  indicator beside the names of voice records that you created. Scroll to the voice record you want to rename, press **Options**, then scroll to and select **Rename**.

play voice record

Find it: MENU (•◂◃•) ▶ ◀◂◃◀ GET IT NOW
▼ Music & Tones ▼ My Sounds

Scroll to the file name of the desired voice record and press **PLAY** (•◂◃•).

take a photo

Use your phone's camera to take photos that you can save or send in in multimedia messages to other wireless phone users.

Your camera lens is on the back of your phone when the phone is open (see page 1). **To get the clearest photos, wipe the lens clean with a soft, dry cloth before you capture a photo.**

take photo & send in message


To activate the camera:

Find it: MENU (•◂◃•) ▶ ◀◂◃◀ GET IT NOW ▼ Picture

1 Scroll to **Take Picture** and press **OK** (•◂◃•).

Tip: You can also activate the phone's camera by pressing the camera key (📷).

The active viewfinder image appears on your phone's screen:



2 Point the camera lens at the camera subject.

Press •◂◃• left and right to zoom in and out.

Press **Options** to open the **OPTIONS** menu (see the following section).

- 3 Press **TAKE** (•◉•) to take a photo.
- 4 Press **SEND** (•◉•) to save the photo and go to the **CREATE PICTURE MESSAGE** screen.

or

Press **Erase** to delete the photo and return to the active viewfinder.

or

Press **Save** to save the picture to **My Pictures**.

Tip: To take a self-portrait, activate the camera, close the flip, point the lens at yourself, and center yourself in the external display. (Hold the camera at least 18 inches away.) Press the smart/speakerphone key to take the photo.

adjust camera settings

When the camera is active, press **Options** to open the **OPTIONS** menu, which can include the following options:

option	
Resolution	Set resolution to 640x480 , 320x240 , or 160x120 .
Self Timer	Set the camera to take a photo after a specific interval.
Brightness	Adjust image brightness.
White Balance	Adjust for different lighting.
Shutter Sound	Activate a sound that plays when you take a photo.
Color Effects	Scroll left or right to select Normal , Antique , Black & White , or Negative .
Fun Frame	Select from different types of backgrounds to frame the image.

send a multimedia message



A *multimedia message* contains embedded media objects (possibly including photos, pictures, sounds, or voice records). You can send a multimedia message to other Wireless multimedia messaging-capable phones and to other email addresses.

create & send message

Find it: MENU (•◊•)  ► MESSAGING
▼ New Message ▼ Picture Message or Video Message

1 Press keypad keys to enter a phone number, then **OK** (•◊•).

or

Press **Add** ▼ **Contacts**, then **OK** (•◊•). For each **Contacts** entry you want to add, scroll to the

entry and press **MARK** (•◊•). Press **Done** when finished selecting entries.

or

Press **Add** ▼ **Recent Calls**, then **OK** (•◊•). For each **Recent Calls** entry you want to add, scroll to the entry and press **MARK** (•◊•). Press **Done** when finished adding entries.

- 2** Scroll to the **Text** entry area.
- 3** Press keypad keys to enter message text.
- 4** Scroll to the **Picture** entry area and press **Pics**.
or
Scroll to the **Video** entry box and press **Videos**.
- 5** Scroll to a picture and press **OK** (•◊•).
or
Scroll to a video clip and press **OK** (•◊•).

6 If you are sending a **Picture** message and want to attach a sound, scroll to the **Sound** entry area and press **Sounds**. Then scroll to a sound and press **OK** (•◂•).

7 Scroll to **Subject**.

8 Press keypad keys to enter the message subject.

or

Press **Options**, scroll to **Add Quick Text** and press **OK** (•◂•). Then select a **Quick Text** item as the message subject.

9 Press **SEND** (•◂•) to send the message.


message options

While creating a multimedia message, press **Options** to open the **OPTIONS** menu, which can include the following options:

option	
Preview	View the current contents of the message.
Add Quick Text	<i>Quick text</i> is a prewritten message that you can quickly select and send. Your phone comes with several quick text messages, and you can create additional ones.
Save as Draft	Save the message to the Drafts folder.
Priority Level	Set to High or Normal .

option	
Validity Period	Specify how long the message stays in the Outbox folder.
Deferred Delivery	Send the message later at a time and date that you set.
Remove Picture, Remove Sound, Remove Video	Remove a multimedia object from the message.
Add Slide	Add a page to the message.
Add To Contacts	Add the message recipient to your Contacts .

receive a multimedia message

When you receive a multimedia message, your phone displays the  (message waiting)

indicator and a **New Message** notification, and plays an alert sound.

Open the flip and press **View Now** to view the message immediately or **View Later** to save it in your **Inbox** to view later.

To view messages in your **Inbox**:

Find it: MENU (•◉•) ▶  MESSAGING ▾ **Inbox**

- 1 Scroll to the desired message.
- 2 Press **Open** to open the message.

Multimedia messages that you receive can contain different media objects:

- Photos, pictures, and animations are displayed as you read the message.
- A sound file begins playing when its slide is displayed. Use the volume keys to adjust the volume as the sound file plays.

- To open an attachment, highlight the file indicator/filename and press **VIEW** (for an image file), **PLAY** (for a sound file), or **OPEN** (for a vObject such as a **Contacts** or datebook entry or an unknown file type).

download pictures



Find it: Press **MENU** (•◂•) ► **GET IT NOW**

▼ **Picture**

- 1 Scroll to **Get New Pictures** and press **OK** (•◂•).
- 2 With **Get New App** highlighted, press **OK** (•◂•) to connect to **Get It Now**.

Note: Normal airtime and/or carrier usage charges apply.

Bluetooth® connections

Your phone supports Bluetooth wireless connections. You can connect your phone with a Bluetooth headset or car kit to make handsfree calls.

Note: The use of wireless phones while driving may cause distraction. Discontinue a call if you can't concentrate on driving. Additionally, the use of wireless devices and their accessories may be prohibited or restricted in certain areas. Always obey the laws and regulations on the use of these products.

Your phone currently supports the following Bluetooth profiles:

- Headset
- Handsfree
- Dial Up Networking (DUN)

- Serial Port Profile (SPP)
- Advanced Audio Device Profile (A2DP—Stereo Bluetooth Profile)
- OBEX profiles—File Transfer Profile (FTP) and Object Push Profile (OPP) for device-generated content (image and video), and vCard (OPP only)

For more information about Bluetooth wireless connections supported by this device, go to FAQ


www.

For information on vehicle compatibility, go to www.

Note: All multimedia (video player, audio player, shutter tone, V CAST) will play from the speakerphone when your phone is connected to another Bluetooth device **except** Bluetooth A2DP stereo headphones.

For maximum Bluetooth security, you should always connect Bluetooth devices in a safe, private environment, away from other devices with Bluetooth connection capabilities.

turn Bluetooth power on or off

Find it: Press MENU (•◉•) ▶  SETTINGS & TOOLS
▼ Bluetooth

Press the left soft key to turn Bluetooth power **On** or **Off**.

Note: To extend battery life, use this procedure to set Bluetooth power to **Off** when not in use. Your phone will not connect to devices until you set Bluetooth power back to **On** and connect your phone with the device again.


pair with a headset, handsfree device, or PC

Note: If you want to use your Motorola Bluetooth headset with both an audio device and your phone, use your phone's Bluetooth menus to connect the phone with the headset. If you establish the connection by pressing a button on the headset, or if you allow the headset to connect automatically by turning it on, you may experience unexpected results.

Before you try to connect your phone with another Bluetooth device, make sure your phone's Bluetooth power is **On** and the other device is in *pairing* or *bonding* mode (see the user's guide for the device). You can connect your phone with only one device at a time.


Find it: MENU (•◉•) ▶  **SETTINGS & TOOLS**
▼ **Bluetooth** ▼ **Add New Device**

Note: If your Bluetooth power is not turned on, your phone will prompt you to turn it on.

Your phone lists the devices it finds within range. If your phone is already connected to a device, your phone identifies that device with a  (Bluetooth connection active) indicator.

- 1 Scroll to a device in the list.
- 2 Press **Pair** to connect to the device.
- 3 If the device requests permission to bond with your phone, press **YES** and enter the device PIN code to create a secure connection with the device. (The PIN code is typically set to **0000**).

Note: See the instructions that came with your device for the device PIN code and other information about the device.


When the connection is made, the Bluetooth connection active indicator () or a **Bluetooth** message displays in the home screen.

Tip: When Bluetooth power is on, your phone can automatically connect to a handsfree device you have used before. Just turn on the device or move it near the phone.

cable connections



Your phone has a mini-USB port so you can connect it to a computer.



If you use a USB cable connection:

- You must use the cables included with the Motorola Original™ data kit (see the data kit user's guide for more information).
- Make sure to connect the phone to a high-power USB port on your computer (not a low-power one such as the USB

port on your keyboard or bus-powered USB hub). Typically, USB high-power ports are located directly on your computer.

Note: If you connect your phone to a low-power USB port, the computer may not recognize your phone.

- Make sure both your phone and the computer are turned on.

TTY operation

You can use an optional TTY device with your phone to send and receive calls. You must plug the TTY device into the phone's headset connector and set the phone to operate in one of three TTY modes.


Note: Use a TSB-121 compliant cable (provided by the TTY manufacturer) to connect the TTY device to your phone. **If the**

cable has a 2.5mm jack, you will also need a Motorola Original™ 2.5mm-to-EMU TTY adapter to attach the jack to the phone.

Note: Set the phone to level 4 (middle setting) for proper operation. If you experience a high number of incorrect characters, adjust the volume as needed to minimize the error rate.

Note: For optimal performance, your phone should be at least 12 inches (30 centimeters) from the TTY device. Placing the phone too close to the TTY device may cause high error rates.

set TTY mode

 When you set your phone to a TTY mode, it operates in that mode whenever a TTY device is connected.

Find it: MENU (◉) ▶  **SETTINGS & TOOLS**
▼ Call Settings ▼ TTY Mode

TTY Mode can include these options:

option	
TTY Full	Transmit and receive TTY characters.
TTY + Talk	Receive TTY characters but transmit by speaking into microphone.
TTY + Hear	Transmit TTY characters but receive by listening to earpiece.
TTY Off	All TTY modes are turned off.

When your phone is in a TTY mode, your phone displays the international TTY mode, the international TTY symbol, and the mode setting during an active TTY call.

return to voice mode


To return to standard voice mode, select **TTY OFF** from the **TTY MODE** menu.


basics


See page 1 for a basic phone diagram.

home screen


The *home screen* shows when you turn on the phone.







To dial a number from the home screen, press number keys and .

Press the center key  to open the main menu. *Soft key labels* show current soft key functions. (For soft key locations, see page 1.)


Tip: Select a menu option quickly by pressing the number for that option. For example, from the **SETTINGS & TOOLS** menu, press **4** to select **Sounds Settings**.

Press  up, down, left, or right as a shortcut key to open these basic menu features:

navigation key direction & menu		
up		Mobile Web
down		Calendar
left		MUSIC & TONES
right		GET IT NOW

You can set your phone to display or hide these menu icons on the home screen (see page 66).

Your phone displays system status indicators:



alert/indicator

📶 EV 1X Signal Strength







1x-EVDO indicates that phone is in 1x-EVDO coverage area (necessary for V CAST services). 1X indicates when phone is in 1x-RTT coverage area. Vertical bars show the strength of the network connection. Four bars indicate maximum signal strength. One bar indicates minimum.







▲ Roaming







Indicates phone is roaming off your home network.

🔒 SSL

Indicates application verification is via SSL during a download session.


alert/indicator
 Data Call, Tethered, or Embedded WAP/BREW Application Shows during data call, tethered mode, or WAP/BREW application.
 Dormant Indicates phone is dormant and PPP session is active.
 No Service Phone is in area with no service coverage.
 TTY Phone is in TTY mode.
 Voice Call Shows during an active voice call.
 E911 Indicates E911 is On .

alert/indicator
 Location On Indicates Location is set to On .
 Battery Level Shows battery strength. The more bars, the greater the charge. (Four bars indicate maximum strength.)
 All Sounds Off Indicates Master Volume is set to Off .
 Alarm Only Indicates Master Volume is set to Alarm Only .
 Vibrate On Indicates Master Volume is set to Vibrate On .
 Speakerphone Indicates speakerphone is on.


alert/indicator	
 Missed Call	Indicates a call was missed.
 Message	Shows when you receive a new message.
 Calendar Event	Shows number of calendar appointments.
 New Voicemail	Shows when a voicemail message is received.
 Alarm On	Shows when an alarm has been set.
 Bluetooth Connection Active	Indicates your phone is paired to another Bluetooth device.

enter text

Some features let you enter text. The following is an example of a screen for **Contacts** entry information:



The following is an example of an entry screen used when you create a text message:



select entry mode

Multiple entry modes make it easy for you to enter names, numbers, and messages. The mode you select stays active until you select another mode.

To select an entry mode from the CREATE TXT MESSAGE screen, press **Options**, then select **Entry Mode**.

To select an entry mode from the EDIT CONTACT screen, press **Abc**.

You can select one of these entry modes:

entry modes	
iTAP English	The phone predicts each word (in English) as you press keys.
iTAP Spanish	The phone predicts each word (in Spanish) as you press keys.
Abc	Enter letters and numbers by pressing a key one or more times, first character of a sentence in uppercase.
123	Enter numbers only.
Symbols	Enter symbols.

Tip: Press **ⓧ** in a text entry screen to toggle through capitalization options:

abc no uppercase letters

Abc first letter of a sentence in uppercase

ABC all uppercase letters


tap mode

This is the standard mode for entering text on your phone. Regular tap mode cycles through the letters, numbers, and symbols of the key you press.

- 1 Press a key one or more times to select a letter, number, or symbol.
- 2 Enter the remaining characters in the same way.

Tip: Press **#** to enter a space.

When you enter text with tap mode, the soft key functions change:



- Press **◀** left or right to move the flashing cursor to the left or right in a text message.
- If you don't want to save your text or text edits, press **⏏** to exit without saving.

iTAP® mode

iTAP software provides a predictive text entry method that combines your key presses into common words.

When you enter three or more letters in a row, your phone may guess the rest of the word. For example, if you enter **prog**, your phone might show:



Press **⤵** right to accept **program**. Enter a space after **prog** to keep only **prog**.

If you want a different word (such as **progress**), continue pressing keys to enter the remaining letters.

- Scroll down to view other possible combinations, and select the one you want.
- Press **⤵** right to enter the highlighted combination when it spells a word. A space is inserted automatically after the word.
- To enter numbers quickly, press and hold a number key to temporarily switch to numeric mode. Press the number keys to enter the numbers you want.
- Press **[1]** to enter punctuation or other characters.

enter words

- 1 Press keys (one press per letter) to begin entering a word.

As you type, your phone automatically shows additional letters that form a suggested combination.

- 2 Scroll down to view other possible combinations, and highlight the combination you want.
- 3 Press **↵** right to enter the highlighted combination when it spells a word. A space is automatically inserted after the word.

If you enter a word the phone does not recognize, the phone stores it as a new word option. When you fill memory space for new word options, your phone deletes the oldest words to add new ones.

numeric mode

Press keypad keys to enter the numbers you want. When you finish entering numbers,

press the **123** key to switch to another entry mode.

symbol mode

On the **SYMBOLS** screen, scroll to the desired symbol and press **OK** (**↵**) to select it.

Press **Next** to page down to the next set of symbols. Press **Prev** to page up to the previous set.

delete letters & words

Move the cursor to the right of the text you want to delete, then:

- Press and **release** **CLR** to delete one letter at a time.
- Press and **hold** **CLR** to delete an entire word.

adjust volume

With the flip open, press the volume keys to:

- turn off an incoming call alert
- change the earpiece volume during calls
- change the ringer volume from the home screen



Only, or **All Sounds Off**. Press the up volume key to cycle back from silent to vibrate and then to the lowest call volume setting.


external display

When you close your phone, the external display shows the time, status indicators, and notifications for incoming calls and other events. For a list of phone status indicators, see page 27.



change sound settings

In the home screen, with the phone's flip open, press the down volume key to switch to lower the volume for call sounds, then switch to **Vibrate Only, Alarm**



handsfree speaker

You can use your phone's handsfree speaker to make calls without holding the phone to your ear.


The handsfree speaker stays on until you press and hold the smart/speakerphone key again or turn off the phone.


Note: The handsfree speaker won't work when your phone is connected to a handsfree car kit or headset.

flip open

To activate the speakerphone during a call,

press and hold the smart/speakerphone key.

You will see **Spkrphone On** and the speakerphone indicator , and hear a soft audio alert.



To end the call, press **End Call** or . You will see **Call Ended** and hear a soft audio alert.



Note: Closing the flip while using the speakerphone does not end the call (see “flip closed” below).

To turn off the speakerphone, press the smart/speakerphone key.

flip closed

- 1 Open your phone's flip.
- 2 Press and hold the smart/speakerphone key to turn on the speakerphone.
- 3 Enter the number you want to call and press .
- 4 When the call connects, close the flip and continue your conversation.
- 5 To end the call, press . You will see **Call Ended** and hear a soft audio alert.


standalone mode

Note: Consult airline staff about the use of **Standalone Mode** in flight. Turn off your phone whenever instructed to do so by airline staff.

Use *standalone mode* to turn off your phone's calling features in locations where wireless phone use is prohibited. **You cannot make or receive calls or use Bluetooth™ wireless devices in standalone mode**, but you can use your phone's other non-calling features.

Find it: MENU (•◂•) ▶  **SETTINGS & TOOLS**
▼ Phone Settings ▼ Standalone Mode.

Your phone indicates that **Standalone Mode** is set to **On** by displaying indicators and a message on the home screen:



change lock code

Your phone's four-digit **lock code** is originally set to the last four digits of your phone number. If your service provider didn't change this code, you should change it:

Find it: MENU (•◂•) ▶  **SETTINGS & TOOLS**
▼ Phone Settings ▼ Security

- 1 When prompted, enter the lock code and press **OK** (•◉•).
- 2 Scroll to **Edit Code** and press **OK** (•◉•).
- 3 Enter the new four-digit lock code in the **New Code** entry area, then press ◉ down to move the cursor into the **Confirm Code** entry area. Re-enter the new four-digit lock code.
- 4 Press **OK** (•◉•).

lock & unlock phone

You can lock your phone to keep others from using it. To lock or unlock your phone, you need the four-digit lock code.

Note: You can make emergency calls on a locked phone (see page 50). A locked phone still rings or vibrates for incoming calls or

messages, **but you need to unlock it to answer.**

To **manually lock** your phone:


Find it: MENU (•◉•) ▶  **SETTINGS & TOOLS**
▼ Phone Settings ▼ Security

- 1 When prompted, enter the lock code and press **OK** (•◉•).
- 2 Scroll to **Lock Mode** and press **OK** (•◉•).
- 3 Scroll to **Lock** and press **OK** (•◉•).

To **automatically lock** your phone whenever you turn it off:

Find it: MENU (•◉•) ▶  **SETTINGS & TOOLS**
▼ Phone Settings ▼ Security

- 1 When prompted, enter the lock code and press **OK** (•◉•).
- 2 Scroll to **Lock Mode** and press **OK** (•◉•).
- 3 Scroll to **On Power Up** and press **OK** (•◉•).

4 Press  to return to the home screen.

To unlock the phone, enter the four-digit lock code in the **Enter Lock Code** entry area and press **OK** (.

DRAFT

customize

conserve battery charge

Using certain features can quickly deplete your battery's charge. **These features can include downloading music, using the camera, replaying video clips, and using Bluetooth® wireless connections.**

You can conserve your battery's charge by doing the following:

- Turn Bluetooth power off when not in use (see page 22).
- Turn off wallpaper (see page 42) and screen saver (see page 43).
- Turn off backlights (see page 44).

sounds settings

You can set your phone to signal incoming calls or other events by playing specific ringtones or by vibrating.


master volume

Find it: MENU (•◉•) ▶  SETTINGS & TOOLS
▼ Sounds Settings ▼ Master Volume

- 1 Scroll up or down to the desired setting:
High, Med High, Med, Med Low, Low—Your phone rings for incoming calls and other events, depending on the detail settings.
Vibrate Only—The phone vibrates to indicate an incoming call.

Alarm Only—Your phone plays an audible alarm to alert you to events. You are not able to change detail settings for events.

All Sounds Off—The phone does not alert you to incoming calls or other events.

- 2 With the desired setting highlighted, press **SET** (•◊•).
- 3 Press  to return to the home screen.

sounds for calls, events, & alerts

Note: Master Volume must be set to High, Med High, Med, Med Low, or Low.

Set sounds for calls:

Find it: MENU (•◊•) ▶  **SETTINGS & TOOLS**
▼ Sound Settings ▼ Call Sounds

- 1 Scroll to **Call Ringtone** and press **OK** (•◊•), then scroll to a desired ringtone and press **OK** (•◊•).

Note: Press the left soft key to preview the ringtone.

or

Scroll to **Call Vibrate** and press **OK** (•◊•), then scroll to **On** or **Off** and press **OK** (•◊•).

- 2 Press  to return to the home screen.

Set sounds for events (such as incoming messages) or alerts:

Find it: MENU (•◊•) ▶  **SETTINGS & TOOLS**
▼ Sound Settings ▼ Alert Sounds

- 1 Scroll to **TXT Message**, **PIX-FLIX Msg**, or **Voicemail Msg**, and press **OK** (•◊•).

- 2 Scroll to **Tone** and press **OK** (•◉•), then scroll to a desired ringtone and press **OK** (•◉•).

Note: Press the left soft key to preview the ringtone.

or

Scroll to **Vibrate** and press **OK** (•◉•), then scroll to **On** or **Off** and press **OK** (•◉•).


or

Scroll to **Reminder** and press **OK** (•◉•), then scroll to **Once**, **Every 2 Minutes**, **Every 15 Minutes**, or **Off**, and press **OK** (•◉•). (For all settings but **Off**, your phone plays an audible beep at the interval you set.)

- 3 Press  to return to the home screen.

Tip: You can assign a distinctive ringtone to each entry in your Contacts list (see page 57).

get ringtones

Find it: MENU (•◉•) ▶  GET IT NOW

▼ **Music & Tones**

- 1 Scroll to **Get New Ringtones** and press **OK** (•◉•).
- 2 On the **GET NEW RINGTONES** screen, scroll to **Get New App** and press **OK** (•◉•).

Your phone connects to a Web site with ringtone collections. Follow the prompts on the screen to browse ringtone lists and to select and download a ringtone.

- 3 Press  to return to the home screen.

talking phone settings

You can set your phone to **speak aloud the numbers of the keypad keys** when you press them:


Find it: MENU (•◉•) ▶  SETTINGS & TOOLS
▼ Sound Settings ▼ Talking Phone ▼ Keypad Digits.

You can also set your phone to **speak aloud the name of Contacts entries** when you highlight the entries in the CONTACT LIST:

Find it: MENU (•◉•) ▶  SETTINGS & TOOLS
▼ Sound Settings ▼ Talking Phone ▼ Contact List Entries.

answer options

You can use different ways to answer an incoming call:

options	
Flip Open	Answer by opening the flip.
Any Key	Answer by pressing any key.
Send Only	Answer by pressing the  key only.

options

Auto Answer	Automatically answer incoming call (works with headset, Bluetooth® connections, and when phone is operating in handsfree mode).
-------------	---

To activate/deactivate an answer option:

Find it: MENU (•◉•) ▶  SETTINGS & TOOLS
▼ Call Settings ▼ Answer Options.

wallpaper

Set a photo, picture, or animation as a wallpaper (background) image in your home screen **and** your phone's external display:

Find it: MENU (•◉•) ▶  SETTINGS & TOOLS
▼ Display Settings ▼ Wallpaper

- 1 Select **Main Screen** (for the home screen) or **Front Screen** (for the external display).
- 2 Scroll to the picture in **MY PICTURES** that you want, and press **OK** (•◉•).

or

Press **Options**, then select **Take new picture** to take a new photo to use as a wallpaper, **or** select **PIX Place** to select a picture from your **PIX Place**, **or** select **Get New** to go to **GET NEW PICTURES** and download a picture (see page 21).

or

To turn off the wallpaper, scroll to **None** (in **MY PICTURES**) and press **OK** (•◉•).

- 3 Press  to return to the home screen.

screen saver

Set a photo, picture, or animation as a screen saver for you home screen **and** your phone's external display. The screen saver displays when the flip is open and no activity is detected for a set time.

Tip: This feature helps save your screen, but not your battery. To extend battery life, turn off the screen saver.

Find it: MENU (•◉•) ▶  **SETTINGS & TOOLS**
▼ **Display Settings** ▼ **Screen saver**

- 1 Select **Main Screen** (for the home screen) or **Front Screen** (for the external display).
- 2 Scroll to the picture in **MY PICTURES** that you want, and press **OK** (•◉•).

or

Press **Options**, then select **Take new picture** to take a new photo to use as a screen

saver, **or** select **PIX Place** to select a picture from your **PIX Place**, **or** select **Get New** to go to **GET NEW PICTURES** and download a picture (see page 21).

or

To turn off the screen saver, scroll to **None** (in **MY PICTURES**) and press **OK** (•◉•).

3 Press  to return to the home screen.

backlight

Set how long the backlights for the home screen and the keypad remain on, or turn off backlights to extend battery life:

Find it: MENU (•◉•) ▶  **SETTINGS & TOOLS**
▼ **Display Settings** ▼ **Backlight**

Tip: Setting **Backlight** to **Always On** will reduce battery life significantly and require more frequent battery charging.

44 customize

brightness

Set the brightness of your home screen:

Find it: MENU (•◉•) ▶  **SETTINGS & TOOLS**
▼ **Display Settings** ▼ **Brightness**

clock format

Set how your phone shows the current time on the home screen (see page 26) and on the external display (see page 34).

Find it: MENU (•◉•) ▶  **SETTINGS & TOOLS**
▼ **Display Settings** ▼ **Clock Format**

1 Scroll to **Main Clock** (for the home screen) or **Front Clock** (for the external display).

- 2 Scroll to the desired setting and press OK (⬇️):

Digital 12 Time shown as numeric digits in 12-hour notation followed by **am** or **pm**.

Digital 24 Time shown as numeric digits in 24-hour notation (for example, **13:26**).

Analog Time shown on the image of a clock with hour and minute hands.


Off Time not displayed.


AGPS & your location



Your phone can use the *automatic location information* (ALI) feature, along with *Assisted Global Positioning System* (AGPS) satellite

signals, to tell the network where you are physically located.

When ALI is set to **Location On**, your phone displays the  (ALI on) indicator. Services may use your known location to provide useful information (for example, driving directions, or the location of the nearest bank). Your phone prompts you when the network or a service asks for your location. You can refuse at this point.

When ALI is set to **911 Only**, your phone displays the  (ALI off) indicator, and the phone does not send location information unless you call the emergency phone number (such as 911).

Find it: MENU (⬇️) ▶  **SETTINGS & TOOLS**
▼ Phone Settings ▼ Location

- 1 Scroll to **Location On** or **911 Only**.
- 2 Press OK (⬇️) to select the setting.

AGPS limitations & tips

Your phone uses *Assisted Global Positioning System* (AGPS) satellite signals to estimate your location. If your phone cannot find strong satellite signals, your AGPS might be slower, less accurate, or it might not work at all. AGPS provides only an approximate location, often within 150 feet (45 meters) but sometimes much farther from your actual location.

To improve AGPS accuracy:

- Go outside and away from underground locations, covered vehicles, structures with metal or concrete roofs, tall buildings, and foliage. Indoor performance might improve if you move closer to window, but some window sun-shielding films can block satellite signals.



- Move away from radios, entertainment equipment, and other electronic devices that might interfere with or block AGPS satellite signals.
- Extend your phone antenna.
- Hold your phone away from your body, and point the phone antenna toward the sky. Do not cover the antenna area with your fingers.

AGPS uses satellites controlled by the U.S. government and subject to changes implemented in accordance with the Department of Defense AGPS user policy and the Federal Radio Navigation Plan. These changes might affect AGPS performance.



calls

To make and answer calls, see page 12.

redial a number

- 1 Press  to see the dialed calls list.
- 2 Scroll to the entry you want to call.
- 3 Press  to redial the number.

To redial a busy number:

- 1 Press  from the home screen.
- 2 Scroll to the entry you want to call.
- 3 Press .

automatic redial




When you receive a busy signal, your phone displays **Call Failed, Number Busy**.

With automatic redial, your phone automatically redials the number for four minutes. When the call goes through, your phone rings or vibrates once, displays **Redial Successful**, and connects the call.

You must turn on automatic redial to use the feature:


Find it: MENU () ►  **SETTINGS & TOOLS**
▼ **Call Settings** ▼ **Auto Retry**



When automatic redial is turned off, you can manually activate it to redial a number. When


you hear a fast busy signal and see **Call Failed**, press  or **RETRY** to automatically redial.

recent calls

Your phone keeps lists of the last ninety calls you received and dialed, even if the calls didn't connect. The most recent calls are listed first. The oldest calls are deleted as new calls are added.

Shortcut: Press  from the home screen to view the **All Calls** list.

Find it: MENU () ►  RECENT CALLS

- 1 Scroll to **Missed**, **Received**, **Dialed**, or **All**.
- 2 Press **OK** () to select the list.
- 3 Scroll to an entry.
- 4 Press  to call the entry's number.

or

Press **Message** to send a message to the entry's number.

or

Press **OPEN** () to view entry details.


or


Press **Options** to open the **Options** menu to perform other actions on the entry.

The **Options** menu can include these options:

options	
Save	Create a Contacts entry with the number in the No. field.
Erase	Delete the selected entry (if the entry is not locked).
Lock	Lock selected entry so it cannot be erased.
Erase All	Delete all unlocked entries.
View Timers	Go to the View Timers screen.

return unanswered calls

Your phone keeps a record of your unanswered calls, and displays the  (missed call) indicator and **X Missed Calls**.

- 1 Press **VIEW** to see the received calls list.
- 2 Scroll to the call you want to return.
- 3 Press  to make the call.



speed dial

You can assign a unique *speed dial* number to each entry you store in **Contacts**.

Note: Your service provider may have already assigned speed dial number 1 to your voice mail number.


To assign a speed dial number to an entry:

Find it: MENU () ▶  **CONTACTS** ▾ **Speed Dials**


- 1 Scroll to an unassigned speed dial number and press **SET** ()
- 2 Scroll to a contact in the Contacts list and press **OK** ()

To see an entry's speed dial number:

Find it: MENU () ▶  **CONTACTS** ▾ **Contact List**

Scroll to the entry and press **View**. The speed dial number is displayed with the  icon.

To speed dial an entry:


- 1 Enter the one- or two-digit speed dial number for the entry you want to call.
- 2 Press  to call the entry.

Tip: Use 1-touch dialing for quick calling! **To dial entries 1 through 9**, press and hold the one-digit speed dial number for one second. **To dial entries 10 and higher**, press the first digit, then press and hold the second digit.

emergency calls

Your service provider programs one or more emergency phone numbers, such as 911 or 112, that you can call under any circumstances, even when your phone is locked.

Note: Emergency numbers vary by country. Your phone's preprogrammed emergency number(s) may not work in all locations, and sometimes an emergency call cannot be placed due to network, environmental, or interference issues.

- 1 Enter the emergency number.
- 2 Press  to call the emergency number.

AGPS during an emergency call



When you make an emergency call, your phone can use *Assisted Global Positioning System* (AGPS) satellite signals to tell the emergency response center your approximate location.

The AGPS feature has limitations, so always tell the emergency response center your best knowledge of your location. Remain on the phone for as long as the emergency response center instructs you.

AGPS **might not work** for emergency calls:

- Your phone's AGPS feature must be turned on (see page 45).
- Your local emergency response center might not process AGPS location

information. For details, contact your local authorities.

For best results:

- Go outside and away from underground locations, covered vehicles, structures with metal or concrete roofs, tall buildings, and foliage. Indoor performance might improve if you move closer to windows, but some window sun shielding films can block satellite signals.
- Move away from radios, entertainment equipment, and other electronic devices that might interfere with or block AGPS satellite signals.

If your phone cannot find strong AGPS satellite signals, the location of the nearest cell tower in contact with your phone is



automatically provided to the emergency response center.


voicemail

Your network stores the voicemail messages you receive.




Note: Your service provider may include additional information about using this feature.

When you **receive** a voicemail message, your phone shows the voicemail message indicator . Press  to call your voicemail phone number.

Tip: Your service provider may assign speed dial number 1 to your voicemail phone number. If so, simply press and hold  to call your voicemail number.

To **check** voicemail messages later:

Find it: MENU (•◂◃) ▶  MESSAGING ▼ Voicemail

Press  (send key) to call your voicemail phone number.

Your phone may prompt you to store your voicemail phone number. If you don't know your voicemail number, contact your service provider.

Note: You can't store a **p** (pause), **w** (wait), or **n** (number) character in this number. If you want to store a voicemail number with these characters, create a **Contacts** entry for it. Then, you can use the entry to call your voicemail.

in-call options

During an active call, press **OPTIONS** to access these options:

1. Send TXT Msg

2. Messages

5. Voice Privacy

6. Connect Bluetooth

3. Contacts



4. Recent Calls


7. Phone Info

8. Location






other features

advanced calling

features
restrict calls 
MENU (•◉•) ▶  SETTINGS & TOOLS
▼ Call Settings ▼ Call Restrictions
When prompted, enter the lock code and press OK (•◉•). Then select Outgoing Calls or Incoming Calls and press OK (•◉•). Scroll to All, Contacts, or None , and press OK (•◉•).

features
DTMF tones
Your phone can send <i>Dual Tone Multi Frequency</i> (DTMF) tones for calling card calls or to navigate automated systems (such as banking by phone).
Set up DTMF tones:
MENU (•◉•) ▶  SETTINGS & TOOLS ▼ Call Settings
▼ DTMF Tones
Select Normal or Long .
Send DTMF tones during a call:
Press number keys.

messages

features	
send text message	
MENU (⬢) ▶  MESSAGING ▼ New Message ▼ TXT Message	
Press Options to perform other actions on the message.	
store message objects	
Go to a multimedia message slide (see page 20) and press Options , then select Save Picture or Save Sound .	
view sent messages	
MENU (⬢) ▶  MESSAGING ▼ Sent	
Scroll to the message you want to view and press Open (⬢). Press Options to perform other actions on the message.	

features

read received message



MENU (⬢) ▶  MESSAGING ▼ Inbox

Scroll to the message you want to read and press **Open** (⬢).

Press **Options** to perform other actions on the message.

view drafts



MENU (⬢) ▶  MESSAGING ▼ Drafts

Scroll to the message you want to view and press **EDIT** (⬢).

To delete the message, press **Erase**.

Press **Options** to perform other actions on the message.

features

erase messages



MENU (•◉•) ▶  MESSAGING

Press **Options**, then scroll to **Erase Inbox**, **Erase Drafts**, **Erase Sent**, or **Erase All**, and press **OK** (•◉•).

E-Mail



MENU (•◉•) ▶  MESSAGING ▾ E-mail

Access your internet e-mail account to exchange e-mail from your phone.

Mobile IM



MENU (•◉•) ▶  MESSAGING ▾ Mobile IM

Access your internet Instant Messaging account to exchange messages in real time with family and friends.

features

Chat



MENU (•◉•) ▶  MESSAGING ▾ Chat

Access your internet chat account to chat in real time with family and friends.

contacts

features

create entry

MENU (•◉•) ▶  CONTACTS ▾ New Contact

features

insert special characters



While entering a number, press **Options**. Then select one of the following:

2-Sec Pause—Your phone pauses for two seconds before it dials the next digit.

Wait—Your phone waits until the call connects, then prompts you for confirmation before it dials the next digit(s).

edit entry

MENU (•◂•) ▶  CONTACTS ▾ Contact List

Scroll to the entry and press **Edit**.

erase entry

MENU (•◂•) ▶  CONTACTS ▾ Contact List

Scroll to the entry and press **Options**, then scroll to **Erase** and press **OK** (•◂•).

features

assign picture to entry

When you assign a picture to a **Contacts** entry, your phone displays that picture when you receive a call from the entry.

MENU (•◂•) ▶  CONTACTS ▾ Contact List

Scroll to the entry and press **Edit**. Scroll to **Picture** and press **Set** to go to **My Pictures**. Scroll to the desired picture and press **OK** (•◂•).

features

assign ringtone to entry

When you assign a ringtone to a **Contacts** entry, your phone plays that ringtone when you receive a call from the entry.

MENU (•◂•) ▶  **CONTACTS** ▾ **Contact List**

Scroll to the entry and press **Edit**. Scroll to **Ringtone** and press **Set** to go to the **MY RINGTONES** menu. Scroll to the desired ringtone and press **OK** (•◂•).

Note: **Master Volume** must be set to **High**, **Med High**, **Med**, **Med Low**, or **Low** (see page 34).

features

download ringtone for entry

You can download a ringtone and assign it to a **Contacts** entry. When you receive a call from that entry, your phone plays that ringtone.

MENU (•◂•) ▶  **CONTACTS** ▾ **Contact List**

Scroll to the entry and press **Edit**. Scroll to **Ringtone** and press **Set** to go to the **MY RINGTONES** menu. Select **Get New Ringtones**, then proceed to download and save a ringtone.

features

set speed dial number

Assign a speed dial number to a **Contacts** entry:

MENU (•◉) ▶  **CONTACTS** ▾ **Contact List**

Scroll to the entry and press **Edit**. Scroll to the number to be assigned a speed dial number and press **Options**, then scroll to **Set Speed Dial** and press **OK** (•◉).

set default number for entry

Set the default number for a **Contacts** entry with multiple numbers:

MENU (•◉) ▶  **CONTACTS** ▾ **Contact List**

Scroll to the entry and press **Edit**. Scroll to the number to be set as the default number and press **Options**, then scroll to **Set As Default** and press **OK** (•◉).

features

add entries to group

Tip: You can add a **Contacts** entry to a group while editing that entry by scrolling to **Group** and pressing **Set**.

MENU (•◉) ▶  **CONTACTS** ▾ **Groups**

Scroll to the group name and press **Options**, then scroll to **Add** and press **OK** (•◉). On the **Add Contacts** screen, scroll to each contact you want to add and press **OK** (•◉).

When you are finished adding contacts to a group, press **Done**.

When you send a message to a group list, the message goes to all entries in that group.

features

add group

Add a new group as an entry on the **Groups** screen:


MENU (•◉•) ▶  **CONTACTS** ▼ **Groups**

Press **New**. Enter the name for the new group and press **SAVE** (•◉•).

When you send a message to a group list, the message goes to all **Contacts** entries in that group.

call an entry

MENU (•◉•) ▶  **CONTACTS**

Scroll to **Contact List** and press **OK** (•◉•), then scroll to the entry you want to call and press .

personalizing

voice recognition

Your phone's voice recognition feature enables you to place calls and complete other actions by speaking commands to your phone.

voice recognition tips

- When speaking the name of a **Contacts** entry, say the name exactly as it is listed. For example, to call the mobile number for an entry named Bill Smith, say "Call Bill Smith mobile." (If the entry includes only one number for Bill Smith, say "Call Bill Smith.")
- Speak numbers at a normal speed and volume, and pronounce each digit distinctly. Avoid pausing between digits.

- Your phone may be set to play voice command instructions through the speakerphone when you press the voice key, enabling you to see the **VOICE COMMANDS** menu. If you then use the **Call** command to place a call, audio plays through the phone's earpiece when the call connects. You can turn this feature off if desired (see page 64).

voice commands

- 1 Press and release the voice key on the right side of the phone.

Your phone **displays** and **says Say a command**, then displays a list of voice commands.

- 2 Say one of the commands listed in the following table. Your phone performs the corresponding action.

feature
Call <Name or #> Place a call to: <ul style="list-style-type: none">• a Contacts entry whose name you speakor• a phone number you speak For example, when prompted to say a command, say "Call Bill Smith mobile" or "Call 8475551212."

feature**Send <Msg Type>**

Send a text or multimedia message.

Say “Send text” or “Send picture,” then:

- the name of a **Contacts** entry
- or**
- a phone number

For instructions on sending a text or multimedia message, see page 54.

Lookup <Name>

Look up a **Contacts** entry by saying its name.

feature**Go To <Menu>**

Access the menu or perform the action you specify:

Voicemail—Dial your voicemail number.

Camera—Activate your phone’s camera.

Redial—Redial the last number you called.

Received Calls—Go to the received calls list.

feature

Check <Item>

View status of the item you say:

Status—coverage, signal strength, and battery charge

Voicemail—new voicemail messages

Messages—new received text or multimedia messages

Missed Calls—unanswered incoming calls

Time—time and date

Battery—battery charge

Signal Strength—network connection strength

Volume—ringer volume

feature

My Account

Launch Mobile Web and display your account options.

Help Guide

Access help information for the voice recognition feature.

modify voice recognition settings

- 1 Press and release the voice key on the right side of the phone.
- 2 Press **Settings**.

- 3 Scroll to the desired option and press OK (⬇️).

voice recognition settings

Choice Lists

If your phone is not sure that it has correctly identified a name or number that you speak, it can display up to three choices and prompt you to confirm the correct one.

You can control when choice lists appear:

Automatic—Display a list of choices from multiple alternatives.

Always On—Always display a list of choices when there are multiple alternatives.

Always Off—Never display a choice list. The phone chooses from the best alternatives.

voice recognition settings

Sensitivity

This setting allows you to fine tune the phone's ability to recognize voice commands.

If sensitivity is too strict, your phone will often reject voice commands and display "Please repeat ..." or "No match found." Adjust the sensitivity toward **Reject Less**.

If sensitivity is too forgiving, you will often experience false activations (indicating that the phone detects a wrong match). Adjust the **Sensitivity** setting toward **Reject More**.

voice recognition settings

Digit Dialing

Adapt digit dialing to your voice:

Adapt Digits—Adapt digits to improve recognition of spoken phone numbers. Adaptation takes about sixty seconds.

Reset Digits—Erase any digital adaptation you did previously and reset digit recognition to the factory default. If you have not adapted digits, this option appears in grey (not available).

voice recognition settings

Sound

Customize voice recognition by turning playback on or off for prompts, names, and numbers. You can also adjust the speed and volume of name playback.

Prompts—Turn playback on or off for prompts such as “Please say a command.”

Digits—Turn playback on or off for digits (for example, when confirming a phone number).


Names—Turn playback on or off for names.





Name Settings—Adjust speed and volume of name playback.

Speakerphone—Set whether your phone plays instructions through the speakerphone when you press the voice key (see “voice recognition tips” on page 59).

To access help additional information for a setting you have selected, press **INFO**.

more personalizing features

features
alert lights
Set lights on the flip (see page) 2 to turn on when you receive a call.
MENU (•◉•) ▶  SETTINGS & TOOLS
▼ Display Settings ▼ Alert Lights
You can set alert lights to blink in different rhythmic patterns for incoming calls. The lights will also pulse while the phone is charging until charging is 90% complete.

features
keypad volume
MENU (•◉•) ▶  SETTINGS & TOOLS
▼ Sounds Settings ▼ Keypad Volume
Note: Master Volume must be set to High , Med High , Med , Med Low , or Low .
power on/off sounds
MENU (•◉•) ▶  SETTINGS & TOOLS
▼ Sounds Settings ▼ Power On/Off
Note: Master Volume must be set to High , Med High , Med , Med Low , or Low .
display themes 
Set the colors and styles of screens that your phone displays:
MENU (•◉•) ▶  SETTINGS & TOOLS
▼ Display Settings ▼ Display Themes

features

menu language

MENU (•◉•) ▶  SETTINGS & TOOLS

▼ Phone Settings ▼ Language

banner



Create a heading to display on your phone's home screen:

MENU (•◉•) ▶  SETTINGS & TOOLS

▼ Display Settings ▼ Banner

show or hide menu icons

Show or hide menu icons in the home screen that you can use as shortcuts to those menus:

MENU (•◉•) ▶  SETTINGS & TOOLS

▼ Phone Settings ▼ Shortcut Key

Scroll to and select **Icons Mode**, then select **Show** or **Hide**.

features

change home keys


Change menus selected with the navigation keys in the home screen:

MENU (•◉•) ▶  SETTINGS & TOOLS





▼ Phone Settings ▼ Shortcut Key







Select **Up Key**, **Down Key**, **Right Key**, or **Left Key**, then scroll to and select the menu you want to assign to that key.

call times & data volumes

Network connection time is the elapsed time from the moment you connect to your service provider's network to the moment you end the call by pressing . This time includes busy signals and ringing.

The amount of network connection time you track on your resettable timer may not equal the amount of time for which you are billed by your service provider. For billing information, contact your service provider.

features	
call times	
MENU (•◊•) ▶  RECENT CALLS	
▼ View Timers	
Scroll to the appropriate timer and press OK (•◊•).	
set in-call timer	
MENU (•◊•) ▶  SETTINGS & TOOLS	
▼ Sounds Settings ▼ Service Alerts ▼ Minute Beep	

features	
data volumes	
MENU (•◊•) ▶  RECENT CALLS	
▼ View Timers	
Scroll to Transmit KB, Received KB, Total KB, or Lifetime Data Counter, and press OK (•◊•).	
reset timer	
MENU (•◊•) ▶  RECENT CALLS	
▼ View Timers	
Scroll to the timer you want to reset and press Reset . To reset all timers, press Reset All .	
view last reset	
MENU (•◊•) ▶  RECENT CALLS	
▼ View Timers ▼ Last Reset	

handsfree

Note: The use of wireless phones while driving may cause distraction. Discontinue a call if you can't concentrate on driving. Additionally, the use of wireless devices and their accessories may be prohibited or restricted in certain areas. Always obey the laws and regulations on the use of these products.

features

accessory volume settings (car kit or headset)



Adjust volume of headsets or car kit accessories that are enable for Bluetooth wireless connections:

During an active call, press your phone's up or down volume key.

Bluetooth® wireless connections

features





make phone visible to other device







Allow an unknown Bluetooth device to discover your phone:

MENU (•◂•) ▶  SETTINGS & TOOLS ▾ Bluetooth
▾ Settings ▾ Discovery Mode

Scroll to **On** and press OK (•◂•).

features	
<p>connect to recognized device </p> <p>MENU (•◉•) ▶  SETTINGS & TOOLS ▼ Bluetooth ▼ Add New Device</p> <p>Select the device.</p> <p>Note: To ensure the best Bluetooth connection, always connect to Bluetooth devices using your phone's menus rather than making your device discoverable.</p>	
<p>connect to handsfree device during a call </p> <p>Press OPTIONS, then select Connect Bluetooth.</p> <p>Note: You cannot switch to a headset or car kit if you are already connected to a Bluetooth device.</p>	
<p>disconnect from device </p> <p>Scroll to Bluetooth and select Off.</p>	

features	
<p>set Bluetooth power always on </p> <p>Set Bluetooth power to be on whenever your phone is on:</p> <p>MENU (•◉•) ▶  SETTINGS & TOOLS ▼ Bluetooth ▼ On</p>	
<p>set Bluetooth options </p> <p>MENU (•◉•) ▶  SETTINGS & TOOLS ▼ Bluetooth ▼ Settings</p>	

network

features

network settings



Adjust network settings:

MENU (•◉•) ▶  **SETTINGS & TOOLS**

▼ **Phone Settings** ▼ **System Select**

Scroll to **Set Mode** and press **OK** (•◉•).

set call drop alerts



Set phone to beep whenever the network drops a call. (Because digital networks are so quiet, the call drop alert may be your only indication that a call was dropped.)

MENU (•◉•) ▶  **SETTINGS & TOOLS**

▼ **Sounds Settings** ▼ **Service Alerts** ▼ **Voice Call Drop**

features

set call connect alerts



Set phone to beep whenever an outgoing call is connected:

MENU (•◉•) ▶  **SETTINGS & TOOLS**

▼ **Sounds Settings** ▼ **Service Alerts** ▼ **Call Connect**

set roaming alerts








Set phone to beep whenever phone begins roaming:

MENU (•◉•) ▶  **SETTINGS & TOOLS**

▼ **Sounds Settings** ▼ **Service Alerts** ▼ **ERI**

personal organizer

features
add calendar appointment MENU (•◐•) ▶  SETTINGS & TOOLS ▼ Tools ▼ Calendar Scroll to the desired date and press Add , then enter new appointment information.
see calendar appointment MENU (•◐•) ▶  SETTINGS & TOOLS ▼ Tools ▼ Calendar Scroll to the date of the appointment and press VIEW (•◐•). Press VIEW (•◐•) again to see appointment details.
set alarm clock MENU (•◐•) ▶  SETTINGS & TOOLS ▼ Tools ▼ Alarm Clock

features
turn off alarm Press Off or  .
view world clock View current time in cities around the world: MENU (•◐•) ▶  SETTINGS & TOOLS ▼ Tools ▼ World Clock Scroll left or right to the desired city.
use notepad Write notes to yourself: MENU (•◐•) ▶  SETTINGS & TOOLS ▼ Tools ▼ Notepad
calculator MENU (•◐•) ▶  SETTINGS & TOOLS ▼ Tools ▼ Calculator

security

features

voice privacy

Encrypt outgoing voice calls and use secure channels when available:

MENU (•◉•) ▶  SETTINGS & TOOLS ▾ Call Settings
▾ Voice Privacy

fun & games

Note: A lock (🔒) icon next to a picture or sound means that you cannot send or copy it.

features

launch game or application

Launch a **Get It Now** game or application:

MENU (•◉•) ▶  GET IT NOW ▾ Games

Select the game or application you want to launch.

features

download game or application

Download a **Get It Now** game or application:

MENU (•◉•) ▶  **GET IT NOW** ▼ **Games**
▼ **Get New App**

Select a category, application, and pricing option. Normal airtime and/or carrier usage charges apply.

Web sessions

Select or create a Web session:

From the home screen, press •◉• up to select **MOBILE WEB**.

features

manage pictures

MENU (•◉•) ▶  **GET IT NOW** ▼ **Picture**

Scroll to **My Pictures** and press **OK** (•◉•) to view a list of pictures.

To view a picture, scroll to the picture title and press **VIEW** (•◉•).

Press **Options** to open the **OPTIONS** menu for **My Pictures**, then scroll to and select the desired option: **Send**, **To PIX Place**, **Get New**, **Set As**, **Rename**, **Move**, **Lock**, **Erase**, **Erase All**, **Slide Show**, or **Picture Info**.

Note: The **OPTIONS** menu includes different options for locked or preloaded images.

service & repairs

If you have questions or need assistance, we're here to help.

Go to www.motorola.com/consumer/support, where you can select from a number of customer care options. You can also contact the Motorola Customer Support Center at 1-800-331-6456 (United States), 1-888-390-6456 (TTY/TDD United States for hearing impaired), or 1-800-461-4575 (Canada).

Specific Absorption Rate Data

This model wireless phone meets the government's requirements for exposure to radio waves.

Your wireless phone is a radio transmitter and receiver. It is designed and manufactured not to exceed limits for exposure to radio frequency (RF) energy set by the Federal Communications Commission (FCC) of the U.S. Government and by the Canadian regulatory authorities. These limits are part of comprehensive guidelines and establish permitted levels of RF energy for the general population. The guidelines are based on standards that were developed by independent scientific organizations through periodic and thorough evaluation of scientific studies. The standards include a substantial safety margin designed to assure the safety of all persons, regardless of age or health.

The exposure standard for wireless mobile phones employs a unit of measurement known as the Specific Absorption Rate, or SAR. The SAR limit set by the FCC and by the Canadian regulatory authorities is 1.6 W/kg.¹ Tests for SAR are conducted using standard operating positions accepted by the FCC and by Industry Canada with the phone transmitting at its highest certified power level in all tested frequency bands. Although the SAR is determined at the highest certified power level, the actual SAR

level of the phone while operating can be well below the maximum value. This is because the phone is designed to operate at multiple power levels so as to use only the power required to reach the network. In general, the closer you are to a wireless base station, the lower the power output.

Before a phone model is available for sale to the public in the U.S. and Canada, it must be tested and certified to the FCC and Industry Canada that it does not exceed the limit established by each government for safe exposure. The tests are performed in positions and locations (e.g., at the ear and worn on the body) reported to the FCC and available for review by Industry Canada. The highest SAR value for this model phone when tested for use at the ear is 1.54 W/kg, and when worn on the body, as described in this user guide, is 1.13 W/kg. The SAR value for this product in its data transmission mode (body-worn use) is 0.56 W/kg. (Body-worn measurements differ among phone models, depending upon available accessories and regulatory requirements).²

While there may be differences between the SAR levels of various phones and at various positions, they all meet the governmental requirements for safe exposure. Please note that improvements to this product model could cause differences in the SAR value for later products; in all cases, products are designed to be within the guidelines.

Additional information on Specific Absorption Rates (SAR) can be found on the Cellular Telecommunications & Internet Association (CTIA) Web site:

<http://www.phonefacts.net>

or the Canadian Wireless Telecommunications Association (CWTA) Web site:

<http://www.cwta.ca>

1. In the United States and Canada, the SAR limit for mobile phones used by the public is 1.6 watts/kg (W/kg) averaged over one gram of tissue. The standard incorporates a substantial margin of safety to give additional protection for the public and to account for any variations in measurements.
2. The SAR information includes the Motorola testing protocol, assessment procedure, and measurement uncertainty range for this product.



MOTOROLA

**Important Safety and
Legal Information**

DRAFT

Safety and General Information

This section contains important information on the safe and efficient operation of your mobile device. Read this information before using your mobile device.*

Exposure to Radio Frequency (RF) Energy

Your mobile device contains a transmitter and receiver. When it is ON, it receives and transmits RF energy. When you communicate with your mobile device, the system handling your call controls the power level at which your mobile device transmits.

Your Motorola mobile device is designed to comply with local regulatory requirements in your country concerning exposure of human beings to RF energy.

Operational Precautions

For optimal mobile device performance and to be sure that human exposure to RF energy does not exceed the guidelines set forth in

* The information provided in this document supersedes the general safety information in user's guides published prior to May 1, 2006.

the relevant standards, always follow these instructions and precautions.

External Antenna Care

If your mobile device has an external antenna, use only a Motorola-supplied or approved replacement antenna. Use of unauthorized antennas, modifications, or attachments could damage the mobile device and/or may result in your device not complying with local regulatory requirements in your country.

DO NOT hold the external antenna when the mobile device is IN USE. Holding the external antenna affects call quality and may cause the mobile device to operate at a higher power level than needed.

Product Operation

When placing or receiving a phone call, hold your mobile device just like you would a landline phone.

If you wear the mobile device on your body, always place the mobile device in a Motorola-supplied or approved clip, holder, holster, case, or body harness. If you do not use a body-worn accessory supplied or approved by Motorola, keep the mobile device and its antenna at least 2.5 centimeters (1 inch) from your body when transmitting.

When using any data feature of the mobile device, with or without an accessory cable, position the mobile device and its antenna at least 2.5 centimeters (1 inch) from your body.

Using accessories not supplied or approved by Motorola may cause your mobile device to exceed RF energy exposure guidelines. For a list of Motorola-supplied or approved accessories, visit our Web site at: www.motorola.com.

RF Energy Interference/Compatibility

Nearly every electronic device is subject to RF energy interference from external sources if inadequately shielded, designed, or otherwise configured for RF energy compatibility. In some circumstances your mobile device may cause interference with other devices.

Follow Instructions to Avoid Interference Problems

Turn off your mobile device in any location where posted notices instruct you to do so. These locations include hospitals or health care facilities that may be using equipment that is sensitive to external RF energy.

In an aircraft, turn off your mobile device whenever instructed to do so by airline staff. If your mobile device offers an airplane mode or similar feature, consult airline staff about using it in flight.

Pacemakers

If you have a pacemaker, consult your physician before using this device.

Persons with pacemakers should observe the following precautions:

- ALWAYS keep the mobile device more than 20 centimeters (8 inches) from your pacemaker when the mobile device is turned ON.
- DO NOT carry the mobile device in the breast pocket.
- Use the ear opposite the pacemaker to minimize the potential for interference.
- Turn OFF the mobile device immediately if you have any reason to suspect that interference is taking place.

Hearing Aids

Some mobile devices may interfere with some hearing aids. In the event of such interference, you may want to consult your hearing aid manufacturer or physician to discuss alternatives.

Other Medical Devices

If you use any other personal medical device, consult your physician or the manufacturer of your device to determine if it is adequately shielded from RF energy.

Driving Precautions

Check the laws and regulations on the use of mobile devices in the area where you drive. Always obey them.

When using your mobile device while driving, please:

- Give full attention to driving and to the road. Using a mobile device may be distracting. Discontinue a call if you can't concentrate on driving.
- Use handsfree operation, if available.
- Pull off the road and park before making or answering a call if driving conditions so require.

Responsible driving practices can be found in the "Smart Practices While Driving" section at the end of this guide and/or at the Motorola Web site: www.motorola.com/callsmart.

Operational Warnings

Obey all posted signs when using mobile devices in public areas, such as health care facilities or blasting areas.

Automobile Air Bags

Do not place a mobile device in the air bag deployment area.

Potentially Explosive Atmospheres

Areas with potentially explosive atmospheres are often but not always posted, and can include fueling areas such as below decks

on boats, fuel or chemical transfer or storage facilities, or areas where the air contains chemicals or particles, such as grain, dust, or metal powders.

When you are in such an area, turn off your mobile device, and do not remove, install, or charge batteries. In such areas, sparks can occur and cause an explosion or fire.

Damaged Products

If your mobile device or battery has been submerged in water, punctured, or subjected to a severe fall, do not use it until you take it to a Motorola Authorized Service Center. Do not attempt to dry it with an external heat source, such as a microwave oven.








Batteries and Chargers

If jewelry, keys, beaded chains, or other conductive materials touch exposed battery terminals, this could complete an electrical circuit (short circuit), become very hot, and could cause damage or injury. Be careful when handling a charged battery, particularly when placing it inside a pocket, purse, or other container with metal objects. **Use only Motorola Original batteries and chargers.**

Caution: To avoid risk of personal injury, do not dispose of your battery in a fire.



Your battery, charger, or mobile device may contain symbols, defined as follows:

Symbol	Definition
	Important safety information follows.
	Do not dispose of your battery or mobile device in a fire.
	Your battery or mobile device may require recycling in accordance with local laws. Contact your local regulatory authorities for more information.
	Do not throw your battery or mobile device in the trash.
	Your mobile device contains an internal lithium ion battery.
	Do not let your battery, charger, or mobile device get wet.
	Listening at full volume to music or voice through a headset may damage your hearing.

Choking Hazards

Your mobile device or its accessories may include detachable parts, which may present a choking hazard to small children. Keep your mobile device and its accessories away from small children.

Glass Parts

Some parts of your mobile device may be made of glass. This glass could break if the product is dropped on a hard surface or receives a substantial impact. If glass breaks, do not touch or attempt to remove. Stop using your mobile device until the glass is replaced by a qualified service center.

Seizures/Blackouts

Some people may be susceptible to epileptic seizures or blackouts when exposed to flashing lights, such as when playing video games. These may occur even if a person has never had a previous seizure or blackout.

If you have experienced seizures or blackouts, or if you have a family history of such occurrences, please consult with your physician before playing video games or enabling a flashing-lights feature (if available) on your mobile device.

Discontinue use and consult a physician if any of the following symptoms occur: convulsion, eye or muscle twitching, loss of awareness, involuntary movements, or disorientation. It is always a good idea to hold the screen away from your eyes, leave the

lights on in the room, take a 15-minute break every hour, and stop use if you are very tired.

Caution About High Volume Usage



Listening at full volume to music or voice through a headset may damage your hearing.

Repetitive Motion

When you repetitively perform actions such as pressing keys or entering finger-written characters, you may experience occasional discomfort in your hands, arms, shoulders, neck, or other parts of your body. If you continue to have discomfort during or after such use, stop use and see a physician.

ITC06-405

Industry Canada Notice to Users

Operation is subject to the following two conditions: (1) This device may not cause interference and (2) This device must accept any interference, including interference that may cause undesired operation of the device. See RSS-GEN 7.1.5.

DRAFT

FCC Notice To Users

Motorola has not approved any changes or modifications to this device by the user. Any changes or modifications could void the user's authority to operate the equipment. See 47 CFR Sec. 15.21.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. See 47 CFR Sec. 15.19(3).

If your mobile device or accessory has a USB connector, or is otherwise considered a computer peripheral device whereby it can be connected to a computer for purposes of transferring data, then it is considered a Class B device and the following statement applies:

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is

encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and the receiver.
- Connect the equipment to an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Motorola Limited Warranty for the United States and Canada

What Does this Warranty Cover?

Subject to the exclusions contained below, Motorola, Inc. warrants its telephones, pagers, messaging devices, and consumer and professional two-way radios (excluding commercial, government or industrial radios) that operate via Family Radio Service or General Mobile Radio Service, Motorola-branded or certified accessories sold for use with these Products ("Accessories") and Motorola software contained on CD-ROMs or other tangible media and sold for use with these Products ("Software") to be free from defects in materials and workmanship under normal consumer usage for the period(s) outlined below. This limited warranty is a consumer's exclusive remedy, and applies as follows to new Motorola Products, Accessories and Software purchased by consumers in the United States or Canada, which are accompanied by this written warranty:

Products and Accessories

Products Covered	Length of Coverage
Products and Accessories as defined above, unless otherwise provided for below.	One (1) year from the date of purchase by the first consumer purchaser of the product unless otherwise provided for below.
Decorative Accessories and Cases. Decorative covers, bezels, PhoneWrap™ covers and cases.	Limited lifetime warranty for the lifetime of ownership by the first consumer purchaser of the product.
Monaural Headsets. Ear buds and boom headsets that transmit mono sound through a wired connection.	Limited lifetime warranty for the lifetime of ownership by the first consumer purchaser of the product.

Products Covered	Length of Coverage
Consumer and Professional Two-Way Radio Accessories.	Ninety (90) days from the date of purchase by the first consumer purchaser of the product.
Products and Accessories that are Repaired or Replaced.	The balance of the original warranty or for ninety (90) days from the date returned to the consumer, whichever is longer.

Exclusions

Normal Wear and Tear. Periodic maintenance, repair and replacement of parts due to normal wear and tear are excluded from coverage.

Batteries. Only batteries whose fully charged capacity falls below 80% of their rated capacity and batteries that leak are covered by this limited warranty.

Abuse & Misuse. Defects or damage that result from: (a) improper operation, storage, misuse or abuse, accident or neglect, such as physical damage (cracks, scratches, etc.) to the surface of the product resulting from misuse; (b) contact with liquid, water, rain, extreme humidity or heavy perspiration, sand, dirt or the like, extreme heat, or food; (c) use of the Products or Accessories for commercial purposes or subjecting the Product or Accessory to abnormal usage or conditions; or (d) other acts which are not the fault of Motorola, are excluded from coverage.

Use of Non-Motorola Products and Accessories. Defects or damage that result from the use of Non-Motorola branded or certified Products, Accessories, Software or other peripheral equipment are excluded from coverage.

Unauthorized Service or Modification. Defects or damages resulting from service, testing, adjustment, installation, maintenance, alteration, or modification in any way by someone other than Motorola, or its authorized service centers, are excluded from coverage.

Altered Products. Products or Accessories with (a) serial numbers or date tags that have been removed, altered or obliterated; (b) broken seals or that show evidence of tampering; (c) mismatched board serial numbers; or (d) nonconforming or non-Motorola housings, or parts, are excluded from coverage.

Communication Services. Defects, damages, or the failure of Products, Accessories or Software due to any communication service or signal you may subscribe to or use with the Products Accessories or Software is excluded from coverage.

Software

Products Covered	Length of Coverage
Software. Applies only to physical defects in the media that embodies the copy of the software (e.g. CD-ROM, or floppy disk).	Ninety (90) days from the date of purchase.

Exclusions

Software Embodied in Physical Media. No warranty is made that the software will meet your requirements or will work in combination with any hardware or software applications provided by third parties, that the operation of the software products will be uninterrupted or error free, or that all defects in the software products will be corrected.

Software NOT Embodied in Physical Media. Software that is not embodied in physical media (e.g. software that is downloaded from the internet), is provided "as is" and without warranty.

Who Is Covered?

This warranty extends only to the first consumer purchaser, and is not transferable.

What Will Motorola Do?

Motorola, at its option, will at no charge repair, replace or refund the purchase price of any Products, Accessories or Software that does not conform to this warranty. We may use functionally equivalent reconditioned/refurbished/pre-owned or new Products, Accessories or parts. No data, software or applications added to your Product, Accessory or Software, including but not limited to personal contacts, games and ringer tones, will be reinstalled. To avoid losing such data, software and applications please create a back up prior to requesting service.

How to Obtain Warranty Service or Other Information

USA	Phones 1-800-331-6456 Pagers 1-800-548-9954 Two-Way Radios and Messaging Devices 1-800-353-2729
Canada	All Products 1-800-461-4575
TTY	1-888-390-6456
For Accessories and Software , please call the telephone number designated above for the product with which they are used.	

You will receive instructions on how to ship the Products, Accessories or Software, at your expense, to a Motorola Authorized Repair Center. To obtain service, you must include: (a) a copy of your receipt, bill of sale or other comparable proof of purchase; (b) a written description of the problem; (c) the name of your service provider, if applicable; (d) the name and location of the installation facility (if applicable) and, most importantly; (e) your address and telephone number.

What Other Limitations Are There?

ANY IMPLIED WARRANTIES, INCLUDING WITHOUT LIMITATION THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, SHALL BE LIMITED TO THE DURATION OF THIS LIMITED WARRANTY, OTHERWISE THE REPAIR, REPLACEMENT, OR REFUND AS PROVIDED UNDER THIS EXPRESS LIMITED WARRANTY IS THE EXCLUSIVE REMEDY OF THE CONSUMER, AND IS PROVIDED IN LIEU OF ALL OTHER WARRANTIES, EXPRESS OR IMPLIED. IN NO EVENT SHALL MOTOROLA BE LIABLE, WHETHER IN CONTRACT OR TORT (INCLUDING NEGLIGENCE) FOR DAMAGES IN EXCESS OF THE PURCHASE PRICE OF THE PRODUCT, ACCESSORY OR SOFTWARE, OR FOR ANY INDIRECT, INCIDENTAL, SPECIAL OR CONSEQUENTIAL DAMAGES OF ANY KIND, OR LOSS OF REVENUE OR PROFITS, LOSS OF BUSINESS, LOSS OF INFORMATION OR DATA, SOFTWARE OR APPLICATIONS OR OTHER FINANCIAL LOSS ARISING OUT OF OR IN CONNECTION WITH THE ABILITY OR INABILITY TO USE THE PRODUCTS, ACCESSORIES OR SOFTWARE TO THE FULL EXTENT THESE DAMAGES MAY BE DISCLAIMED BY LAW.

Some states and jurisdictions do not allow the limitation or exclusion of incidental or consequential damages, or limitation on the length of an implied warranty, so the above limitations or exclusions may not apply to you. This warranty gives you specific legal rights, and you may also have other rights that vary from state to state or from one jurisdiction to another.

Laws in the United States and other countries preserve for Motorola certain exclusive rights for copyrighted Motorola software such as the exclusive rights to reproduce and distribute copies of the Motorola software. Motorola software may only be copied into, used in, and redistributed with, the Products associated with such Motorola software. No other use, including without limitation disassembly of such Motorola software or exercise of the exclusive rights reserved for Motorola, is permitted.

Hearing Aid Compatibility with Mobile Phones

Some Motorola phones are measured for compatibility with hearing aids. If the box for your particular model has "Rated for Hearing Aids" printed on it, the following explanation applies.

When some mobile phones are used near some hearing devices (hearing aids and cochlear implants), users may detect a buzzing, humming, or whining noise. Some hearing devices are more immune than others to this interference noise, and phones also vary in the amount of interference they generate.

The wireless telephone industry has developed ratings for some of their mobile phones, to assist hearing device users in finding phones that may be compatible with their hearing devices. Not all phones have been rated. Phones that are rated have the rating on their box or a label on the box.

The ratings are not guarantees. Results will vary depending on the user's hearing device and hearing loss. If your hearing device happens to be vulnerable to interference, you may not be able to use a rated phone successfully. Trying out the phone with your hearing device is the best way to evaluate it for your personal needs.

M-Ratings: Phones rated M3 or M4 meet FCC requirements and are likely to generate less interference to hearing devices than phones that are not labeled. M4 is the better/higher of the two ratings.

T-Ratings: Phones rated T3 or T4 meet FCC requirements and are likely to be more usable with a hearing device's telecoil ("T Switch" or "Telephone Switch") than unrated phones. T4 is the better/higher of the two ratings. (Note that not all hearing devices have telecoils in them.)

Hearing devices may also be measured for immunity to this type of interference. Your hearing device manufacturer or hearing health professional may help you find results for your hearing device. The more immune your hearing aid is, the less likely you are to experience interference noise from mobile phones.

Information from the World Health Organization

Present scientific information does not indicate the need for any special precautions for the use of mobile phones. If you are concerned, you may want to limit your own or your children's RF

exposure by limiting the length of calls or by using handsfree devices to keep mobile phones away from your head and body.

Source: WHO Fact Sheet 193

Further information: <http://www.who.int./peh-emf>

Product Registration

Online Product Registration:

`direct.motorola.com/hellomoto/
Motosupport/source/registration.asp`

Product registration is an important step toward enjoying your new Motorola product. Registering helps us facilitate warranty service, and permits us to contact you should your product require an update or other service. Registration is for U.S. residents only and is not required for warranty coverage.

Please retain your original dated sales receipt for your records. For warranty service of your Motorola Personal Communications Product you will need to provide a copy of your dated sales receipt to confirm warranty status.

Thank you for choosing a Motorola product.

Export Law Assurances

This product is controlled under the export regulations of the United States of America and Canada. The Governments of the United States of America and Canada may restrict the exportation

or re-exportation of this product to certain destinations. For further information contact the U.S. Department of Commerce or the Canadian Department of Foreign Affairs and International Trade.

Wireless: The New Recyclable

Your wireless mobile device can be recycled. Recycling your mobile device reduces the amount of waste disposed in landfills and allows recycled materials to be incorporated into new products.

The Cellular Telecommunications Industry Association (CTIA) and its members encourage consumers to recycle their mobile devices and have taken steps to promote the collection and environmentally sound recycling of end-of-life devices.

As a mobile device user, you have an important role in ensuring that this device is recycled properly. When it comes time to give this mobile device up or trade it in for a new one, please remember that the mobile device, the charger, and many of its accessories can be recycled. It's easy. To learn more about CTIA's Recycling Program for Used Wireless Devices, please visit us at:

[recycling.motorola.young-america.com/
index.html](http://recycling.motorola.young-america.com/index.html)

California Perchlorate Label

Some mobile phones use an internal, permanent backup battery on the printed circuit board that may contain very small amounts of perchlorate. In such cases, California law requires the following label:

"Perchlorate Material – special handling may apply. See www.dtsc.ca.gov/hazardouswaste/perchlorate."

There is no special handling required by consumers.

Smart Practices While Driving

Drive Safe, Call SmartSM

Check the laws and regulations on the use of mobile devices and their accessories in the areas where you drive. Always obey them. The use of these devices may be prohibited or restricted in certain areas. Go to www.motorola.com/callsmart for more information.

Your mobile device lets you communicate by voice and data—almost anywhere, anytime, wherever wireless service is available and safe conditions allow. When driving a car, driving is your first responsibility. If you choose to use your mobile device while driving, remember the following tips:

- **Get to know your Motorola mobile device and its features such as speed dial and redial.** If available, these features help you to place your call without taking your attention off the road.
- **When available, use a handsfree device.** If possible, add an additional layer of convenience to your mobile device with one of the many Motorola Original handsfree accessories available today.
- **Position your mobile device within easy reach.** Be able to access your mobile device without removing your



eyes from the road. If you receive an incoming call at an inconvenient time, if possible, let your voice mail answer it for you.

- **Let the person you are speaking with know you are driving; if necessary, suspend the call in heavy traffic or hazardous weather conditions.** Rain, sleet, snow, ice, and even heavy traffic can be hazardous.
- **Do not take notes or look up phone numbers while driving.** Jotting down a "to do" list or going through your address book takes attention away from your primary responsibility—driving safely.
- **Dial sensibly and assess the traffic; if possible, place calls when your car is not moving or before pulling into traffic.** If you must make a call while moving, dial only a few numbers, check the road and your mirrors, then continue.
- **Do not engage in stressful or emotional conversations that may be distracting.** Make people you are talking with aware you are driving and suspend conversations that can divert your attention away from the road.

- **Use your mobile device to call for help.** Dial 911 or other local emergency number in the case of fire, traffic accident, or medical emergencies.*
- **Use your mobile device to help others in emergencies.** If you see an auto accident, crime in progress, or other serious emergency where lives are in danger, call 911 or other local emergency number, as you would want others to do for you.*
- **Call roadside assistance or a special non-emergency wireless assistance number when necessary.** If you see a broken-down vehicle posing no serious hazard, a broken traffic signal, a minor traffic accident where no one appears injured, or a vehicle you know to be stolen, call roadside assistance or other special non-emergency wireless number.*

* Wherever wireless phone service is available.

index

A

accessories 10, 68
accessory connector port 1
alarm clock 71
alert
 turn off 34
alert lights 65
alert sounds 40
answer a call 13
attach a number 56

B

backlight 44
banner 66
battery 11
 extending battery life 10,
 22, 39

Bluetooth connection
 description 21, 68
brightness 44

C

cables 24
calculator 71
calendar 71
call
 answer 13
 end 12, 13
 make 12
 restrict 53
call drop alerts 70
call sounds 40
call timers 67
car kit 68

center key 1
center select key 9
chat 55
clock
 alarm 71
 world 71
codes 36, 37
Contacts
 assign picture 56
 assign ringtone 57
 call entry 59
 create entry 55
 create group 58, 59
 download ringtone 57
 edit entry 56
 erase entry 56
 set default number 58

set speed dial number 58
speak entry 42

D

data volume 67
dial a phone number 12
dialed calls 48
display 26
display themes 65
draft message 54
DTMF tones 53

E

earpiece volume 34
email 55
emergency number 50
end a call 12, 13
end key 1, 12, 13
event sounds 40
export regulations 92
external display 34

F

flip 13

H

handsfree speaker 34
headset 68
headset jack 1
hearing aids 90
home keys 66
home screen 26

I

iTAP text entry mode 32

K

keypad 65

L

language 66

lights

 alert 65

linking. See Bluetooth
 connection

lock

 phone 37

lock code 36

M

make a call 12
master volume 39
menu 9
 icons 66
message 54
 chat 55
 draft 54
 email 55
 Mobile IM 55
 objects 54
 read 54

message (continued)
 received 54
 sent 54
Mobile IM 55

N

navigation key 1, 9
network settings 70
number. See phone number
numeric entry mode 33

O

optional accessory 10
optional feature 9

P

pairing. See Bluetooth
 connection
perchlorate label 93
personalize 59

phone number 14
phonebook 55, 56
photo 73
picture 73
power key 1, 12

R

received calls 48
received message 54
recent calls 48
recycling 92
redial 47
reset timer 67
restrict calls 53
ringer volume 34
roaming alert 70

S

safety information 79
safety tips 94
screen saver 43

send key 1, 12, 13
sent message 54
service tones 70
soft keys 1, 26
sound settings 34, 39
speak Contact list entry 42
speak keypad digits 41
speakerphone 68
store your number 14
symbol entry mode 33

T

talking phone 41
tap text entry mode 31
telephone number. See
 phone number
text entry 29
text message 54
themes 65
timers 67
turn on/off 12

U

unlock
 phone 37
unlock code 37
USB cables 24

V

voice privacy 72
voice recognition 59
voicemail 51
voicemail message indicator
 51
volume 34, 65

W

wallpaper 42
warranty 86
WHO information 91
world clock 71

Y

your phone number 14

U.S. patent Re. 34,976

DRAFT