

APPLICANT: MOTOROLA, INC.

FCC ID: IHDT56KY1

INSTRUCTION MANUAL

A preliminary draft copy of the Users Manual follows:



MOTO™ VE440

Quick Start Guide

congratulations

The **Motorola VE440** will make you the envy of your friends. Set the trend wherever you go. Take pictures, play music, or simply make a call with this hot looking phone.

Put music in your pocket! With dedicated music keys and the 3.5 mm headset jack, the built-in music player makes your favorite song just a few clicks away.

We've crammed all of the main features of your phone into this handy guide, and in a matter of minutes we'll show you just how easy your phone is to use. So go on, check it out, then feel the beat.

Caution: Before using your phone for the first time, please read the important **legal and safety** information at the back of this guide (page 48).

this guide

symbols in this guide



This means a feature is network or subscription dependent, and may not be available in all areas. Contact your service provider for more information.




This means a feature requires an optional accessory.

contents


your phone	4
main menu	6
let's go	7
basics	8
home screen	11
calls	14
phonebook	16
messages	18
text entry	21
tips & tricks	23
personalize	25
photos	26
music	27
Web	40
Bluetooth® wireless	41
tools	43
security	45
service & repairs	47
Legal & Safety	48

your phone

the important keys & connectors



your phone



3.5 mm
Headset
Jack

**Music
Buttons:**

Skip back/Rewind

Play/Pause

Skip ahead/
Fast Forward

main menu



Phonebook



Multimedia

- Music & Sounds
- Camera
- Pictures
- Storage Device



Settings

- Sounds
- Display
- Phone
- Call
- Bluetooth
- USB
- Storage Device
- Phone Info
- Setup Wizard



Tools

- Voice Commands
- Datebook
- Alarm Clock
- World Clock
- Calculator
- Notepad
- Stopwatch



MetroWEB



Messaging

- Inbox
- Create Message
- Conversations
- Email
- IM
- Voicemail
- Outbox
- Drafts
- Facebook



@metro



Phone Info

- My Number
- SW/HW Version
- Icon Glossary



Recent Calls

- Received Calls
- Missed Calls
- Dialed Calls
- All Calls
- Timers



Datebook



Music Player



Ringtones

* Network dependent
This is the standard main menu layout.

Your phone's menu may be different.


let's go

let's get you up & running


1 cover off




2 push tab aside



3 microSD in




4 battery in



5 cover on



6 charge





Caution: See page 48 for battery use & safety.

basics


here are some basics to get you started

turn it on & off

Press and hold  for a few seconds or until the screen lights up.




make & answer calls

To **make a call**, enter a phone number and press .


To **answer a call**, just press .

To choose **Hold**, **Mute**, **Transfer**, or other options during a call, press **Options**.



end calls


Press .




navigation & volume keys

Press the **Center Key**  to open the **Main Menu**.

Press the **Navigation Key**  up or down to scroll to and highlight a menu option.



Press  to select the highlighted option.

Press the **Volume Keys** (page 5) to change your ring style from the home screen, silence your phone when it rings, or change the speaker volume during calls.

store contacts

- 1 Enter a number in the home screen.
- 2 Press **Save**.
- 3 Select **Create New Contact**.
- 4 Select an entry type.
- 5 Enter contact details, then press **Save**.

call or text contacts

- 1 From the home screen, press **Contacts**.
- 2 Scroll to highlight the contact.

Tip: To jump to a contact, enter the name.

If a contact has more than one number, scroll left or right to choose a number.

- 3 To **call**, press .

To **send a text message**, press **Send Message**.

home screen






you can always go home

You see the *home screen* when you turn on the phone or when you press the End Key (). Status indicators appear at the top:











Status Indicators













status indicators

	Bars indicate network connection strength.
1X	Phone is in a 1xRTT coverage area. (1xRTT offers higher voice and data transmission than CDMA.)
	Phone is in airplane mode.
	Phone is roaming off your home network
	SSL —Indicates phone is using Secure Sockets Layer (SSL) secure data transmission.
	Data Call —Shows during an active data call.

home screen

	Dormant —Indicates phone is dormant and PPP session is active.
	No Service —Phone is in area with no service coverage.
	VR Active —Indicates the phone's Voice Recognition feature is active.
	VR Listening —Indicates the phone's Voice Recognition feature is waiting for a voice command.
	Phone is in TTY mode
	Location is On
	Keypad/Phone Locked —The keypad/phone is locked.
	Battery Level —Shows battery charge level. The more bars, the greater the charge.
	Bluetooth Active —Your phone is paired to another Bluetooth device.
	Bluetooth On —Your phone's Bluetooth power is On .

home screen



	Bluetooth Connected —Your phone is connected to another Bluetooth device.
	Active voice call
	New Message —Phone received a new text message.
	New Voicemail Message —Phone received a new voicemail message.
	New Text & Voicemail Message —Phone received a new text and a new voicemail message.
	All sounds off.
	Vibrate only.
	Alarm only.
	Missed Call —Phone received an unanswered call.
	An alarm has been set

calls

it's good to talk

For the basics, see page 8.

redial a number

From the home screen, press  to see **ALL CALLS**. Scroll to the entry you want to call and press  again.

handsfree

To **activate the handsfree speaker** during a call, press and hold the Smart/Speaker Key (page 5) on the left side of the phone. You hear an audible alert, and your phone shows  and **SPEAKER PHONE ON**.

To **turn off the handsfree speaker**, press and hold the Smart/Speaker Key. Your phone shows **SPEAKER PHONE OFF**.

To **end the call**, press . You hear an audible alert.

Note: You can also use **headsets or car kits** with a micro USB (page 4) or Bluetooth® connection (page 41). The handsfree speaker won't work when your phone is connected to a handsfree car kit or headset.

emergency calls




To call an emergency number, enter the emergency number and press .


Your service provider programs emergency phone numbers, (such as 911), that you can call under any circumstances, even when your phone is locked.

Emergency numbers vary by country. Your phone's pre-programmed emergency number(s) may not work in all locations, and sometimes an emergency call cannot be placed due to network, environmental, or interference issues.

voicemail



When you **receive** a voicemail message, your phone shows  and **New Voicemail**. To hear the new message, select **Listen Now**. To close the notification, press . The  stays at the bottom of the screen until you listen to your message.

To check your voicemail from the home screen, press and hold .

got their number? now do more

To store and call contacts, see page 9.

edit or delete contacts

- 1 From the home screen, press **Contacts**.
- 2 Scroll to the contact or enter the first letters of a contact you want.

To edit the contact, press **Options > Edit Contact**. To save your changes, press **Save**.

To delete the contact, press **Options > Delete**.

add a ringtone for a contact



- 1 From the home screen, press **Contacts**.
- 2 Scroll to the entry and press the **Options > Edit Contact**.
- 3 Scroll to **Call Ringer ID** and press **Options > Set Call Ringer ID**.
- 4 Scroll to the ringtone and press **◆**.
- 5 Press **Save** to save changes.

Note: Ring tones will not sound if the **Master Volume** is **Vibrate Only**, **Alarm Only**, or **All Sounds Off**.

speed dial contacts

To **set** a speed dial number for a contact:

Find it:  >  Phonebook > Speed Dial

- 1** Scroll to an unassigned speed dial number and press .
- 2** Scroll to a contact and press , then select **Yes** to confirm your entry.

To **call** a speed dial contact: From the home screen, (for 1-9) press and hold the speed dial number, **or** (for 10-99) press the first number and press and hold the second number.


messages

sometimes it's better 2 say it in a message

text messages

create & send text messages

Find it:  >  **Messaging** > **Create Message**



- 1** Enter contact names, or press  (**Add**) to choose recipients.
- 2** Scroll down to the text entry area and enter text (page 21).

While entering text, you can press **Options** for message options.

- 3** To send the message, press **Send**.

receive text messages

Find it:  >  **Messaging** > **Inbox**

- 1** Scroll to a message. (Newest ones are listed first.)
 - 2** To read the message, press .
- To call the sender, press .

messages

To open message options (such as **Forward** or **Lock**), press **Options**.

email



Find it:  >  **Messaging** > **Email**

Choose your email provider and log in.

For more information, contact your email provider.

instant messages (IM)



Find it:  >  **Messaging** > **Email**

Choose your IM community and log in.

conversations


Conversations organizes your messages into conversation strings that you can follow quickly and easily.

Find it:  >  **Messaging** > **Conversations**

1 Scroll to the message sender you want.

When a message sender is highlighted, you see the date, time, and subject of the last message you received from the sender.

messages

- 2 Press  to select the highlighted sender.

You see a partial view of the last message you received from the sender. Above that is a partial view of the previous message.

- 3 Press  **to open and view a highlighted message.**

Scroll up **to view earlier messages.**

Scroll down to the entry area at the bottom of the screen **to enter a reply.** Press **Send** to send the reply.

- 4 Press  to return to the home screen.

text entry

how fast can u text?

To change modes when you are entering text, press

Options >Entry Mode:

entry modes	
iTAP English	The phone predicts each word (in English) as you press keys.
iTAP Spanish	The phone predicts each word (in Spanish) as you press keys.
Abc	Enter numbers and letters, first character of a sentence in uppercase.
ABC	Enter numbers and letters, all characters in uppercase (not available when editing a contact).
123	Enter numbers only.
Symbols	Enter symbols.



text entry

When text mode is set to iTAP English or iTAP Spanish, press  in any text entry screen to toggle between these capitalization options:

capitalization options	
iTAPEn	first letter of sentence in uppercase (English)
iTAPEN	all uppercase letters (English)
iTAPen	all lowercase letters (English)
iTAPEs	first letter of sentence in uppercase (Spanish)
iTAPES	all uppercase letters (Spanish)
iTAPes	all lowercase letters (Spanish)



To accept a word completion, press  right.

To enter a space, press .





To delete a character, press  (to delete a whole word, press and hold .

tips & tricks

make your phone even faster

options	
home screen shortcuts	In the home screen, press  up, down, or left. (To change shortcuts, see page 25.)
set phone to vibrate	Press and hold  to switch to Vibrate Only and back.
turn handsfree speaker on/off	Press and hold the Smart/Speaker Key on the left side of the phone (page 5).
lock keypad	Press and hold the Lock Key on the top of the phone (page 5).

improve battery life

- To make your backlight turn off sooner: From the home screen,  >  **Settings** > **Display** > **Backlight**, select **Display** or **Keypad**, and select **7 seconds**.
- To turn off Bluetooth® power when you're not using it: From the home screen, press  >  **Settings** > **Bluetooth**, and select **Turn off**.

voice commands

Press and the Voice Key on the top of the phone (page 5), then speak a voice command:

- **Call <Name or #>**
- **Send Message <Name or #>**
- **Go To <Shortcut>**
- **Check <Item>**
- **Redial**
- **Play <Playlist>**

personalize

add your personal touch

ringtone

Find it:  >  **Settings** > **Sounds**

To set your ring style and volume, select **Easy Set-up**.

To customize your sounds, select other options in the **Sounds Settings** list.


display settings

Find it:  >  **Settings** > **Display**

To set your display appearance, select **Easy Set-up**.

To customize display settings, select other options in the **Display Settings** list.

home screen shortcuts

You can set the features that open when you press  up or down.


Find it:  >  **Settings** > **Phone** > **Shortcuts**




photos

see it, capture it, send it!



take photos


- 1 From the home screen, press the camera key .



Press  left or right to zoom in and out.

Press **Options** to see more options.

- 2 To take the photo, press  or .

 - To save the photo, press .
 - To send the photo, press **Send**.
 - To discard the photo, press **Delete**.

music

when music is what you need

get music

Note: You'll need **an optional microSD memory card** installed in your phone to use the music player.

Just **load your favorite music onto your computer**. Then, **transfer the music from the computer to your phone**. You'll need:

- the Windows XP™ operating system
- Windows Media Player, version 11 or later

To download Windows Media Player, go to **<http://www.microsoft.com/windowsmedia>**.

- a USB data cable (sold separately)

Note: The unauthorized copying of copyrighted materials is contrary to the provisions of the Copyright Laws of the United States and other countries. This device is intended solely for copying non-copyrighted materials, materials in which you own the copyright, or materials which you are authorized or legally permitted to copy. If

music

you are uncertain about your right to copy any material, please contact your legal advisor.

load music onto your computer

You can purchase Microsoft™ Windows™ Media DRM-protected music files from supported on-line music stores (such as Urge and Napster).

You can also **load song files from a music CD** onto your computer:

- ➊ Insert the music CD in your computer's CD drive.
- ➋ Launch Windows Media Player 11.
- ➌ Copy the music CD to the media player library (also called *ripping* the CD).



If your computer is connected to the Internet, the media player may retrieve information such as song titles, album name, artist name, and album artwork. This information will display in your phone's music player after you transfer the music to your phone.

music

transfer music

Before you copy files to your phone, make sure the files are in a format that the phone recognizes. Your phone's music player can play the following types of audio files: AAC, AAC+, MP3, WAV, WMA, Real Audio G2/8/10.

Before you transfer music to your phone:

- 1 Insert a memory card into your phone (see page 7).
- 2 Set your phone to **Mass Storage** mode by pressing  >  **Settings** > **USB** > **Mass Storage**.
- 3 Attach a Motorola Original USB cable to the micro USB port on your phone and to an available USB port on your computer. A Motorola Original USB cable and supporting software may be included with your phone. These tools are also sold separately.



TM

transfer with Windows Media Player

You can use Windows Media Player 11 to transfer music from the computer to your phone.

Note: Windows Media Player 11 requires Windows XP™ or later to run. If you are using an earlier version of Windows OS, you'll need to manually transfer music to your phone.

- 1** Run Windows Media Player 11.

Your phone appears in the upper right corner of the Windows Media Player 11 screen. Music files stored on the phone's memory card are listed on the left side of the screen.

- 2** Select the "Sync" tab in Windows Media Player 11.
- 3** Drag and drop songs or playlists onto the "Sync List" on the right side of the Windows Media Player 11 screen.
- 4** Click "Start Sync" to copy the songs onto the phone's memory card.
- 5** When you finish, disconnect your phone from the computer.

transfer manually

- 1 On your computer, double-click on the “My Computer” icon to locate the “Removable Disk” icons for your phone and memory card.
- 2 Double-click the “Removable Disk” icon for your phone or memory card.
- 3 In the “Removable Disk” window, create the “my_music” folder (if one does not already exist).

Note: The music player checks for songs only in this folder.

- 4 Drag and drop the music files you want onto the “my_music” folder.
- 5 When you finish, right-click the “Safely Remove Hardware” icon in the system tray at the bottom of your computer screen, then select “USB Mass Storage Device.” Disconnect the USB cable.

music

play music

- 1 Press and hold the play/pause button ►|| (on the right side of the phone—see page 5).

Tip: You can also press  >  **Music Player**, or press  >  **Multimedia** > **Music & Sounds** > **Music Player**.

Your phone displays the **Music Player** menu.


- 2 Press ► or ◀ to scroll up or down through the menu, then press ►|| to select a highlighted option.

To control music playback:

controls	
play/resume play	Press ►.
pause	Press .
fast forward	Press & hold ►►.
next song	Press ►►.
rewind	Press & hold ◀◀.
previous song	Press ◀◀.

music

While a song is playing on the music player, your phone's screen will look similar to the following:



During a song, the music player shows the song title, artist, album, and artwork, if available.

Note: If you receive a call during a song, the music player pauses the song until the call is over.

playlists

Personalize your music collection by creating your own playlists.

When you name a playlist:

- The name must be fewer than 32 characters.
- The name cannot include these characters: / \ : * ? < > | " !


Note: Your music player includes a special playlist named **ringtones**. You can't rename this playlist. Songs added to this playlist are not visible in other categories (for example, **Genres**) in the music player. The **ringtones** playlist initially contains ringtones that are preloaded on your phone. You can still edit this playlist, just like any other playlist, to add or remove new ringtones that you purchase.

music

create a playlist

- 1 Press and hold the play/pause button ►||.
- 2 Scroll to **Playlists** and press ⬇️.
- 3 Press **Options**, then select **Create Playlist**.
- 4 Enter a name for the playlist and press **Done**.
- 5 With the new playlist highlighted on the **Playlists** screen, press **Options**, then select **Add a Song**. Scroll to a desired song and press ⬇️.

Repeat this step to add more songs.





- 6 Press  when you finish adding songs.

add song to playlist




- 1 Press and hold the play/pause button ►||.
- 2 Scroll to **Playlists** and press ⬇️.
- 3 Scroll to the playlist and press **Options**.
- 4 Scroll to **Add a Song** and press ⬇️.
- 5 Scroll to the song you want to add and press ⬇️.

Tip: To add a song that is playing to a playlist, just press **Settings** and select **Add to Playlist**.

remove song from playlist

- 1 Press and hold the play/pause button ►||.
- 2 Scroll to **Playlists** and press .
- 3 Scroll to the playlist and press .
- 4 Scroll to the song you want to remove and press **Options**.
- 5 Scroll to **Remove from Playlist** and press , then scroll to **Yes** and press .

delete a playlist

- 1 Press and hold the play/pause button ►||.
- 2 Scroll to **Playlists** and press .
- 3 Scroll to the playlist and press **Options**.
- 4 Scroll to **Delete Playlist** and press , then scroll to **Yes** and press .

music

wake up music player

While the music player is active, your phone may conserve battery power by turning off the display and keypad backlights.

To turn display and backlights back on, press any key.

settings

From the home screen, press and hold the play/pause button ►||, then select **Settings**.

While a song is playing, press **Settings**.

options	
Audio Effects	Customize music playback by selecting Club , Full Bass , or Dance . Select None to use the player's default playback settings.
Visual Effects	Select custom visual effects for the music playback screen.

music

options	
Repeat	Replay a song (when you select a single song for play—does not replay a playlist or album).
Shuffle	Play songs in random order.
Add to Playlist	Add the song that is currently playing to a playlist. Note: This option is available only while a song is playing.
Background Play	Continue music playback while returning to home screen to complete other activities. Note: This option is available only while a song is playing.

music player tips


- If you are navigating music player menus while a song is playing and don't press a key for more than five seconds, the player returns to the current song list screen.
- **Note: Optional accessory required.** Turn off the player before connecting the phone to a computer. If you connect the phone to a computer while the player is turned on, the phone automatically turns off the player.
- **Note: Optional accessory required.** If you use a headset with the phone, music plays through the headset. Music plays through the phone speaker when the headset is disconnected.

Web

you don't need a PC, surf the Web with your phone



Find it:  >  MetroWEB


- To **select** a highlighted link, press **Select**.
- To **enter a Web page address**, press **Menu**, select **Go to URL**, then enter the Web address (URL).
- To **bookmark** a page, press **Menu**, then select **Add Favorite**. To open bookmarks, press **Options** > **Open** > **Bookmark**.
- To **enter text**, select a field and press  to open it.

lose the wires and go wireless



connect new devices



Find it:  >  Settings > Bluetooth

- 1** Select **Bluetooth Menu**, select **Add New Device**.
- 2** Make sure the Bluetooth device you are pairing with is in *discoverable* mode (see the user's guide for the device).
- 3** With **Add New Device** highlighted, press  to search for available Bluetooth devices.

Note: If Bluetooth power is not turned on, your phone will display **Turn Bluetooth Power On?** Select **Yes**.

- 4** Highlight the device you want to connect to and press .
- 5** If necessary, enter the device PIN (such as **0000**) and press .

Tip: For specific information about a device, check the instructions that came with it. For more Bluetooth support, go to www.motorola.com/Bluetoothsupport

Bluetooth® wireless

For maximum Bluetooth security, always connect Bluetooth devices in a safe, private environment.

Note: Your phone's Bluetooth features and Bluetooth Class 1 power levels are not allowed for outdoor operation in France. To avoid unlawful interference with radio signals, do not use the Bluetooth features in France unless you are indoors.

Note: The use of wireless phones while driving may cause distraction. Discontinue a call if you can't concentrate on driving. Additionally, the use of wireless devices and their accessories may be prohibited or restricted in certain areas. Always obey the laws and regulations on the use of these products.

reconnect devices




To **automatically reconnect** your phone with a device, just turn on the device when it is near the phone. If the device doesn't connect, turn it off and back on, and make sure your phone's Bluetooth power is on.

keep up with life


add a calendar event

Find it:  >  **Datebook**

- 1 Scroll to the desired date and press **Add**.
- 2 Enter new appointment name and details. To change the time, recurrence, or alert type, scroll to the line and press .
- 3 To save the appointment, press **Save**.

set an alarm

Find it:  >  **Tools** > **Alarm Clock**

- 1 Scroll to **Alarm 1**, **Alarm 2**, or **Alarm 3**, and press **Edit**.
- 2 Select **On**, and set the alarm time, recurrence, and alert sound by scrolling to the category and pressing .
- 3 When finished, press **Done**.

calculator

Find it:  >  Tools > Calculators

Select **Basic Calculator** or **Tip Calculator**. Use the full keypad to enter numbers.

For **Basic Calculator**, press  to select functions,  to enter a decimal point, and  to change to a positive or negative number.

security

keep your phone safe

codes & passwords

Your phone's four-digit **lock code** is originally set to the last four digits of your phone number. To change the lock code:

Find it:  >  **Settings** > **Phone** > **Security**

- 1** When prompted, enter the lock code and press **Done**.
- 2** Select **Edit Lock Code**.
- 3** Enter the new four-digit lock code in the **Enter New Code** entry area and in the **Confirm New Code** entry area.
- 4** Press **Done**.

lock & unlock phone

You can lock your phone to keep others from using it.

Find it:  >  **Settings** > **Phone** > **Security**

- 1 When prompted, enter the lock code and press **Done**.
- 2 Select **Lock Phone Now**.

To unlock your phone:

- 1 From the home screen, press **Unlock**.
- 2 Enter your unlock code and press **Done**.

service & repairs

we're here to help

If you have questions or need assistance, we're here to help.

Go to www.motorola.com/myrival, where you can select from a number of customer care options. You can also contact the Motorola Customer Support Center at 1-800-331-6456 (United States), 1-888-390-6456 (TTY/TDD United States for hearing impaired), or 1-800-461-4575 (Canada).

Battery Use & Safety

Important: Handle and store batteries properly to avoid injury or damage.

Most battery issues arise from improper handling of batteries, and particularly from the continued use of damaged batteries.

DON'Ts

- **Don't disassemble, crush, puncture, shred, or otherwise attempt to change the form of your battery.**
- **Don't let the phone or battery come in contact with water.** Water can get into the phone's circuits, leading to corrosion. If the phone and/or battery get wet, have them checked by your carrier or contact Motorola, even if they appear to be working properly.
- **Don't allow the battery to touch metal objects.** If metal objects, such as jewelry, stay in prolonged contact with the battery contact points, the battery could become very hot.
- **Don't place your battery near a heat source.** Excessive heat can damage the phone or the battery. High temperatures can cause the battery to swell, leak, or malfunction. Therefore:
 - Do **not** dry a wet or damp battery with an appliance or heat source, such as a hair dryer or microwave oven.
 - Avoid leaving your phone in your car in high temperatures.

DOs

- **Do avoid dropping the battery or phone.** Dropping these items, especially on a hard surface, can potentially cause damage.
- **Do contact your service provider or Motorola if your phone or battery has been damaged from dropping or high temperatures.**

Important: Use Motorola Original products for quality assurance and safeguards. To aid consumers in identifying authentic Motorola batteries from non-original or counterfeit batteries (that may not have adequate safety protection),

Motorola provides holograms on its batteries. Consumers should confirm that any battery they purchase has a “Motorola Original” hologram.

Motorola recommends you always use Motorola-branded batteries and chargers. Motorola mobile devices are designed to work with Motorola batteries. If you see a message on your display such as **Invalid Battery** or **Unable to Charge**, take the following steps:

- Remove the battery and inspect it to confirm that it has a “Motorola Original” hologram;
- If there is no hologram, the battery is not a Motorola battery;
- If there is a hologram, replace the battery and retry charging it;
- If the message remains, contact a Motorola authorized service center.

Important: Motorola’s warranty does not cover damage to the phone caused by non-Motorola batteries and/or chargers.

Warning: Use of a non-Motorola battery or charger may present a risk of fire, explosion, leakage, or other hazard.

Proper and safe battery disposal and recycling: Proper battery disposal is not only important for safety, it benefits the environment. Consumers may recycle their used batteries in many retail or service provider locations. Additional information on proper disposal and recycling may be found on the Web:

- www.motorola.com/recycling
- www.rbc.org/call2recycle/ (in English only)

Disposal: Promptly dispose of used batteries in accordance with local regulations. Contact your local recycling center or national recycling organizations for more information on how to dispose of batteries.



Warning: Never dispose of batteries in a fire because they may explode.

Battery Charging

Notes for charging your phone’s battery:

- When charging your battery, keep it near room temperature. Never expose batteries to temperatures below 0°C (32°F) or above 45°C (113°F) when charging.
- New batteries are not fully charged.
- New batteries or batteries stored for a long time may take more time to charge.

- Motorola batteries and charging systems have circuitry that protects the battery from damage from overcharging.

Specific Absorption Rate

Your model wireless phone meets the governmental requirements for exposure to radio waves.

Your wireless phone is a radio transmitter and receiver. It is designed and manufactured to not exceed limits for exposure to radio frequency (RF) energy set by the Federal Communications Commission (FCC) of the U.S. Government and by the Canadian regulatory authorities. These limits are part of comprehensive guidelines and establish permitted levels of RF energy for the general population. The guidelines are based on standards that were developed by independent scientific organizations through periodic and thorough evaluation of scientific studies. The standards include a substantial safety margin designed for the safety of all persons, regardless of age or health, and to account for any variations in measurements.

The exposure standard for wireless mobile phones employs a unit of measurement known as the Specific Absorption Rate (SAR). The SAR limit set by the FCC and by the Canadian regulatory authorities is 1.6 watts per kilogram (W/kg), averaged over one gram of tissue. Tests for SAR are conducted using procedures accepted by the FCC and by Industry Canada with the phone transmitting at its highest certified power level in all tested frequencies. Although the SAR is determined at the highest certified power level, the actual SAR level of the phone while operating can be below the maximum value. This is because the phone is designed to operate at multiple power levels so as to use only the power required to reach the network. In general, the closer you are to a wireless base station, the lower the power output. Before a phone model is available for sale to the public in the U.S. and Canada, it must be tested and certified to the FCC and Industry Canada that it does not exceed the limit established by each government for safe exposure. The tests are performed in positions and locations (e.g., at the ear and worn on the body) submitted to the FCC and available for review by Industry Canada. The highest SAR value for this model phone when tested for use at the ear is 1.49 W/kg, and when worn on the body, as described in this guide, is 1.53 W/kg. Body-worn measurements can differ, depending upon available accessories and regulatory requirements. The SAR

information includes the Motorola testing protocol, assessment procedure, and measurement uncertainty range for this product.

While there may be differences between the SAR levels of various phones and at various positions, they meet the governmental requirements for safe exposure. Please note that improvements to this product model could cause differences in the SAR value for later products; in all cases, products are designed to be within the guidelines.

Additional information on SAR can be found on the Cellular Telecommunications & Internet Association (CTIA) Web site:

<http://www.phonefacts.net>

or the Canadian Wireless Telecommunications Association (CWTA) Web site:

<http://www.cwta.ca>

Software Copyright Notice

Motorola products may include copyrighted Motorola and third-party software stored in semiconductor memories or other media. Laws in the United States and other countries preserve for Motorola and third-party software providers certain exclusive rights for copyrighted software, such as the exclusive rights to distribute or reproduce the copyrighted software. Accordingly, any copyrighted software contained in Motorola products may not be modified, reverse-engineered, distributed, or reproduced in any manner to the extent allowed by law. Furthermore, the purchase of Motorola products shall not be deemed to grant either directly or by implication, estoppel, or otherwise, any license under the copyrights, patents, or patent applications of Motorola or any third-party software provider, except for the normal, non-exclusive, royalty-free license to use that arises by operation of law in the sale of a product.

Content Copyright

The unauthorized copying of copyrighted materials is contrary to the provisions of the Copyright Laws of the United States and other countries. This device is intended solely for copying non-copyrighted materials, materials in which you own the copyright, or materials which you are authorized or legally permitted to copy. If you

are uncertain about your right to copy any material, please contact your legal advisor.

AGPS & Emergency Calls

When you make an emergency call, your mobile device can use *Assisted Global Positioning System* (AGPS) satellite signals to tell the emergency response center your approximate location.

The AGPS feature has limitations, so always tell the emergency response center your best knowledge of your location. Remain on the phone for as long as the emergency response center instructs you.

AGPS **might not work** for emergency calls, if your local emergency response center does not process AGPS location information. For details, contact your local authorities.

If your mobile device cannot find strong AGPS satellite signals, the location of the nearest cell tower in contact with your mobile device is automatically provided to the emergency response center.

AGPS Performance Tips

- Go outside and away from underground locations, covered vehicles, structures with metal or concrete roofs, tall buildings, and foliage. Indoor performance might improve if you move closer to windows, but some window sun shielding films can block satellite signals.
- Move away from radios, entertainment equipment, and other electronic devices that might interfere with or block AGPS satellite signals.

AGPS uses satellites controlled by the U.S. government and subject to changes implemented in accordance with the Department of Defense AGPS user policy and the Federal Radio Navigation Plan. These changes might affect AGPS performance.

Safety & General Information

This section contains important information on the safe and efficient operation of your mobile device. Read this information before using your mobile device.

Exposure to Radio Frequency (RF) Energy

Your mobile device contains a transmitter and receiver. When it is ON, it receives and transmits RF energy. When you communicate with your mobile device, the system handling your call controls the power level at which your mobile device transmits.

Your mobile device is designed to comply with local regulatory requirements in your country concerning exposure of human beings to RF energy.

Operational Precautions

For optimal mobile device performance, and to be sure that human exposure to RF energy does not exceed the guidelines set forth in the relevant standards, always follow these instructions and precautions.

Product Operation

When placing or receiving a phone call, hold your mobile device just like you would a landline phone.

If you wear the mobile device on your body, always place the mobile device in a Motorola-supplied or approved clip, holder, holster, case, or body harness. If you do not use a body-worn accessory supplied or approved by Motorola, keep the mobile device and its antenna at least 2.5 centimeters (1 inch) from your body when transmitting.

Using accessories not supplied or approved by Motorola may cause your mobile device to exceed RF energy exposure guidelines. For a list of Motorola-supplied or approved accessories, visit our Web site at: www.motorola.com.

RF Energy Interference/Compatibility

Nearly every electronic device is subject to RF energy interference from external sources if inadequately shielded, designed, or otherwise configured for RF energy compatibility. In some circumstances, your mobile device may cause interference with other devices.

Follow Instructions to Avoid Interference Problems

Turn off your mobile device in any location where posted notices instruct you to do so.

In an aircraft, turn off your mobile device whenever instructed to do so by airline staff. If your mobile device offers an airplane mode or similar feature, consult airline staff about using it in flight.

Implantable Medical Devices

If you have an implantable medical device, such as a pacemaker or defibrillator, consult your physician before using this mobile device.

Persons with implantable medical devices should observe the following precautions:

- ALWAYS keep the mobile device more than 20 centimeters (8 inches) from the implantable medical device when the mobile device is turned ON.
- DO NOT carry the mobile device in the breast pocket.
- Use the ear opposite the implantable medical device to minimize the potential for interference.
- Turn OFF the mobile device immediately if you have any reason to suspect that interference is taking place.

Read and follow the directions from the manufacturer of your implantable medical device. If you have any questions about using your mobile device with your implantable medical device, consult your healthcare provider.

Driving Precautions

The use of wireless phones while driving may cause distraction. Discontinue a call if you can't concentrate on driving.

Additionally, the use of wireless devices and their accessories may be prohibited or restricted in certain areas. Always obey the laws and regulations on the use of these products.

Responsible driving practices can be found in "Smart Practices While Driving."

Operational Warnings

Obey all posted signs when using mobile devices in public areas.







Potentially Explosive Atmospheres

Areas with potentially explosive atmospheres are often, but not always, posted and can include fueling areas, such as below decks on boats, fuel or chemical transfer or storage facilities, or areas where the air contains chemicals or particles, such as grain dust, or metal powders.

When you are in such an area, turn off your mobile device, and do not remove, install, or charge batteries. In such areas, sparks can occur and cause an explosion or fire.

Symbol Key

Your battery, charger, or mobile device may contain symbols, defined as follows:

Symbol	Definition
	Important safety information follows.
	Do not dispose of your battery or mobile device in a fire.
	Your battery or mobile device may require recycling in accordance with local laws. Contact your local regulatory authorities for more information.
	Do not throw your battery or mobile device in the trash.
	Do not let your battery, charger, or mobile device get wet.
	Listening at full volume to music or voice through a headset may damage your hearing.

Batteries & Chargers

Caution: Improper treatment or use of batteries may present a danger of fire, explosion, leakage, or other hazard. For more information, see “Battery Use & Safety.”

Keep Your Mobile Device and Its Accessories Away From Small Children

These products are not toys and may be hazardous to small children. For example:

- A choking hazard may exist for small, detachable parts.
- Improper use could result in loud sounds, possibly causing hearing injury.
- Improperly handled batteries could overheat and cause a burn.

Glass Parts

Some parts of your mobile device may be made of glass. This glass could break if the product is dropped on a hard surface or receives a substantial impact. If glass breaks, do not touch or attempt to remove. Stop using your mobile device until the glass is replaced by a qualified service center.

Seizures/Blackouts

Some people may be susceptible to epileptic seizures or blackouts when exposed to flashing lights, such as when playing video games. These may occur even if a person has never had a previous seizure or blackout.

If you have experienced seizures or blackouts, or if you have a family history of such occurrences, please consult with your physician before playing video games or enabling a flashing-lights feature (if available) on your mobile device.

Discontinue use and consult a physician if any of the following symptoms occur: convulsion, eye or muscle twitching, loss of awareness, involuntary movements, or disorientation. It is always a good idea to hold the screen away from your eyes, leave the lights on in the room, take a 15-minute break every hour, and stop use if you are tired.

Caution About High Volume Usage

Warning: Exposure to loud noise from any source for extended periods of time may affect your hearing. The louder the volume sound level, the less time is required before your hearing could be affected.

To protect your hearing:

- Limit the amount of time you use headsets or headphones at high volume.
- Avoid turning up the volume to block out noisy surroundings.
- Turn the volume down if you can't hear people speaking near you.



If you experience hearing discomfort, including the sensation of pressure or fullness in your ears, ringing in your ears, or muffled speech, you should stop listening to the device through your headset or headphones and have your hearing checked.

For more information about hearing, see our Web site at www.motorola.com/hearingsafety (in English only).

Repetitive Motion

When you repetitively perform actions such as pressing keys or entering finger-written characters, you may experience occasional discomfort in your hands, arms, shoulders, neck, or other parts of your body. If you continue to have discomfort during or after such use, stop use and see a physician.

[Jan0109]

Industry Canada Notice to Users

Operation is subject to the following two conditions: (1) This device may not cause interference and (2) This device must accept any interference, including interference that may cause undesired operation of the device. See RSS-GEN 7.1.5.

FCC Notice to Users

The following statement applies to all products that have received FCC approval. Applicable products bear the FCC logo, and/or an FCC ID in the format FCC-ID:xxxxxx on the product label.

Motorola has not approved any changes or modifications to this device by the user. Any changes or modifications could void the user's authority to operate the equipment. See 47 CFR Sec. 15.21.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. See 47 CFR Sec. 15.19(3).

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy

and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and the receiver.
- Connect the equipment to an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Use & Care

To care for your Motorola phone, please keep it away from:



liquids of any kind

Don't expose your phone to water, rain, extreme humidity, sweat, or other moisture. If it does get wet, don't try to accelerate drying with the use of an oven or dryer, as this may damage the phone.



extreme heat or cold

Avoid temperatures below 0°C/32°F or above 45°C/113°F.



microwaves

Don't try to dry your phone in a microwave oven.



dust and dirt

Don't expose your phone to dust, dirt, sand, food, or other inappropriate materials.



cleaning solutions

To clean your phone, use only a dry soft cloth. Don't use alcohol or other cleaning solutions.



the ground

Don't drop your phone.

Motorola Limited Warranty for the United States and Canada

What Does this Warranty Cover?

Subject to the exclusions contained below, Motorola, Inc. warrants its telephones, pagers, messaging devices, and consumer and professional two-way radios (excluding commercial, government or industrial radios) that operate via Family Radio Service or General Mobile Radio Service, Motorola-branded or certified accessories sold for use with these Products ("Accessories") and Motorola software contained on CD-ROMs or other tangible media and sold for use with these Products ("Software") to be free from defects in materials and workmanship under normal consumer usage for the period(s) outlined below. This limited warranty is a consumer's exclusive remedy, and applies as follows to new Motorola Products, Accessories, and Software purchased by consumers in the United States or Canada, which are accompanied by this written warranty:

Products and Accessories

Products Covered	Length of Coverage
Products and Accessories as defined above, unless otherwise provided for below.	One (1) year from the date of purchase by the first consumer purchaser of the product unless otherwise provided for below.

Products Covered	Length of Coverage
Decorative Accessories and Cases. Decorative covers, bezels, PhoneWrap™ covers and cases.	Limited lifetime warranty for the lifetime of ownership by the first consumer purchaser of the product.
Monaural Headsets. Ear buds and boom headsets that transmit mono sound through a wired connection.	Limited lifetime warranty for the lifetime of ownership by the first consumer purchaser of the product.
Consumer and Professional Two-Way Radio Accessories.	Ninety (90) days from the date of purchase by the first consumer purchaser of the product.
Products and Accessories that are Repaired or Replaced.	The balance of the original warranty or for ninety (90) days from the date returned to the consumer, whichever is longer.

Exclusions (Products and Accessories)

Normal Wear and Tear. Periodic maintenance, repair and replacement of parts due to normal wear and tear are excluded from coverage.

Batteries. Only batteries whose fully charged capacity falls below 80% of their rated capacity and batteries that leak are covered by this limited warranty.

Abuse & Misuse. Defects or damage that result from: (a) improper operation, storage, misuse or abuse, accident or neglect, such as physical damage (cracks, scratches, etc.) to the surface of the product resulting from misuse; (b) contact with liquid, water, rain, extreme humidity or heavy perspiration, sand, dirt or the like, extreme heat, or food; (c) use of the Products or Accessories for commercial purposes or subjecting the Product or Accessory to abnormal usage or conditions; or (d) other acts which are not the fault of Motorola, are excluded from coverage.

Use of Non-Motorola Products and Accessories. Defects or damage that result from the use of non-Motorola branded or certified Products, Accessories, Software or other peripheral equipment are excluded from coverage.

Unauthorized Service or Modification. Defects or damages resulting from service, testing, adjustment, installation, maintenance, alteration, or modification in any way by someone other than Motorola, or its authorized service centers, are excluded from coverage.

Altered Products. Products or Accessories with (a) serial numbers or date tags that have been removed, altered or obliterated; (b) broken seals or that show evidence of tampering; (c) mismatched board serial numbers; or (d) nonconforming or non-Motorola housings, or parts, are excluded from coverage.

Communication Services. Defects, damages, or the failure of Products, Accessories or Software due to any communication service or signal you may subscribe to or use with the Products Accessories or Software is excluded from coverage.

Software

Products Covered	Length of Coverage
Software. Applies only to physical defects in the media that embodies the copy of the software (e.g. CD-ROM, or floppy disk).	Ninety (90) days from the date of purchase.

Exclusions (Software)

Software Embodied in Physical Media. No warranty is made that the software will meet your requirements or will work in combination with any hardware or software applications provided by third parties, that the operation of the software products will be uninterrupted or error free, or that all defects in the software products will be corrected.

Software NOT Embodied in Physical Media. Software that is not embodied in physical media (e.g. software that is downloaded from the internet), is provided "as is" and without warranty.

Who is Covered?

This warranty extends only to the first consumer purchaser, and is not transferable.

What Will Motorola Do?

Motorola, at its option, will at no charge repair, replace or refund the purchase price of any Products, Accessories or Software that does not conform to this warranty. We may use functionally equivalent reconditioned/refurbished/pre-owned or new Products, Accessories or parts. No data, software or applications added to your Product, Accessory or Software, including but not limited to personal contacts, games and ringer tones, will be reinstalled. To avoid losing such data, software and applications please create a back up prior to requesting service.

How to Obtain Warranty Service or Other Information

USA	Phones: 1-800-331-6456 Pagers: 1-800-548-9954 Two-Way Radios and Messaging Devices: 1-800-353-2729
Canada	All Products: 1-800-461-4575
TTY	1-888-390-6456
For Accessories and Software , please call the telephone number designated above for the product with which they are used.	

You will receive instructions on how to ship the Products, Accessories or Software, at your expense, to a Motorola Authorized Repair Center. To obtain service, you must include: (a) a copy of your receipt, bill of sale or other comparable proof of purchase; (b) a written description of the problem; (c) the name of your service provider, if applicable; (d) the name and location of the installation facility (if applicable) and, most importantly; (e) your address and telephone number.

What Other Limitations are There?

ANY IMPLIED WARRANTIES, INCLUDING WITHOUT LIMITATION THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, SHALL BE LIMITED TO THE DURATION OF THIS LIMITED WARRANTY, OTHERWISE THE REPAIR, REPLACEMENT, OR REFUND AS PROVIDED UNDER THIS EXPRESS LIMITED WARRANTY IS THE EXCLUSIVE REMEDY OF THE CONSUMER, AND IS PROVIDED IN LIEU OF ALL OTHER WARRANTIES, EXPRESS OR IMPLIED. IN NO EVENT SHALL MOTOROLA BE LIABLE, WHETHER IN CONTRACT OR TORT (INCLUDING NEGLIGENCE) FOR DAMAGES IN EXCESS OF THE PURCHASE PRICE OF THE PRODUCT, ACCESSORY OR SOFTWARE, OR FOR ANY INDIRECT, INCIDENTAL, SPECIAL OR CONSEQUENTIAL DAMAGES OF ANY KIND, OR LOSS OF REVENUE OR PROFITS, LOSS OF BUSINESS, LOSS OF INFORMATION OR DATA, SOFTWARE OR APPLICATIONS OR OTHER FINANCIAL LOSS ARISING OUT OF OR IN CONNECTION WITH THE ABILITY OR INABILITY TO USE THE PRODUCTS, ACCESSORIES OR SOFTWARE TO THE FULL EXTENT THESE DAMAGES MAY BE DISCLAIMED BY LAW.

Some states and jurisdictions do not allow the limitation or exclusion of incidental or consequential damages, or limitation on the length of an implied warranty, so the above limitations or exclusions may not apply to you. This warranty gives you specific legal rights, and you may also have other rights that vary from state to state or from one jurisdiction to another.

Hearing Aid Compatibility with Mobile Phones

Some Motorola phones are measured for compatibility with hearing aids. If the box for your particular model has "Rated for Hearing Aids" printed on it, the following explanation applies.

When some mobile phones are used near some hearing devices (hearing aids and cochlear implants), users may detect a buzzing, humming, or whining noise. Some hearing devices are more immune than others to this interference noise, and phones also vary in the amount of interference they generate.

The wireless telephone industry has developed ratings for some of their mobile phones, to assist hearing device users in finding phones that may be compatible

with their hearing devices. Not all phones have been rated. Phones that are rated have the rating on their box or a label on the box.

The ratings are not guarantees. Results will vary depending on the user's hearing device and hearing loss. If your hearing device happens to be vulnerable to interference, you may not be able to use a rated phone successfully. Trying out the phone with your hearing device is the best way to evaluate it for your personal needs.

M-Ratings: Phones rated M3 or M4 meet FCC requirements and are likely to generate less interference to hearing devices than phones that are not labeled. M4 is the better/higher of the two ratings.

T-Ratings: Phones rated T3 or T4 meet FCC requirements and are likely to be more usable with a hearing device's telecoil ("T Switch" or "Telephone Switch") than unrated phones. T4 is the better/higher of the two ratings. (Note that not all hearing devices have telecoils in them.)

Hearing devices may also be measured for immunity to this type of interference. Your hearing device manufacturer or hearing health professional may help you find results for your hearing device. The more immune your hearing aid is, the less likely you are to experience interference noise from mobile phones.

Information from the World Health Organization

Present scientific information does not indicate the need for any special precautions for the use of mobile phones. If you are concerned, you may want to limit your own or your children's RF exposure by limiting the length of calls or by using handsfree devices to keep mobile phones away from your head and body.

Source: WHO Fact Sheet 193

Further information: <http://www.who.int/peh-emf>

Product Registration

Online Product Registration:

www.motorola.com/us/productregistration

Product registration is an important step toward enjoying your new Motorola product. Registering permits us to contact you for product or software updates and allows you to subscribe to updates on new products or special promotions. Registration is not required for warranty coverage.

Please retain your original dated sales receipt for your records. For warranty service of your Motorola Personal Communications Product you will need to provide a copy of your dated sales receipt to confirm warranty status.

Thank you for choosing a Motorola product.

Export Law Assurances

This product is controlled under the export regulations of the United States of America and Canada. The Governments of the United States of America and Canada may restrict the exportation or re-exportation of this product to certain destinations. For further information contact the U.S. Department of Commerce or the Canadian Department of Foreign Affairs and International Trade.

Caring for the Environment by Recycling

This symbol on a Motorola product means the product should not be disposed of with household waste.



Disposal of your Mobile Device & Accessories

Please do not dispose of mobile devices or electrical accessories (such as chargers, headsets, or batteries) with your household waste. Do not dispose of your battery or mobile device in a fire. These items should be disposed of in accordance with the national collection and recycling schemes operated by your local or regional authority. Alternatively, you may return unwanted mobile devices and electrical accessories to any Motorola Approved Service Center in your region. Details of Motorola approved national recycling schemes, and further information on Motorola recycling activities can be found at:



www.motorola.com/recycling

Disposal of your Mobile Device Packaging & User's Guide

Product packaging and user's guides should only be disposed of in accordance with national collection and recycling requirements. Please contact your regional authorities for more details.

California Perchlorate Label

Some mobile phones use an internal, permanent backup battery on the printed circuit board that may contain very small amounts of perchlorate. In such cases, California law requires the following label:

Perchlorate Material – special handling may apply. See www.dtsc.ca.gov/hazardouswaste/perchlorate

There is no special handling required by consumers.

Privacy & Data Security

Motorola understands that privacy and data security are important to everyone. Because some features of your mobile device may affect your privacy or data security, please follow these recommendations to enhance protection of your information:

- **Monitor access**—Keep your mobile device with you and do not leave it where others may have unmonitored access. Lock your device's keypad where this feature is available.
- **Keep software up to date**—If Motorola or a software/application vendor releases a patch or software fix for your mobile device that updates the device's security, install it as soon as possible.
- **Erase before recycling**—Delete personal information or data from your mobile device prior to disposing of it or turning it in for recycling. For instructions on how to delete all personal information from your device, see your product guide.

Note: For information on backing up your mobile device data before erasing it, go to www.motorola.com and navigate to the “downloads” section of the consumer Web page for “Motorola Backup” or “Motorola Phone Tools.”

- **Understanding AGPS**—To provide location information for emergency calls, certain Motorola mobile devices incorporate *Assisted Global Positioning System* (AGPS) technology. AGPS technology also can be used in non-emergency applications to track and monitor a user's location—for example, to provide driving directions. Users who prefer not to permit such tracking and monitoring should avoid using such applications.

If you have further questions regarding how the use of your mobile device may impact your privacy or data security, please contact Motorola at privacy@motorola.com, or contact your service provider.

Smart Practices While Driving

Drive Safe, Call Smart

Check the laws and regulations on the use of mobile devices and their accessories in the areas where you drive. Always obey them. The use of these devices may be prohibited or restricted in certain areas -- for example, handsfree use only. Go to www.motorola.com/callsmart (in English only) for more information.

Your mobile device lets you communicate by voice and data—almost anywhere, anytime, wherever wireless service is available and safe conditions allow. When driving a car, driving is your first responsibility. If you choose to use your mobile device while driving, remember the following tips:

- **Get to know your Motorola mobile device and its features such as speed dial and redial.** If available, these features help you to place your call without taking your attention off the road.
- **When available, use a handsfree device.** If possible, add an additional layer of convenience to your mobile device with one of the many Motorola Original handsfree accessories available today.
- **Position your mobile device within easy reach.** Be able to access your mobile device without removing your eyes from the road. If you receive an incoming call at an inconvenient time, if possible, let your voicemail answer it for you.



- **Let the person you are speaking with know you are driving; if necessary, suspend the call in heavy traffic or hazardous weather conditions.** Rain, sleet, snow, ice, and even heavy traffic can be hazardous.
- **Do not take notes or look up phone numbers while driving.** Jotting down a “to do” list or going through your address book takes attention away from your primary responsibility—driving safely.
- **Dial sensibly and assess the traffic; if possible, place calls when your car is not moving or before pulling into traffic.** If you must make a call while moving, dial only a few numbers, check the road and your mirrors, then continue.
- **Do not engage in stressful or emotional conversations that may be distracting.** Make people you are talking with aware you are driving and suspend conversations that can divert your attention away from the road.
- **Use your mobile device to call for help.** Dial 911 or other local emergency number in the case of fire, traffic accident, or medical emergencies (wherever wireless phone service is available).
- **Use your mobile device to help others in emergencies.** If you see an auto accident, crime in progress, or other serious emergency where lives are in danger, call 911 or other local emergency number (wherever wireless phone service is available), as you would want others to do for you.
- **Call roadside assistance or a special non-emergency wireless assistance number when necessary.** If you see a broken-down vehicle posing no serious hazard, a broken traffic signal, a minor traffic accident where no one appears injured, or a vehicle you know to be stolen, call roadside assistance or other special non-emergency wireless number (wherever wireless phone service is available).

Motorola, Inc.
Consumer Advocacy Office
600 N US Hwy 45
Libertyville, IL 60048

www.hellomoto.com

Note: Do not ship your phone to the above address. If you need to return your phone for repairs, replacement, or warranty service, please contact the Motorola Customer Support Center at:

1-800-331-6456 (United States)

1-888-390-6456 (TTY/TDD United States for hearing impaired)

1-800-461-4575 (Canada)

Certain mobile phone features are dependent on the capabilities and settings of your service provider's network. Additionally, certain features may not be activated by your service provider, and/or the provider's network settings may limit the feature's functionality. Always contact your service provider about feature availability and functionality. All features, functionality, and other product specifications, as well as the information contained in this user's guide, are based upon the latest available information and believed to be accurate at the time of printing. Motorola reserves the right to change or modify any information or specifications without notice or obligation.

MOTOROLA and the Stylized M Logo are registered in the US Patent & Trademark Office. The Bluetooth trademarks are owned by their proprietor and used by Motorola, Inc. under license. Microsoft, Windows, Windows Me, and Windows Vista are registered trademarks of Microsoft Corporation in the United States and other countries. All other product or service names are the property of their respective owners.

© 2009 Motorola, Inc. All rights reserved.

Caution: Changes or modifications made in the radio phone, not expressly approved by Motorola, will void the user's authority to operate the equipment.

Manual Number: _____

U.S. patent Re. 34,976

www.motorola.com

