

INSTRUCTION MANUAL

A representative version of the user's manual follows:

MOTOROLA MT870

LIFE.  POWERED.



# CONGRATULATIONS

## MOTOROLA MT870

Your MOTOROLA **MT870** phone is loaded with premium features to manage your daily communications for work or pleasure. Your very own multimedia center—all in a stylish, touchscreen phone.

- **Video calls:** Talk with friends and family—face to face.
- **Mobile video:** Record and watch videos in high-quality 720p HD. Download or stream videos to watch on your phone, or play them on your HDTV with DLNA sharing.
- **Photos:** Take and share great photos with a high performance 8MP camera.
- **Web:** Internet multimedia at the speed you want. Huge screen, full HTML and support for Adobe™ Flash™ Player. Search, browse, everything you want to do, all made easier.
- **Speed and multi-tasking:** Dual-core processor for fast speed and multi-tasking.


**Note:** Certain apps and features may not be available in all countries.

**Caution:** Before assembling, charging, or using your phone for the first time, please read the important legal and safety information packaged with your product.

## MORE

- **Support:** Phone updates, PC software, online help and more at [www.motorola.com/support](http://www.motorola.com/support).
- **Accessories:** Find accessories for your phone at [www.motorola.com/products](http://www.motorola.com/products).

# YOUR PHONE



When you turn your phone, the screen adjusts for you.



**Note:** Your phone might look a little different.

# CONTENTS

LET'S GO .....	3
TOUCHSCREEN & KEYS .....	5
HOME SCREEN .....	8
APP MENU .....	10
SOCIAL NETWORKING .....	11
CALLS .....	13
CONTACTS .....	17
MESSAGING .....	20
MEDIA SHARE .....	22
PHOTOS & VIDEOS .....	24
MUSIC .....	29
WEB .....	34
APPS FOR ALL .....	36
TIPS & TRICKS .....	37
TEXT ENTRY .....	39
PERSONALIZE .....	40
TOOLS .....	42
BLUETOOTH™ WIRELESS .....	44
WI-FI™ .....	46
USB, MEMORY CARD & FILE TRANSFER .....	48
MANAGEMENT .....	51
SECURITY .....	52
TROUBLESHOOTING .....	54
SAFETY, REGULATORY & LEGAL .....	55

# LET'S GO

*let's get you up and running*

## ASSEMBLE & CHARGE

1 Cover off.



2 SIM in.



3 microSD in.



4 Battery in.



5 Cover on.




6 Charge up.




**Caution:** Please read “**BATTERY USE & SAFETY**” on page 55.

**Tip:** To save battery life, see “**BATTERY TIPS**” on page 38.


## TURN IT ON & OFF

To turn on your phone, press Power  (on the top left).


To turn off your phone, press and hold Power , then touch **Power off** in the menu that opens.

**Note:** This phone supports data-intensive apps and services. It is strongly recommended that you purchase a data plan that meets your needs. Contact your service provider for details.

## UNLOCK


To unlock your phone, touch the unlock icon  and drag it to the right.

## SOUNDS OFF & ON

To turn phone sounds off, touch the sound icon  and drag it to the left.



## WI-FI™ CONNECT

You can use a Wi-Fi connection for even faster Internet access. Touch Menu  > **More** > **Settings** > **Wireless & networks** > **Wi-Fi settings**. Touch **Wi-Fi** to turn it on and search for nearby wireless networks. Touch a network to connect. There's more in “**WI-FI™**” on page 46.

## COOL CONTENT & MORE

Browse and download the coolest apps on the planet from the Internet. On top of that, you get a full HTML browser, so you can surf in style.


Download new apps from the “**WEB**” on page 34. Your phone comes with 8 GB of internal memory, and a microSD memory card already installed—you can load it up with photos, videos, and music from your computer using “**USB, MEMORY CARD & FILE TRANSFER**” on page 48.

## TOUCHSCREEN & KEYS

*a few essentials*

### TOUCHSCREEN ON/OFF


Your touchscreen is on when you need it and off when you don't.

- To make your touchscreen sleep or wake up, just press Power .
- When you hold the phone to your ear during calls, your touchscreen sleeps to prevent accidental touches.

### TOUCH TIPS

Here are some tips on how to navigate around your phone.


#### TOUCH


To choose an icon or option, *touch* it. Try it: In the home screen, touch  **Gallery**.




#### TOUCH & HOLD

To open special options, *touch and hold* an icon or other item.



Try it: In the home screen, touch , then touch

 **Contacts**. Touch and hold a contact to open options.






## DRAG

To scroll through a list or move slowly, *drag* across the touchscreen. Try it: In the home screen, touch , then touch  **Contacts**, then drag your contact list up or down.

**Tip:** Touch the small letters on the right to show a letter, then drag to move the list to a letter A - Z.




## FLICK

To scroll through a list or move quickly, *flick* across the touchscreen (drag quickly and release).

**Tip:** When you flick a long list, touch the screen to stop it from scrolling.

## PINCH-TO-ZOOM

Get a closer look at web pages, or photos. To zoom in, *touch* the screen with two fingers and then slide them apart. To zoom out, *drag* your fingers together.



### Zoom

To zoom in or out, pinch two fingers together or apart.

## PHONE COVERS



Your touchscreen might stay dark during calls if the sensor just above it is covered. Don't use covers or screen protectors (even clear ones) that cover this sensor.






Screen protectors can also interfere with touchscreen performance. To find Motorola accessories for your phone, visit [www.motorola.com/products](http://www.motorola.com/products).

## KEY TIPS

### MENU, HOME, BACK, & SEARCH



Touch Home  to close any app or menu and return to the home screen. Touch and hold Home  to show the recent apps you have used, then touch an app to open it.




Touch Menu  to open menu options, or Back  to go back.

Touch Search  to text search.


### SLEEP & WAKE UP

To save your battery, prevent accidental touches, or when you want to wipe smudges off your touchscreen, put the touchscreen to sleep by pressing Power . To wake up the touchscreen, just press Power  again.



To change how long your phone waits before the screen goes to sleep automatically, touch Menu  > **More** > **Settings** > **Display** > **Screen timeout**.

### POWER KEY MENU

Press and hold Power  to open the phone options menu, where you can turn off the phone (**Power off**), or turn **Silent**, **Sleep** and **Airplane mode** on or off. You can also, set your phone to **Ringer**, **Ringer and Vibration**, or **Vibration**.

### ADJUST VOLUME

Press the volume keys to change the ringer volume (in the home screen), or the earpiece volume (during a call).



### ROTATE THE SCREEN

The touchscreen can spin to stay right-side up when you rotate your phone:

**Find it:** Menu  > **More** > **Settings** > **Display** > **Auto-rotate screen**

# HOME SCREEN

quick access to the things you need most

## QUICK START: HOME SCREEN

The *home screen* gives you all your latest information in one place. It's what you see when you turn on the phone or touch Home (🏠) from a menu. It's basically like this:



Use the widgets, shortcuts, and panels to show what's important to you—whether it's home, work or play.

**Tip:** From the home screen, touch Menu (☰) > **Profiles** to design different home screens for **Work**, **Home**, or **Weekend**.

## USE & CHANGE YOUR HOME SCREEN

On your home screen, *shortcuts* are icons that open your favorite apps, web bookmarks, contacts, email, or music playlists. *Widgets* show you news, weather, messages, and other updates.


Flick the home screen left or right to see other *panels* of shortcuts and widgets.


- To **open** something, touch it. Touch Home (🏠) to return to the home screen.

**Tip:** When you open a widget, touch Menu (☰) to show any options or settings (you can choose accounts for **Messages**, **Social Networking**, or **Calendar** widgets).


There's more about social networking widgets in "**VIEW ACCOUNT UPDATES & FEATURES**" on page 12 and "**UPDATE YOUR STATUS**" on page 11.

- To **resize Motorola widgets**, touch and hold one until you feel a vibration, then release. Drag a corner to resize.





- To **add** something or change your **wallpaper**, touch and hold an empty spot until you see the **Add to Home screen** menu. (You can also touch Menu  > **Add** > **Motorola widgets**, **Android widgets**, **Shortcuts**, **Folders**, or **Wallpapers**).


You can add a folder to organize your shortcuts.

- To **move** or **delete** something, touch and hold it until you feel a vibration, then drag it to another spot, another panel, or the trash  at the top of the screen.



## RUNNING MULTIPLE APPS


No need to close an app before opening another one. Your phone runs multiple apps, all at once.

You can open a new app while running another. Touch Home  to return to the home screen, touch  to open the main menu, then touch the app you want. To switch from one running app to another, touch and

hold Home  to see what apps are already open, then touch the one you want.

## SEARCH


Touch Search  on the front of the phone, or touch  > **Search**.



### Text Search

Type, then touch .

Choose what to search.

To change search settings, touch Menu  > **Search settings**.

## PHONE STATUS & NOTIFICATIONS

At the top of the screen, icons on the left notify you about new messages or events (notifications). Icons