



MOTOROLA
SPICE™ XT

LIFE.  POWERED.

CONGRATULATIONS

MOTOROLA SPICE™ XT

Your MOTOROLA **SPiCE XT** phone delivers more for your work and play!

- **Search:** Touch Search  to search across your apps, contacts, web, and maps—or just enter the address for a place or a web page.
- **Apps:** Open  **Market** to download games for fun, social networking apps to keep in touch (like Facebook™ or Twitter), or find something else you like with “**APPS**” on page 10!
- **Touch Display:** Browse the web and pinch to zoom on the 8.9cm HVGA touch display in “**WEB**” on page 27.
- **Camera:** Capture photos and videos with the 5MP auto-focus camera with flash in “**PHOTOS & VIDEOS**” on page 30.

Note: Some apps and features might not be available in all countries.

Caution: Before assembling, charging, or using your phone for the first time, please read the important legal and safety information packaged with your product.

MORE

- **Support:** Phone updates, PC software, online help and more at www.motorola.com/support.
- **Accessories:** Find accessories for your phone at www.motorola.com/products.

YOUR PHONE

the important keys & connectors



Note: Your phone might look a little different.

CONTENTS

LET'S GO	5
HOME SCREEN & APPS	9
PERSONALIZE	13
CALLS	15
CONTACTS	17
MESSAGING	19
TEXT ENTRY	22
SCHEDULE	25
WEB	27
LOCATION	29
PHOTOS & VIDEOS	30
MUSIC	32
BLUETOOTH™, WI-FI, & CABLE CONNECTIONS	34
SECURITY	36
TROUBLESHOOTING	38
SAFETY, REGULATORY & LEGAL	39

LET'S GO

let's get you up and running

ASSEMBLE & CHARGE

1 Cover off



2 SIM in



3 microSD in (may already be inserted)



4 Battery in



5 Cover on



6 Charge up





Caution: Please read "**BATTERY USE & SAFETY**" on page 39.


SET UP & GO

Note: This phone supports data-intensive apps and services. It is strongly recommended that you purchase a data plan that meets your needs. Contact your service provider for details.


When you turn on your new phone, you can create or enter a Google™ account so that you can download apps, use Gmail™, and much more:

- 1 Press and hold Power  to turn on your phone.
- 2 Touch the Android™ image to begin setup.
- 3 Touch a button to **Create** a Google account, **Sign in** with one you have, or **Skip**.
- 4 Enter details to create or sign into your account. When your phone confirms the account, it shows account sync options.
 - To change whether your phone shows the Google account's contacts, Gmail™, and calendar, touch the Google account name.
 - To add another account, touch **Add account**. For details, see “**EMAIL**” on page 20.
 - To exit setup touch Home .



If your phone cannot connect, you can touch Menu  > **Wireless settings** to change mobile network settings.

POWER & SLEEP

Your screen sleeps when you hold it to your ear during a call, or when it is inactive. To change the sleep delay, touch Menu  > **Settings** > **Display** > **Screen timeout**.



Power/Sleep Key

Hold=power
Press=sleep or wake up

KEYS

Use your phone's keys to navigate and open options at any time.


Press the volume keys to change the ringer volume (in the home screen), or the earpiece volume (during a call).





Volume Keys

Camera Key

From any screen, press the camera key on the right side of the phone to open the camera.



Touch Home  to return to the home screen. Touch and hold Home  to see your recent apps.

HOME SCREEN & APPS


a few essentials


Use your home screen for quick access to apps, search, and more. Download social networking apps (like Facebook™ or Twitter) to keep in touch!


QUICK START: HOME SCREEN

You'll see the home screen when you turn on the phone or touch Home  from a menu:




- To open shortcuts or widgets, **touch** them. Touch Home  to return to the home screen.

When you open shortcuts or widgets, touch Menu  for options.


- To move or delete shortcuts or widgets, **touch and hold** them until you feel a vibration, then drag it to another spot, another panel, or  at the bottom.

In lists like **Contacts**, touch and hold list items for options.

- To add shortcuts, widgets, or wallpaper, touch and hold an empty spot until you see the menu. You can also add a folder to organize your shortcuts.

- To show more panels, **drag** or **flick** right or left. Touch and hold  to show panel thumbnails.





In lists like **Contacts**, drag or flick to scroll.


To change your ringtone, display brightness, and more, touch Menu  > **Settings** > **Sound** or **Display**. For details, see “**PERSONALIZE**” on page 13.





APPS

To show your **app menu**, touch .


- To scroll through the menu, flick up or down.
- To open an app, touch an icon.

- To group your apps, touch , then go to the top of the app menu and touch  **All apps** > **Add New Group**. Enter the group name and save it, then touch  to add apps to the group.
- To close the app menu, touch Back .

Tip: To show the last eight apps you opened, touch and hold Home .

To **download** new apps from Android Market™, touch  >  **Market**. Touch Search  to find an app, or touch **My Apps** to show or reinstall the apps you downloaded. To download apps from websites, you need to change your security settings: From the home screen, touch Menu  > **Settings** > **Applications** > **Unknown sources**.

Warning: Apps downloaded from the web can be from unknown sources. To protect your phone and personal data, only download apps from sources you trust.

To **move or uninstall** your apps, from the home screen touch Menu  > **Settings** > **Applications** > **Manage applications**. Touch an app in the list to show details and options.

On your computer, you can browse and manage apps for all your devices powered by Android™ at market.android.com.