



EN

MOTOROLA **XT555c**

LIFE.  POWERED.



CONTROLLED COPY

January 20, 2012

Confidential

MOTOROLA CONFIDENTIAL RESTRICTED

# CONGRATULATIONS

## MOTOROLA XT555C

Your MOTOROLA **XT555c** helps you seamlessly manage your “Office” and “Outdoor” lifestyles.

- **Lifeproof:** Your phone is water-resistant, dustproof, and has a scratch-resistant screen, because accidents happen.
- **Dashboard:** Easy access to all your favorite Outdoor apps, like **Camera**, **Compass**, and a pedometer, see “**DASHBOARD**” on page 6.
- **MotoSwitch:** MotoSwitch is a dynamic interface that gives you seamless access to content that is relevant to you. For details, see “**MOTOSWITCH**” on page 7.
- **Extended battery life:** So you have longer to use your phone outdoors, see “**BATTERY TIPS**” on page 29.

**Note:** Certain apps and features may not be available in all countries.

**Caution:** Before assembling, charging, or using your phone for the first time, please read the important safety, regulatory and legal information provided with your product.

**SAR** This product meets the applicable limit for exposure to radio waves (known as SAR) of 1.6 W/kg (FCC & IC). The limits and guidelines include a substantial safety margin designed to assure the safety of all persons, regardless of age and health. The highest SAR values measured for this device are listed in the regulatory information packaged with your product.

## WANT MORE?

More help, more accessories, more free stuff. We're here to help.

- **Updates:** Phone updates, PC software, user's guides, online help, and more at [www.motorola.com/support](http://www.motorola.com/support).
- **Accessories:** Find more for your phone at [www.motorola.com/products](http://www.motorola.com/products).
- **Social:** The latest news, tips & tricks, videos, and so much more—join us on:



**YouTube™** [www.youtube.com/motorola](http://www.youtube.com/motorola)



**Facebook™** [www.facebook.com/motorola](http://www.facebook.com/motorola)



**Twitter** [www.twitter.com/motomobile](http://www.twitter.com/motomobile)

# YOUR PHONE

*the important keys & connectors*

**3.5mm HSJ  
Headset Jack**

**Notification  
Light**

Flash=missed  
call, new  
message, or  
other  
notification.

**Front Camera**

**Micro USB**

**Microphone**

**Menu**  
Open options.

**Home**  
Touch=  
home screen  
Hold=  
recent apps

**Back**  
Go back one  
screen.

**Search**  
Touch=text

**Power/  
Sleep Key**  
Press=sleep  
Hold=power

**Volume Keys**

**Camera**

**Cover Lock**

January 20, 2012

**Note:** To help protect your phone, always make sure that the battery cover and any connector covers are closed and secure.

# CONTENTS

LET'S GO .....	3
HOME SCREEN & APPS .....	5
PERSONALIZE .....	9
CALLS .....	10
CONTACTS .....	13
MESSAGING .....	14
TEXT ENTRY .....	16
SCHEDULE .....	18
WEB .....	19
LOCATION .....	20
PHOTOS & VIDEOS .....	21
MUSIC .....	23
MEDIA .....	24
BLUETOOTH™, WI-FI, & CABLE CONNECTIONS .....	25
SECURITY .....	28
TIPS & TRICKS .....	29
TOOLS .....	30
TROUBLESHOOTING .....	32
SAFETY, REGULATORY & LEGAL .....	33

## LET'S GO

*let's get you up and running*

## ASSEMBLE & CHARGE

1 Cover off



2 microSD in



3 Battery in



4 Cover on



5 Charge up




**Caution:** Please read “**BATTERY USE & SAFETY**” on page 33.

## SET UP & GO

**Note:** This phone supports apps and services that use a lot of data, so make sure your data plan meets your needs. Contact your service provider for details.

When you turn on your new phone, you can create or enter a Google™ account so that you can download apps, use Gmail™, and much more:

1 Press and hold Power  to turn on your phone.

2 Touch the Android™ image to begin setup.


3 Touch a button to **Create** a Google account, **Sign in** with one you have, or **Skip**.

You can log into your account from a computer at [accounts.google.com](http://accounts.google.com).

4 When your phone confirms the account, it shows account sync options.

- To change whether your phone shows the Google account's contacts, Gmail™, and calendar, touch the Google account name.
- To add another account, touch **Add account**. For details, see “**EMAIL**” on page 15.
- To exit setup, touch Home .



If your phone cannot connect, touch Menu  > **WLAN settings** to change mobile network settings.

## RUGGED


Your phone is designed to be tough and durable, helping to protect it from life's extremes. So whether your life gets cold and wet, warm and humid, or dry and dusty, your phone can handle it.


Of course, your phone isn't indestructible, so remember:

- Always make sure that the battery and connector covers are closed and secure.
- Avoid prolonged or extreme exposure to rugged conditions.

And finally, the details. Your phone will resist damage from exposure to these rugged conditions: high/low temperatures, water, blowing rain, humidity, salt fog, dust, shock, vibration, and low pressure (high altitude).

## SLEEP & WAKE UP

Your screen sleeps when you hold it to your ear during a call, or when it is inactive. To change the sleep delay, touch Menu  > **Settings** > **Display** > **Screen timeout**.


To **unlock** the screen, drag  to the outer circle.


**Tip:** To access all your favorite apps from a lock screen, see “**MOTOSWITCH**” on page 7.

## KEYS

Use your phone's keys to navigate and open options at any time.

Press the volume keys to change the ringer volume (in the home screen), or the earpiece volume (during a call).

Touch Home  to return to the home screen.

Touch and hold Home  to see your recent apps.




Volume Keys



## HOME SCREEN & APPS

*a few essentials*

### QUICK START: HOME SCREEN

You'll see the home screen when you turn on the phone or touch Home  from a menu:



Status Indicators


Notifications  
Flick down for details.


Widgets  
Touch to open. Touch & hold to move or delete.


Drag or flick to open panels (or scroll in lists).

Shortcuts


Open the app menu.

- To open shortcuts or widgets, **touch** them. Touch Home  to return to the home screen.


When you open shortcuts or widgets, touch Menu  for options.


- To move or delete shortcuts or widgets, **touch and hold** them until you feel a vibration, then drag it to another spot, another panel, or  at the top.

In lists like **Contacts**, touch and hold list items for options.



- To add shortcuts, widgets, or wallpaper, touch and hold an empty spot until you see the menu. You can also add a folder to organize your shortcuts.
- To show more panels, **drag or flick** right or left. Touch Home  to show panel thumbnails.

In lists like **Contacts**, drag or flick to scroll.

To change your ringtone, display brightness, and more, touch Menu  > **Settings** > **Sound** or **Display**. For details, see “**PERSONALIZE**” on page 9.

**Tip:** From the home screen, touch Menu  > **Themes** to design different home screens for **Work**, **Home**, or **Weekend**. Your changes are stored in each profile.

## DASHBOARD

You can access the outdoor apps on your phone, with the dashboard, just touch  >  **DashBoard**.




Drag or flick to see other apps.

Start/Stop/Save pedometer record.

To change app that is shown.

Shortcuts

Your dashboard shows apps, like **Camera**, **Compass**, and **FM Radio**. You can also see a pedometer that reports your runtime, steps, and calories burned—it's the ideal fitness companion.

**Note:** To set the pedometer, touch Menu  > **Settings** > **Height and Weight**, then enter your details.

To view or share your records, touch Menu  > **My Record** or **Share**.



## MOTOSWITCH

Jump right to your favorite apps from the lock screen!

To set up your lock screen apps:



Your favorites.

Touch & hold between the two rings to show your most used apps at the bottom.

Drag to scroll.

Most used apps. Drag an app to the outer ring to add it to your favorites.


To **go to a favorite app** from the lock screen, drag the app towards the lock icon .


**Note:** For toggle apps, such as **Bluetooth** or **Flight Mode**, the screen will remain locked.





## APPS


To show your **app menu**, touch .

- To scroll, flick up or down.


- To open an app, touch it.
- To close the app menu, touch Back .

**Tip:** To show the last eight apps you opened, touch and hold Home .

To **download** new apps from Android Market™, touch  >  **Market**. Touch Search  to find an app, or touch **Downloads** to show or reinstall the apps you downloaded. To download apps from websites, you need to change your security settings: Touch Menu  > **Settings** > **Applications** > **Unknown sources**.

**Tip:** Choose your apps and updates carefully, from trusted sites like  **Market**, as some may impact your phone's performance—see "**CHOOSE CAREFULLY**" on page 8.


**Note:** When installing an app, make sure you read the alerts that tell you what information the app will access. If you don't want the app to have access to this information, cancel the installation.

To **move or uninstall** your apps, touch Menu  > **Settings** > **Applications** > **Manage applications**. Touch an app in the list to show details and options.


On your computer, you can browse and manage apps for all your devices powered by Android™ at [market.android.com](http://market.android.com).

## CHOOSE CAREFULLY


Apps are great. There's something for everyone. Play, communicate, work, or have fun. But remember, choose your apps carefully. Here are a few tips:

- To help prevent spyware, phishing, or viruses from affecting your phone or privacy, use apps from trusted sites, like  **Market**.
- In **Market**, check the apps' ratings and comments before installing.
- If you doubt the safety of an app, don't install it.
- Like all apps, downloaded apps will use up memory, data, battery, and processing power—some more than others. For example, a simple battery level widget will use less than a streaming music player app. After installing an app, if you're not happy with how much memory, data, battery or processing power it's using, uninstall it. You can always install it again later.
- Just like web browsing, you may want to monitor childrens' access to apps to help prevent exposure to inappropriate content.
- Certain apps may not provide completely accurate information. Take care, especially when it comes to personal health.

## MANAGE & RESTORE APPS


To manage your apps, from the home screen touch Menu  > **Settings** > **Applications** > **Manage apps**.











Touch the app to open the details screen—from here you can review, uninstall, and more.

To reinstall any downloaded items, from the home screen touch  > **Market** > **My apps**. All previously installed apps are listed and available for download.

## PHONE STATUS & NOTIFICATIONS

In the status bar at the top of your screen, the right side shows phone status. The left side shows new messages or events (for details, flick the bar down).




	network strength		battery strength
	new voicemail		new text message
	Bluetooth™ on		Bluetooth connected
	Wi-Fi connected		airplane mode
	USB connected		alarm set
	silent ringer		silent ringer, vibrate on
	mute call		speakerphone

# PERSONALIZE

add your personal touch


## QUICK START: PERSONALIZE

From the home screen, touch Menu  > **Settings** > **Sound** or **Display**.



Choose separate volume settings for incoming calls, media, alarms, and notifications.

### Call & Message Notifications




Turn on or off menu animations.

All window animations are shown

Adjust the delay before the screen automatically turns off

To...

Choose a **ringtone** or **vibration** for calls and messages

Touch Menu  > **Settings** > **Sound**, then choose **Phone ringtone**, **Notification ringtone**, or **Vibrate**.

Change the **volume**

Touch Menu  > **Settings** > **Sound** > **Volume**.

Turn **dialpad** sounds on or off

Touch Menu  > **Settings** > **Sound** > **Audible touch tones**.

Turn menu **selection** sounds on or off

Touch Menu  > **Settings** > **Sound** > **Audible selection**.

Change your **wallpaper**

Touch and hold an empty spot on the home screen, then touch **Wallpapers**.

Change **shortcuts** and **widgets** on your home screen

Touch and hold them. For details, see "**HOME SCREEN & APPS**" on page 5.

Set display **brightness**

Touch Menu  > **Settings** > **Display** > **Brightness**.

To...


Control whether some apps **rotate** the screen when you rotate your phone

Touch Menu  > **Settings** > **Display** > **Auto-rotate screen**.

Set **animations** that make your menus look smoother

Touch Menu  > **Settings** > **Display** > **Animation**.

Calibrate the **sensors** used by some games or navigation apps

Touch Menu  > **Settings** > **Display** > **G-Sensor Calibration** (movement) or **E-Compass Calibration** (direction).


## LANGUAGE & REGION

To set your menu language and region, touch Menu  > **Settings** > **Language & keyboard** > **Select language**.

## CALLS

*it's good to talk*

## QUICK START: CALLS

From the home screen, touch .




Call.

Hang up.



Start a conference call.

Open a list, then touch an entry to call.





Shows matching numbers, flick down to see more.






- To **make** a call, touch , enter a number, then touch .

When dialing, touch Menu  to add a pause (pauses two seconds), or wait (waits for your confirmation). To enter the international dialing code, touch and hold .

**Note:** Using a mobile device or accessory while driving may cause distraction and may be illegal. Always obey the laws and drive safely.


- To **answer** a call, drag  to the right.
- **During** a call, touch **Recorder** to record the call. Touch Home  or Back  to hide the active call display (to reopen it, touch , then touch the call in the list).


**Note:** Recording of calls is subject to varying State and Federal laws regarding privacy and recording of conversations. Always obey the laws and regulations on the use of this feature.

- To use the **speakerphone** during a call, touch **Speaker**.
- To **enter numbers** during a call, touch **Dialing Pad**.
- To **mute** or **unmute** a call, touch **Mute**.
- To put a call on **hold**, touch Menu  > **Hold**.
- To **end** a call, touch .
- To **ignore** an incoming call, drag  to the left.

**Tip:** For quick access to contacts, see “**FAVORITES**” on page 13.

## RECENT CALLS

To show recent calls, touch  > **Call log**.


- To call, text, open, or save an entry, touch and hold it.
- To clear the list, touch Menu  > **Clear call log**.

## CONFERENCE CALLS

To start a conference call, call the first number. After they answer, touch **Add call** and call the next number. When the next number answers, touch **Merge calls**. To remove individual callers, touch **Manage**.


## CALL WAITING

If you are on a call and a new call arrives:


- With call waiting on, you can drag  to the right to answer the new call and put the old call on hold. Then, touch **Swap** to switch between calls, or **Merge calls** to combine them.
- With call waiting off, the new caller gets the busy tone.

To turn on call waiting, touch Menu  > **Settings** > **Call settings** > **Additional settings** > **Call waiting**.

## CALL FORWARDING


To forward calls, touch Menu  > **Settings** > **Call settings** > **Call forwarding**. You can forward calls all the time, or only when your phone is busy, unanswered, or unreachable (not on the network)

## RESTRICTED CALLS

To restrict your phone so that it can only dial a few numbers, touch Menu  > **Settings** > **Call settings** > **Fixed Dialing Numbers**.

- To turn fixed dialing on, touch **Enable FDN**.
- To add or delete the allowed numbers, touch **FDN list**.

## YOUR PHONE NUMBER

To show your phone number, touch Menu  > **Settings** > **About phone** > **Status** > **My phone number**.

## YOUR CALLER ID

To hide your number from the people you call, touch Menu  > **Settings** > **Call settings** > **Call feature settings** > **Additional settings** > **Caller ID**.


## COOL DOWN

In very limited circumstances, such as where your phone has been exposed to extreme heat, you may see

“Cool Down” messages. To avoid possible damage to your battery and phone, you should follow these instructions until the phone is within its recommended temperature range. When your phone is in “Cool Down” mode, only emergency calls can be made.

## EMERGENCY CALLS

**Note:** Your service provider programs one or more emergency phone numbers that you can call under any circumstances, even when your phone is locked. Emergency numbers vary by country. Your pre-programmed emergency number(s) may not work in all locations, and sometimes an emergency call cannot be placed due to network, environmental, or interference issues.

- 1 Touch  (if your phone is locked, then touch **Emergency Call**).
- 2 Enter the emergency number.
- 3 Touch **Call** to call the emergency number.


**Note:** Your phone can use location based services (GPS and AGPS) to help emergency services find you. See “Location Services” in your legal and safety information.

# CONTACTS

contacts like you've never had before


## QUICK START: CONTACTS




From the home screen, touch  **Contacts**.





Switch to the dialer, recent calls, favorites or groups.

Drag or flick to scroll.

Touch  to search, create, and more.


- To **create** a contact, touch  **Contacts** > Menu  > **New contact**, choose where you want to store the contact, then enter details (to close the keyboard, touch Back ).

**Contacts** shows the contacts from your Google™ account, which you can open from any computer at [contacts.google.com](http://contacts.google.com) (or open your contacts within

[mail.google.com](http://mail.google.com)). To stop synchronizing with your account, touch  **Contacts** > Menu  > **Accounts**, touch your Google account, then uncheck **Sync Contacts**.

- To **call**, **text**, or **email** a contact, touch  **Contacts**, touch the contact, then touch  (call),  (text), or  (email).
- To **edit** or **delete** a contact, touch  **Contacts**, touch the contact, then touch Menu .

## FAVORITES

For quick access to a favorite contact, open the contact, then touch the star next to their name. To show your favorites, touch  and touch **Favorites** at the top.

To add a shortcut to your favorites, touch and hold a blank spot on your home screen, then touch **Folders** > **Starred contacts**. You can also add a shortcut for an individual contact: Touch and hold a blank spot on your home screen, then choose **Shortcuts** > **Contact**.

## STORAGE & TRANSFER

When you create a new contact, your phone asks if you want to store it in your Google™ account, phone memory, or SIM card. Contacts in all three places appear in your **Contacts** list, but if you change phones: