

# MOTOROLA **PHOTON™ Q** 4G LTE

## User Guide

**Sprint**



06/06/2012  
FCC

©2012 Sprint. Sprint and the logo are trademarks of Sprint. Other marks are trademarks of their respective owners.

# Table of Contents

---

Get Started .....	1
Your Phone at a Glance .....	1
Set Up Your Phone.....	1
Activate Your Phone.....	2
Complete the Setup Application.....	3
Set Up Voicemail.....	3
Setting Up Visual Voicemail .....	3
Setting Up Traditional Voicemail .....	4
Sprint Account Information and Help .....	4
Sprint Account Passwords .....	4
Manage Your Account.....	5
Sprint Support Services .....	6
Phone Basics .....	7
Your Phone's Layout .....	7
Key Functions .....	8
Turn Your Phone On and Off .....	9
Turn Your Screen On and Off.....	9
Touchscreen Navigation.....	10
Touch Gestures .....	10
Your Home Screen.....	10
Customize the Home Screen .....	11
App Menu.....	11
Recent Apps .....	12
Search.....	12
Status Bar .....	12
Enter Text.....	13
QWERTY Keyboard.....	14
Touchscreen Keyboard.....	14
Tips for Editing Text.....	15
Auto-Correction.....	15

Text Input Settings .....	15
Phone .....	16
Make Phone Calls .....	16
Call Using the Phone Dialer .....	16
Call from Recent .....	16
Call from Contacts .....	17
Call from Favorites .....	17
Call a Number in a Text Message .....	17
Call Emergency Numbers .....	17
Receive Phone Calls .....	18
Answer an Incoming Call .....	18
Mute the Ringing Sound .....	18
Reject an Incoming Call .....	18
Phone Call Options.....	18
Making a Conference Call .....	19
Phone Settings.....	20
Wireless & Network Settings .....	20
Airplane Mode.....	20
Wi-Fi Settings .....	21
Bluetooth® Settings .....	21
Tethering & Mobile Hotspot Settings .....	21
VPN Settings .....	21
Mobile Network Settings .....	21
Call Settings .....	21
Voicemail Settings .....	22
Other Call Settings.....	22
Sound Settings.....	23
General Sound Settings .....	23
Incoming Call Sound Settings .....	24
Notifications .....	24
Sound Feedback Settings .....	24
Display Settings.....	25
Brightness.....	25

Auto-Rotate Screen .....	25
Screen Timeout.....	25
Wallpaper Settings.....	25
Battery Settings.....	25
Battery Remaining .....	25
Battery Capacity.....	26
Charging the Battery .....	26
Battery Cool Down.....	26
Battery mode .....	26
Location Settings.....	27
My Location .....	27
Security Settings .....	27
Set Up Screen Lock.....	27
Data Encryption .....	29
Passwords .....	29
Device Administration .....	29
Credential Storage.....	29
Certificates.....	29
Account Settings .....	30
Set Up a New Account.....	30
Manage Existing Accounts.....	30
Applications Settings.....	30
Unknown Sources.....	30
Manage Applications.....	30
Running Services.....	31
Privacy Settings.....	31
Backup and Restore .....	31
Resetting Your Phone.....	31
Storage Settings.....	31
Internal Storage.....	31
SD Card.....	32
Language & Keyboard Settings .....	32
Language Settings.....	32

Keyboard Settings.....	32
Voice Input & Output Settings.....	34
Voice Input.....	34
Voice Output.....	34
Accessibility Settings.....	34
Date & Time Settings.....	34
Changing the Date & Time.....	34
About Phone.....	35
System Updates.....	35
Status.....	35
Legal Information.....	35
Contacts.....	36
Get Started with Contacts.....	36
Access Contacts.....	36
Add a Contact.....	37
Save a Phone Number.....	37
Edit a Contact.....	38
Sync or Transfer Contacts.....	38
Transfer Contacts Using a microSD Card.....	39
Share Contacts.....	39
Call or Text Contacts.....	39
Make Groups.....	40
Calendar & Tools.....	41
Calendar.....	41
Add Calendar Events.....	41
Manage Calendar Events.....	41
File Manager.....	42
Alarm Clock and Timer.....	42
Alarm Clock.....	42
Timer.....	42
Help Center.....	43
Calculator.....	43
Tasks.....	43

Quickoffice .....	43
Quick Office Programs .....	43
Create a New File .....	44
Open a Document .....	44
Browse Files .....	44
Tips .....	44
Update Your Phone Software .....	44
Voice Commands .....	45
Voice Actions .....	45
Voice Commands .....	45
Bluetooth® Connections .....	45
Turn Bluetooth On or Off .....	46
Connect New Devices .....	46
Reconnect Devices .....	47
Disconnect Devices .....	47
Edit the Device Name .....	47
MOTOPRINT .....	47
Print a Document or File .....	47
Add a Printer .....	47
Smart Actions .....	47
microSD Card .....	48
Optional microSD Card .....	48
Insert the microSD Card .....	48
microSD Card Settings .....	49
View Memory in the microSD Card .....	49
Format the microSD Card .....	49
microSD Card .....	49
Connect Your Phone to Your Computer .....	49
Camera .....	51
Take Photos .....	51
Photo Options .....	51
Record Videos .....	52
Video Options .....	52

View Photos & Videos .....	53
Change Gallery Settings .....	53
Share Photos and Videos .....	54
Manage Photos and Videos .....	54
Edit Photos and Videos .....	54
<b>Sprint Basics</b> .....	55
Voicemail.....	55
Visual Voicemail.....	55
Traditional Voicemail.....	58
Accounts .....	58
Setting Up Accounts .....	58
Gmail™ and Google™ .....	59
Text Messages and MMS .....	62
Roaming.....	65
Roaming Icon.....	65
Setting Roam Mode .....	65
Call Guard.....	65
Data Roam Guard.....	65
Apps and Entertainment.....	67
Google Play Store™ .....	67
Find and Install Apps .....	67
Create a Google Checkout™ Account .....	68
Request a Refund for a Paid App.....	68
Manage or Remove Apps .....	68
Download Apps from the Web .....	68
Manage Your Downloads.....	69
Navigation .....	69
Google Maps™ .....	69
Google Latitude™ .....	70
Google Play Music.....	71
Get Music.....	72
Tips and Tricks.....	73
Web and Data.....	74

Wi-Fi.....	74
Turn Wi-Fi On or Off.....	74
Wi-Fi Search and Connect.....	74
Wi-Fi Modes.....	75
Wi-Fi Hotspot.....	75
Setting up the Hotspot.....	75
Activating the Hotspot.....	76
Browser.....	76
Your Browser.....	76
Connect.....	76
Select Links.....	76
See Options.....	76
Go to a Specific Website.....	77
Adjust Browser Settings.....	77
YouTube™.....	78
Sprint Worldwide Wireless Service.....	79
Getting started with Sprint Worldwide Service.....	79
Activating Global Roaming Mode.....	79
Making and Receiving Worldwide Calls.....	80
Making Calls Using Plus (+) Code Dialing.....	80
Sprint Voicemail Service.....	80
Setting Up Your Voicemail Access Number.....	80
Accessing Your Voicemail.....	81
International Data Roaming.....	81
Getting Started with Data Services.....	82
Accessing Your Email and Data Services on GSM/UMTS Networks.....	82
Accessing Your Email and Data Services on CDMA Networks.....	82
Understanding Status Messages.....	82
Contacting Sprint.....	84
Please call the numbers below if you need assistance:.....	84
Important Safety Information.....	86
General Precautions.....	87
Maintaining Safe Use of and Access to Your Phone.....	87



Battery Use & Safety .....	88
DON'Ts.....	88
DOs .....	88
Battery Charging .....	89
Third Party Accessories.....	90
Driving Precautions .....	90
Seizures/Blackouts.....	91
Caution About High Volume Usage .....	91
Repetitive Motion.....	91
Children.....	91
Glass Parts.....	92
Operational Warnings.....	92
Potentially Explosive Areas.....	92
Symbol Key.....	92
Radio Frequency (RF) Energy.....	93
Exposure to RF Energy.....	93
RF Energy Operational Precautions.....	93
RF Energy Interference/Compatibility.....	94
Regulatory Information .....	94
Specific Absorption Rate (FCC & IC).....	94
European Union Directives Conformance Statement.....	95
FCC Notice to Users.....	96
Industry Canada Notice to Users.....	96
Software Notices .....	97
Location Services .....	97
Your Location.....	97
Emergency Calls.....	98
Navigation .....	98
Privacy & Data Security.....	98
Use & Care.....	99
Recycling.....	100
Mobile Devices & Accessories .....	100
Packaging & Product Guides .....	100

California Perchlorate Label .....	100
Hearing Aid Compatibility with Mobile Phones .....	101
Software Copyright Notice .....	101
Content Copyright .....	102
Open Source Software Information .....	102
Export Law Assurances .....	102
Product Registration .....	103
Service & Repairs .....	103
How to Obtain Service or Other Information .....	103
Owner's Record .....	104
Copyright & Trademarks .....	104
Manufacturer's Warranty .....	106
Manufacturer's Warranty .....	106
Motorola Mobility Inc. Limited Global Warranty Mobile Phones .....	106
<a href="#">Index</a> .....	112

06/06/2012  
FCC

# Get Started

---

This section gives you all the information you need to set up your phone and Sprint service the first time.

[Your Phone at a Glance](#)

[Set Up Your Phone](#)

[Activate Your Phone](#)

[Complete the Setup Application](#)

[Set Up Voicemail](#)

[Sprint Account Information and Help](#)

## Your Phone at a Glance



## Set Up Your Phone

You must first install and charge the battery to begin setting up your phone.

1. Charge your battery for at least three hours.



2. Press and hold the **Power/Lock** button on top of your phone to turn it on.



- If your phone is activated, it will turn on, and show some setup instructions.
- If your phone is not yet activated, see [Activate Your Phone](#) for more information.

**Note:** Please read the battery use and safety text in the important legal and safety information packaged with your phone.

**Note:** Your battery is designed to last the life of the product. It should only be removed by a recycling facility. Any attempt to remove or replace your battery may damage the product and void your warranty.

## *Activate Your Phone*

Depending on your account or how and where you purchased your phone, it may be ready to use or you may need to activate it for your Sprint account.

- If you purchased your phone at a Sprint Store, it is probably activated and ready to use.
- If you received your phone in the mail and it is for a new Sprint account or a new line of service, **it is designed to activate automatically. To confirm your activation, make a phone call.**
- If you received your phone in the mail and you are activating a new phone for an existing number on your account, **you will need to go online to activate your new phone.**
  - From your computer's Web browser, go to [sprint.com/activate](http://sprint.com/activate) and complete the onscreen instructions to activate your phone.

When you have finished, make a phone call to confirm your activation. If your phone is still not activated or you do not have access to the Internet, contact Sprint Customer Service at **1-888-211-4727** for assistance.

**Tip:** Do not press the **Power/Lock** button while the phone is being activated. Pressing it cancels the activation process.

**Note:** If you are having any difficulty with activation, contact Sprint Customer Service by calling **1-888-211-4727** from any other phone.

## Complete the Setup Application

After activation and any required updates, your phone should power off and then back on again. After the restart, you'll see a Welcome screen. You can then complete the Setup steps.

1. Touch the Android™ icon to begin the setup application. Follow the prompts to set up your phone and accounts.

- **View a tutorial:** Touch **Begin** to see a brief tutorial about getting started.
- **Set up your Google™ Account:** Create or sign in to your Google account.
- **Use Google Location Service™:** Touch the check marks to select options.
- **Backup and restore:** Choose whether or not to back up data with your Google™ account.

**Note:** You do not need to sign up for a Google™ account to make a phone call. However, to download applications from the Google Play Store™, you must link your phone to a Google account.

2. Touch **Finish setup**.



**Note:** To skip account setup and go directly to the home screen, touch **Skip** from the Welcome page. You can set up accounts in the Accounts settings menu.

## Set Up Voicemail

### Setting Up Visual Voicemail

Your phone automatically transfers all unanswered calls to your voicemail, even if your phone is in use or turned off. You should set up your Sprint Voicemail and personal greeting as soon as your phone is activated.





To setup your Visual Voicemail:

1. Touch **Apps**  >  **Voicemail**.
2. Touch Personalize now and follow the system prompts to:
  - Create a password (part of standard voicemail).
  - Record your name announcement.
  - Record your greeting.

3. When prompted to enter information, touch **Dialpad** to bring up the onscreen dialpad to enter your numeric responses.
4. Once you have completed the setup process return to the voicemail page (see step 1).
5. Touch the Welcome to Voicemail message on the screen to play a brief explanation of the voicemail services.

## *Setting Up Traditional Voicemail*

To set up your voicemail:

1. Touch  **Phone** to open the dial screen, and then touch and hold  (the number 1 on the dial pad - voicemail) or touch **Apps**  >  **Voicemail**.
2. Follow the system prompts to:
  - Create your password.
  - Record your name announcement.
  - Record your greeting.

**Note: Voicemail Password** – Sprint strongly recommends that you create a password when setting up your voicemail to protect against unauthorized access. Without a password, anyone who has access to your phone is able to access your voicemail messages.

For more information about using your voicemail, see [Voicemail](#).

## *Sprint Account Information and Help*

[Sprint Account Passwords](#)

[Manage Your Account](#)

[Sprint Support Services](#)

### *Sprint Account Passwords*

As a Sprint customer, you enjoy unlimited access to your personal account information, your voicemail account, and your data services account. To ensure that no one else has access to your information, you will need to create passwords to protect your privacy.

#### *Account User Name and Password*

If you are the account owner, you will create an account user name and password when you sign on to [sprint.com](#). (Click **Sign in** and then click **Sign up now!** to get started.) If you are not the account owner (if someone else receives the bill for your Sprint service) you can get a sub-account password at [sprint.com](#).

## *Voicemail Password*

You'll create your voicemail password when you set up your voicemail. See [Set Up Voicemail](#) for more information on your voicemail password.

## *Data Services Password*

With your Sprint phone, you may elect to set up an optional data services password to control access and authorize Premium Service purchases.

For more information, or to change your passwords, sign on to [sprint.com](http://sprint.com) or call Sprint Customer Service at **1-888-211-4727**.













## *Manage Your Account*

Manage your Sprint account from your computer, your Sprint phone, or any other phone.

**Online:** [sprint.com](http://sprint.com)

- Access your account information.
- Check your minutes used (depending on your Sprint service plan).
- View and pay your bill.
- Enroll in Sprint online billing and automatic payment.
- Purchase accessories.
- Shop for the latest Sprint phones.
- View available Sprint service plans and options.
- Learn more about data services and other products like Sprint Picture Mail, games, ringtones, screen savers, and more.

### **From Your Sprint Phone**

- Touch  \*  4   to check minute usage and account balance.
- Touch  \*  3   to make a payment.
- Touch  \*  2   to launch SprintZone, with access to account information, phone details, tips and tricks, and more. To contact Sprint Customer Service, touch **Call Sprint**.

### **From Any Other Phone**

- Sprint Customer Service: **1-888-211-4727**.

- Business Customer Service: **1-888-788-4727**.

## ***Sprint Support Services***

### ***Sprint 411***

Sprint 411 gives you access to a variety of services and information, including residential, business, and government listings; movie listings or showtimes; driving directions, restaurant reservations, and major local event information. You can get up to three pieces of information per call, and the operator can automatically connect your call at no additional charge.

There is a per-call charge to use Sprint 411, and you will be billed for airtime.

- ▶ Touch 

### ***Sprint Operator Services***

Sprint Operator Services provides assistance when you place collect calls or when you place calls billed to a local telephone calling card or third party.

- ▶ Touch 

For more information or to see the latest in products and services, visit us online at [sprint.com](http://sprint.com).

06/06/2012  
FCC



# Phone Basics

---

Your Phone's Layout

Turn Your Phone On and Off

Turn Your Screen On and Off

Touchscreen Navigation


Your Home Screen

Status Bar

Enter Text

Tip: **Phone Software Upgrades** – Updates to your phone's software may become available from time to time. Sprint will automatically upload critical updates to your phone. You can also use the menu to check for and download updates. Touch **Apps** (⋮) > **Settings** (⚙️) > **About phone** > **System updates** > **Update Motorola Software** to search for and download available updates.

## Your Phone's Layout





Note: From the home screen, press the voice key to start a voice search. If you're composing a message, press the voice key to begin dictation.

### Key Functions

- **Speaker Button** lets you use the speakerphone.
- **Message Light** allows you to see when you have a new message or see your phone's charging status at a glance.
- **Volume Buttons** adjust the ringer volume or adjust the voice volume during a call.
- **Micro USB Connector** connects the phone charger or an optional USB cable (included).
- **Microphone** allows other callers to hear you clearly when you are speaking to them.
- **Voice Key** lets you use the hands-free speaker or voice recognition feature when entering text.
- **Camera Button** opens your camera to take photos or videos.
- **Touchscreen** lets you display all the information needed to operate your phone, such as the call status, the Contacts list, the date and time, and the signal and battery strength.
- **Power/Screen Lock Button:** turn the phone on or off or put the display to sleep.
- **3.5 mm Headset Jack** allows you plug in either a stereo headset (included) or an optional headset for convenient, hands-free conversations.

**CAUTION!** Inserting an accessory into the incorrect jack may damage the phone.

## Turn Your Phone On and Off

### Turn Your Phone On

- ▶ Press and hold the **Power/Lock** button.

Once your phone is on, it may display “**Searching for Service.**” When your phone finds a signal, it enters standby mode—the phone’s idle state. At this point, you are ready to begin making and receiving calls.

If your phone is unable to find a signal after 15 minutes of searching, a Power Save feature is automatically activated. When a signal is found, your phone automatically returns to standby mode.

**Tip:** The Power Save feature conserves your battery power when you are in an area where there is no signal.

### Turn Your Phone Off

- ▶ Press and hold the **Power/Lock** button to open the phone options menu. Touch **Power off** to turn the phone off.

Your screen remains blank while your phone is off (unless the battery is charging).


## Turn Your Screen On and Off

### Turn the Screen Off When Not in Use

- ▶ To quickly turn the screen off, press the **Power/Lock** button. Pressing it again or receiving an incoming call will turn on your phone screen and show the lock screen.

To save battery power, the phone automatically turns off the screen after a certain period of time when you leave it idle. You will still be able to receive messages and calls while the phone’s screen is off.

### Turn the Screen On and Unlock It

1. To turn the screen on, press the **Power/Lock** button.
2. Drag the lock  to the right to unlock the screen.
  - If you have set up a screen lock, you will be prompted to draw the pattern or enter the password or PIN. See [Set Up Screen Lock](#).

# Touchscreen Navigation

## Touch Gestures

- **Touch:** Choose an icon or option.
- **Touch and Hold:** Select an item and open an action bar.
- **Drag:** Move items in the home screen, or scroll slowly through lists.
- **Flick:** Scroll quickly between views or through lists.

**Tip:** When you flick a long list, touch the screen to stop it from scrolling.

- 
- **Pinch or double-touch:** Zoom in and out on websites, photos, and maps.

## Phone Covers

Your touchscreen might stay dark during calls if the sensor just above it is covered. Don't use covers or screen protectors (even clear ones) that cover this sensor.

Screen protectors can also interfere with touchscreen performance.

## Your Home Screen

The home screen is the starting point for your phone's applications, functions, and menus. You can customize your home screen by adding application icons, shortcuts, folders, widgets, and more. Your home screen can extend beyond the initial screen. Swipe the screen left or right to display additional screens.

SCREEN NOT YET AVAILABLE

**Note:** Your home screen might look a little different.


## Customize the Home Screen

### Add Pages to the Home Screen


To create more home screen pages for additional shortcuts and widgets, flick right in the home screen until you see the Add a page screen, and then select Blank page or Start with a template.

To rearrange or remove home screen pages, touch Manage pages at the bottom of the Add a page screen.

### Add Items to the Home Screen

- **Widget:** Touch **Apps** , touch **Widgets** at the top, and then touch and hold a widget (or flick left to see more widgets).

To resize a widget, touch and hold a side until feel a vibration, and then drag.

- **Shortcut:** Touch **Apps** , touch and hold an app and then drag it to a spot on the home screen page.

To create a shortcut folder, drag one shortcut onto another to put them both in a folder. To add other shortcuts, drag them onto the folder icon. To name the folder, touch it and enter a name at the bottom.

- **Wallpaper:** Touch and hold a blank spot on the home screen. Select a wallpaper source from your picture gallery, Sprint ID wallpapers, live wallpapers, or other preloaded options.

### Move or Remove Items on the Home Screen

- To move the item, touch and hold it, and then drag it to a new location.
- To remove the item, touch and hold it, and then drag it to **Remove** at the top of the screen.

## App Menu

The app menu shows you all of your applications. To open it from the home screen, touch



**Apps** .

## SCREEN NOT YET AVAILABLE

Flick left and right to see all of your apps. Any new apps that you download (see [Google Play Store™](#)) are added to the app menu.

To close the app menu, touch Home  or Back .

### *Recent Apps*

Touch Recent Apps  to see the last few apps you used, and then touch the app you want. Touch Back  to return to the home screen.

### *Search*



## SCREEN NOT YET AVAILABLE


















**Note:** You can also use the Voice search key on the keyboard.

### *Status Bar*

Your phone's display provides information about your phone's status and options. This list identifies some of the symbols you'll see: To view notification alerts, touch the status bar and drag it down.

#### *Status Icons*

Icon	Description
	Bluetooth® active
	GPS active

	Wi-Fi active
	downloading
	vibrate mode
	ringer off
	mute call
	speakerphone active
	speakerphone off
	network (full signal)
	3G (data service)
	4G (data service)
	airplane mode
	sync active
	alarm set
	battery (charging)
	battery (full charge)
	missed call
	mobile hotspot active

To view notification alerts, touch the status bar and drag it down.

## *Enter Text*

You can type on your phone's QWERTY keyboard or touchscreen keyboard.

[QWERTY Keyboard](#)

[Touchscreen Keyboards](#)

[Tips for Editing Text](#)


## QWERTY Keyboard



**Tip:** When you type, your phone suggests words for you. You can turn this on or off or explore other options by touching **Apps**  > **Settings** > **Language & input**.

**Note:** When you're entering text, press the Voice Key to begin voice recognition dictation.

## Touchscreen Keyboard

Certain applications let you use a touchscreen keyboard in landscape mode. Touch a text field to open a touchscreen keyboard when your phone is in landscape mode. Touch Back  to close it.

To move the cursor, touch where you want to move it.







## Multi-Touch Keyboard

Use the touchscreen keyboard to enter letters one at a time.

SCREEN NOT YET AVAILABLE




## Tips for Editing Text

To...	
Enter <b>alternate</b> characters	To enter characters appearing at the top of the keys (including numbers), press  <b>ALT</b> on the keyboard or touch  ?123 on the multi-touch keyboard.
Enter <b>one capital</b> letter	Touch  <b>Shift</b> .
Enter <b>only capital letters</b> , until you touch  <b>Shift</b> again	Touch  <b>Shift</b> twice. Touch again to revert to lowercase.
<b>Select</b> text	Touch and hold text to select it.  Or, when viewing a Web page or received message, touch and hold text until you see two bookend cursors. Drag the cursors to either end of the text to select. Touch the selected text for more options.
<b>Cut</b> or <b>Copy</b> selected text	Touch and hold text, then touch Select word or Select all.  Touch and hold again, then select Cut or Copy.
<b>Move</b> the cursor	Touch where you want to move the cursor. When you see a red icon, drag it to where you want the cursor.
<b>Paste</b> cut or copied text	Touch and hold location to paste, then touch Paste.
<b>Delete</b> a character (hold to delete more)	Touch  Delete.

## Auto-Correction

As you type, your phone suggests words from your dictionary and chosen language.

Your phone also automatically enters apostrophes in some words, like “don’t.” You can also touch two keys at the same time, such as  **Shift** with a letter.

## Text Input Settings

- ▶ Touch Apps  >  **Settings** > **Language & input**.

# Phone

---

With the Sprint National Network and your phone's phone, you can enjoy clear calling across the country.

[Make Phone Calls](#)

[Receive Phone Calls](#)

[Phone Call Options](#)

[Making a Conference Call](#)

## *Make Phone Calls*

There are several convenient ways to place calls from your phone.

[Call Using the Phone Dialer](#)

[Call from Call log](#)



[Call from Contacts](#)

[Call from Favorites](#)

[Call a Number in a Text Message](#)

[Call Emergency Numbers](#)



### *Call Using the Phone Dialer*

- ▶ From the home screen, touch  **Phone**, enter a number using the dialpad, and touch .

SCREEN NOT YET AVAILABLE

### *Call from Recent*



- ▶ To see recent or missed calls, touch  **Phone** > **Recent**.

- To call a number, touch  **Call**.
- To send a text message, touch and hold an entry, and then select **Send text message**.
- To clear the list, touch Menu  > **Clear list**.


## Call from Contacts

1. Touch  **People**
2. Touch a contact, and then touch **Call [number type]** (for example, **Call work**).

## Call from Favorites



- ▶ Touch  **People** > **Favorites**.
  - To call a number, touch  **Call** on the right. If necessary, select the type of number.
  - To send a text message, view a contact, or other options, touch an entry.

## Call a Number in a Text Message

1. With the message open, touch the number.
2. When the dialer screen opens, touch .

## Call Emergency Numbers

**Note:** Your service provider programs one or more emergency phone numbers (such as 911 or 112) that you can call under any circumstances, even when your phone is locked. Emergency numbers vary by country. Your pre-programmed emergency number(s) may not work in all locations, and sometimes an emergency call cannot be placed due to network, environmental, or interference issues.

1. Touch  **Phone**. (If your phone is locked, touch **Emergency Call**.)
2. Enter the emergency number (for example, 911).
3. Touch  to call the emergency number.

**Note:** Your mobile phone can use GPS and AGPS signals to help emergency services find you.

## Enhanced 911 (E911) Information

This phone features an embedded Global Positioning System (GPS) chip necessary for utilizing E911 emergency location services where available.

When you place an emergency 911 call, the GPS feature of your phone seeks information to calculate your approximate location. Depending on several variables, including availability and access to satellite signals, it may take up to 30 seconds or more to determine and report your approximate location.

**Important:** Always report your location to the 911 operator when placing an emergency call. Some designated emergency call takers, known as Public Safety Answering Points (PSAPs) may not be equipped to receive GPS location information from your phone.

## Receive Phone Calls

### Answer an Incoming Call

- ▶ To answer a call touch  and flick to .

### Mute the Ringing Sound

- ▶ To mute the ringer without rejecting the call, press the volume button down.

### Reject an Incoming Call

- ▶ To send an incoming call to your voicemail, touch  and flick to .

When you ignore a call, you can automatically send a text message to the caller. See [Text Message Reply](#).

## Phone Call Options





SCREEN NOT YET AVAILABLE

During a call:

- To use a Bluetooth® device, touch **Bluetooth**. (First, turn on your phone and pair it. See [Connect New Devices](#).)
- To mute a call, touch **Mute**.
- To use the speakerphone, touch **Speaker**.

Note: Using a mobile phone or accessory while driving may cause distraction and may be illegal. Always obey the laws and drive safely.

Note: Your phone includes a proximity sensor. When you hold the phone to your ear, the display goes dark to prevent accidental touches. When you move your phone away from your ear, the display lights up again.

Tip: You can touch Home  or Back  to leave the active call display. To reopen it, touch Home  >  **Phone > Return to call in progress.**

## *Making a Conference Call*

With 3-way calling, you can talk to two people at the same time. When using this feature, the normal airtime rates will be charged for each of the two calls.

- ▶ To start a conference call, call the first number. After the call connects, touch **Add Call**. Dial the next number, or select it from contacts or favorites. When the next number answers, touch **Merge**.

06/06/2012  
FCC

# Phone Settings

---

Wireless & Network Settings

Call Settings

Sound Settings

Display Settings

Battery & Data Manager Settings

Location & Security Settings

Account Settings

Applications Settings

Privacy Settings

Storage Settings

Language & Keyboard Settings

Voice Input & Output Settings

Accessibility Settings

Date & Time Settings

About Phone

## ***Wireless & Network Settings***

Airplane Mode

Wi-Fi Settings

Bluetooth® Settings

Tethering & Wi-Fi Hotspot Settings

VPN Settings

Mobile Network Settings

### ***Airplane Mode***

Airplane Mode turns off all your wireless connections and allows you to use many of your phone's features when you are in an airplane or in any other area where making or receiving

calls or data is prohibited. When you set your phone to Airplane Mode, it cannot send or receive any calls or access online information.

- ▶ Press and hold **Power/Lock** button and touch **Airplane mode**.

## *Wi-Fi Settings*

Your phone lets you take advantage of Wi-Fi hotspots for high-speed data access using available computer networks. For details on your phone's Wi-Fi features and settings, see [Wi-Fi](#).

- ▶ Touch **Apps**  >  **Settings** > **Wi-Fi** to access the Wi-Fi settings menu.

## *Bluetooth® Settings*

Your phone's Bluetooth capabilities let you use wireless headsets, send and receive pictures and files, and more. For details on your phone's Bluetooth settings, see [Bluetooth® Connections](#).

- ▶ Touch **Apps**  >  **Settings** > **Bluetooth** to access the Bluetooth settings menu.



## *Tethering & Mobile Hotspot Settings*

Share your phone's mobile data connection via USB or as a Mobile Hotspot.

- ▶ Touch **Apps**  >  **Settings** > **Tethering & Mobile Hotspot** to access the USB Tethering & Mobile Hotspot settings menus.



## *VPN Settings*

You can set up a Virtual Private Network (VPN). Select either basic or advanced options.

- ▶ Touch **Apps**  >  **Settings** > **More...** > **VPN** to access the VPN settings menu.

## *Mobile Network Settings*

Set options for roaming or change your CDMA subscription. For more about roaming and data guard, see [Roaming](#).

- ▶ Touch **Apps**  >  **Settings** > **More...** > **Mobile networks** to access the Mobile network settings menu.



## *Call Settings*

Your phone's Call Settings menu lets you configure your voicemail options and a number of other settings for the phone application.

[Voicemail Settings](#)

[Other Call Settings](#)



## Voicemail Settings

- ▶ Touch  **Phone** > Menu  > **Settings** > **Voicemail settings** to access the voicemail settings menu.

For more about voicemail, see [Voicemail](#).



## Other Call Settings

### Plus Code Dialing

- ▶ To select the plus code for domestic dialing or set an international dialing code, touch  **Phone** > Menu  > **Settings** > **Plus Code Dialing** > **Domestic Dialing** or **International Dialing**.

### Caller ID Readout

Your phone can read out your incoming caller's name.

- ▶ Touch  **Phone** > Menu  > **Settings** > **Caller ID Readout** and select **Ring only**, **Caller ID then Ring**, or **Caller ID repeat**.

### TTY Mode

A TTY (also known as a TDD or Text Telephone) is a telecommunications device that allows people who are deaf, hard of hearing, or who have speech or language disabilities to communicate by telephone.

Your phone is compatible with select TTY devices. Please check with the manufacturer of your TTY device to ensure that it is compatible with digital cell phones. Your phone and TTY device will connect via a special cable that plugs into your phone's headset jack. If this cable was not provided with your TTY device, contact your TTY device manufacturer to purchase the connector cable.

To turn TTY Mode on or off:

- ▶ Touch  **Phone** > Menu  > **Settings** > **TTY mode** and select an option.

For additional information about Sprint Relay Services and TTY compatibility, call Sprint Relay Customer Service at 800-676-3777 or visit [sprintrelay.com](http://sprintrelay.com).

**Warning:** **911 Emergency Calling**  
Sprint recommends that TTY users make emergency calls by other means, including Telecommunications Relay Services (TRS), analog cellular, and landline communications. Wireless TTY calls to 911 may be corrupted when received by public safety answering points (PSAPs), rendering some communications unintelligible. The problem encountered appears related to software used by PSAPs. This matter has been brought to the attention of the FCC, and the wireless industry and the PSAP community are currently working to resolve this.



## HAC Mode Settings

If you wear a hearing aid, select this setting for compatibility.

- ▶ Touch  **Phone** > Menu  > **Settings** > > **HAC Mode Settings**.





## Auto Answer With Headset

Your phone can automatically answer incoming calls when you are wearing a headset.

- ▶ Touch  **Phone** > Menu  > **Settings** > **Auto answer on headset** > **On**.

## Text Message Reply

When you **Ignore** an incoming call, your phone can automatically send a text message to the caller.

- ▶ To send a text message to an ignored call, touch  and flick to .
- ▶ To edit the outgoing message, touch  **Phone** > Menu  > **Settings** > **Quick responses**, and touch a quick response to edit it.

## Voice Privacy



Enable enhanced privacy mode to make it harder for devices to pick up your frequency.

- ▶ Touch  **Phone** > Menu  > **Settings** > **Voice privacy**.



# Sound Settings

## General Sound Settings

### Silent Mode

- ▶ To silence all sounds except media and alarms, touch **Apps**  >  **Settings** > **Sound** > **Silent mode**.



### Vibrate

- ▶ To add a vibration to Silent Mode, touch **Apps**  >  **Settings** > **Sound** > **Silent mode** > **Vibrate**.

### Vibrate Patterns

- ▶ To select a vibration pattern, touch **Apps**  >  **Settings** > **Sound** > **Vibrate patterns** and select a pattern.

### Volume



- ▶ To set volume for ringtone, media, and alarms, touch **Apps**  >  **Settings** > **Sound** > **Volume**.



- ▶ Press the volume buttons to change the ring volume (in the home screen), or the earpiece/speaker volume (during a call or while listening to music).



## *Incoming Call Sound Settings*

### *Phone Ringtone*

- ▶ To set a ringtone for incoming phone calls, touch **Apps**  >  **Settings** > **Sound** > **Phone ringtone**. Select a ringtone, and touch **OK**.

## *Notifications*

### *Notification Ringtone*

- ▶ To set a ringtone for notifications, touch **Apps**  >  **Settings** > **Sound** > **Default notification**. Select a ringtone, and touch **OK**.

## *Sound Feedback Settings*

The Feedback settings menu lets you select whether you hear tones when touching numbers on the dialpad, selecting onscreen options, and more.

- **Dial pad touch tones:** Play tones when using the dialpad.
- **Touch sounds:** Play sounds when making an onscreen selection.
- **Screen lock sound:** Play sounds when locking or unlocking the screen.
- **Vibrate on touch:** Vibrate when touching keys and during certain other instances.
- **SD card notifications:** Play sound for SD card notifications.
- **Call connect:** Set sound emitted when a call is connected.
- **Network Lost tone:** Play alert when phone loses network coverage.
- **Software update alert:** Play alert tone for software update notifications.



## Display Settings

Adjusting your phone's display settings not only helps you see what you want, it can also help increase battery life.



### Brightness

- ▶ To set display brightness, touch **Apps**  >  **Settings** > **Display** > **Brightness**.

### Auto-Rotate Screen

- ▶ To set the screen to rotate automatically when you rotate the phone from portrait to landscape mode, touch **Apps**  >  **Settings** > **Display** > **Auto-rotate screen**.



### Screen Timeout

- ▶ To set the number of minutes before your screen goes dark, touch **Apps**  >  **Settings** > **Display** > **Sleep** and select the number of minutes or **Never timeout**.

**Note:** Longer screen timeout settings increase battery usage.



### Wallpaper Settings

To apply a new wallpaper:

1. Touch and hold an empty spot on your home screen, and then touch **Wallpapers**.  
—or—  
Touch **Apps**  >  **Settings** > **Display** > **Wallpaper**.
2. Touch **Gallery**, **ID wallpapers**, **Live wallpapers**, or **Wallpapers**, and choose a wallpaper.

## Battery Settings

### Battery Remaining

- ▶ To see battery usage statistics, touch **Apps**  >  **Settings** > **Battery**.

**Warning:** Use only Sprint-approved or Motorola chargers with your phone. The failure to use a Sprint-approved or Motorola charger may increase the risk that your phone will overheat, catch fire, or explode, resulting in serious bodily injury, death, or property damage.

Sprint-approved or Motorola batteries and accessories can be found at Sprint Stores or through Motorola; or call 1-866-866-7509 to order. They're also available at [sprint.com](http://sprint.com).

## ***Battery Capacity***

Your phone is equipped with a Lithium Ion (Li-Ion) battery. It allows you to recharge your battery before it is fully drained.

Your phone warns you with an audible alert when the battery reaches 15% and 5% of its capacity. When there are approximately two minutes of talk time left, the phone plays another alert and then turns off.

**Note:** Long backlight settings, searching for service, vibrate mode, browser use, and other variables may reduce the battery's talk and standby times.

**Tip:** Watch your phone's battery level indicator and charge the battery before it runs out of power.

**Warning:** Do not handle a damaged or leaking Li-Ion battery as you can be burned.

## ***Charging the Battery***

Keeping track of your battery's charge is important. If your battery level becomes too low, your phone automatically turns off, and you will lose any information you were just working on.

Always use a Sprint-approved or Motorola desktop charger, travel charger, or vehicle power adapter to charge your battery.


1. Insert the small end of the USB cord into the charger/accessory jack on the left side of your phone.
2. Insert the larger end of the USB cord into the AC adapter.
3. Plug the AC adapter into an electrical outlet and charge for at least three hours.

With the Sprint-approved Li-Ion battery, you can recharge the battery before it becomes completely run down.

## ***Battery Cool Down***

In very limited circumstances, such as where your phone has been exposed to extreme heat, "Cool Down" message screens will appear. To avoid possible damage to your battery and phone, you should follow these instructions until the phone is within its recommended temperature range. When your phone is in "Cool Down" mode, only emergency calls can be made.

## ***Battery mode***

- ▶ To set how your phone uses battery charge, touch **Apps**  > **Smart Actions** > **Battery Extender** > or **Nighttime saver**.

# Location Settings



## My Location

Your phone is equipped with a Location feature for use in connection with location-based services.

The Location feature allows the network to detect your position. Turning Location off will hide your location from everyone, except 911.

**Note:** Turning Location on will allow the network to detect your position using GPS technology, making some Sprint applications and services easier to use. Turning Location off will disable the GPS location function for all purposes except 911, but will not hide your general location based on the cell site serving your call. No application or service may use your location without your request or permission. GPS-enhanced 911 is not available in all areas.

To enable your phone's Location feature:

- ▶ Touch **Apps**  >  **Settings** > **Location services** and select one or more services to use, such as **Google's location service** or **GPS satellites**.

## Security Settings

### Set Up Screen Lock

**Note:** You can make emergency calls on a locked phone (see [Call Emergency Numbers](#)). A locked phone still rings, but you need to unlock it to answer.



You can increase the security of your phone by creating a screen lock. When enabled, you have to draw the correct unlock pattern on the screen, enter the correct PIN, or enter the correct password to unlock the phone's control keys, buttons, and touchscreen.

To lock the screen:

1. Press the **Power/Lock** button on top of the phone.
2. Let the screen time out (don't press anything).
3. Switch the power off.

To unlock the screen, press the **Power/Lock** button. Then, drag  to the right.



### Pattern

1. To set the lock pattern, touch **Apps**  >  **Settings** > **Security** > **Screen lock** > **Pattern**.
2. Follow the instructions to draw your lock pattern, and then touch **Continue**.



3. When prompted, draw the pattern to unlock the phone, and then touch **Confirm**.

If you fail to draw the correct unlock pattern on the screen after five attempts, you will be prompted to wait for 30 seconds before you can try again.

### *PIN Lock*

1. Touch Menu **Apps**  >  **Settings** > **Security** > **Screen lock** > **PIN**.
2. Enter a numeric PIN, and then confirm it.
3. When prompted, enter PIN to unlock the phone.



### *Password Lock*


1. Touch Menu **Apps**  >  **Settings** > **Security** > **Screen lock** > **Password**.
2. Enter password, and then confirm it.
3. When prompted, enter the password to unlock the phone.

### *Face Unlock*



Use face recognition software to unlock your phone.

**Note:** This feature is less secure than a pattern, PIN, or password.

1. Touch Menu **Apps**  >  **Settings** > **Security** > **Screen lock** > **Face Unlock** > **Set it up**.
2. Hold your phone at eye level, look into the front camera, and follow the instructions on the screen.
3. When the face capture is complete, you will be prompted to choose a pattern or PIN as a backup security measure you can use when the phone cannot see your face clearly.

To unlock the phone, flick  to the right and look toward the front camera lens.



### *Disable the Screen Lock*

1. Touch Menu **Apps**  >  **Settings** > **Security** > **Change screen lock** > **None**.
2. Draw your unlock screen pattern or enter password or a numeric PIN, and then confirm it.

### *Forgot Your Pattern or Passcode?*

If you forget your pattern, password, or your PIN, contact Sprint.

### *Security Lock Timer*

- ▶ Touch **Apps**  >  **Settings** > **Security** > **Security lock timer**, and then select a length of time your phone is idle before it locks.



**Note:** Security lock timer is only available if you have a screen lock enabled.

### *Allow Bluetooth<sup>®</sup> Bypass*

Allow voice commands to be launched via Bluetooth even if your phone is locked.

- ▶ Touch Apps  >  **Settings > Security > Allow Bluetooth bypass.**

### *Data Encryption*

1. To encrypt data on your phone, first set up a screen lock (see [Set Up Screen Lock](#)).
2. Touch Apps  >  **Settings > Security > Data encryption.**
3. Select **Device data encryption** to encrypt all personal data on your phone.
4. Select **Storage encryption** to include files you save on your optional memory card (sold separately) and in phone storage.
5. Touch **Apply**.

### *Passwords*

Select whether to show passwords as you enter them instead of \*\*\*\*\*.

- ▶ Touch Apps  >  **Settings > Security > Visible passwords.**



### *Device Administration*

Activate the device administrator role so that you can have further control over erasing phone data, changing passwords, setting password rules, monitoring failed screen unlock attempts, and locking the screen.

- ▶ Touch Apps  >  **Settings > Security > Device administrators.**

### *Credential Storage*

Use secure credential information from an SD card.

- ▶ Touch Apps  >  **Settings > Security** and select from the following options:
  - **Install from SD card:** install credentials from a memory card.
  - **Clear storage:** clear all credential storage and reset the password.

### *Certificates*



Manage your security certificates:

- ▶ Touch Apps  >  **Settings > Security > Manage all certificates.**




## Account Settings

The Accounts menu lets you add and manage all your email, social networking, and picture and video sharing accounts.

### Set Up a New Account

1. Touch **Apps**  >  **Settings** > **Accounts & sync** > **Add account**.
2. Touch an account type:
  - Corporate, Email, MotoCast ID, Google.
3. Enter your account information and touch **Next**.
  - Depending on the account type, you may need to enter an email address or user address, password, domain name, or other information. For Corporate accounts, contact your server administrator to determine what information you will need.
4. Touch **Done** when you are finished.

### Manage Existing Accounts

1. Touch **Apps**  >  **Settings** > **Accounts & sync**.
2. Touch an account to manage its settings.
  - Touch a field to edit it.
  - Touch **Remove** account to delete it from your phone.
3. Touch **Back**  when you are finished.

## Applications Settings

### Unknown Sources

Allow installation of applications from vendors other than the Google Play Store™.

- ▶ Touch **Apps**  >  **Settings** > **Security** > **Unknown sources**.

### Manage Applications

Remove, stop, and manage your apps.



1. Touch **Apps**  >  **Settings** > **Apps**.
2. Touch an app for more options.



3. To remove an app, touch **Uninstall**.

## Running Services

View apps that are currently running.

- ▶ Touch **Apps**  >  **Settings** > **Apps** > **Running**.
  - To stop an app, touch the app and then touch **Stop**.

## Privacy Settings

### Backup and Restore

#### Back Up My Data

Select whether to back up your personal data (passwords and settings) to Google™ servers.

- ▶ Touch **Apps**  >  **Settings** > **Privacy** > **Back up my data**.




#### Automatic Restore

Set whether to automatically restore backed up data if you reinstall an app.

- ▶ Touch **Apps**  >  **Settings** > **Privacy** > **Automatic restore**.

### Resetting Your Phone

Selecting **Reset phone** resets all phone settings back to their default values and clears all information (text messages, contacts, emails, etc.) and downloaded apps.

1. Touch **Apps**  >  **Settings** > **Privacy** > **Factory data reset**.
2. Select **Erase internal storage (media area)** or **Erase SD card**, and then touch **Reset Phone**.
3. Read the prompt and touch **Erase everything** to complete the reset. (Touch **Back**  to cancel.)

**Warning:** All data on your phone will be deleted. (Nothing on your memory card is deleted unless you select **Erase SD card**.)

## Storage Settings

### Internal Storage

#### Format Internal Storage

To format and erase your internal storage.

- ▶ Touch **Apps**  >  **Settings** > **Storage** > **Format internal storage**.

## *SD Card*

### *Mount/Unmount SD Card*

To insert or remove a memory card:

- ▶ Touch **Apps**  >  **Settings** > **Storage** > **Mount/Unmount SD card**.

### *Format SD Card*

To format and erase your memory card:

- ▶ Touch **Apps**  >  **Settings** > **Storage** > **Erase SD card**.



**Note:** You must first unmount an SD card before you can erase it.

## *Language & Keyboard Settings*

### *Language Settings*




#### *Select Locale*

To set your menu language and region:

- ▶ Touch **Apps**  >  **Settings** > **Language & input** > **Locale** and select **English** or **Español**.

#### *Personal Dictionary*

Add words to your personal dictionary so they appear as suggestions when you enter text:

1. Touch **Apps**  >  **Settings** > **Language & input** > **Personal dictionary**.
2. To add a word, touch **Menu**  type the word, and touch **Ok**.



### *Keyboard Settings*

#### *Input Method*

Your phone has options for text entry.

#### *Motorola Input*



Your phone's touchscreen input method is the multi-touch keyboard.

- ▶ Touch **Apps**  >  **Settings** > **Language & input** > **Motorola Input setting** to set the following options:

- **Input languages:** Slide your finger on the spacebar to quickly change to a secondary language.
- Text Correction
  - **Add-on dictionaries:** Install additional dictionaries.
  - **Auto correction:** Automatically correct your spelling and typing errors.
  - **Show correction suggestions:** Show word suggestions as you type.
- General
  - **Auto-capitalization:** Automatically capitalize the next word after a period (.).
  - **Auto-punctuate:** Press the spacebar twice to insert a period (.).
  - **Vibrate on keypress:** Vibrate when you press a key.
  - **Sound on keypress:** Make a sound when you press a key.
  - **Auto-correct errors:** Automatically correct your spelling and typing errors.
  - **Popup on keypress:** Keys pop up as you touch them.
  - **Show settings key:** Display settings key on keypad.
  - **Voice input key:** Select where voice input key appears on keypad.
- Other Options
  - **Transfer learned words:** Import or export your user dictionary (learned words and phrases) using the memory card.
  - **Clear learned words:** Clear all saved words from your user dictionary.
  - **Advanced settings:** Options for expert users


### *Built-In Keyboard*

Your phone's built-in keyboard has options for text entry.


- ▶ Touch **Apps**  >  **Settings** > **Language & input** > **Built-in keyboard** to set the following options:
  - **Auto-replace:** Correct mistyped words.
  - **Auto-capitalization:** Automatically capitalize the first letter in sentences.
  - **Auto-punctuate:** Press the spacebar twice to insert a period (.).

# Voice Input & Output Settings



## Voice Input

- ▶ Touch Apps  >  **Settings** > **Language & input** > **Voice Search** to set the following settings for voice recognition:
  - **Language:** Set the language.
  - **SafeSearch:** Filter out explicit images when using Google Voice Search™.
  - **Block offensive words:** Hide offensive words during recognition.

## Voice Output

- ▶ Touch Menu  > **Settings** > **Voice input & output** > **Text-to-speech settings** for the following settings:
  - **Preferred Engine:** Your speech synthesis engine is Google Text-to-speech.
  - **Speech rate:** Select the speed of spoken text.
  - **Listen to an example:** Play a short demonstration of speech synthesis.



## Accessibility Settings

- ▶ Touch Apps  >  **Settings** > **Accessibility** for the following settings:
  - **TalkBack, Large text, Power button ends call,** and more.



## Date & Time Settings

### Changing the Date & Time

To set date, time, and time zone:

- ▶ Touch Apps  >  **Settings** > **Date & time** and select **Automatic** or a manual setting (**Set date**, **Select time zone**, or **Set time**).

To set date and time formats:

- ▶ Touch Apps  >  **Settings** > **Date & time** > **Use 24-hour format** or **Select date format**.

## About Phone

The About Phone menu lets you access important phone information, search for and apply updates, and view legal and safety information.

### System Updates

Check for software updates directly on your phone:

- ▶ Touch **Apps** (⋮) > **Settings** (⚙️) > **About phone** > **System updates**.

### Status

View battery status, phone number, network information, and more:

- ▶ Touch **Apps** (⋮) > **Settings** (⚙️) > **About phone** > **Status**.

### Legal Information

- ▶ Touch **Apps** (⋮) > **Settings** (⚙️) > **About phone** > **Legal information**.

06/06/2012  
FCC

# Contacts

---

Get Started with Contacts

Add a Contact

Save a Phone Number

Edit a Contact

Sync or Transfer Contacts

Share Contacts

Call or Text Contacts

Make Groups

## Get Started with Contacts

Before using Contacts, it's best to learn the basics.

### Access Contacts

► Touch  **People**

SCREEN NOT YET AVAILABLE

**Tip:** To search the list, begin typing a name.



► Touch Menu  to display options:

- **Contacts to display:** Filter and sort your contact list.
- **Import/Export:** Import or export contacts from a memory card.
- **Accounts:** Touch **Add account** to add another account from which to use contacts, or touch an account, and then touch Remove account to delete it from your phone.

- **Share contacts:** Begin typing to search for a contact to share; touch **Done**; select the information to share; select how you want to share the information; and then select a recipient for the information.
- **Settings:** Touch **Display options** to show suggested Groups and Favorites or touch **Contact storage** to choose where to store new and imported contacts.

## Add a Contact


**Note:** Before entering contacts, you must set up at least one email account on your phone. See [Complete the Setup Application](#) or [Setting Up Messaging Accounts](#).

1. Touch  **People** > .
2. Choose an account for storing your contact.

3. Fill in as much or as little information as you'd like.
4. When you're finished, touch **Save**.






## Save a Phone Number

You can save a phone number directly from the dialpad.

1. Touch  **Phone**.
2. Enter the phone number and touch **Add to Contacts**.
3. To add the number to an existing contact, touch **Existing**. To create a new contact for the number, touch **New**.
4. For an existing contact, touch the contact name, select a number type for the new number, and then touch **Save**.  
—or—  
For a new contact, enter the first and last name and any additional information, and then touch **Save**.

## Edit a Contact

After you add a contact, you can add or edit it, assign a caller ID picture, customize with a unique ringtone, and more.

1. Touch  **People**.
2. Touch a contact, touch Menu  > **Edit contact**.
  - **To edit the contact:** Touch any field you want to add or change. When you are finished, touch **Save**.
  - **To assign a stored picture to a contact:** Touch the picture icon at the top of the entry, and then touch **Select existing photo**. Select **Files** (for a picture in internal storage, memory card, or shared network folders) or **Gallery** (for a picture in your gallery). Then touch a photo to select it.
  - **To assign a new picture to a contact:** Touch the picture icon at the top of the entry, and then touch **Take photo**. Your camera opens. Touch  the **Shutter** icon to take the photo. Touch **Checkmark** to continue. (Touch and drag the square to crop the picture.) Touch **Crop** to assign the picture.
3. **To assign a ringtone to a contact**, touch the contact, touch Menu  > **Set ringtone**. Touch Ringtone to select a tone. Then touch **OK**.
4. **To delete a contact**, touch the contact, touch Menu  > **Delete**. Then touch **OK**.

## Sync or Transfer Contacts



When you change one of your contacts, your phone automatically updates your other social networking accounts. Also, your phone updates your contacts and social networking account whenever you change a friend in your social networking accounts.

Get all your contacts, all in one place. Here are a few helpful hints:

- **Use Gmail™:** All your Gmail contacts are automatically synced to your phone. Various computer applications for mobile phones and email accounts allow you to export your contacts as a “.CSV” file. You can then use Gmail to import the file. For details, see [motorola.com/transfercontacts](http://motorola.com/transfercontacts) or log in to your Gmail account on your computer and select “Help”.
- **Use a microSD card:** You can transfer contacts from your old phone to your new Motorola phone using a microSD card. See [Transfer Contacts Using a microSD Card](#).
- **More:** Find other methods and tools to help you at [motorola.com/transfercontacts](http://motorola.com/transfercontacts).






## Transfer Contacts Using a microSD Card



1. On your old phone, copy all the contacts to your microSD card. (They'll be copied as a VCard file.)
2. Insert the microSD card in your new phone. See [Optional microSD Card](#).
3. To import the contacts from your microSD card, touch  **People** > Menu  > **Import/Export** > **Import from Storage**.

## Share Contacts

You can share contacts via Bluetooth, email, Gmail, or text messaging.




1. Touch  **People**
2. Touch a contact, touch Menu  > **Share**.
3. Select the information that you want to share, and then touch **OK**.
4. Select the method you want to use to share the contact:
  - **Bluetooth** to use a Bluetooth connection. See [Bluetooth® Connections](#) for details about pairing and sharing.
  - **Email** to send the information as an email attachment. If prompted, select an email account. Address the message, add a subject and a message, and then touch the **Send** icon. See [Email](#) for details about sending email.
  - **Gmail** to send the information as a Gmail attachment. Address the message, add a subject and a message, and then touch . See [Gmail™ and Google™](#) for details.
  - **Messaging** to send the information in a text message. Select a contact or enter a wireless phone number or email address, enter any additional information, and then touch the **Send** icon. For more information on text messaging, see [Text Messages and MMS](#).

## Call or Text Contacts

1. Touch  **People**  
—or—  
Touch  **Phone** > **Phonebook**.
2. For **View contact**, **Call contact**, **Text contact**, or other options, touch and hold the contact.

## Make Groups

You can set up groups in Contacts for Group Connect calls or for quick messaging.

1. Touch  **People** > **Groups** > .
2. Enter a name for your group.
3. Type in a name to search for people to add to the group. When the list of **People** entries pops up, touch a name to add that person to the group.  
--or--  
Touch Menu  > Add members, and select members from the list. When finished touch **OK**.
4. Touch **Save**.

**Note:** You may see different options based on the information you have for the contact.

06/06/2012  
FCC

# Calendar & Tools

---

Calendar

File Manager

Alarm Clock and Timer

Help Center

Calculator

Tasks

Quickoffice

Update Your Phone Software

Bluetooth® Connections

## Calendar


Create and manage events, meetings, and appointments.

► Touch **Apps**  >  > **Calendar**.


Touch the date to view your calendar events by **Agenda**, **Day**, **Week**, or **Month**. When you highlight an event, more details appear.

**Tip:** You can set up multiple calendars through your Gmail account so you can access them from your phone wherever you go.

## Add Calendar Events

1. From any view, touch . Enter the event start time and other details. You can even set a reminder so you don't forget about the event. (When you set the reminder time to 0 minutes, it plays at the event start time.)
2. When you finish entering event details, touch **Done**.

## Manage Calendar Events

- To edit an event, touch and hold it, and then touch **Edit event**. When you're done, touch **Save**.
- To delete an event, touch and hold it, and then touch **Delete event**.
- To go to a specific day, touch **Menu**  > **Go to date**. Enter a date and touch **Go**.

## File Manager

File Manager allows you to manage files such as pictures, videos, music, and applications stored on a microSD card.

- ▶ Touch **Apps**  >  **Files** > **SD card**.

Touch a file or folder to open, and then touch and hold a file to **Delete** or **Share**.

## Alarm Clock and Timer

### Alarm Clock

Your phone has multiple alarm capabilities.



- ▶ Touch **Apps**  >  **Alarm & Timer**.

SCREEN NOT YET AVAILABLE

- To turn on an alarm, touch the check box.
- When an alarm sounds, slide to **Dismiss** to turn it off or **Snooze** to delay for ten minutes.
- To add an alarm, touch **Add alarm**, and enter alarm details. Touch **OK** when you are finished.
- To enable or disable an alarm, touch the check box.

### Timer

To set a timer:

1. Touch **Apps**  >  **Alarm & Timer** > **Timer**.
2. Set a time and touch **Start**.

## Help Center



- ▶ Touch **Apps**  >  **Help Center**.

You can also flick your home screen left or right to see the **Tips & Tricks** widget.

## Calculator


Your phone comes with a handy calculator.

- ▶ Touch **Apps**  >  **Calculator**.

Your calculator has basic and advanced views. To change views touch **Menu**  > **Advanced panel/Basic panel**. To clear history, touch **Menu**  > **Clear history**.

## Tasks

1. Touch **Apps**  >  **Tasks**.

2. To add a task, touch .

Touch **All tasks** to view your tasks by due date, priority, and more.

SCREEN NOT YET AVAILABLE

## Quickoffice

- ▶ Touch **Apps**  >  **Quickoffice**.

### Quick Office Programs

- **Quickword**: Create and edit Microsoft Word® documents.
- **Quicksheet**: Create and edit Microsoft Excel® spreadsheets.
- **Quickpoint**: Create and edit Microsoft PowerPoint® presentations.
- **QuickPDF**: View Adobe Acrobat® PDF files.

## Create a New File

- ▶ To create a new file, touch the icon of the type of file you want to create, and then touch **Create New Document**.


## Open a Document

- ▶ To open an existing file, touch the icon of the type of file you want to edit, touch **SD Card** to search for a file, or touch **Recent Documents**.

## Browse Files


- ▶ To browse files on your optional memory card (sold separately), touch **Browse > SD Card**. Touch a file or folder to open, or touch and hold a file for options. You can edit most text or spreadsheet files.

## Tips

- Place your cursor by touching the text.
- Select text by double-touching it.
- Choose formatting, save the file, or to choose other options, touch Menu .
- To manage your folders and transfer files, see [File Manager](#).

## Update Your Phone Software

Stay up to date with the latest software updates for your phone. You can check, download and install updates using your phone, or using your computer:

- Using your phone:
  - You may get an automatic notification of an available update on your phone. Simply follow the instructions to download and install.
  - To manually check for updates, press Menu  > **Settings > System Updates > Update Motorola software**.
  - Your phone downloads any updates over your mobile network. Remember, these updates can be quite large (25MB or more) and may not be available in all countries. If you don't have an unlimited data plan, or mobile network updates are not available in your country, you can update using a computer.
- Using your computer:
  - On your computer, go to [motorola.com](http://motorola.com), search for your phone model, and check the “**Software**” links. If an update is available, follow the installation instructions.

# Voice Commands

## Voice Actions

- ▶ To begin a voice search, press the **Voice** key on the keyboard.

**Note:** If you're writing a text message, press the Voice key to begin dictation mode. Your phone recognizes words you speak and enters them into your message.

- ▶ Or, press the **Voice** key and say one of the following commands:

To...	Say...
Map a route	"navigate to"
Send a text message	"send text"
Make a call	"call"
Send email	"send email"
Find local businesses	"map of..."
Browse the Web	"go to"
Make a voice note	"note to self"
Get directions	"directions to"

**Tip:** To learn more about voice actions, press the **Voice** key on the keyboard, and then select **Watch Video**.

## Voice Commands

For more voice commands, touch **Apps**  >  **Voice Commands** and follow the prompts.

**Tip:** For quick access to Voice Commands, add a shortcut to a home screen page. Touch and hold an empty area, and then touch **Shortcuts > Applications > Voice Commands**.

## Bluetooth® Connections

Bluetooth is a short-range communications technology that allows you to connect wirelessly to a number of Bluetooth devices, such as headsets and hands-free car kits, and Bluetooth-enabled handhelds, computers, printers, and wireless phones. The Bluetooth communication range is usually up to approximately 30 feet.

- Touch **Apps**  >  **Settings** > **Wireless & networks** > **Bluetooth settings**.

SCREEN NOT YET AVAILABLE

### *Turn Bluetooth On or Off*

- Touch **Apps**  >  **Settings** > **Bluetooth** > **On**.

**Note:** To extend battery life, turn Bluetooth power off when not in use.

### *Connect New Devices*




**Note:** This feature requires an optional accessory.

#### *Standard Method*

To connect with a new device, you need to pair with it. You only need to do this once for each device. To connect again, just turn on the device.

1. Make sure the device you are pairing with is in discoverable mode.

**Note:** Refer to the guide that came with the device for details.

2. Touch **Apps**  >  **Settings** > **Bluetooth**.
3. Touch **ON** to turn on and scan. If Bluetooth power is already on, touch **SEARCH FOR DEVICES**.
4. Touch a device to connect.
5. If necessary, touch **OK**, or enter the device passkey (like 0000) to connect to the device. When the device is connected, the Bluetooth indicator  appears in the status bar.

**Note:** Using a mobile device or accessory while driving may cause distraction and may be illegal. Always obey the laws and drive safely.

#### *NFC Method*

You can also use Near Field Communication (NFC) to pair an NFC enabled Bluetooth device to your phone.

1. To turn NFC on, touch **Apps**  >  **Settings** > **More...** > **NFC**.



2. Make sure your phone's screen is on, and then touch the Bluetooth device to your phone's NFC tag location. Hold the device to the phone until pairing is complete.

## *Reconnect Devices*

- ▶ To automatically reconnect your phone with a paired device, simply turn on the device.
- ▶ To manually reconnect your phone with a paired device, touch the device name in the Bluetooth devices list.

## *Disconnect Devices*

- ▶ To automatically disconnect your phone from a paired device, simply turn off the device.
- ▶ To manually disconnect your phone from a paired device, touch the device name in the devices list, and then touch **OK**.

## *Edit the Device Name*

- ▶ Touch **Apps**  >  **Settings** > **Bluetooth** > Menu  > **Rename phone**. Enter a name and touch **OK**.

## *MOTOPRINT*

Print email, documents, pictures, and contacts directly to shared printers on a Wi-Fi network – no printer drivers necessary. MOTOPRINT automatically discovers networked printers for you. You can even save your favorite printers and geo-tag their location for future use

### *Print a Document or File*

To print something from **Email**, **Quickoffice**, or **Gallery**, open it and touch Menu  > **Print**.

### *Add a Printer*

Open the document or file you want to print, then touch Menu  > **Print** > **Find printers**.

## *Smart Actions*

Tired of doing the same tasks over and over again? Let smart actions do them for you. You can create rules to do things like automatically dim the touch screen when the battery is low, set your ringer to vibrate at work, and set different wallpaper at home.

- ▶ **Apps**  > **Smart Actions**

For more information, open the Smart Actions app and touch Menu  > **Help**.

# microSD Card

---

Optional microSD Card

microSD Card Settings

microSD Card Files

Connect Your Phone to Your Computer

## Optional microSD Card

You can purchase an optional microSD (Secure Digital) memory card to expand the phone's available memory space. It allows you to store images, videos, music, and voice data in your phone.

**Note:** You can easily damage the microSD card by improper operation. Please be careful when inserting, removing, or handling them.

### Insert the microSD Card

1. Remove the battery cover by pulling up from the notch at the bottom of the phone. (See [Set Up Your Phone](#).)
2. Open the memory card slot cover, and slide in the memory card until it clicks into place.



3. Close the memory card slot cover and replace the battery cover.



**Note:** Be sure to use only recommended microSD cards. Using non-recommended microSD cards could cause data loss and damage your phone.

**Note:** DO NOT remove a microSD card while files are being accessed or transferred. Doing so will result in loss or damage of data.

**Note:** Make sure your battery is fully charged before using the microSD card. Your data may become damaged or unusable if the battery runs out while using the microSD card.



## microSD Card Settings

### View Memory in the microSD Card

- ▶ With the microSD card inserted, touch **Apps**  >  **Settings** > **Storage**. (The used and available memory space will be displayed.)



### Format the microSD Card

**Note:** Do not remove your memory card while your phone is using it or writing files on it.

1. Before you remove or format your memory card you need to unmount it. Touch **Apps**  >  **Settings** > **Storage** > **Unmount SD card**.
2. To format your memory card, touch **Format SD card**.

**Note:** The formatting procedure erases all the data on the microSD card, after which the files CANNOT be retrieved. To prevent the loss of important data, please check the contents before you format the card.

### microSD Card


1. Touch **Apps**  >  **Files** > **SD card**.
2. Touch a file or folder to open.

## Connect Your Phone to Your Computer

You can connect your phone to a computer with a USB cable.

**Note:** The first time you use a USB connection, your computer may indicate that drivers are being installed. Follow any prompts you see to complete the installation. This may take a few minutes.

**Note:** You also may see MotoHelper installation for using Motorola Media Link, an easy way to transfer files to your phone.

1. Connect a Motorola micro USB data cable from your phone's micro USB port to a USB port on your computer. Your phone should show  in the status bar.

**Note:** Make sure to connect the phone to a high power USB port. Typically, these are located directly on your computer.

2. On your phone, flick down the status bar and touch the USB notification to see the USB connection options.

Note: If the USB connection options do not appear, you can change the settings by touching

**Apps**  >  **Settings** > **Storage** > Menu  > **USB computer connection** > **Media device (MTP)**.

3. Touch an option:

- **Mass Storage:** Drag and drop files between your computer and memory card folders. When you're done, use "**Safely Remove Hardware**" before disconnecting the USB cable.
- **Media device (MTP):** Transfer media files between your phone and computer

Note: To transfer media files between your phone and a Mac, you will need to use Android File Transfer. For more information on Android file transfer see [www.android.com/filetransfer](http://www.android.com/filetransfer).

- **Camera (PTP):** Transfer photos using camera software, and transfer any files that do not support MTP.

Note: You can't use the files on your memory card with your phone while it is connected to the computer.

06/06/2012  
FCC

# Camera

---

Take Photos



Record Videos

View Photos & Videos


Edit Photos and Videos



## Take Photos

Take that family photo, and post it online for everyone to see.


1. Touch **Apps**  >  **Camera** or press and hold the camera button on the side of the phone. Rotate the phone counter-clockwise to view the camera screen.


SCREEN NOT YET AVAILABLE






**Note:** Photos can be stored either on an optional microSD memory card or in the phone's internal storage. Touch **Menu**  > **Settings** > **Storage Location** to set your default storage location.

2. To take the photo, touch the viewfinder to lock the focus, and then touch  or press the camera button to take the photo.
  - To send the photo in a message or post it online, and then touch .
  - To delete the photo, open it and then touch **Delete**.



## Photo Options

You can make adjustments to optimize your shot. Drag open the panel at the bottom left of the viewfinder (or touch **Menu** ):






-  **Settings:** Change **Widescreen**, **Volume Key Function**, **Geo-tag**, **Storage Location**, or **Shutter Tone**.

-  **Effects:** Change photo look: **Normal, Negative, Black and White**, and more.
-  **Scenes:** Adjust for better image capture in different environments: **Auto, Portrait, Landscape, Sport**, and more. Touch the screen when finished to return to the viewfinder.
-  **Modes:** Select **Single shot, Panorama, Multi-shot**, or **Timer**.
-  **Brightness:** Adjust for better image capture in different environments.
-  **Flash:** Set **Flash On, Flash Off**, or **Auto Flash**.

## Record Videos



1. Touch **Apps**  >  **Camera** and switch over to camcorder mode.





SCREEN NOT YET AVAILABLE

2. To record the video, touch . Touch  again to stop the recording.
3. Open your gallery and touch a video to view options:
  - To play the video, touch .
  - To send the video in a message or post it online, and then touch .
  - To delete the video, touch **Menu**  > **Delete**.

## Video Options

You can make adjustments to optimize your video. Drag open the panel at the bottom left of the viewfinder (or touch **Menu** 

-  **Settings:** Change **Video Resolution**, **Volume Key Function**, **Geo-tag**, **Storage Location**, or **Shutter Tone**.
-  **Effects:** Change video look: **Normal, Negative, Black and White**, and more.

-  **Audio Scenes:** Adjust for better audio capture in different environments.
-  **Modes:** Select **Normal video**, **Video Message**, **Time Lapse**.
-  **Brightness:** Adjust for better video capture in different environments.
-  **Light:** Turn a light on or off to adjust for the lighting where you are recording.

## View Photos & Videos

Using the Gallery application, you can view photos and watch videos that you've taken with your phone's camera, downloaded, or copied onto your storage card. You can also take a look at your photos and your friends' photos that are on your social networks (Facebook™ and Flickr only).


For photos that are on your phone or storage card, you can do basic editing such as rotating and cropping. You can also easily make a photo as your contact picture or wallpaper and share photos with your friends.

► Touch **Apps**  >  **Gallery**.

SCREEN NOT YET AVAILABLE




Touch a folder to display all of its photos or videos.

### Change Gallery Settings







1. While you're viewing a photo or video, touch **Menu**  > **More**.
2. Choose from these options:
  - **Slideshow:** Play a slideshow.
  - **Edit:** Edit the picture.
  - **Rotate left:** Rotate the picture to the left
  - **Rotate right:** Rotate the picture to the right.
  - **Crop:** Crop the picture

- **Set picture as:** Set the picture as a **Contact photo** or **Wallpaper**.
- **Details:** View more info about the picture or video.
- **Print:** Print the picture.

## Share Photos and Videos

1. Touch **Apps**  >  **Gallery**.
2. Touch a photo or video, and then touch .
3. Choose how you want to share—like Bluetooth, Email, Messaging, or an online album.

## Manage Photos and Videos

1. Touch **Apps**  >  **Gallery**.
2. Touch a thumbnail image from your camera roll or library, and then:
  - To delete the photo or video, touch **Menu**  > **Delete**, or touch [Trash Icon].
  - To set the photo as a contact picture or wallpaper, touch **Menu**  > **Set as**.
  - Touch  to share it.
  - Touch **Menu**  for more options.

**Tip:** To copy photos to/from a computer, go to [Connect Your Phone to Your Computer](#).

## Edit Photos and Videos

- ▶ Touch **Apps**  >  **Gallery** > *picture* > **Menu**  > **Edit**.

You can choose advanced editing features to resize, crop, change the color, and more.



# Sprint Basics

---

Voice

Accounts and Messaging

Roaming

## Voice

### Visual Voice


Visual Voice gives you a quick and easy way to access your voice. Now you can find exactly the message you are looking for without having to listen to every voice message first. This new feature periodically goes out to your voice, and gathers the caller information from the current voice messages. It then creates a list with the caller name and number, along with the length of time and priority level of the voice message.

#### Setting up Visual Voice

To set up voice, see [Set Up Voice](#).



#### Reviewing Visual Voice

Visual Voice lets you easily access and select which messages you want to review.

1. Touch **Apps**  >  **Voice**
2. Touch a message to review it.

**Note:** Touch **Menu**  > **Lock** to prevent the message from accidentally being deleted.

Featured available while reviewing messages include:

- **Timeline:** Provides a visual timeline for the current message. Touch and drag the bar to move to different points in the message.
  - Touch  **Pause** to pause the playback. Touch  **Play** to resume.
- **Call:** Call the person who left the voice message.
- **Reply:** Reply to the message. You can then reply to the sender or forward the message to anyone with an email account or phone number. This allows you to send a voice message to several recipients at the same time. You can tag the reply message for both Urgency and Privacy.
  - Touch **Send** to deliver the new message.

- **Speaker Off/On:** Turn the speakerphone on or off during playback. If the speakerphone feature was enabled within the Voicemail settings menu, the speakerphone will always be automatically enabled during voicemail playback.
- **Delete:** Delete the current voicemail message.

### *Listen to Multiple Voicemail Messages*



When you are done listening to a voicemail message, you can easily listen to other messages without returning to the main voicemail screen.

- ▶ After listening to a voicemail, flick the screen left or right to move to the previous or next message. (It will begin playing automatically.)



You can navigate through voicemail messages as frequently as you like. You can even move to the next or previous message before you are finished listening to the current one.

### *Configuring Visual Voicemail*

*To access the voicemail options:*

1. Touch **Apps**  > **Voicemail**.
2. Touch **Menu**  and select from the following:
  - **Compose** to compose a new voicemail message.
  - **Move to SD** to move voicemails to your microSD card.
  - **Play all new** to listen to all new messages.
  - **Undelivered** to list all undelivered voicemail messages.
  - **Delete** to delete selected messages from your current list of available voicemail messages.
  - **Search** to search through voicemail messages for keywords.
  - **Settings** to configure your voicemail application settings.




*To access a voicemail messages options:*

1. Touch **Apps**  > **Voicemail**.
2. Touch a voicemail message, touch **Menu**  and select from the following:
  - **Lock/Unlock** to prevent deletion of the selected voicemail message.
  - **Text message** to create and deliver a new text message to the sender's phone number.

- **Reply** to reply to the voicemail. You can reply to the sender or forward it to anyone with an email account or phone number. This allows you to send this voicemail message to several recipients at the same time.
- **Forward** to forward the voicemail to another recipient.
- **Add to contacts** to add the sender's phone number to People.




### *Configuring Visual Voicemail Settings*

The visual voicemail settings menu lets you access settings for notifications, pictures, greetings, and more.

1. Touch **Apps**  >  **Voicemail**.
2. Touch Menu  > **Settings** and select from the following:
  - Touch **Notifications** to determine how you are notified of new voicemails. Choose from: **Notifications**, **Select ringtone**, and **Vibrate**.
  - Touch **Pictures** to replace the default Visual Voicemail icon with a specific People entry's image. This image is pulled from the entry's People details.
  - Touch **Speakerphone** to automatically activate the speakerphone when you review your Visual Voicemail.
  - Touch **Personalize voicemail** to adjust your voicemail greeting.
  - Touch **Display name** to enter a name or a number that is attached to your outgoing voicemails as part of an identification string.
  - Touch **Check for update** to search for an upgrade to your visual message software.
  - Touch **About Voicemail** to view information about the Visual Voicemail application, such as the version.




### *Automatically Enable the Speakerphone*

Every time you access a message from your Visual Voicemail list, you can configure your phone to automatically turn on the speakerphone so you can clearly hear the message.



1. Touch **Apps**  >  **Voicemail**.
2. Touch Menu  > **Settings** > **Speakerphone** to activate the feature. You will see a light blue check mark on the right.
  - ▶ To deactivate the speakerphone, touch **Speakerphone** again. The checkmark will disappear.

### *Changing your Main Greeting via the Voicemail Menu*

Your main greeting can be changed directly via the Visual Voicemail system, This direct access saves you from having to navigate within the voicemail menu.

1. Touch **Apps**  >  **Voicemail**.
2. Touch **Menu**  > **Settings** > **Personalize voicemail**.
3. Touch **OK** to connect to the Sprint voicemail system. Follow the prompts to change your current greeting.

### *Edit the From Name via the Voicemail Menu*

1. Touch **Apps**  > **Voicemail**.
2. Touch **Menu**  > **Settings** > **Display name**.
3. Touch the existing identification field and enter a new identifying name or number (used to identify you to recipients of your voice messages)
4. Touch **OK** to save your information.

## **Traditional Voicemail**




### *Set Up Your Voicemail*


To set up voicemail, see [Set Up Voicemail](#).

### *Voicemail Notification*

When you have a new voicemail,  shows at the top of your screen.



### *Retrieve Your Voicemail Messages*

When you have a new voicemail,  shows at the top of your screen. To hear the message, touch  **Phone** to open the dial screen, and then touch and hold .

If you need to change your voicemail number, in the home screen, touch **Menu**  > **Settings** > **Call settings** > **Voicemail settings**.

## **Accounts**

### *Setting Up Accounts*

- ▶ To add other messaging accounts, touch **Apps**  >  **Settings** > **Accounts & sync** > **Add account**.
  - Corporate Sync is for Exchange server work email accounts. Enter details from your IT administrator.

**Tip:** You might need to enter your domain name with your user name (like domain/username).

- Email is for most personal email accounts. For account details, contact the account provider.

## *Gmail™ and Google™*

You will need a Google account to access several phone features such as Gmail, Google Maps™, Google Talk™, and Google Play Store™ apps. Before you can use Google apps, you need to enter your account information. These apps sync between your phone and your online Google account.



### *Create a Google Account*

If you do not already have a Google account, you can create one online or using your phone.



#### Create a Google Account Online

1. On your computer, launch a browser and go to [google.com](http://google.com).
2. Click **Sign in** > **Create an account now** and follow the instructions to create your free account.
3. Check your email for a message from Google confirming your account. Respond to the email to activate your account.





#### Create a Google Account Using Your Phone

1. Touch **Apps**  >  **Settings** > **Accounts** > **Add account**.
2. Touch **Google** > **Next** > **Create**.
3. Enter your information, and then touch **Next**.
4. When prompted, enter and reenter your password.
5. Create a security question and answer, enter a secondary email address to help you recover your password if you ever lose it, and then touch **Create**.
6. Follow the prompts to read and accept the Google terms of service.
7. After your phone connects with Google servers, select the items you want to sync with your phone, and then touch **Sync Now**.
8. Touch **Finish setup**, and your phone will sync with the Google servers.





#### *Sign In To Your Google Account*

1. Touch **Apps**  >  **Settings** > **Accounts** > **Add account**.
2. Touch **Google** > **Next** > **Sign in**.
3. Enter your Google password, and then touch **Sign in**.
4. After your phone connects with Google servers, select the items you want to sync with your phone, and then touch **Sync Now**.
5. Touch **Finish setup** and your phone will synchronize the selected items.

## Access Gmail

- ▶ Touch **Apps**  >  **Gmail**.
- **To view more email messages:** If the inbox is full, swipe your finger up the screen to view more messages and conversations.
- **Read a new email message:** Touch the unread message or the conversation with an unread message (just-arrived items display in bold).
- **Select messages and conversations:** Touch the box before the email or conversation.
- **View the Inbox of your other Gmail account:** Touch Menu  > **Settings** > **Accounts** and then touch the account that you want.
- **Refresh the inbox:** Touch Menu  > **Refresh**.

## Send a Gmail Message

1. Touch **Apps**  >  **Gmail**.
2. Touch .
3. Enter the message recipient's email address in the **To** field. If you are sending the email message to several recipients, separate the email addresses with a comma. As you enter email addresses, any matching addresses from your contacts list are displayed. Touch a match to enter that address directly.
4. Enter the email subject, and then compose your email.
5. After composing your message, touch .



## Read and Reply to Gmail Messages

1. Touch **Apps**  >  **Gmail**.
2. Touch a message.
  - To **Reply** or **Reply to all**, touch  or Menu  > **Reply all**, and enter an additional message.
  - To **Forward** a message, Touch Menu  > **Forward**, enter or select recipients, and then enter an additional message.
3. After composing your message, touch .



## Email

Use the Email app to send and receive email from your webmail or other accounts, using POP3 or IMAP. You can also access your Corporate Sync email and other features on your phone.

### Add an Email Account (POP or IMAP)

1. Touch **Apps**  >  **Accounts** > **Add an Account** > **Email**.
2. Enter your existing email account address and password.
3. Select **Automatically configure account**.  
—or—  
De-select **Automatically configure account** to enter server settings manually.
4. Touch **Next** to enter account settings:
  - **General Settings:** Enter your account name, real name, and email address.
  - **Incoming server:** Enter your POP or IMAP incoming server information.
  - **Outgoing server:** Enter your SMTP server information.
5. Touch **OK** to set up your account.

### Add a Corporate Sync Account

1. Touch **Apps**  >  **Settings** > **Accounts** > **Add account**.
2. Touch **Corporate Sync**.
3. Enter the Corporate Sync account details and then touch **Next**.
4. Select the type of information you want to synchronize and touch **Finish setup**.

### Compose and Send Email

Compose and send email using any account you have set up on your phone. Increase your productivity by attaching files such as pictures, videos, or documents to your email messages.




1. Touch **Apps**  >  **Email**.
2. Touch .
3. Enter an address or select a contact.
4. Enter a subject, and then compose your message.
5. To add an attachment, touch .
6. Touch the **Send** to send the message immediately, or Menu  > **Save draft** to send it later.

### View and Reply to Email

1. Touch **Apps**  >  **Email**.


2. Touch the message you want to view.
3. Touch the Reply/Forward icon and select **Reply** or **Reply all**.

### Manage Your Email Inbox


1. Touch **Apps**  >  **Email**.
2. Touch the message account you want to view.
3. For a single message account, touch  to switch to your **Trash**, **Outbox**, or **Sent**, or folders.

### Refresh an Email Account

Whatever your automatic synchronization settings are, you can synchronize your email messages manually at any time.

- ▶ While in the account you want to synchronize, Touch .

### Delete Email Messages



1. Touch a message or messages that you want to delete.
2. Touch Menu  > **Delete**.

### Edit Email Account Settings

You can edit settings for your individual email accounts, such as email address and password, name display and signature, frequency of retrieval, and more.

- ▶ Touch **Apps**  >  **Email** > .

### Delete an Email Account

1. Touch **Apps**  >  **Settings** > **Accounts** and select the account you want to delete.
2. Touch **Remove account** to delete it from your phone.

## *Text Messages and MMS*

With Text Messaging (SMS), you can send and receive instant text messages between your wireless phone and another messaging-ready phone.

Multimedia messages, or MMS, can contain text and pictures, recorded voice, audio or video files, picture slideshows, contact cards (vCard), or appointments (vCalendar).

See your service plan for applicable charges for messaging.

### *Compose Text Messages*

Compose and send text messages.

1. Touch **Apps**  >  **Messages** > .



2. Enter one or more recipients:

- Enter phone numbers directly in the To field. If you're sending the message to several phone numbers, separate the phone numbers with a comma. As you enter information, any matching phone numbers from your contacts list are displayed. Touch a match to enter that number or address directly.
- Enter a contact from your list by beginning to type the contact's name. Touch the name to enter it.

3. Touch the **Compose message** field to begin entering your message.

4. Touch the **Send** icon to send the message.

### Send a Multimedia Message (MMS)

1. Touch **Apps**  >  **Messages** > .

2. Enter one or more recipients:

- Enter phone numbers directly in the **To** field. If you're sending the message to several phone numbers, separate the phone numbers with a comma. As you enter information, any matching phone numbers from your contacts list are displayed. Touch a match to enter that number or address directly.
- Enter a contact from your list by beginning to type the contact's name. Touch the name to enter it.

3. Touch the **Compose message** field to begin entering your message.

4. Touch  and select an item to insert.

**Tip:** To send and receive large attachments faster, use Wi-Fi. See [Wi-Fi Search and Connect](#).

5. Touch the **Send** to send the message.

### Save and Resume a Draft Message

Any message that you do not send is automatically saved as a draft unless you delete it.

To resume composing the message:

1. In the **Text Messaging** screen, touch the message that you want to resume editing.
2. When you are finished, touch the **Send** icon.

### New Messages Notification

Depending on your notification settings, the phone plays a ringtone, vibrates, or displays an icon in the status bar when you receive a new text or multimedia message. To change the notification for new text and multimedia messages, see [Text and MMS Options](#) for details.

To open the message, slide the status bar down to open the Notifications panel. Tap the new message to open and read it.

### Text and MMS Options

► Touch **Apps**  >  **Messages** > Menu  > **Settings** for options.

#### ▪ **General Settings**

- **Message limit:** Choose the maximum number of text messages to store in each conversation thread. (This does not include locked messages.)
- **Display suggestions:** Show suggestions while composing messages.
- **Group message type:** Choose whether group messages will be Group conversations, where everyone can reply to all, or if they will be individual conversations.
- **Send location cards:** Uses MMS messaging when inserting a location.
- **Message signature:** Include a signature at the end of every message.
- **Edit signature:** Edit your message signature.
- **Clear search history:** Clears your search history.
- **Creation mode restricted:** Avoid sending attachments that may not be supported by the receiving device.

#### ▪ **Notification Settings**

- **Notifications:** Set the phone to display message notifications in the status bar.
- **Select ringtone:** Select a ringtone for message notifications.
- **Vibrate:** Set the phone to vibrate when a new text or multimedia message arrives.

### *Google Talk™*

To send and receive instant messages, your phone comes preloaded with Google Talk™.

You can also download an instant messaging app from the Google Play Store™: touch **Apps**


 >  **Play Store** > **Apps** > **Communication**, and then choose an app for your provider.

Once you download the app, you'll see it in the app menu. See [App Menu](#).

**Note:** Your IM options will depend on your IM provider. To browse instant messaging apps from your computer, go to [android.com/market](http://android.com/market).



# Roaming

## Roaming Icon

Your phone lets you know when you're off the Nationwide Sprint Network. Anytime you are roaming, the phone shows the roaming icon (  ).

## Setting Roam Mode



Control your roaming capabilities.

- ▶ Touch **Apps**  >  **Settings** > **More...** > **Mobile networks**, and then make selections under **CDMA Roaming Settings**

## Call Guard

Your phone has two ways of alerting you when you are roaming off the Nationwide Sprint Network: the onscreen roaming icon and Call Guard. Call Guard requires an extra step before you can place or answer a roaming call. (This extra step is not required when you make or receive calls on the Nationwide Sprint Network.)

*To turn Call Guard on or off:*

1. Touch **Apps**  >  **Settings** > **More...** > **Mobile networks** > **Roaming Guards**.
2. Check or uncheck **Call Guard** under **Domestic Roaming** and **International Roaming**.

**Note:** Call Guard is turned on by default on your phone.

**Note:** Voice dialing is not available when you are roaming with Call Guard enabled.



**Note:** If the Call Guard feature is set to **On**, you need to take extra steps to make and receive roaming calls.

## Data Roam Guard

Depending on service availability and roaming agreements, your phone may be able to access data services while roaming on certain digital systems. You can set your phone to alert you when you are roaming off the Nationwide Sprint Network and try to use data services such as messaging.

**Note:** Data Roam Guard is turned on by default on your phone.

*To set your Data Roam Guard notification:*

1. Touch **Apps**  >  **Settings** > **More...** > **Mobile networks** > **Roaming Guards**.
2. Check or uncheck **Data Guard** under **Domestic Roaming** and **International Roaming**.

To use data services when Data Roam Guard is active:

- ▶ When a notification appears informing you that data roam charges may apply, touch **Roam** to connect.



# Apps and Entertainment

---

Google Play Store™

Download Apps from the Web

Navigation


Google Play Music

## Google Play Store™





The Google Play Store is the place to go to find new apps for your phone. Choose from a wide variety of free and paid apps ranging from productivity apps to games. When you find an app you want, you can easily download and install it on your phone.

**Note:** You must first connect to the Internet using your phone's Wi-Fi, Sprint 4G, or data connection and you must set up a Google™ account (see [Set Up Your Phone](#)) in order to buy and download apps from the Google Play™ Store.

► Touch **Apps**  >  **Play Store**.

Get all the fun games and cool apps you want. The Google Play Store provides access to applications created by developers worldwide, so you can find the app you want. If you need help or have questions about the Google Play Store, touch Menu  > **Help**.

### Find and Install Apps

1. Touch **Apps**  >  **Play Store**.
2. When you open the Google Play Store for the first time, you must agree to the terms of service. Touch **Accept** to continue.
3. To browse:
  - **Featured apps:** Scroll through the list of featured apps when you open the Google Play Store.
  - **Categories:** Touch **Apps** or **Games**, and then touch a category. Under a category, you can filter the apps by **Top paid**, **Top free**, or **Just in**.
  - **Apps recommended by Sprint:** Touch **Sprint**, and then scroll through the list.
  - **Search by name:** Touch  **Search** on the Google Play Store home screen, enter the name or type of app you're looking for, and then touch  **Search** to the right of the search box.

4. Touch the app you want to install. Then, touch **FREE** (if app is free) or touch the price.
5. If an app you are downloading requires access to your data or control of functions on your phone, you'll be asked to give your permission. After selecting **FREE**, the app will download. After touching the price, you may be asked to sign in to an additional Google™ account. Sign in and select **Purchase now** to proceed. Follow the on-screen instructions. To see the download progress, open the notifications window.

After you download an app, the icon for that app appears on the App menu. (See [App Menu](#).)

## Create a Google Checkout™ Account


You need a Google Checkout account to purchase items from the Google Play Store.

- ▶ On your computer, go to [checkout.google.com](http://checkout.google.com) to create a Google Checkout account.  
—or—
- ▶ The first time you use your phone to buy an item from the Google Play Store, you're prompted to enter your billing information to set up a Google Checkout account.


## Request a Refund for a Paid App

If you are not satisfied with an application, you can ask for a refund within 24 hours of the purchase. Your credit card is not charged and the application is uninstalled from your phone.

If you change your mind, you can install the application again, but you can't request a refund a second time.


1. Touch Menu  > **Manage apps** > **Downloaded**.
2. Touch the application to uninstall.
3. Touch **Uninstall & refund**. Your application is uninstalled and the charge is cancelled.
4. Touch the reason for removing the app, and then touch **OK**.




## Manage or Remove Apps

1. Touch Menu  > **Manage apps**.
2. Touch an app in the list, and then touch **Uninstall** (for apps you downloaded), **Clear cache**, or other options.

**Note:** To reinstall any downloaded items, touch **Apps**  >  **Play Store**.





## Download Apps from the Web

**Warning:** Apps downloaded from unknown sources can include spyware, phishing, or viruses that affect your phone, phone performance, and personal data. For security, download apps only from trusted sites, like  **Play Store**.

1. To download apps from any Web page, touch **Apps**  >  **Settings** > **Applications** > **Unknown sources**.
2. To launch the browser, touch  **Browser**.
3. Find the app you want to download and touch the download link.

**Note:** Downloaded apps are stored in your phone's memory.

## Manage Your Downloads

- ▶ To view files or apps you've downloaded, touch  **Browser**, touch Menu  > **More** > **Downloads**.
- ▶ To clear your download history, touch Menu  > **Clear list**. To cancel, touch Menu  > **Cancel all downloads**.

## Navigation


Your phone offers a number of location-based navigation programs to help you figure out where you are and get you where you're going.

### Google Maps™

- ▶ Touch **Apps**  >  **Maps**.

Google Maps offers powerful, user-friendly mapping technology and local business information—including business locations, contact information, and driving directions.



For help, touch Menu  > **More** > **Help**.

**Note:** Want to know what's in your immediate area? Try Google Places™. Touch **Apps**  >  **Places** to see listings for **Restaurants**, **ATMs**, **Gas Stations**, and more based on your current location.



SCREEN NOT YET AVAILABLE

## Set Your Location Sources

Set your phone to determine your location using GPS satellite signals (highly accurate, but uses battery power) or using the mobile network (less accurate, but conserves battery power).

- ▶ To set your location source, touch **Apps**  > **Settings**  > **Location & security** > **Use GPS satellites** and/or **Use wireless networks**.





## Find Any Location

1. Touch Menu  > **Search**.
2. Enter text in the search box, like an address, business, or city, and then touch  **Search**.



**Tip:** If it's an address you have visited before, select from the list shown.

3. Touch the location you're searching for in the results list.

## Get Directions


1. Touch Menu  > **Directions**.
2. Enter a starting point address or touch  **Bookmark** and select **My current location**, **Contacts**, or **Point on map**.
3. Enter an end point address, or touch  **Bookmark** and select **Contacts** or **Points on map**.
4. Select your mode of transport (car, public transport or walk), and then touch **Go**. Your directions are shown as a list. To view your directions on a map, touch **Show on map**. To have your phone provide turn by turn driving directions, touch **Navigate**.
5. When you have finished, touch  **Layers** > **Clear map**.

## Select Map Mode

- ▶ Touch  **Layers** to select from **Map** (standard map view), **Satellite** (map with photos), **Traffic** (map with traffic conditions).
  - Touch  **Layers** > **Clear Map** to clear your selections.

## Google Latitude™

See where your friends and family are on Google Maps™. Plan to meet up, check that your parents got home safely, or just stay in touch.



Don't worry, your location is not shared unless you agree to it. You need to join Google Latitude, and then invite your friends to view your location or accept their invitations. When using Google Maps, touch Menu  > **Join Latitude**. Read the privacy policy and if you agree with it, touch **Agree & Share**.



## Adding and Removing Friends



- ▶ Touch **Apps**  >  **Latitude**.

To add friends:

1. Touch **Menu**  > **Add friends** or touch .
2. Touch **Select from Contacts**, and then touch a contact. Or, touch **Add via email address**, and then enter an email address.
3. Touch **Yes**.

If your friends already use Google Latitude, they'll receive an email request and a notification. If they have not yet joined Google Latitude, they'll receive an email request that invites them to sign in to Google Latitude with their Google account.

To remove friends:



1. Touch **Menu**  > **Latitude** to show your friends list, and then touch a friend in your list.
2. Touch  **Delete**.

## Sharing Location



When you receive a request to share location details you can choose to:

- **Accept and share back:** See your friend's location, and your friend can see yours.
- **Accept, but hide my location:** See your friend's location, but they can't see yours.
- **Don't accept:** Location information is not shared between you and your friend.

## Hiding Your Location

- ▶ To hide your location from a friend, touch **Menu**  > **Latitude** to show your friends list. Touch your contact name, and then touch **Menu**  > **Edit privacy settings** > **Hide your location**.

## Turning Off Google Latitude






- ▶ Touch **Menu**  > **Latitude** to show your friends list. Touch **Menu**  > **Edit privacy settings** > **Sign out of Latitude**.

## Google Play Music

Listen and create playlists anytime with music on your phone.

- ▶ Touch **Apps**  >  **Play Music**.

## SCREEN NOT YET AVAILABLE

- **Go back:** When you open a song or artist list, touch  in the top left to go back.
- **Shuffle or repeat:** During a song, touch  to show shuffle  and repeat  at the bottom. Touch  once to repeat the current song list, or twice to repeat only the current song.
- **Volume:** Press the volume keys.

### Get Music

**Note:** Copyright – do you have the right? Always follow the rules. See [Content Copyright](#).

#### *Transferring Music from a Windows Computer*

1. Using a USB cable, connect your phone to your computer.
2. Flick down the status bar, and make sure that your phone's USB connection is set to **Media device (MTP)**.

**Note:** If the USB connection options do not appear, you can change the settings by touching

**Apps**  >  **Settings** > **Storage** > Menu  > **USB computer connection** > **Media device (MTP)**.

3. Your phone's internal storage or microSD card will appear on your computer as a drive. You can now copy music files on to your phone's storage as you would to any other drive.
4. When finished, disconnect your phone from your computer.

## Transferring Music from a Macintosh Computer


**Note:** Mac OS does not natively support Media device (MTP) file transfer. To transfer media files between your phone and a Mac, you will need to use Android File Transfer. For more information on Android file transfer see [www.android.com/filetransfer](http://www.android.com/filetransfer).

1. Install Android File Transfer, and then open it.

**Note:** Once you have used Android File Transfer for the first time, you will no longer need to open it before connecting your phone. It will open automatically when you connect your phone to your computer.

2. Using a USB cable, connect your phone to your computer.
3. A window displaying the contents of your phone appears. You can then copy music files on to your phone.
4. When finished, disconnect your phone from your computer.

## Tips and Tricks

- **Hide the music player:** To use another app while your music plays, touch Home . To return to the music player, flick down the status bar and touch the song title.

**Tip:** Control music playback from the home screen by adding the **Google Play Music** widget.

- **Playlists:** Touch and hold a song in your library to add it to a playlist or show other options. To edit, delete, and rename a playlist, touch and hold its name in the music library.
- **Help:** to get help or access your Google Play Music with a computer visit [www.google.com/music](http://www.google.com/music).

# Web and Data

---

Wi-Fi

Wi-Fi Hotspot

Browser

YouTube™

## Wi-Fi

Wi-Fi provides wireless Internet access over distances of up to 300 feet. To use your phone's Wi-Fi, you need access to a wireless access point or "hotspot."


The availability and range of the Wi-Fi signal depends on a number of factors, including infrastructure and other objects through which the signal passes.

To use a Wi-Fi computer network for even faster Internet access:

- ▶ Touch **Apps**  >  **Settings** > **Wi-Fi**.

SCREEN NOT YET AVAILABLE

## Turn Wi-Fi On or Off

- ▶ Touch **Apps**  >  **Settings** > **Wi-Fi**. Drag the Wi-Fi power switch to the right to turn it on, drag it to the left to turn it off.

**Note:** To extend battery life, turn off Wi-Fi power when not in use.


## Wi-Fi Search and Connect

To find networks in your range

1. Touch **Apps**  >  **Settings** > **Wi-Fi**.

2. Turn Wi-Fi to scan. If Wi-Fi is already on, touch **Scan**. Your phone lists the networks it finds within range.

**Tip:** To see your phone's MAC address or other Wi-Fi details, touch Menu  > **Advanced**.

3. Touch a network to connect.
4. If necessary, enter **Network SSID**, **Security**, and **Wireless password**, and touch **Connect**. When your phone is connected to the network, the wireless indicator  appears in the status bar.

**Tip:** When you are in range and Wi-Fi is on, you will automatically reconnect to available networks you've connected to before.

## Wi-Fi Modes

For those who like to get a bit more technical, your phone supports the following Wi-Fi modes: 802.11 b, g, n.

## Wi-Fi Hotspot

You can set up your phone as a Wi-Fi hotspot to provide portable, convenient internet access for up to 5 other Wi-Fi enabled devices.

**Note:** You need to subscribe to Wi-Fi hotspot service to use this feature. Contact Sprint for details.

**Note:** You cannot use a Wi-Fi hotspot when your phone is roaming.

## Setting up the Hotspot

**Note:** Risks can be associated with connecting to the public internet. Your phone allows you to create a 3G Mobile Hotspot, which may be accessible by unauthorized users. It is highly recommended that you use a password other possible steps to protect your computer from unauthorized access.

To add security to your Wi-Fi hotspot:

1. Touch **Apps**  >  **Settings** > **Tethering & Mobile Hotspot** > **Mobile Hotspot settings** > **Configure Mobile Hotspot** if you have already turned it on.
2. Touch a setting to modify it:
  - **SSID:** Enter a unique name for your hotspot.
  - **Security:** Select the type of security you want, and touch **Save: WEP, WPA, or WPA2**. Enter a unique Wireless password. Other users can access your Wi-Fi hotspot only if they enter the correct password.

**Note:** **WEP** is the weakest option because it is highly vulnerable to hacking. **WPA2** is recommended by IEEE.

- **Channel:** Select a channel that minimizes potential interference. You may need to try different channels after your hotspot is active for a time.



3. Touch **Save** when the settings are complete.

## Activating the Hotspot

- ▶ Touch **Apps**  >  **Settings** > **Tethering & Mobile Hotspot** > **Mobile Hotspot**.

When your Wi-Fi hotspot is active, other Wi-Fi enabled devices can connect by entering your hotspot's **SSID**, selecting a **Security** type, and entering the correct **Wireless password**.

## Browser

- ▶ To open the browser, touch **Apps**  >  **Browser**.
- ▶ To go to a Web page, touch the URL area to enter a Web address.

## Your Browser

Web pages look like the following example:

SCREEN NOT YET AVAILABLE

**Note:** If you can't connect, contact Sprint.

## Connect

Your phone uses the mobile phone network (over the air) or a Wi-Fi connection to automatically access the Web.

To use a Wi-Fi connection, touch **Apps**  >  **Settings** > **Wi-Fi**, and drag the power switch to the left to turn on and search for nearby wireless networks. Touch a network to connect.

## Select Links

When you touch a link, your phone outlines it and goes to that page. If you touch and hold the link, your phone shows options, such as **Open in new window** or **Bookmark link**.

## See Options

Touch Menu  with the browser open to see these options:

Options	
Refresh	Reload the current page.
Back/Forward	Navigate to previously viewed pages.
Homepage	View the browser windows that are currently open.
Bookmarks	See your bookmarks.
Back/Forward	Navigate to previously viewed pages.
Save to bookmarks	Bookmark the current webpage.
Share page	Share page via Bluetooth, Email, and more.
Find on page	Find a word or phrase on current website.
Request desktop site	Open the standard desktop website instead of the mobile version.
Save for offline reading	Save current webpage for offline viewing.
Settings	Open page and privacy settings.
Print	Print the current webpage.
Exit	Close the browser app.

## Go to a Specific Website

To enter a URL (Web address):

1. Touch the URL field at the top of the browser screen.
2. Use the keyboard to type the address. If the website you want appears within the suggested sites list, tap the entry to begin surfing.
3. Press Enter.

## Adjust Browser Settings

You can change the page settings for your browser, including default zoom level, pop-up blocking, display options, setting your home page, and more.

1. Touch  **Browser** > Menu  > **More** > **Settings**.

2. Choose from these options:

- **General:** Set the homepage and auto-fill setting.
- **Privacy & security:** Manage the browser's privacy and security settings..
- **Accessibility:** Set browser accessibility features such as text size and zoom.
- **Advanced:** Manage advanced browser features such as blocking pop-ups and default zoom.
- **Bandwidth management:** Set how your browser manages images and search result preloading.
- **Labs:** Set up **Quick controls** and **Fullscreen** mode..



## YouTube™

Share videos with YouTube users everywhere. You don't need a YouTube account to browse and view videos.

► Touch **Apps**  >  **YouTube**.

**Note:** If you want a YouTube account, go to [youtube.com](https://youtube.com).

To sign in to your YouTube account:

1. Touch **Apps**  >  **YouTube** > **Accounts** > **Add account**.
2. Touch your Google Account or touch **Add account** to enter your information.



# Sprint Worldwide Wireless Service

---

Getting started with Sprint Worldwide Service

Activating Global Roaming Mode

Making and Receiving Worldwide Calls

Sprint Voicemail Service

International Data Roaming

International Data Roaming

Contacting Sprint

## Getting started with Sprint Worldwide Service

Before using your device in global roaming mode, you must activate Sprint Worldwide Service.



To activate Sprint Worldwide service:

- ▶ Chat with or email an international support rep by visiting [www.sprint.com/international](http://www.sprint.com/international) and clicking the Chat with us or Email us link on the right side of the screen.
- ▶ Call Sprint Worldwide customer support at **1-888-226-7212, option 2.**

## Activating Global Roaming Mode

Your phone is designed to enter global roaming mode automatically when you activate your Sprint Worldwide service, meaning that it should automatically connect to an appropriate CDMA network or GSM/UMTS network when you travel. You may also set global roaming options through the settings menu.

To set your global roaming options manually:

- ▶ Touch **Apps**  > **Settings**  > **More...** > **Mobile networks** > **Network Mode**.
  - To allow connections to the Nationwide Sprint Network only, touch **Sprint Only**.
  - To allow connections to CDMS networks only, touch **Any CDMA**.
  - To allow connections to GSM or UMTS networks only, touch **Any GSM/UMTS**.
  - To allow connections to available CDMA or GSM/UMTS networks, touch **Automatic**. (This is the recommended setting.)

## Making and Receiving Worldwide Calls

When travelling on international networks, you can place and answer calls as you would on the Sprint network (see [Make Phone Calls](#) and [Receive Phone Calls](#)), although some additional instructions may be required to place a call. Some features and services are not available in all countries. For more information on services that are available while roaming, visit [www.sprint.com/sww](http://www.sprint.com/sww).



### Making Calls Using Plus (+) Code Dialing

Placing calls from one country to another country is simple with the Plus (+) Code Dialing feature. When placing international calls, you can use Plus Code Dialing to enter the appropriate international access code for your location (for example, 011 for international calls placed from the United States).

**Note:** Plus Code Dialing is only available when roaming internationally on GSM networks and on certain CDMA networks in the United States, Canada, and the Caribbean.

International access codes and dialing information are available online at [www.sprint.com/sww](http://www.sprint.com/sww).

*To use Plus Code Dialing to place an international call:*

1. Touch  **Phone** to display the phone dial screen.
2. If you are on the GSM network, touch and hold  on the dialpad to insert a “+” on the phone dial screen. (The “+” symbol automatically inserts the international access code for the country from which you are calling.)
3. If you are on the CDMA network outside of Canada or the Caribbean, enter the international access code for the country from which you are calling.
4. Enter the US country code, and then enter the area code and number.
5. Touch [Call] to place the call.

### Sprint Voicemail Service

Your Sprint voicemail will follow you as you travel. All of your unanswered calls will be forwarded to your Sprint voicemail. You will need to be sure your voicemail box is already set up and that you know your voicemail password.

**Note:** In India, Sprint voicemail is not available while roaming on the GS network; it does work with the CDMA network.

### Setting Up Your Voicemail Access Number

To simplify accessing your Sprint Voicemail while traveling, you can set up your voicemail access number as a People entry. This will make it faster and easier to access your messages while roaming internationally.

1. Touch  **People** > . Type the contact information (for example “Voicemail”).

2. Touch and hold **0\*** and then touch **1**, your area code, and your wireless phone number.
3. Touch **Save**.

## Accessing Your Voicemail

### New Message Indicators




Your voicemail message indicators may be displayed differently when roaming internationally.

- A “Message Waiting” indicator icon or a text message is displayed when a voicemail message is received.
- You may see “Missed Call” on your screen prior to receiving a message notification.
- You must call voicemail in order to retrieve messages. Follow the instructions on the previous page to store your voicemail number for easy access.

### Retrieving Voicemail Messages

The voicemail retrieval process while travelling is the same as on the Sprint Network; however, you will be required to enter your voicemail password.

#### To retrieve your voicemail messages:

1. Touch  **People**, touch the voicemail entry and then touch the number to call it.
2. When your voicemail answers, touch , enter the password and press  to access your voicemail.

### Voicemail Troubleshooting

Please keep the following tips in mind when using Sprint voicemail while traveling:

- Some carriers may not support voicemail indicators. It may be necessary to call your voicemail to see if you have any new messages.
- If you hear the message “Please enter the number of the subscriber you wish to call,” enter your 10-digit wireless phone number.

## International Data Roaming

Sprint Worldwide Wireless Service can also keep you connected via email and Web browsing when travelling in countries in which Sprint offers data service. Data services are available on both CDMA and GSM/UMTS networks; check [www.sprint.com/sww](http://www.sprint.com/sww) to determine the services available where you are travelling.

**Note:** Prior to using your Sprint Worldwide GSM/UMTS Data Services, you must establish and utilize your CDMA data services domestically on the Sprint Network.

## Getting Started with Data Services

To use Sprint Worldwide Data Services, you will need to have these services activated on your account.



- ▶ To activate, call Sprint Worldwide Customer Support at **1-888-226-7212, option 2**. Representatives are available 24 hours a day, 7 days a week to assist you.

Once your services are activated, you may need to select a GSM data services provider for the country you are in.

## Accessing Your Email and Data Services on GSM/UMTS Networks

To access your email and browse the Web when travelling, you may need to manually select the carrier that provides Sprint service in your location. You can find a list of carriers for each country where GSM data service is offered at [www.sprint.com/sww](http://www.sprint.com/sww). Then, follow the instructions below to select the appropriate carrier network on your phone.

*To select a GSM data service for a specific country:*

1. Touch **Apps**  >  **Settings** > **More...** > **Mobile networks**.
2. Touch **Network Mode**, and select **Any GSM/UMTS**.
3. Under **GSM/UMTS Settings**, touch **Select Network** and select a wireless network that supports Sprint International GSM Data Roaming.

**Note:** Be sure you have the **Allow GSM Data** option checked.

## Accessing Your Email and Data Services on CDMA Networks

If data service is available on a CDMA network, then you only need to set the phone to CDMA; you will not need to select the specific carrier. Selecting a specific carrier is only necessary for providers on the GSM network. If your device has automatically selected a GSM network while travelling, then you will need to set the phone to CDMA to access CDMA data services. (See [Activating Global Roaming Mode](#).) Visit [www.sprint.com/sww](http://www.sprint.com/sww) for a list of services available in each country.

## Understanding Status Messages

You may receive status messages under certain conditions. Before contacting Sprint Worldwide Customer Support, note the message, numeric code, and the conditions under which it appeared. The following table lists and describes the status messages.

Status Messages	Message Description
Number Not in Service	The number that you entered is not valid.

Status Messages	Message Description
<b>User Not Available</b>	The phone that you called is either busy, out-of-range, or turned off. Please try again later.
<b>User Not Authorized</b>	The phone that you called is either busy, out-of-range, or turned off. Please try again later.
<b>Please Try Later</b>	This service is temporarily not available. Please try again later.
<b>Service Restricted</b>	Service may not be activated properly. Please contact Sprint Customer Service to report the issue for resolution.
<b>Service Not Available</b>	This feature is not available on the current network.
<b>Emergency Calls Only</b>	Either the service is not activated properly or the current network is available for emergency calling only. Adjust your network settings to check for other available networks. If service is still not available after adjusting the settings, contact Sprint Customer Service to report the issue for resolution.
<b>System Busy. Try Later</b>	The system is experiencing heavy traffic. Please try again later.
<b>Service Conflict</b>	This service cannot be enabled because an incompatible service has already been turned on.
<b>Please Try Again</b>	An error occurred. Note the error code and try again.
<b>Self Check Error</b>	A fault was detected with your phone. If this error recurs, note the error and contact Sprint Customer Service.
<b>Self Check Fail</b>	An operational fault was detected with your phone. Note the numeric code, turn your phone off, and contact Sprint Customer Service.
<b>Wrong PIN</b>	You have entered an incorrect SIM PIN number. You have only three attempts to enter your PIN. After a third unsuccessful attempt, your phone will be locked and you will have to call Sprint Customer Service to have it unlocked. Sprint sets the default to PIN off; if you elect to enable the PIN then you will need to contact Sprint for the default PIN and PUK.
<b>PIN Blocked. Call Your Provider</b>	An incorrect SIM PIN was entered three consecutive times. You will be unable to send or receive calls on your phone. Contact Sprint Customer Service to obtain the PIN Unblocked Key (PUK) code. Sprint sets the default to PIN off; if you elect to enable the PIN then you will need to contact Sprint for the default PIN and PUK.
<b>Insert SIM</b>	Your SIM Card is not being detected. Please check to ensure that you have inserted the SIM Card.
<b>Check SIM Card</b>	Please check your SIM card to make sure it is properly inserted.

## Contacting Sprint

If you experience any issues with voice or data services while outside of the United States, Sprint offers customer support 24 hours a day. In the event that you do experience an issue, try the following actions:

- First try powering your device off and then back on; this will force your phone to reregister with the network.
- Try manually selecting another network. Information for selecting networks can be found in the phone guide.

If neither of these actions resolves your issue, you will need to contact customer service (see below). When calling to report an issue, the following information will be beneficial in trying to resolve your issue as quickly as possible:

- Your wireless phone number.
- The city and country you are travelling in.
- Any error message that displays on your phone or that you heard when trying to place a call.
- If the issue is with data, were you able to place voice calls?
- If the issue is with voice service, were you able to access data?

### *Please call the numbers below if you need assistance:*

#### **While in the United States:**

- Call **1-888-226-7212, option 2.**

#### **While traveling outside the United States:**

- In GSM mode: touch and hold 0 and then dial **1-817-698-4199, option 3.**
- In CDMA mode: enter the country code and then dial **1-817-698-4199, option 3.**

There is no charge for this call from your wireless phone.

#### **From a landline phone when outside the United States:**

Sprint Worldwide Customer Support can be reached from a landline phone at **1-817-698-4199, option 3.** Access or connection fees may apply. The toll free numbers below can also be used to contact Sprint Worldwide Customer Support in the following countries:

Country	From Landline Phone
Caribbean (Anguilla, Barbados, Cayman Islands, and Dominica)	1-88-226-7212
France	0800-903200
Germany	0800-180-0951
Italy	800-787-986
Mexico	001-877-294-9003
Trinidad and Tobago	1-800-201-7545
United Kingdom	0808-234-6616

Note: This toll free service is available on ordinary landline phones and some public pay phones. This service does not cover and hotel access charges.

06/06/2012  
FCC

# *Important Safety Information*

---

General Precautions

Battery Use & Safety

Battery Charging

Third Party Accessories

Driving Precautions

Seizures/Blackouts

Caution About High Volume Usage

Repetitive Motion

Children

Glass Parts

Operational Warnings

Radio Frequency (RF) Energy

Specific Absorption Rate (IEEE)

Information from the World Health Organization

European Union Directives Conformance Statement

FCC Notice to Users

Industry Canada Notice to Users

Location Services

Navigation

Smart Practices While Driving

Privacy & Data Security

Use & Care

Recycling

California Perchlorate Label



Hearing Aid Compatibility with Mobile Phones

Software Copyright Notice

Content Copyright

Open Source Software Information

Export Law Assurances

Product Registration

Service & Repairs

Owner's Record

Copyright & Trademarks

This phone guide contains important operational and safety information that will help you safely use your phone. Failure to read and follow the information provided in this phone guide may result in serious bodily injury, death, or property damage.

## ***General Precautions***

There are several simple guidelines to operating your phone properly and maintaining safe, satisfactory service.

- To maximize performance, do not touch the bottom portion of your phone where the internal antenna is located while using the phone.
- Speak directly into the mouthpiece.

**Note:** For the best care of your phone, only Sprint-authorized personnel should service your phone and accessories. Failure to do so may be dangerous and void your warranty.

## ***Maintaining Safe Use of and Access to Your Phone***

### ***Do Not Rely on Your Phone for Emergency Calls***

Mobile phones operate using radio signals, which cannot guarantee connection in all conditions. Therefore you should never rely solely upon any mobile phone for essential communication (e.g., medical emergencies). Emergency calls may not be possible on all cellular networks or when certain network services or mobile phone features are in use. Check with your local service provider for details.

### ***Following Safety Guidelines***

To operate your phone safely and efficiently, always follow any special regulations in a given area. Turn your phone off in areas where use is forbidden or when it may cause interference or danger.

### *Turning Off Your Phone Before Flying*

Turn off your phone before boarding any aircraft. To prevent possible interference with aircraft systems, the U.S. Federal Aviation Administration (FAA) regulations require you to have permission from a crew member to use your phone while the plane is on the ground. To prevent any risk of interference, FCC regulations prohibit using your phone while the plane is in the air.

## **Battery Use & Safety**

The following battery use and safety information applies to all Motorola mobile devices. If your mobile device uses a non-removable main battery (as stated in your product information), details related to handling and replacing your battery should be disregarded—the battery should only be replaced by a Motorola-approved service facility, and any attempt to remove or replace your battery may damage the product.

**Important:** **Handle and store batteries properly to avoid injury or damage.** Most battery safety issues arise from improper handling of batteries, and particularly from the continued use of damaged batteries.

### **DON'Ts**

- **Don't disassemble, crush, puncture, shred, or otherwise attempt to change the form of your battery.**
- **Don't use tools, sharp objects, or excessive force to insert or remove the battery as this can damage the battery.**
- **Don't let the mobile device or battery come in contact with liquids.\*** Liquids can get into the mobile device's circuits, leading to corrosion.
- **Don't allow the battery to touch metal objects.** If metal objects, such as jewelry, stay in prolonged contact with the battery contact points, the battery could become very hot.
- **Don't place your mobile device or battery near a heat source.\*** High temperatures can cause the battery to swell, leak, or malfunction.
- **Don't dry a wet or damp battery with an appliance or heat source,** such as a hair dryer or microwave oven.

### **DOs**

- **Do avoid leaving your mobile device in your car in high temperatures.\***
- **Do avoid dropping the mobile device or battery.\*** Dropping these items, especially on a hard surface, can potentially cause damage.\*
- **Do contact your service provider or Motorola if your mobile device or battery has been damaged in any of the ways listed here.**

**Note:** \* Always make sure that any battery, connector and compartment covers are closed and secure to avoid direct exposure of the battery to any of these conditions, even if your product information states that your **mobile device** can resist damage from these conditions.

**Important:** Motorola recommends you always use Motorola-branded batteries and chargers for quality assurance and safeguards.

Motorola's warranty does not cover damage to the mobile device caused by non-Motorola batteries and/or chargers. To help you identify authentic Motorola batteries from non-original or counterfeit batteries (that may not have adequate safety protection), Motorola provides holograms on its batteries. You should confirm that any battery you purchase has a "**Motorola Original**" hologram.

If you see a message on your display such as **Invalid Battery** or **Unable to Charge**, take the following steps:

- Remove the battery and inspect it to confirm that it has a "**Motorola Original**" hologram;
- If there is no hologram, the battery is not a Motorola battery;
- If there is a hologram, replace the battery and try charging it again;
- If the message remains, contact a Motorola authorized service center.

**Warning:** Use of a non-Motorola battery or charger may present a risk of fire, explosion, leakage, or other hazard.

**Proper and safe battery disposal and recycling:** Proper battery disposal is not only important for safety, it benefits the environment. You can recycle your used batteries in many retail or service provider locations. Additional information on proper disposal and recycling can be found at [motorola.com/recycling](http://motorola.com/recycling).



**Disposal:** Promptly dispose of used batteries in accordance with local regulations. Contact your local recycling center or national recycling organizations for more information on how to dispose of batteries.

**Warning:** Never dispose of batteries in a fire because they may explode.

## Battery Charging

**Notes for charging your product's battery:**

- During charging, keep your battery and charger near room temperature for efficient battery charging.
- New batteries are not fully charged.

- New batteries or batteries stored for a long time may take more time to charge.
- Motorola batteries and charging systems have circuitry that protects the battery from damage from overcharging.

## *Third Party Accessories*

Use of third party accessories, including but not limited to batteries, chargers, headsets, covers, cases, screen protectors and memory cards, may impact your mobile device's performance. In some circumstances, third party accessories can be dangerous and may void your mobile device's warranty. For a list of Motorola accessories, visit [motorola.com/products](http://motorola.com/products).

## *Driving Precautions*

Responsible and safe driving is your primary responsibility when behind the wheel of a vehicle. Using a mobile device or accessory for a call or other application while driving may cause distraction, and may be prohibited or restricted in certain areas – always obey the laws and regulations on the use of these products.

### **While driving, NEVER:**

- Type, read, enter or review texts, emails, or any other written data.
- Surf the Web.
- Input navigation information.
- Perform any other functions that divert your attention from driving.

### **While driving, ALWAYS:**

- Keep your eyes on the road.
- Use a handsfree device if available or required by law in your area.
- Enter destination information into a navigation device **before** driving.
- Use voice activated features (such as voice dial) and speaking features (such as audible directions), if available.
- Obey all local laws and regulations for the use of mobile devices and accessories in the vehicle.
- End your call or other task if you cannot concentrate on driving.

Remember to follow the “[Smart Practices While Driving](#)” in this guide and at [motorola.com/callsmart](http://motorola.com/callsmart) (in English only).

## Seizures/Blackouts

To reduce eyestrain and avoid headaches, it is always a good idea to hold the screen a comfortable distance from your eyes, use in a well-lit area, and take frequent breaks.

Some people may be susceptible to seizures or blackouts (even if they have never had one before) when exposed to flashing lights or light patterns, such as when playing video games, or watching videos with flashing-light effects.

Discontinue use and consult a physician if any of the following symptoms occur: seizures, blackout, convulsion, eye or muscle twitching, loss of awareness, or disorientation.

If you or someone in your family has experienced seizures or blackouts, please consult with your physician before using an application that produces flashing-light effects on your mobile device.

## Caution About High Volume Usage

**Warning:** Exposure to loud noise from any source for extended periods of time may affect your hearing. The louder the volume sound level, the less time is required before your hearing could be affected.

To protect your hearing:

- Limit the amount of time you use headsets or headphones at high volume.
- Avoid turning up the volume to block out noisy surroundings.
- Turn the volume down if you can't hear people speaking near you.

If you experience hearing discomfort, including the sensation of pressure or fullness in your ears, ringing in your ears, or muffled speech, you should stop listening to the device through your headset or headphones and have your hearing checked.

For more information about hearing, see our website at <http://direct.motorola.com/hellomoto/nss/AcousticSafety.asp> (in English only).

## Repetitive Motion

When you repetitively perform actions such as pressing keys or entering finger-written characters, you may experience occasional discomfort in your hands, arms, shoulders, neck, or other parts of your body. If you continue to have discomfort during or after such use, stop use and see a physician.

## Children

**Keep your mobile device and its accessories away from small children.** These products are not toys and may be hazardous to small children. For example:

- A choking hazard may exist for small, detachable parts.
- Improper use could result in loud sounds, possibly causing hearing injury.
- Improperly handled batteries could overheat and cause a burn.

**Supervise access for older children.** Similar to a computer, if an older child does use your mobile device, you may want to monitor their access to help prevent:

- Exposure to inappropriate apps or content.
- Improper use of apps or content.
- Loss of data.

## Glass Parts

Some parts of your mobile device may be made of glass. This glass could break if the product receives a substantial impact. If glass breaks, do not touch or attempt to remove. Stop using your mobile device until the glass is replaced by a qualified service center.

## Operational Warnings

Obey all posted signs when using mobile devices in public areas.



## Potentially Explosive Areas






Potentially explosive areas are often, but not always, posted and can include blasting areas, fueling stations, fueling areas (such as below decks on boats), fuel or chemical transfer or storage facilities, or areas where the air contains chemicals or particles, such as grain dust, or metal powders.

When you are in such an area, turn off your mobile device, and do not remove, install, or charge batteries, unless it is a radio product type especially qualified for use in such areas and certified as “Intrinsically Safe” (for example, Factory Mutual, CSA, or UL approved). In such areas, sparks can occur and cause an explosion or fire.

## Symbol Key

Your battery, charger, or mobile device may contain symbols, defined as follows:

Symbol	Definition
	Important safety information follows.
	Do not dispose of your battery or mobile device in a fire.

 	<p>Your battery or mobile device may require recycling in accordance with local laws. Contact your local regulatory authorities for more information.</p>
	<p>Do not dispose of your battery or mobile device with your household waste. See <a href="#">Recycling</a> for more information.</p>
	<p>Do not use tools.</p>
	<p>For indoor use only.</p>

## Radio Frequency (RF) Energy

### Exposure to RF Energy

Your mobile device contains a transmitter and receiver. When it is ON, it receives and transmits RF energy. When you communicate with your mobile device, the system handling your call controls the power level at which your mobile device transmits.

Your mobile device is designed to comply with local regulatory requirements in your country concerning exposure of human beings to RF energy.

### RF Energy Operational Precautions

For optimal mobile device performance, and to be sure that human exposure to RF energy does not exceed the guidelines set forth in the relevant standards, always follow these instructions and precautions:

- When placing or receiving a phone call, hold your mobile device just like you would a landline phone.
- If you wear the mobile device on your body, always place the mobile device in a Motorola-supplied or approved accessory (e.g. clip, holder, holster, case or arm band). If you do not use a body-worn accessory supplied or approved by Motorola, ensure that whatever product is used is free of any metal and that it positions the mobile device at least 2.5 cm (1 inch) away from the body.
- Using accessories not supplied or approved by Motorola may cause your mobile device to exceed RF energy exposure guidelines. For a list of Motorola-supplied or approved accessories, visit our website at: [www.motorola.com](http://www.motorola.com).

## ***RF Energy Interference/Compatibility***

Nearly every electronic device is subject to RF energy interference from external sources if inadequately shielded, designed, or otherwise configured for RF energy compatibility. In some circumstances, your mobile device may cause interference with other devices.

### ***Follow Instructions to Avoid Interference Problems***

Turn off your mobile device in any location where posted notices instruct you to do so, such as hospitals or health care facilities.

In an aircraft, turn off your mobile device whenever instructed to do so by airline staff. If your mobile device offers an airplane mode or similar feature, consult airline staff about using it in flight.

### ***Medical Devices***

If you have a medical device, including an implantable medical device such as a pacemaker or defibrillator, consult your healthcare provider and the device manufacturer's directions before using this mobile device.

Persons with implantable medical devices should observe the following precautions:

- ALWAYS keep the mobile device more than 20 centimeters (8 inches) from the implantable medical device when the mobile device is turned ON.
- DO NOT carry the mobile device in the breast pocket.
- Use the ear opposite the implantable medical device to minimize the potential for interference.
- Turn OFF the mobile device immediately if you have any reason to suspect that interference is taking place.

## ***Regulatory Information***

Your Motorola mobile device is designed to comply with national and international regulatory requirements. For full compliance statements and details, please refer to the regulatory information in your printed product guide.

## ***Specific Absorption Rate (FCC & IC)***

### ***YOUR MOBILE DEVICE MEETS FCC AND IC LIMITS FOR EXPOSURE TO RADIO WAVES.***

Your mobile device is a radio transmitter and receiver. It is designed not to exceed the limits for exposure to radio waves (radio frequency electromagnetic fields) adopted by the Federal Communications Commission (FCC) and Industry Canada (IC). These limits include a substantial safety margin designed to assure the safety of all persons, regardless of age and health.



The radio wave exposure guidelines use a unit of measurement known as the Specific Absorption Rate, or SAR. The SAR limit for mobile devices is 1.6 W/kg.

Tests for SAR are conducted using standard operating positions with the device transmitting at its highest certified power level in all tested frequency bands. The highest SAR values under the FCC and IC guidelines for your device model are listed below:

Head SAR	LTE 1950, Wi-Fi, Bluetooth	0.89 W/kg
Body-worn SAR	CDMA 1900, Wi-Fi, Bluetooth	0.77 W/kg

During use, the actual SAR values for your device are usually well below the values stated. This is because, for purposes of system efficiency and to minimize interference on the network, the operating power of your mobile device is automatically decreased when full power is not needed for the call. The lower the power output of the device, the lower its SAR value.

If you are interested in further reducing your RF exposure then you can easily do so by limiting your usage or simply using a hands-free kit to keep the device away from the head and body.

Additional information can be found at [www.motorola.com/rfhealth](http://www.motorola.com/rfhealth).

## European Union Directives Conformance Statement

The following CE compliance information is applicable to Motorola mobile devices that carry one of the following CE marks:

CE0168


CE0168  (Only Indoor Use Allowed In France for Bluetooth and/or Wi-Fi)

Hereby, Motorola declares that this product is in compliance with:

- The essential requirements and other relevant provisions of Directive 1999/5/EC
- All other relevant EU Directives

For products that support Wi-Fi 802.11a (as defined in your product information): This device is restricted to indoor use when operating in the 5.15 to 5.25 GHz (802.11a) Wi-Fi frequency band.

The following gives an example of a typical Product Approval Number:



You can view your product's Declaration of Conformity (DoC) to Directive 1999/5/EC (to R&TTE Directive) at [motorola.com/rtte](http://motorola.com/rtte) (in English only). To find your DoC, enter the Product Approval Number from your product's label in the "Search" bar on the website.

## ***FCC Notice to Users***

**The following statement applies to all products that bear the FCC logo on the product label.**

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. See 47 CFR Sec. 15.105(b). These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and the receiver.
- Connect the equipment to an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. See 47 CFR Sec. 15.19(a)(3).

Motorola has not approved any changes or modifications to this device by the user. Any changes or modifications could void the user's authority to operate the equipment. See 47 CFR Sec. 15.21.

For products that support Wi-Fi 802.11a (as defined in your product information): This device is restricted to indoor use when operating in the 5.15 to 5.25 GHz (802.11a) Wi-Fi frequency band.

## ***Industry Canada Notice to Users***

This device complies with Industry Canada license-exempt RSS standard(s). Operation is subject to the following two conditions: (1) This device may not cause interference and (2) This device must accept any interference, including interference that may cause undesired operation of the device. See RSS-GEN 7.1.5. This Class B digital apparatus complies with Canadian ICES-003.

## Software Notices

### **Warning against unlocking the bootloader or altering a product's operating system**

**software:** Motorola strongly recommends against altering a product's operating system, which includes unlocking the bootloader, rooting a device or running any operating software other than the approved versions issued by Motorola and its partners. Such alterations may permanently damage your product, cause your product to be unsafe and/or cause your product to malfunction. In such cases, neither the product nor any damage resulting therefrom will be covered by warranty.

**Important FCC information:** You must not make or enable any changes to the product that will impact its FCC grant of equipment authorization. The FCC grant is based on the product's emission, modulation, and transmission characteristics, including: power levels, operating frequencies and bandwidths, SAR levels, duty-cycle, transmission modes (e.g., CDMA, GSM), and intended method of using the product (e.g., how the product is held or used in proximity to the body). A change to any of these factors will invalidate the FCC grant. It is illegal to operate a transmitting product without a valid grant.

## Location Services

The following information is applicable to Motorola mobile devices that provide location based functionality. Location sources can include GPS, AGPS and Wi-Fi.

Your mobile device can use **Global Positioning System** (GPS) signals for location-based applications. GPS uses satellites controlled by the U.S. government that are subject to changes implemented in accordance with the Department of Defense policy and the Federal Radio Navigation Plan. These changes may affect the performance of location technology on your mobile device.

Your mobile device can also use **Assisted Global Positioning System** (AGPS), which obtains information from the cellular network to improve GPS performance. AGPS uses your wireless service provider's network and therefore airtime, data charges, and/or additional charges may apply in accordance with your service plan. Contact your wireless service provider for details.

Your mobile device can also use Wi-Fi signals to determine your approximate location, using information from known and available Wi-Fi networks.

## Your Location

Location-based information includes information that can be used to determine the approximate location of a mobile device. Mobile devices which are connected to a wireless network transmit location-based information. Devices enabled with location technology also transmit location-based information. Additionally, if you use applications that require location-based information (e.g. driving directions), such applications transmit location-based information. This location-based information may be shared with third parties, including your wireless service provider, applications providers, Motorola, and other third parties providing services.

## Emergency Calls

When you make an emergency call, the cellular network may activate the AGPS technology in your mobile device to tell the emergency responders your approximate location.

AGPS has limitations and **might not work in your area**. Therefore:

- Always tell the emergency responder your location to the best of your ability; and
- Remain on the phone for as long as the emergency responder instructs you.

## Navigation

The following information is applicable to Motorola mobile devices that provide navigation features.

When using navigation features, note that mapping information, directions and other navigational data may contain inaccurate or incomplete data. In some countries, complete information may not be available. Therefore, you should visually confirm that the navigational instructions are consistent with what you see. All drivers should pay attention to road conditions, closures, traffic, and all other factors that may impact driving. Always obey posted road signs.

## Privacy & Data Security

Motorola understands that privacy and data security are important to everyone. Because some features of your mobile device may affect your privacy or data security, please follow these recommendations to enhance protection of your information:

- **Monitor access**—Keep your mobile device with you and do not leave it where others may have unmonitored access. Use your device's security and lock features, where available.
- **Keep software up to date**—If Motorola or a software/application vendor releases a patch or software fix for your mobile device that updates the device's security, install it as soon as possible.
- **Secure Personal Information**—Your mobile device can store personal information in various locations including your SIM card, memory card, and phone memory. Be sure to remove or clear all personal information before you recycle, return, or give away your device. You can also backup your personal data to transfer to a new device.

**Note:** For information on how to backup or wipe data from your mobile device, go to [motorola.com/support](http://motorola.com/support).

- **Online accounts**—Some mobile devices provide a Motorola online account (such as MOTOBLUR). Go to your account for information on how to manage the account, and how to use security features such as remote wipe and device location (where available).

- **Applications and updates**—Choose your apps and updates carefully, and install from trusted sources only. Some apps can impact your phone's performance and/or have access to private information including account details, call data, location details and network resources.
- **Wireless**—For mobile devices with Wi-Fi features, only connect to trusted Wi-Fi networks. Also, when using your device as a hotspot (where available) use network security. These precautions will help prevent unauthorized access to your device.
- **Location-based information**—Mobile devices enabled with location based technologies such as GPS, AGPS or Wi-Fi, can transmit location-based information. See [Location Services](#) for more details.
- **Other information your device may transmit**—Your device may also transmit testing and other diagnostic (including location-based) information, and other non-personal information to Motorola or other third-party servers. This information is used to help improve products and services offered by Motorola.

If you have further questions regarding how the use of your mobile device may impact your privacy or data security, please contact Motorola at [privacy@motorola.com](mailto:privacy@motorola.com), or contact your service provider.

## Use & Care

To care for your Motorola mobile device, please observe the following:



### Liquids

Don't expose your mobile device to water, rain, extreme humidity, sweat, or other liquids.



### Drying

Don't try to dry your mobile device using a microwave oven, conventional oven, or dryer, as this may damage the mobile device.



### Extreme Heat or Cold

Don't store or use your mobile device in temperatures below -10°C (14°F) or above 60°C (140°F). Don't recharge your mobile device in temperatures below 0°C (32°F) or above 45°C (113°F).



### Dust and Dirt

Don't expose your mobile device to dust, dirt, sand, food, or other inappropriate materials.

 **Cleaning**

To clean your mobile device, use only a dry soft cloth. Don't use alcohol or other cleaning solutions.

 **Shock and Vibration**

Don't drop your mobile device.

 **Protection**

To help protect your mobile device, always make sure that any battery, connector and compartment covers are closed and secure.

## *Recycling*

### *Mobile Devices & Accessories*

Please do not dispose of mobile devices or electrical accessories (such as chargers, headsets, or batteries) with your household waste, or in a fire. These items should be disposed of in accordance with the national collection and recycling schemes operated by your local or regional authority. Alternatively, you may return unwanted mobile devices and electrical accessories to any Motorola Approved Service Center in your region. Details of Motorola approved national recycling schemes, and further information on Motorola recycling activities can be found at: [www.motorola.com/recycling](http://www.motorola.com/recycling).



### *Packaging & Product Guides*

Product packaging and product guides should only be disposed of in accordance with national collection and recycling requirements. Please contact your regional authorities for more details.

### *California Perchlorate Label*

Some mobile phones use an internal, permanent backup battery on the printed circuit board that may contain very small amounts of perchlorate. In such cases, California law requires the following label:

**Perchlorate Material – special handling may apply when the battery is recycled or disposed of.** See [www.dtsc.ca.gov/hazardouswaste/perchlorate](http://www.dtsc.ca.gov/hazardouswaste/perchlorate) (in English only).

There is no special handling required by consumers.

## *Hearing Aid Compatibility with Mobile Phones*

Some Motorola phones are measured for compatibility with hearing aids. If the box for your particular model has “Rated for Hearing Aids” printed on it, the following explanation applies.

When some mobile phones are used near some hearing devices (hearing aids and cochlear implants), users may detect a buzzing, humming, or whining noise. Some hearing devices are more immune than others to this interference noise, and phones also vary in the amount of interference they generate.

The wireless telephone industry has developed ratings for some of their mobile phones, to assist hearing device users in finding phones that may be compatible with their hearing devices. Not all phones have been rated. Phones that are rated have the rating on their box or a label on the box. To maintain the published Hearing Aid Compatibility (HAC) rating for this mobile phone, use only the original equipment battery model.

This phone has been tested and rated for use with hearing aids for some of the wireless technologies that it uses. However, there may be some newer wireless technologies used in this phone that have not been tested yet for use with hearing aids. It is important to try the different features of this phone thoroughly and in different locations, using your hearing aid or cochlear implant, to determine if you hear any interfering noise. Contact your service provider or Motorola for information on hearing aid compatibility. If you have questions about return or exchange policies, contact your service provider or phone retailer.

The ratings are not guarantees. Results will vary depending on the user’s hearing device and hearing loss. If your hearing device happens to be vulnerable to interference, you may not be able to use a rated phone successfully. Trying out the phone with your hearing device is the best way to evaluate it for your personal needs.

**M-Ratings:** Phones rated M3 or M4 meet FCC requirements and are likely to generate less interference to hearing devices than phones that are not labeled. M4 is the better/higher of the two ratings.

**T-Ratings:** Phones rated T3 or T4 meet FCC requirements and are likely to be more usable with a hearing device’s telecoil (“T Switch” or “Telephone Switch”) than unrated phones. T4 is the better/higher of the two ratings. (Note that not all hearing devices have telecoils in them.)

Hearing devices may also be measured for immunity to this type of interference. Your hearing device manufacturer or hearing health professional may help you find results for your hearing device. The more immune your hearing aid is, the less likely you are to experience interference noise from mobile phones.

## *Software Copyright Notice*

Motorola products may include copyrighted Motorola and third-party software stored in semiconductor memories or other media. Laws in the United States and other countries preserve for Motorola and third-party software providers certain exclusive rights for copyrighted

software, such as the exclusive rights to distribute or reproduce the copyrighted software. Accordingly, any copyrighted software contained in Motorola products may not be modified, reverse-engineered, distributed, or reproduced in any manner to the extent allowed by law. Furthermore, the purchase of Motorola products shall not be deemed to grant either directly or by implication, estoppel, or otherwise, any license under the copyrights, patents, or patent applications of Motorola or any third-party software provider, except for the normal, non-exclusive, royalty-free license to use that arises by operation of law in the sale of a product.

## *Content Copyright*

The unauthorized copying of copyrighted materials is contrary to the provisions of the Copyright Laws of the United States and other countries. This device is intended solely for copying non-copyrighted materials, materials in which you own the copyright, or materials which you are authorized or legally permitted to copy. If you are uncertain about your right to copy any material, please contact your legal advisor.

## *Open Source Software Information*

For instructions on how to obtain a copy of any source code being made publicly available by Motorola related to software used in this Motorola mobile device, you may send your request in writing to the address below. Please make sure that the request includes the model number and the software version number.

MOTOROLA MOBILITY, INC.  
OSS Management  
600 North US Hwy 45  
Libertyville, IL 60048  
USA

The Motorola website <http://opensource.motorola.com> (in English only) also contains information regarding Motorola's use of open source.

Motorola has created the <http://opensource.motorola.com> website to serve as a portal for interaction with the software community-at-large.

To view additional information regarding licenses, acknowledgments and required copyright notices for open source packages used in this Motorola mobile device, please press **Menu Key** > **Settings** > **About phone** > **Legal information** > **Open source licenses**. In addition, this Motorola device may include self-contained applications that present supplemental notices for open source packages used in those applications.

## *Export Law Assurances*

This product is controlled under the export regulations of the United States of America and Canada. The Governments of the United States of America and Canada may restrict the exportation or re-exportation of this product to certain destinations. For further information



contact the U.S. Department of Commerce or the Canadian Department of Foreign Affairs and International Trade.

## ***Product Registration***

Online Product Registration:

[motorola.com/us/productregistration](http://motorola.com/us/productregistration) (in English only)

Product registration is an important step toward enjoying your new Motorola product. Registering permits us to contact you for product or software updates and allows you to subscribe to updates on new products or special promotions. Registration is not required for warranty coverage.

Please retain your original dated sales receipt for your records. For warranty service of your Motorola product you will need to provide a copy of your dated sales receipt to confirm warranty status.

Thank you for choosing a Motorola product.

## ***Service & Repairs***

If you have questions or need assistance, we're here to help.

Go to [www.motorola.com/repair](http://www.motorola.com/repair) (United States) or [www.motorola.com/support](http://www.motorola.com/support) (Canada), where you can select from a number of customer care options. You can also contact the Motorola Customer Support Center at 1-800-734-5870 (United States), 1-888-390-6456 (TTY/TDD United States for hearing impaired), or 1-800-461-4575 (Canada).

## ***How to Obtain Service or Other Information***

1. Please access and review the online Customer Support section of Motorola's consumer website prior to requesting warranty service.
2. If the Product is still not functioning properly after making use of this resource, please contact the Warrantor listed at the Motorola website or the contact information for the corresponding location.
3. A representative of Motorola, or of a Motorola Authorized Repair Center, will help determine whether your Product requires service. You may be required to download, or otherwise obtain and accept software updates from Motorola or a Motorola Authorized Repair Center. You are responsible for any applicable carrier service fees incurred while obtaining the required downloads. Complying with the warranty process, repair instructions and accepting such software updates is required in order to receive additional warranty support.
4. If the software update does not fix the problem, you will receive instructions on how to ship the Product to a Motorola Authorized Repair Center or other entity.
5. To obtain warranty service, as permitted by applicable law, you are required to include:
  - (a) a copy of your receipt, bill of sale or other comparable proof of purchase;
  - (b) a written

description of the problem; (c) the name of your service provider, if applicable; (d) your address and telephone number. In the event the Product is not covered by the Motorola Limited Warranty, Motorola will inform the consumer of the availability, price and other conditions applicable to the repair of the Product.

**To obtain service or other information, please access and review the online Customer Support section of Motorola's consumer website at [www.motorola.com](http://www.motorola.com).**

## Owner's Record

The model number, regulatory number, and serial number are located on a nameplate inside the battery compartment. Record the serial number in the space provided below. This will be helpful if you need to contact us about your phone in the future.

Model: MOTOROLA XT897

Serial No.:

## Copyright & Trademarks

Motorola Mobility, Inc.  
Consumer Advocacy Office  
600 N US Hwy 45  
Libertyville, IL 60048

[motorola.com](http://motorola.com)

**Note:** Do not ship your product to the above address. If you need to return your product for repairs, replacement, or warranty service, please contact the Motorola Customer Support Center at:

1 (800) 734-5870 (United States)

1 (888) 390-6456 (TTY, TDD United States for hearing impaired)

1 (800) 461-4575 (Canada)

Certain features, services and applications are network dependent and may not be available in all areas; additional terms, conditions and/or charges may apply. Contact your service provider for details.

All features, functionality, and other product specifications, as well as the information contained in this guide, are based upon the latest available information and believed to be accurate at the time of printing. Motorola reserves the right to change or modify any information or specifications without notice or obligation.

**Note:** The images in this guide are examples only.

MOTOROLA and the Stylized M Logo are trademarks or registered trademarks of Motorola Trademark Holdings, LLC. Google, the Google logo, Google Maps, Google Talk, Google Latitude, Gmail, YouTube, Picasa, Google Books, Google Docs, Google Goggles, Google Finance, Google Places, Google Maps Navigation Beta, Google Calendar, Android and Google


Play Store are trademarks of Google, Inc. All other product or service names are the property of their respective owners.

© 2012 Motorola Mobility, Inc. All rights reserved.

**Caution:** Motorola does not take responsibility for changes/modification to the transceiver.

Product ID: MOTOROLA Photon Q 4G LTE (Model XT897)

Manual Number: NNTNXXXXA



# Manufacturer's Warranty

---

## Manufacturer's Warranty

Your phone has been designed to provide you with reliable, worry-free service. If for any reason you have a problem with your equipment, please refer to the manufacturer's warranty in this section.

For information regarding the terms and conditions of service for your phone, please visit [sprint.com](http://sprint.com) or call Sprint Customer Service at **1-888-211-4727**.

**Note:** In addition to the warranty provided by your phone's manufacturer, which is detailed on the following pages, Sprint offers a number of optional plans to cover your equipment for non-warranty claims. Sprint Total Equipment Protection provides the combined coverage of the **Sprint Equipment Replacement Program** and the **Sprint Equipment Service and Repair Program**, both of which are available separately. Each of these programs may be signed up for within 30 days of activating your phone. For more details, please visit your nearest Sprint Store or call Sprint at **1-800-584-3666**.

## Manufacturer's Warranty

### *Motorola Mobility Inc. Limited Global Warranty Mobile Phones*

**Note:** This Limited Warranty is not applicable in Quebec, Canada.

FOR CONSUMERS WHO ARE COVERED BY CONSUMER PROTECTION LAWS OR REGULATIONS IN THEIR COUNTRY OF PURCHASE OR, IF DIFFERENT, THEIR COUNTRY OF RESIDENCE, THE BENEFITS CONFERRED BY THIS LIMITED WARRANTY ARE IN ADDITION TO ALL RIGHTS AND REMEDIES CONVEYED BY SUCH CONSUMER PROTECTION LAWS AND REGULATIONS.

#### *Who is Covered?*

This Limited Warranty extends only to the first consumer purchaser of the Product, and is not transferable.

#### *What Does this Limited Warranty Cover?*

Motorola Mobility Inc. or its subsidiaries' warranty obligations are limited to the terms and conditions set forth herein. Subject to the exclusions contained below, Motorola Mobility Inc or its subsidiaries ("Motorola") warrant this Mobile Phone, and any in-box accessories which accompany such Mobile Phone ("Product") against defects in materials and workmanship, under normal consumer use, for a period of ONE (1) YEAR from the date of retail purchase by the original end-user purchaser, or the period of time required by the laws of the country where the Product is purchased, whichever is longer ("Warranty Period").

Repairs made under this Limited Warranty are covered for the balance of the original Warranty Period, or 90 days from the date of service, whichever is longer. Any upgrade to the original product will be covered only for the duration of the original Warranty Period.

This Limited Warranty is only available in the country where the Product was purchased. Motorola may provide service outside the country of purchase, to the extent that it is possible and under the terms and conditions of the country of purchase.

This Limited Warranty applies only to new Products which are a) manufactured by or for Motorola as identified by the "Motorola" trademark, trade name, or logo legally affixed to them; b) purchased by consumers from an authorized reseller or distributor of Motorola Products; and c) accompanied by this written Limited Warranty.

### *What Will Motorola Do?*

If a covered defect or damage arises and a valid warranty claim is received within the applicable Warranty Period, Motorola, at its sole option, unless otherwise required by applicable law, will either (1) repair, at no charge, the defect or damage using new, used or reconditioned/refurbished functionally equivalent replacement parts; or (2) exchange the Product with a replacement Product that is new or which has been reconditioned/refurbished or otherwise remanufactured from new or used parts and is functionally equivalent to the original Product; or (3) refund the purchase price of any Products covered by the terms and conditions of this Limited Warranty.

Products, parts and supporting documentation provided to Motorola as part of the warranty process, shall become the property of Motorola, and may not be returned. When a replacement or refund is given, the Product for which the replacement or refund is provided must be returned to Motorola and shall become the property of Motorola.

### *Exclusions (Products and Accessories)*

**This warranty does not apply to:**

- (a) **Consumable parts**, such as batteries or protective coatings designed to diminish over time unless failure has occurred due to a defect in materials or workmanship. As with all batteries, the maximum capacity of the battery will decrease with time and use; this is not a defect. Only defective batteries and batteries that leak are covered by this warranty.
- (b) **Cosmetic damage**, including but not limited to scratches, dents, cracks or other cosmetic damage.
- (c) **Damage caused by use with non-Motorola products**. Defects or damage that result from the use of non-Motorola branded or certified Products, accessories or other peripheral equipment, including without limitation housings, parts, or software, are excluded from coverage.
- (d) **Damage caused by accident, abuse, misuse, liquid contact, fire, earthquake or other external causes**; including but not limited to: (i) improper usage or operation (e.g. operating the Product outside their permitted or intended uses as defined by Motorola, including but not

limited to as set forth by Motorola in the Products' User Manual, Quick Start Guide, Online Tutorials, and other documentation), improper storage (e.g. subjecting the Product to extreme temperatures), abuse or neglect (e.g. broken/bent/missing clips/fasteners/connectors); impact damage (e.g. dropping the Product) (ii) contact with liquids, water, rain, extreme humidity, heavy perspiration or other moisture; sand, food, dirt or similar substances (except for Products sold as resistant to such substances, but only to the extent the damage was not caused by incorrectly securing the phone's protective elements or subjecting the Product to conditions beyond its stated specifications or limits); (iii) use of the Products for commercial rental purposes; or (iv) external causes or acts which are not the fault of Motorola, including but not limited to flood, fire, earthquake, tornado or other acts of God, are excluded from coverage.

(e) **Unauthorized Service or Modification.** Defects or damage resulting from service, testing, adjustment, installation, maintenance, alteration, or modification in any way, including but not limited to tampering with or altering the software, by someone other than Motorola, or its authorized service centers, are excluded from coverage. Notwithstanding the foregoing, any Product which has had its bootloader unlocked, or whose operating system has been altered, including any failed attempts to unlock the bootloader or alter such operating system, is not covered by this warranty, regardless of whether such modifications are authorized, approved, or otherwise sanctioned by Motorola.

(f) **A product or part that has been modified in any manner without the written permission of Motorola.** Products that have been altered in any manner so as to prevent Motorola from determining whether such Products are covered under the terms of this Limited Warranty are excluded from coverage. The foregoing shall include but not be limited to (i) serial numbers, date tags or other manufacturer coding that has been removed, altered or obliterated; (ii) mismatched or duplicated serial numbers; or (iii) broken seals or other evidence of tampering. Do not open the Product or attempt to repair the Product yourself; such conduct may cause damage that is not covered by this warranty.

(g) **Normal wear and tear or otherwise due to the normal aging of the Product.**

(h) **Defects, damages, or the failure of the Product due to any communication service or network you subscribe to or use with the Products.**

(i) **All software, including operating system software, third-party software, applications, and all other software of any kind.** Software distributed by Motorola is provided "AS-IS" and "AS AVAILABLE," "WITH ALL FAULTS" and without a warranty of any kind. The Limited Warranty does not apply to any non-Motorola product or any software, even if packaged or sold with the Motorola hardware, unless otherwise required by applicable local law.

(j) **Products that have been refurbished, reconditioned, or remanufactured,** except for Products repaired or replaced pursuant to the terms of this Limited Warranty.

If damage is outside the scope of warranty coverage, repair services may be available, but all costs associated with such out of warranty repair will be your responsibility.

### *What Other Limitations are There?*

- TO THE EXTENT PERMITTED BY APPLICABLE LAW, THIS LIMITED WARRANTY AND THE REMEDIES SET FORTH HEREIN ARE EXCLUSIVE AND IN LIEU OF ALL OTHER WARRANTIES AND REMEDIES, WHETHER ORAL OR WRITTEN, STATUTORY, EXPRESS OR IMPLIED. NO ORAL OR WRITTEN REPRESENTATIONS MADE BY MOTOROLA OR ANY SELLER, RESELLER OR DISTRIBUTOR OF THE PRODUCTS, INCLUDING EMPLOYEES AND AGENTS THEREOF, SHALL CREATE ANY ADDITIONAL WARRANTY OBLIGATIONS, INCREASE THE SCOPE, OR OTHERWISE MODIFY IN ANY MANNER THE TERMS OF THIS LIMITED WARRANTY.
- TO THE EXTENT PERMITTED BY APPLICABLE LAW, MOTOROLA SPECIFICALLY DISCLAIMS ANY AND ALL STATUTORY OR IMPLIED WARRANTIES, INCLUDING, WITHOUT LIMITATION, WARRANTIES OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE, NONINFRINGEMENT AND ALL WARRANTIES AGAINST HIDDEN OR LATENT DEFECTS. WHERE SUCH STATUTORY OR IMPLIED WARRANTIES CANNOT LAWFULLY BE DISCLAIMED, THEN TO THE EXTENT PERMITTED BY LAW, ALL SUCH WARRANTIES SHALL BE LIMITED IN DURATION TO THE DURATION OF THE EXPRESS LIMITED WARRANTY CONTAINED HEREIN AND THE REMEDIES OF REPAIR, REPLACEMENT, OR REFUND AS DETERMINED BY MOTOROLA IN ITS SOLE DISCRETION SHALL BE THE EXCLUSIVE REMEDY OF THE CONSUMER.
- TO THE EXTENT PERMITTED BY APPLICABLE LAW, MOTOROLA DOES NOT WARRANT THAT THE OPERATION OF ANY PRODUCTS OR SOFTWARE COVERED UNDER THIS LIMITED WARRANTY WILL MEET YOUR REQUIREMENTS, WORK IN COMBINATION WITH ANY HARDWARE OR SOFTWARE APPLICATIONS OR THIRD PARTY SERVICES, BE UNINTERRUPTED, ERROR-FREE, OR WITHOUT RISK TO, OR LOSS OF, ANY INFORMATION, DATA, SOFTWARE OR APPLICATIONS CONTAINED THEREIN, OR THAT DEFECTS IN THE PRODUCTS OR SOFTWARE WILL BE CORRECTED.
- TO THE EXTENT PERMITTED BY APPLICABLE LAW, IN NO EVENT SHALL MOTOROLA BE LIABLE, WHETHER IN CONTRACT, TORT OR UNDER OTHER LEGAL THEORY (INCLUDING NEGLIGENCE), FOR DAMAGES IN EXCESS OF THE PURCHASE PRICE OF THE PRODUCTS, OR FOR ANY INDIRECT, INCIDENTAL, SPECIAL OR CONSEQUENTIAL DAMAGES OF ANY KIND, OR LOSS OF REVENUE OR PROFITS; LOSS OF BUSINESS; BUSINESS INTERRUPTION; LOSS OF OPPORTUNITY; LOSS OF GOODWILL; LOSS OF REPUTATION; LOSS OF, DAMAGE TO, OR CORRUPTION OF INFORMATION, DATA, SOFTWARE OR APPLICATIONS (INCLUDING ANY COSTS ASSOCIATED WITH RECOVERING, PROGRAMMING, OR REPRODUCING ANY INFORMATION, DATA, SOFTWARE OR APPLICATIONS STORED ON OR USED WITH MOTOROLA PRODUCTS, OR ANY FAILURE TO MAINTAIN THE CONFIDENTIALITY OF ANY INFORMATION OR DATA STORED ON THE PRODUCTS); OR OTHER FINANCIAL LOSS ARISING OUT OF OR IN CONNECTION WITH THE ABILITY OR INABILITY TO USE THE PRODUCTS.

- SOME STATES OR JURISDICTIONS DO NOT ALLOW THE LIMITATION OR EXCLUSION OF INCIDENTAL OR CONSEQUENTIAL DAMAGES, OR THE EXCLUSION OR LIMITATION ON THE LENGTH OF AN IMPLIED WARRANTY, OR THE LIMITATION OR EXCLUSION OF DAMAGES FOR PERSONAL INJURIES CAUSED BY NEGLIGENCE, SO THE ABOVE LIMITATIONS OR EXCLUSIONS MAY NOT APPLY TO YOU. THIS WARRANTY GIVES YOU SPECIFIC LEGAL RIGHTS, AND YOU MAY ALSO HAVE OTHER RIGHTS THAT VARY FROM STATE OR JURISDICTION.
- **DATA BACKUP:** ALL INFORMATION, DATA, SOFTWARE OR OTHER APPLICATIONS, INCLUDING BUT NOT LIMITED TO PERSONAL CONTACTS, ADDRESS BOOKS, PICTURES, MUSIC AND GAMES WILL BE ERASED DURING THE REPAIR PROCESS, AND CAN NOT BE REINSTALLED BY MOTOROLA. TO AVOID LOSING SUCH INFORMATION, DATA, SOFTWARE OR OTHER APPLICATIONS PLEASE CREATE A BACK UP BEFORE YOU DELIVER YOUR PRODUCT FOR WARRANTY SERVICE, REMOVE ANY CONFIDENTIAL, PROPRIETARY OR PERSONAL INFORMATION AND DISABLE ANY SECURITY PASSWORDS. YOU WILL BE RESPONSIBLE FOR REINSTALLING ALL SUCH INFORMATION, DATA, SOFTWARE, OTHER APPLICATIONS AND PASSWORDS. MOTOROLA AND/OR ITS AUTHORIZED SERVICE CENTERS ARE NOT RESPONSIBLE FOR THE LOSS OR MISUSE OF ANY DATA, FILES, CONTENT, APPLICATIONS AND PROGRAMS WHEN THE PRODUCT IS DELIVERED FOR WARRANTY SERVICE. YOUR PRODUCT OR A REPLACEMENT PRODUCT WILL BE RETURNED TO YOU AS YOUR PRODUCT WAS CONFIGURED WHEN ORIGINALLY PURCHASED, SUBJECT TO APPLICABLE SOFTWARE UPDATES. MOTOROLA MAY INSTALL OPERATING SYSTEM SOFTWARE UPDATES AS PART OF WARRANTY SERVICE THAT MAY PREVENT THE PRODUCT FROM REVERTING TO AN EARLIER VERSION OF THE OPERATING SYSTEM SOFTWARE. THIRD PARTY APPLICATIONS INSTALLED ON THE PRODUCT MAY NOT BE COMPATIBLE OR WORK WITH THE PRODUCT AS A RESULT OF THE OPERATING SYSTEM SOFTWARE UPDATE. MOTOROLA AND ITS AUTHORIZED SERVICE CENTERS ARE NOT RESPONSIBLE FOR THE LOSS OF, OR INABILITY TO USE, SUCH INFORMATION, DATA, SOFTWARE OR OTHER APPLICATIONS.
- **WARNING AGAINST UNLOCKING THE BOOTLOADER OR ALTERING A PRODUCT'S OPERATING SYSTEM SOFTWARE:** MOTOROLA STRONGLY RECOMMENDS AGAINST ALTERING A PRODUCT'S OPERATING SYSTEM, WHICH INCLUDES UNLOCKING THE BOOTLOADER, ROOTING A DEVICE OR RUNNING ANY OPERATING SOFTWARE OTHER THAN THE APPROVED VERSIONS ISSUED BY MOTOROLA AND ITS PARTNERS. SUCH ALTERATIONS MAY PERMANENTLY DAMAGE YOUR PRODUCT, CAUSE YOUR PRODUCT TO BE UNSAFE AND/OR CAUSE YOUR PRODUCT TO MALFUNCTION. IN SUCH CASES, NEITHER THE PRODUCT NOR ANY DAMAGE RESULTING THEREFROM WILL BE COVERED BY THIS WARRANTY.



- **IMPORTANT FCC INFORMATION:** YOU MUST NOT MAKE OR ENABLE ANY CHANGES TO THE PRODUCT THAT WILL IMPACT ITS FCC GRANT OF EQUIPMENT AUTHORIZATION. THE FCC GRANT IS BASED ON THE PRODUCT'S EMISSION, MODULATION, AND TRANSMISSION CHARACTERISTICS, INCLUDING: POWER LEVELS, OPERATING FREQUENCIES AND BANDWIDTHS, SAR LEVELS, DUTY-CYCLE, TRANSMISSION MODES (E.G., CDMA, GSM), AND INTENDED METHOD OF USING THE PRODUCT (E.G., HOW THE PRODUCT IS HELD OR USED IN PROXIMITY TO THE BODY). A CHANGE TO ANY OF THESE FACTORS WILL INVALIDATE THE FCC GRANT. IT IS ILLEGAL TO OPERATE A TRANSMITTING PRODUCT WITHOUT A VALID GRANT.

06/06/2012  
FCC

# Index

---

- 3-way Call, 20
- Accounts
  - Set Up, 61
- Accounts
  - Google Checkout™ Account, 71
- Activation, 2
- Airplane Mode, 22
- Alarm Clock, 44
- Applications
  - Find and Install, 70
  - Manage or Remove, 71
  - Manage Your Downloads, 72
  - Request a Refund, 71
- Apps
  - Alarm Clock and Timer, 44
  - Browser, 79
  - Calculator, 45
  - Calendar, 43
  - File Manager, 44
  - Google Latitude™, 74
  - Google Maps™, 72
  - Google Play Music, 75
  - MOTOPRINT, 49
  - Quickoffice, 45
  - Smart Actions, 49
  - Tasks, 45
  - Wi-Fi, 77
  - YouTube™, 81
- Audible touch tones**, 26
- Battery
  - Charging, 27
  - Cool Down Messages, 28
    - mode, 28
- Battery Capacity
  - Settings, 27
- Bluetooth
  - Connect New Devices, 48
  - Disconnect Devices, 49
  - Edit the Device Name, 49
  - Reconnect Devices, 49

Turn On or Off, 48

Browser, 79

- Adjust Settings, 80
- Connect to the Web, 79
- Go to a Specific Website, 80
- See Options, 79
- Select Links, 79
- Your Browser, 79

Calendar

- Add Events, 43
- Manage Events, 43

Call Guard, 68

Camcorder

- Record Videos, 55
- Video Options, 55

Camera, 54

- Photo Options, 54
- Take Photos, 54

Charge your battery, 2

Contacts

- Access, 38
- Add, 39
- Call or Text, 41
- Edit, 40
- Make Groups, 42
- Save a Phone Number, 39
- Share, 41
- Sync or Transfer, 40
- Transfer Using a microSD Card, 41

Data Roam Guard, 68

Delete an Email Account, 65

Display Settings

- Auto-Rotate Screen, 26
- Brightness
- Screen Timeout, 26
- Wallpaper, 26

Downloading Apps from the Web, 72

Email, 63

- Add a Corporate Sync Account, 64
- Add an Account, 64
- Compose and Send, 64
- Delete Messages, 65
- EditAccountSettings, 65
- Manage Your Inbox, 65

Refresh an Account, 65  
View and Reply, 64  
Emergency Numbers, 18  
Enhanced 911 (E911), 19  
Global Roaming  
Activating, 82  
Contacting Sprint, 87  
International Data Roaming, 85  
Making and Receiving Worldwide Calls, 83  
Status Messages, 86  
Voicemail, 83  
Gmail  
Access Account, 63  
Gmail  
Send Message, 63  
Gmail  
Read and Reply to Messages, 63  
Gmail™ and Google™, 62  
Google Account  
Create, 62  
Google Account  
Sign In, 62  
Google Checkout™ Account  
Create, 71  
Google Play Store™, 70  
HAC Mode  
Settings, 24  
Hearing Aid Compatibility Settings, 24  
Help Center, 45  
Home Screen  
Customize, 11  
Move or Remove items, 12  
Key Functions, 9  
Keyboard  
QWERTY, 14  
Touchscreen, 15  
Keyboard Settings, 34  
Language & Keyboard Settings, 34  
Language Settings, 34  
Settings, 37  
Location  
Find, 73  
Get Directions, 73  
Select Map Mode, 73

Location Settings, 28  
Making a Conference Call, 20  
microSD Card, 51  
    Delete or Share, 52  
    Format, 52  
    Inserting, 51  
    Unmount, 52  
    View Memory, 52  
MOTOPRINT  
    Add a Printer, 49  
    Print a Document or File, 49  
My Location, 28  
Navigation  
    Touch Gestures, 10  
Notification Ringtone  
    Sound Settings, 25  
Passwords  
    Account, 5  
    Data Services, 5  
    Voicemail, 5  
Phone  
    Set Up, 1  
Phone  
    Turn On, 9  
Phone  
    Turn Off, 10  
Phone, 17  
Phone  
    Dialer, 17  
Phone  
    About Phone, 36  
Phone  
    Software Update, 46  
Phone Calls  
    Emergency numbers, 18  
    Using phone dialpad, 17  
Phone Layout (illustration), 8  
Phone Ringtone  
    Sound Settings, 25  
Photos & Videos  
    View, 56  
Photos and Videos  
    Edit, 57  
    Manage, 57

Share, 57  
Quick Office  
  Programs, 45  
Quickoffice  
  Browse Files, 46  
  Create a New File, 46  
  Open a Document, 46  
Quickoffice  
  Tips, 46  
QWERTY Keyboard, 14  
Roaming, 68  
SD Card, 33  
Security Settings, 28  
Set Up  
  Voicemail, 3  
Settings  
  Running Services (Applications), 32  
  Unknown Application Sources, 32  
Settings, 21  
  Accounts, 31  
  Add New Accounts, 31  
  Airplane Mode, 22  
  Allow Bluetooth<sup>®</sup> Bypass, 30  
  Auto Answer With Headset, 24  
  Battery Remaining, 27  
  Battery Settings, 27  
  Bluetooth, 22  
  Call, 23  
  Caller ID Readout, 23  
  Certificates, 31  
  Credential Storage, 31  
  Data Encryption, 30  
  Device Administration, 30  
  Disable the Screen Lock, 30  
  Display, 26  
  Face Unlock, 29  
  Forgot Pattern or Passcode, 30  
  Hearing Aid Compatibility, 24  
  Incoming Call Sounds, 25  
  Lock Pattern, 29  
  Mobile Hotspot, 22  
  Notification Ringtone Sounds, 25  
  Notification Sounds, 25  
  Password Lock, 29

Passwords, 30  
PIN Lock, 29  
Plus Code Dialing, 23  
Security Lock Timer, 30  
Set Up Screen Lock, 28  
Sound, 24  
Tethering & Mobile Hotspot, 22  
Text Input, 16  
Text Message Reply, 24  
TTY Mode, 23  
Voice Privacy, 24  
Voicemail, 23  
VPN, 22  
Wi-Fi, 22  
Wireless & Network, 21  
Settings  
  Managing Applications, 32  
Settings  
  Backup and Restore (Privacy), 32  
Settings  
  Data Backup (Privacy), 32  
Settings  
  Automatic Restore (Privacy), 32  
Settings  
  Resetting Your Phone, 33  
Settings  
  Format Internal Storage, 33  
Settings  
  Mount/Unmount SD Card, 33  
Settings  
  Format SD Card, 33  
Settings  
  Language, 34  
Settings  
  Select Locale (Language), 34  
Settings  
  Personal Dictionary, 34  
Settings  
  Keyboard, 34  
Settings  
  Keyboard Input Method, 34  
Settings  
  Motorola Input, 34  
Settings

Built-In Keyboard, 35  
Settings  
Voice Input, 35  
Settings  
Voice Output, 36  
Settings  
Date & Time Settings (Accessibility), 36  
Settings  
System Updates, 36  
Settings  
Phone Status, 36  
Settings  
Bluetooth® Connections, 47  
Settings  
microSD Card, 52  
Settings  
Gallery, 56  
Settings  
Email Account, 65  
Settings  
Roam Mode, 68  
Settings  
Data Roam Guard notification, 68  
Settings  
Location Sources, 73  
Settings  
Browser, 80  
Setup Application, 3  
Sign in to your YouTube account, 81  
Sound Settings  
Incoming Calls, 25  
Silent Mode, 24  
Sound Feedback, 25  
Vibrate, 25  
Vibrate Patterns, 25  
Volume, 25  
Sprint Service  
Account Passwords, 5  
Activation, 2  
Sprint Services  
Operator Services, 6  
Sprint 411, 6  
Sprint Worldwide Wireless Service, 82  
Status Icons, 13



Text  
  Auto-Correction, 16  
  Editing Tips, 16  
  Entering, 14  
Text Messages  
  Compose, 65  
Text Messages and MMS, 65  
Text Messaging  
  New Messages Notification, 66  
  Save and Resume a Draft Message, 66  
  Send a Multimedia Message (MMS), 66  
  Text and MMS Options, 67  
Three Way Call, 20  
Timer, 44  
Touchscreen  
  Keyboard, 15  
  Turn off, 10  
  Turn on, 10  
TTY Mode  
  Turn on or Turn off, 23  
turn Call Guard on or off, 68  
Turn Phone Off, 10  
Turn Phone On, 9  
Typing, 14  
Voice  
  Actions, 47  
  Commands, 47  
Voicemail, 58  
  Notification, 61  
  Retrieve Messages, 61  
  Setting up, 3  
  Setup, 58, 61  
Wi-Fi, 77  
  Find networks in range, 77  
  Search and Connect, 77  
Wi-Fi Hotspot, 78  
  Activating, 79  
  Add security to Wi-Fi hotspot, 78  
  Set Up, 78  
Your Account  
  Manage, 5  
  User Name, 5  
Your Phone (illustration), 1