


ADJUST VOLUME


Press the volume keys to change ring volume (in the home screen) or earpiece volume (during a call).

When playing music or video files, press the volume keys to adjust media volume.



ROTATE THE SCREEN


When you turn your smartphone, the touchscreen can rotate to stay right-side up:


Find it: Menu  > **Settings** > **Display** > **Auto-rotate screen**

HOME SCREEN

quick access to the things you need most

QUICK START: HOME SCREEN

The *home screen* gives you all your latest information in one place. It's what you see when you turn on the smartphone or touch Home  from a menu. It's basically like this:




Note: Your home screen might look a little different.


The home screen extends left and right to give you more room for adding shortcuts, widgets, and more. Flick the


home screen left and right to see more *panels* or to add widgets or shortcuts.

USE & CHANGE YOUR HOME SCREEN


On your home screen, *shortcuts* are icons that open your favorite apps, web bookmarks, contacts, mail labels, or music playlists. *Widgets* show you news, weather, messages, and other updates.

To see other panels of shortcuts and widgets, flick the home screen left or right. Or, touch Home  and touch a thumbnail to go to the panel.

- To **open** something, touch it. Touch Home  to return to the home screen.


Tip: When you open a widget, touch Menu  to see any options or settings.


- To **resize** widgets, touch and hold a corner until you feel a vibration, then drag.
- To **add** something or change your wallpaper, touch and hold an empty spot until you see the **Add to Home screen** menu.




You can add a folder to organize your shortcuts.


- To **move** or **delete** something, touch and hold it until you feel a vibration, then drag it to another spot,

another panel, or the trash  at the top of the screen.

To change your ringtone, display brightness, and more, touch Menu  > **Settings** > **Audio profiles** or **Display**. For details, see “**PERSONALIZE**” on page 22.

Tip: From the home screen, touch Menu  > **Themes** to design different home screens for **Work**, **Home**, and **Weekend**. Your changes are stored in each theme.


SEARCH

Touch Search , then use the window that appears.



SMARTPHONE STATUS & NOTIFICATIONS

In the status bar at the top of your screen, the right side shows smartphone status. The left side shows new messages or events (for details, flick the bar down).




	network strength		battery strength
	new voicemail		new text message
	Bluetooth™ on		Bluetooth connected
	Wi-Fi connected		airplane mode
	USB connected		alarm set
	silent ringer		silent ringer, vibrate on
	mute call		speakerphone


APPS & UPDATES



get the app you want

QUICK START: APPS & UPDATES

You can find all of your apps in one place. From the home screen, touch  to open the app menu. To see all of your apps, flick up and down.

From the app menu, touch  **All apps** to view or create app groups.



To close the app menu, touch Home  or Back .


BROWSE & INSTALL APPS

Get all the fun games and cool apps you want! Android Market™ provides direct access to apps, games, and books that you can download and install on your smartphone.

Find it:  >  **Market**



Scroll to and touch the app you want to install. Then, touch **Install** (if app is free) or **Buy**.

New apps that you install are added to the app menu.


Tip: Choose your apps and updates carefully, from trusted sites, like  **Market**, as some may impact your smartphone's performance—see “**CHOOSE CAREFULLY**” on page 20.

Note: When installing an app, make sure you read the alerts that tell you what information the app will access. If you don't want the app to have access to this information, don't install it.

RECENT APPS

Your smartphone remembers the apps that you used most recently. From the home screen, touch and hold Home  to show the most recent apps used. From the app menu, touch  > **Recent**.

MANAGE & RESTORE APPS

From the home screen, touch Menu  > **Settings** > **Applications** > **Manage Applications**.


Touch an app in the list, then touch **Uninstall** (for apps you downloaded), **Clear cache**, or other options.

To reinstall apps from Android Market, touch  >  **Market**, then touch Menu  > **My apps**. Apps

that you have previously purchased from Android Market are listed and available for download.

CHOOSE CAREFULLY

Apps are great. There's something for everyone. Play, communicate, work, or have fun. But remember, choose your apps carefully. Here are a few tips:


- To help prevent spyware, phishing, or viruses from affecting your smartphone or privacy, use apps from trusted sites, like  **Market**.
- In **Market**, check the apps' ratings and comments before installing.
- If you doubt the safety of an app, don't install it.
- Like all apps, downloaded apps will use up memory, data, battery, and processing power—some more than others. For example, a simple battery level widget will use less than a streaming music player app. After installing an app, if you're not happy with how much memory, data, battery or processing power it's using, uninstall it. You can always install it again later.
- Just like web browsing, you may want to monitor childrens' access to apps to help prevent exposure to inappropriate content.
- Certain apps may not provide completely accurate information. Take care, especially when it comes to personal health.

UPDATE MY SMARTPHONE

You can check, download, and install smartphone software updates using your smartphone, or using your computer:

- Using your smartphone:

You may get an automatic notification of an available update on your smartphone. Simply follow the instructions to download and install.

To manually check for updates, touch Menu  > **Settings** > **About phone** > **System updates**.

Your smartphone downloads any updates over your mobile network. Remember, these updates can be quite large (25MB or more) and may not be available in all countries. If you don't have an unlimited data plan, or mobile network updates are not available in your country, you can update using a computer.






- Using your computer:


On your computer, go to www.motorola.com/support and check the "Software" links. If an update is available, follow the installation instructions.

PERSONALIZE

add your personal touch


QUICK START: PERSONALIZE

To show quick settings from the home screen, touch Menu  > **Settings** > Menu  > **Quick settings**. Touch Menu  > **Edit** to change your quick settings and Menu  > **Advance settings** to return to settings. From the home screen, touch Menu  > **Settings** > **Audio profiles** or **Display**.









Choose separate volume settings for incoming calls, media, alarms, and notifications.

Call & Message Notifications




Set screen brightness

- To choose a **ringtone** or **vibration** for calls and messages, touch Menu  > **Settings** > **Audio profiles**, choose a profile (**General**, **Silent**, **Meeting**, or **Outdoor**), then touch **Phone ringtone**, **Notification ringtone**, or **Vibrate**.
- To change the **volume**, touch Menu  > **Settings** > **Audio profiles**, choose a profile (**General**, **Silent**, **Meeting**, or **Outdoor**), then touch > **Volume**.
- To turn **dialpad** sounds on or off, touch Menu  > **Settings** > **Audio profiles**, choose a profile (**General**, **Silent**, **Meeting**, or **Outdoor**), then touch **Audible touch tones**.
- To turn menu **selection** sounds on or off, touch Menu  > **Settings** > **Audio profiles** choose a profile (**General**, **Silent**, **Meeting**, or **Outdoor**), then touch **Audible selection**.
- To change your **wallpaper**, touch and hold an empty spot on the home screen, then touch **Wallpapers**.
- To change **shortcuts** and **widgets** on your home screen, touch and hold them. For details, see “**HOME SCREEN**” on page 14.
- To set display **brightness**, touch Menu  > **Settings** > **Display** > **Brightness**.
- To control whether some apps **rotate** the screen when you rotate your smartphone, touch Menu  > **Settings** > **Display** > **Auto-rotate screen**.

- To turn on or off **animations** that make your menus look smoother, touch Menu  > **Settings** > **Display** > **Animation**.


LANGUAGE & REGION


To set your menu language and region, touch Menu  > **Settings** > **Language & keyboard** > **Select language**.

CALLS

it's good to talk

QUICK START: CALLS


From the home screen, touch .



Open a list, then touch an entry to call.



Start a conference call.
Call.

(If two SIMs are inserted, you will see two Call keys. Choose the SIM you want to use to call.)




Hang up.






- To **make** a call, touch , enter a number, then touch .

When dialing, touch Menu  to add a pause (pauses two seconds), or wait (waits for your confirmation). To enter the international dialing code, touch and hold .

Note: Using a mobile device or accessory while driving may cause distraction and may be illegal. Always obey the laws and drive safely.

- To **answer** a call, touch drag  to the right.

Note: If the both SIM are activated, choose which SIM card to use.

- **During** a call, touch Menu  to switch to a Bluetooth **headset** (see “**CONNECTIONS**” on page 49). Touch Home  or Back  to hide the active call display (to reopen it, touch .
- To use the **speakerphone** during a call, touch **Speaker**.
- To **enter numbers** during a call, touch **Dialpad**.
- To **mute** or **unmute** a call, touch **Mute**.
- To put a call on **hold**, touch **Hold**.
- To **end** a call, touch **End**.
- To **ignore** an incoming call, drag  to the left.

Tip: For quick access to contacts, see “**FAVORITES**” on page 30.