



EN

MOTOLUXE™ XT

LIFE.  POWERED.

CONGRATULATIONS

MOTOLUXE XT

Your **MOTOLUXE XT** phone delivers more for your work and play.

- **Multi-tasking:** A blistering fast dual-core 1.2 GHz processor makes multi-tasking a snap.
- **Camera:** Use your 8MP camera with advanced features to deliver crisp, quality photos. Your phone's Super AMOLED display makes viewing photos and video playback crisper and more vivid than ever before. Find out more in "**PHOTOS & VIDEOS**" on page 22.

Note: Some apps and features might not be available in all countries.

Caution: Before assembling, charging, or using your phone for the first time, please read the important safety, regulatory and legal information provided with your product.


SAR This product meets the applicable limit for exposure to radio waves (known as SAR) of 2.0 W/kg (ICNIRP). The limits and guidelines include a substantial safety margin designed to assure the safety of all persons, regardless of age and health. The highest SAR values measured for this device are

listed in the regulatory information packaged with your product.

Note: When using the product while worn on your body, either use an approved accessory such as a holster or maintain a distance of 2.5 cm (1 inch) from the body to ensure compliance with SAR requirements. Note that the product may be transmitting even if you are not making a phone call.

MORE

- **Updates:** Phone updates, PC software, user's guides, online help, and more at www.motorola.com.
- **Accessories:** Find more for your phone at www.motorola.com/products.
- **Social:** The latest news, tips & tricks, videos, and so much more—join us on:


 **YouTube™** www.youtube.com/motorola

 **Facebook™** www.facebook.com/motorola

 **Twitter** www.twitter.com/motomobile

YOUR PHONE

the important keys & connectors



Note: Your phone might look a little different.


CONTENTS

LET'S GO	3
CONTROL	4
HOME SCREEN	6
UPDATES	9
CALLS	10
CONTACTS	13
MESSAGES	16
TEXT ENTRY	18
SOCIAL NETWORKING	20
TIPS & TRICKS	21
PHOTOS & VIDEOS	22
MUSIC	25
WEB	26
PERSONALIZE	28
WIRELESS	30
TOOLS	33
MANAGEMENT	35
SECURITY	38
TROUBLESHOOTING	41
SAFETY, REGULATORY & LEGAL	42

LET'S GO




let's get you up and running

ASSEMBLE & CHARGE



WI-FI CONNECT

To use a Wi-Fi network for even faster Internet access, touch the status bar at the top of the home screen and drag it down. Touch the **Wi-Fi networks available** notification to select a preferred network.

You can also touch Apps  >  **Settings** > **Wi-Fi**, then touch the **Wi-Fi** power switch to turn it  **ON**, to scan and connect to wireless networks. There's more in "**WI-FI NETWORKS**" on page 30.

Tip: To save battery life, see "**BATTERY LIFE**" on page 21.


Caution: Please read "**BATTERY USE & SAFETY**" on page 42.

CONTROL

a few essentials

TOUCH


- **Touch:** Choose an icon or option.
- **Touch & Hold:** Select an item and open an action bar.
- **Drag:** Move items in the home screen, or scroll slowly through lists.
- **Flick:** Scroll quickly between views or through lists.
- **Pinch or double-touch:** Zoom in and out on websites, photos, and maps.





Slide two fingers apart or together to zoom in or out.

Drag or flick to scroll.



HOME, BACK, AND RECENT APPS


Touch Home  to close a menu or app and return to the home screen.

Touch Back  to go back one screen.

Touch Recent Apps  to see the most recent apps you've used, then touch an app to re-open it.



Tip: To remove an item from the recent apps list, flick it left or right.

In some apps, you can touch Menu  to open menu options, and touch  to start a search.



TOUCHSCREEN ON/OFF


To save your battery, prevent accidental touches, or when you want to wipe smudges off your touchscreen, put the touchscreen to sleep by pressing the Power key. To wake up the touchscreen, just press the Power key again.

To change how long your phone waits before the screen goes to sleep automatically, touch Apps  >  **Settings** > **Display** > **Sleep**.

Tip: To make the screen lock when it goes to sleep, see "**SCREEN LOCK**" on page 39.

ROTATE THE SCREEN

When you turn your phone, the touchscreen can rotate to stay right-side up:

Find it: Apps  >  **Settings > Display > Auto-rotate screen**

PRESS

POWER KEY MENU

Press and hold the Power Key to turn off your phone (**Power off**), **Reboot** your phone, turn **Airplane mode** on and off, or change the sound setting.

VOLUME KEYS

Press the volume keys to change ring volume (in the home screen) or earpiece volume (during a call).



When playing music or videos, press the volume keys to adjust media volume.

Tip: When your phone rings, press a volume key to quickly silence your ringtone.



QUICK TIPS


If you're not sure what to do next, try one of these:


To...	
Open a text message, see contact details, or open items in a list.	Touch the message, contact, or item.
See options for the current screen (if available).	Touch Menu  .
Select an item and open an action bar (if available).	Touch & hold the item.
Go back to the home screen.	Touch Home  .
Wake up your phone.	Press the Power key.
Reboot an unresponsive phone.	Press and hold the Power key and the down volume key for up to 10 seconds.

HOME SCREEN

quick access to the things you need most

QUICK START: HOME SCREEN

The *home screen* gives you all your latest information in one place. It's what you see when you turn on your phone or touch Home .



Status Bar

Notifications

Drag this bar down to see details.

Widgets

Flick left or right to see more pages of shortcuts & widgets.

Shortcuts

Touch to open.

Favorites Tray

Touch Apps  to see all your apps & widgets.

 **Back**


 **Home**

 **Recent Apps**


Note: Your home screen might look a little different.

USE & CHANGE YOUR HOME SCREEN

Shortcuts on the home screen are icons that open your favorite apps. *Widgets* are apps or tools that provide additional phone functionality and live content.

Some shortcuts (like **People**) have a quick view that you can open by flicking up or down on the shortcut—look for  quick view arrows next to the shortcut.

To see other pages of shortcuts and widgets, flick the home screen left or right.

- **Add shortcuts & widgets:** Touch Apps , touch and hold an app or widget, then drag it to a spot on a home screen page.
- **Create shortcut folders:** To create a folder of shortcuts on your home screen, touch and hold a shortcut, then drag it on top of another shortcut. To add more shortcuts, drag them onto the folder. To name the folder, touch it and enter a name at the bottom.


- **Resize widgets:** You can resize some widgets—touch and hold a widget until you feel a vibration, then release. Drag the blue diamonds at the edges to resize.
- **Move or delete shortcuts & widgets:** Touch and hold a shortcut or widget until you feel a vibration, then drag it to another spot, another page, or **Remove** at the top of the screen.
- **Change wallpaper:** Touch and hold an empty spot on the home screen.

Shortcuts in the *favorites tray* at the bottom of the home screen appear in all home screen pages. You can drag shortcuts or folders in or out of the favorites tray (except Apps ☰) for instant access from any home page.

MOTO SWITCH

Jump right to your favorite apps from the lock screen!

To set up your lock screen apps:



Your favorites.

Touch & hold between the two rings to show your most used apps

Drag to scroll.

Most used apps. Drag an app to the outer ring to add it to your favorites.

Tip: To **delete** a favorite app icon, touch and hold between the two rings, then drag the app icon to the trash icon 🗑️.

To **go to a favorite app** from the lock screen, drag the app towards the lock icon 🔒.


Note: For toggle apps, such as **Bluetooth** or **Flight Mode**, the screen will remain locked.



SEARCH

Touch the Search widget in the home screen, then start typing your search text.

As you type, suggestions appear below the search field:


- To search for a suggestion, touch it.
- To add a suggestion to the search field, touch the arrow beside it.
- To search for the text in the search field, touch  on the touchscreen keypad.



The browser shows a list of search results.

PHONE STATUS & NOTIFICATIONS




























Icons at the top right of the home screen show status information, like signal strength, battery level, and time.

Icons at the top left show messages and app notifications. To see your notifications, touch the status bar and drag it down. Touch a notification to select it.



Tip: To remove a notification from the list, flick it left or right. To clear all notifications, touch . To go to your settings menu, touch .

STATUS & NOTIFICATION ICONS

	network (full signal)		H (fastest data)
	Wi-Fi in range		Wi-Fi connected
	Bluetooth™ on		Bluetooth connected
	GPS active		warning
	USB connected		background data sync
	active call		missed call
	airplane mode		microSD card
	new text message		alarm set
	new email		calendar event reminder
	new voicemail		music player active
	vibrate		speakerphone on
	sound off		call muted
	battery (charging)		downloading
	battery (full charge)		

UPDATES

get the app you want

One of the great things about a smartphone is the apps. Whatever you're into, whatever you want to do, there's probably an app that can help you. So, go to the place that has it all, Google Play™ Store, where you can choose from hundreds of thousands of apps.

UPDATE MY PHONE

You can check, download, and install phone software updates using your phone, or using your computer:

- Using your phone:

You may get an automatic notification of an available update on your phone. Simply follow the instructions to download and install.

To manually check for updates, touch Apps (☰) > ⚙️ **Settings** > **About phone** > **System updates**.

Your phone downloads any updates over your mobile network. Remember, these updates can be quite large (25MB or more) and may not be available in all countries. If you don't have an unlimited data plan, or mobile network updates are not available in your country, you can update using a computer.

- Using your computer:

On your computer, go to www.motorola.com and check the "Software" links. If an update is available, follow the installation instructions.

CALLS

it's good to talk

QUICK START: CALLS

In the home screen, touch  **Phone**.

Tip: When the phone is locked, touch  and flick to .

DIALER



Flick the screen left or right to see dialer, recent calls, or phonebook.


Open options.

Call
Enter a phone number & touch here to call it.

Hide dialpad.

Tip: Search for contacts right from the dialpad! For example, to find **Jeff** in your contacts list, touch **5-3-3-3**. Matching contacts appear above the number field.

DURING A CALL



00:12 **Call Timer**

Enter numbers during a call.

End Call





Speakerphone On/Off

Open options.

Add another person for a conference call.

Put call on hold.

To use a Bluetooth™ device, touch **Bluetooth**. (The device must be turned on and previously paired—see **"CONNECT NEW BLUETOOTH DEVICES"** on page 31.)

Tip: You can touch Home  or Back  to leave the active call display. To reopen it, touch Home  >  **Phone**.



Note: Using a mobile device or accessory while driving may cause distraction and may be illegal. Always obey the laws and drive safely.

MAKE & ANSWER CALLS

To **make** a call, touch  **Phone**, enter a number, then touch .

Tip: When you hold your phone to your ear, the display goes dark to prevent accidental touches. When you move the phone away from your ear, the display lights up again.


To **answer** a call, touch  and flick to .



To send an incoming call to your **voicemail**, touch  and flick to .

Tip: To silence an incoming call alert, press the Power key or the volume keys.




RECENT CALLS


Find it:  **Phone** > 

- To call a number, touch  next to the entry.
- To see call details, touch the entry.
- To view options such as send a text message, create a contact, view a contact, touch the contact.



- To search the recent calls list, touch .
- To clear the list, touch Menu  > **Clear call log**.

FAVORITES



Find it: Apps  >  **People** > 

- To call, text, email, or view contact information, touch the contact.
- To edit, share, delete, or set a ringtone for a contact, touch the contact, then touch Menu .

CONFERENCE CALLS

To start a conference call, call the first number. After the call connects, touch . Dial the next number, or select it from contacts or favorites. When the next number answers, touch .



YOUR PHONE NUMBER

Find it: Apps  >  **Settings** > **About phone** > **Status** > **Select Subscription** > **My phone number**

EMERGENCY CALLS

Note: Your service provider programs one or more emergency phone numbers that you can call under any circumstances, even when your phone is locked. Emergency numbers vary by country. Your pre-programmed emergency number(s) may not work in all locations, and sometimes an emergency call cannot

be placed due to network, environmental, or interference issues.

- 1 Touch  **Phone** (if your phone is locked, touch **Emergency Call**).
- 2 Enter the emergency number.
- 3 Touch  to call the emergency number.

Note: Your phone can use location based services (GPS and AGPS) to help emergency services find you.

COOL DOWN

In very limited circumstances, such as where your phone has been exposed to extreme heat, you may see “Cool Down” messages. To avoid possible damage to your battery and phone, you should follow these instructions until the phone is within its recommended temperature range. When your phone is in “Cool Down” mode, only emergency calls can be made.

MORE CALLING FEATURES

Feature

international calls

If your phone service includes international dialing, touch and hold **0** to insert your local international access code (indicated by **+**). Then enter the country code and phone number.

Feature

voicemail

To listen to your voicemail messages, touch & hold **1** in the dialer.


CONTACTS

be a people person

QUICK START: CONTACTS

Find it: Apps  >  **Contacts**

Tip: When the phone is locked, touch  and flick to .



View favorites.

Create & view groups of contacts.

Contacts List

Touch to view contact information, call, send a text message, & more.

Touch a letter to jump to contact names that start with that letter.

Add contacts.

Search for contacts.

TRANSFER CONTACTS

Get all your contacts, all in one place. Here are a few helpful hints:

- Use Gmail™

When you first set up your phone and sign in to your Google™ account, all your Gmail contacts are synced automatically with your People app. After that, your contacts stay in sync whether you make changes on your phone, from another device, or from a web browser. Most contact applications for mobile phones and email accounts allow you to export your contacts as a “.csv” file. You can then use Gmail to import the file. For more details, go to www.motorola.com/transfercontacts or log in to your Gmail account on your computer and select “Help”.



- More

There are other methods and tools to help you at www.motorola.com/transfercontacts.

LINK CONTACTS


You might have two or more contacts for the same person, maybe a Gmail contact who is also stored on your phone, or one friend with two email addresses. To combine these contacts:

Find it: Apps  >  **Contacts**

Touch a contact to open it, touch Menu  > **Edit**
> Menu  > **Join**, then touch the second contact.

CALL OR EMAIL CONTACTS





Find it: Apps  >  **Contacts**

- To call a contact, touch the contact's name, then touch the number you want to call. To send a text message, touch  next to the number.
- To email a contact, touch the contact's name, then touch the contact's email address.

VIEW CONTACTS


When you log in to a social networking account, you'll know what everybody's up to and when.

Find it: Apps  >  **Contacts**

- To find a contact, touch  and type the contact name.
Touch a contact to open its details. You can start a call or message by touching the phone number, message , or email address.
- To change which group of contacts is shown (like **All contacts**) touch Menu  > **Contacts to display**.
- To change how you view the list of contacts, touch Menu  > **Settings** > **Display options**.

CREATE CONTACTS

Find it: Apps  >  **Contacts** > 




The screenshot shows the 'Add New Contact' screen with the following fields and callouts:

- Name:** A text field with a dropdown arrow and a contact picture icon. Callout: "Set a contact picture."
- Add organization:** A text field.
- PHONE:** A section header.
- Phone:** A text field with a dropdown arrow and a close button (X). Callout: "Set the number type."
- Add new:** A text field. Callout: "Remove this number."
- EMAIL:** A section header.
- Email:** A text field with a dropdown arrow. Callout: "Add another number."
- ADDRESS:** A section header.
- Address:** A text field with a dropdown arrow.
- EVENTS:** A section header.
- Date:** A text field with a dropdown arrow.

Touch any entry area to open the touchscreen keypad.
When you're finished, touch **Done**.

FAVORITES

To add a contact to your favorites list, touch the contact to open it, then touch .

To see your favorites list:


Find it: Apps  >  **Contacts** > 

EDIT OR DELETE CONTACTS

Find it: Apps  >  **Contacts** > *contact* > Menu 
> **Edit** or **Delete**

SYNCHRONIZE CONTACTS

When you change one of your contacts, your smartphone automatically updates your other accounts.

When you change a contact in one of your other accounts, your smartphone updates the contact information in your  **Contacts** app.


PERSONALIZE CONTACTS

Find it: Apps  >  **Contacts**





Add a photo: Touch .

Set a ringtone: Touch *contact* > Menu  > **Set ringtone**.

GROUPS

Find it: Apps  >  **Contacts** > **GROUPS** > *group name*

You can put your contacts into groups (like “Friends” or “Family”) to make it easier to find them.

To create a new group, touch Apps  >  **People** > 
> .



2012.09.28
FCC





MESSAGES

sometimes it's best to text, or IM, or email . . .

READ & REPLY TO MESSAGES


Find it: Apps  >  **Messaging**

Tip: From the phone unlock screen, touch  and flick to .

- To **open** a text message and all of its replies, touch it.
- To **respond** to a text message, open it and enter your response in the text box at the bottom.
- To **delete** a message, touch and hold to select it, then drag it to the trash can  in the upper right corner.
- To **adjust** messaging options, touch Apps 
>  **Messaging** > Menu  > **Settings**.


CREATE MESSAGES

Find it: Apps  >  **Messaging** > 

Enter the recipient and message. Touch Menu  to **Insert smiley** or **Add subject**.

To add an attachment, touch  in the upper right corner.

SEND & RECEIVE MESSAGE ATTACHMENTS

To send a file in a message, open a new message and touch  in the upper right corner.



When you receive a message with an attachment, open the message and touch the file name to download it. Touch the name again to open it. Some file types can be converted to HTML for faster viewing, and your phone will show **Get HTML version**.

While viewing the attachment, touch it to save it, share it, and more.

Tip: To send and receive large attachments faster, use a Wi-Fi connection (see “**WI-FI NETWORKS**” on page 30).

EMAIL



You can set up multiple email accounts on your phone.

Touch Apps  >  **Settings** > **Accounts & sync** > **ADD ACCOUNT**, then:

- Select **Corporate** for Microsoft™ Exchange server work email accounts. Enter details from your IT administrator.



Tip: You might need to enter your domain name and user name (like *domain/username*).

- Select **Email** for your personal email accounts. For account details, contact the account provider.

To read and reply to messages on your email accounts, touch Apps  >  **Email**.


INSTANT MESSAGES

To send and receive instant messages, you can use Google Talk™.

Find it: Apps  >  **Talk**

Tip: You can also download an instant messaging app from Play Store™.

VOICEMAIL

When you have a new voicemail,  appears at the top of the screen. Drag down the status bar and touch the **New voicemail** notification to listen to your voicemail message.

If you need to change your voicemail number, in the home screen touch  **Phone** > Menu  > **Settings** then select the SIM card and touch **Voicemail Settings**.


2012.09.28
FCC

TEXT ENTRY


keys when you need them

TOUCHSCREEN KEYPAD


You can open a keypad on your screen by touching a text box.



Open a keypad for numbers & symbols.

Tip: To close the keypad without saving any text (for example, to select a different text box), touch Back .

INPUT METHODS

To select a text input method, touch and hold Space  to open the **Select input method** menu, then touch the method you want.


MOTOROLA INPUT

Enter text a letter at a time. As you type, your phone suggests words from your dictionary and chosen language. The phone also automatically enters apostrophes in some words, like "dont."

To add a word to your dictionary, touch the word, then select **+ add to dictionary**.


SWYPE™

Enter words with one continuous motion. Just drag your finger over the letters in the word.






To enter a word, just trace a path through the letters. To capitalize, go above the keypad. For double letters, circle the letter.

Swype tips:


- To enter apostrophes in common words (like “I’ll”), drag through the **n** as though it was an apostrophe.
- To enter other punctuation, numbers, or symbols, touch Symbols .
- To correct a word, *double-touch* it (tap twice, quickly). Swype shows a small menu of other word options. Swype might also show a menu if it can’t guess your word.
- If Swype doesn’t know a word, you can still touch the letter keys to enter it. Swype remembers, so next time you can just drag over the letters.


TYPING TIPS

To...	
Enter one capital letter	Touch Shift  .
Enter only capital letters	Touch and hold Shift  . Touch again to revert to lowercase.
Move the text entry cursor	Touch the text where you want the cursor to go.

To...	
Select text	Touch and hold or double-touch text to select it. Tabs mark the boundaries of the selected text. Drag the tabs to select the text you want.
Cut or Copy selected text	Touch icons at the top of the screen to Cut or Copy selected text. In a landscape display, touch Edit > Cut or Copy .
Paste cut or copied text at cursor location	Touch the Paste icon at the top of the screen. In a landscape display, touch Edit > Paste .
Delete character to left of cursor	Touch Delete  (hold to delete more).

TEXT INPUT SETTINGS


Find it: Menu  > **System settings** > **Language & input**

- To change the language for your phone and touchscreen keypad, touch **Language**.
- To change the default text input method, touch **Default** under **KEYBOARD & INPUT METHODS**.
- To change text input settings, touch  next to **Android keyboard** or **Swype**.



SOCIAL NETWORKING

my life, your life

BROWSER ACCESS TO SOCIAL SITES

You can use the  **Browser** to track your social networking accounts on sites like Google+, Facebook®, Twitter, and LinkedIn. If you don't have accounts on these sites, visit their websites to set them up.









SYNC ACCOUNTS WITH YOUR PHONE

When you log in to a social networking account on your phone, you may be prompted to sync account contacts, pictures, and status with your  **People** app. You can accept or decline to sync. You can change your sync settings at any time by touching Menu  > **Settings** in the social networking app.

TIPS & TRICKS

a few handy hints



GENERAL TIPS

- Screen brightness changes as your phone senses the current lighting conditions.
- To see recently dialed numbers, touch  **Phone** > .
- To sleep/wake your phone, press the Power key.
- To set screen timeout, touch Apps  >  **Settings** > **Display** > **Sleep**.
- To search, touch Search . To voice search, touch and hold Search .
- To automate everyday tasks, touch Apps  >  **Smart Actions**.
- To change a shortcut in the favorites tray at the bottom of the home screen, touch and hold a shortcut, then drag it in or out of the favorites tray.
- To turn sound on/off, press and hold the Power key, then touch a sound setting.
- To turn airplane mode on/off, press and hold the Power key > **Airplane mode**.












BATTERY LIFE

Your phone is like a small computer, giving you a lot of information and apps, at blazing fast speeds, with a

touch display! Depending on what you use, that can take a lot of power.

To start getting the most out of your battery, touch Apps  >  **Settings** > **Battery**. This shows you what's using the most battery power.

To save even more battery life between charges, try these:

- To help minimize battery use, touch Apps  > **Battery Manager**.
- To help minimize battery use, touch Apps  >  **Smart Actions**. Check out the sample rules that enable battery savings: **Nighttime Battery Saver**, and **Battery Extender**.
- Turn off background data transfers: Touch Apps  >  **Settings** > **Data usage** > Menu  > **Restrict background data**.
- Turn off Wi-Fi and Bluetooth™ power when not in use: Touch Apps  >  **Settings**, then touch the switch next to **Wi-Fi** or **Bluetooth** to turn them .
- Reduce recording or watching videos, listening to music, or taking pictures.
- Remove widgets that stream information to your home screen, like news or weather.
- Reduce GPS use: Touch Apps  >  **Settings** > **Location services**, and uncheck **GPS satellites**.

- Reduce display brightness: Touch Apps (☰) > ⚙️ **Settings** > **Display** > **Brightness** > (dimmer setting).
- Reduce display timeout delay: Touch Apps (☰) > ⚙️ **Settings** > **Display** > **Sleep** > (shorter setting).
- Remove unused online accounts that you registered (“**MANAGE ACCOUNTS**” on page 36).


PHOTOS & VIDEOS

see it, capture it, share it!

QUICK START: CAMERA

Find it: Apps (☰) > 📷 **Camera**


Tip: When the phone is locked, touch 🔒 and flick to 📷.





TAKE PHOTOS


Find it: Apps  >  **Camera**

Touch  to **take** a photo.

Your phone stores the photo in the  **Gallery**, and shows a thumbnail image in the upper left corner. To **see** the photo, touch the thumbnail. Then:

- To **share** the photo in a message or post it online, touch .
- To **delete** the photo, touch .
- To **set** the photo as a contact photo or wallpaper, **print, edit**, or do more with it, press Menu .

CAMERA SETTINGS

Options	
 Settings	<ul style="list-style-type: none">• Store Location• Picture size
Color effect	Set a photo effect: None, Sepia, Negative , and more.
Scene mode	Set the type of photo you want to take: Auto, Portrait, Landscape , and more.
Exposure	Select an exposure setting.
White balance	Set the white balance you want: Auto, Daylight, Cloudy , and more.


Options

Flash mode	Set to On, Off , or Auto .
-------------------	--

RECORD VIDEOS




Find it: Apps  >  **Camera**, then touch  to switch to camcorder

Touch  to **start** and **stop** video recording.


Your phone stores the video in the  **Gallery**, and shows a thumbnail image in the upper left corner. To **see** the video, touch the thumbnail. Then:

- To **play** the video, touch .

Tip: To see the controls when a video is playing, touch the screen.




- To **share** the video in a message or post it online, touch .
- To **delete** the video, touch .
- To see other video options, touch Menu .

CAMCORDER SETTINGS

Options	
 Settings	<ul style="list-style-type: none">• Store location• Video encoder
Video quality	Set your video quality: High , Medium or Low .
Time lapse interval	Set the interval time you want.
Color effect	Set a photo effect: None , Sepia , Negative , and more.
White balance	Set the white balance you want: Auto , Daylight , Cloudy , and more.
Flash mode	Set to On or Off .

EDIT, SHARE, OR DELETE PHOTOS & VIDEOS






Find it: Apps  >  **Gallery**

- **View, share, or delete:** Touch a thumbnail to open it, then touch  to share or Menu  > **Delete** to delete. Touch Menu  to edit or see other options.

Tip: To select multiple files, open a folder, touch and hold a photo, then touch others.

- **Zoom:** Open a photo, then drag two fingers apart or together on the touchscreen.

Tip: Turn your phone sideways for a widescreen view.

- **Wallpaper or contact photo:** Open a picture, then touch Menu  > **Set picture as**.
 - **Edit:** Open a picture, then touch Menu  > **Edit**.
 - **Slideshow:** Open a folder, then touch  at the top. To stop the slideshow, touch the display or Back .
- Tip:** To show the slideshow on a television or other device, touch .


To copy photos to/from a computer, go to “**MEMORY CARD & FILE MANAGEMENT**” on page 35.


MUSIC

when music is what you need...

Keep your music with you! Put music on your phone so you can listen and create playlists anytime.

QUICK START: MUSIC


From the home screen, touch Apps (⋮) >  **Music**, then choose a song to play it:




- To adjust **volume**, use the volume keys.

- When a song is playing, you touch Menu (☰) to add it to a **playlist** or use it as a **ringtone**.

To edit, delete, or rename playlists, touch Apps (⋮) > **Music** touch the **Playlists** tab, then touch and hold the playlist name.


- To **hide** the player and use other apps, touch Home (⏴). Your music keeps playing. To return to the player, flick down the status bar and touch .

Tip: For quick music player controls, touch and hold an empty spot in your home screen, then choose **Widget** > **Music**.

- To **stop** the player, touch .
- Before a **flight**, turn off network and wireless connections so that you can keep listening to music: Press and hold Power (⏻) > **Airplane mode**.

Note: When you select airplane mode, all wireless services are disabled. You can then turn Wi-Fi and/or Bluetooth back on, if permitted by your airline. Other wireless voice and data services (such as calls and text messages) remain off in airplane mode. Emergency calls to your region's emergency number can still be made.

You can use your phone's 3.5mm OMTP headset jack to connect wired headphones, or go wireless with .

To listen to FM **radio** stations, Plug in a 3.5mm OMTP headset and touch Apps  > **FM Radio**. Your phone uses the headset wire as the radio antenna.

MUSIC FILES

To get songs for your music player, you can download them from online services or copy them from your computer. Your music player can play these file formats: MP3, M4A, AAC, ACC+, MIDI, WAV, or OGG Vorbis.

Note: Your phone does not support any DRM protected files.

Note: Copyright—do you have the right? Always follow the rules. See “Content Copyright” in your legal and safety information.

To copy files **from your computer** to your phone, you can use “**USB CONNECTION**” on page 36 or “**BLUETOOTH™ HANDSFREE DEVICES**” on page 31.

To **save a CD** on your computer (“rip” the CD), you can use a program like Microsoft™ Windows™ Media Player. First, make sure you change the format to MP3 (under Rip > Format in Windows Media Player).


WEB

surf the web with your phone

QUICK START: BROWSER

Find it:  **Browser**

Tip: When the phone is locked, touch  and flick to .



Tip: To zoom in, drag two fingers apart on the touchscreen.