

APPLICANT: MOTOROLA, INC.

FCC ID: IHDT6EK1

**INSTRUCTION MANUAL**

A preliminary draft copy of the Users Manual follows:



**MOTOROLA**

A1000 Communicator  
UMTS

***START HERE >***



# Welcome

---

Welcome to world of Motorola digital wireless communications! We are pleased that you have chosen the Motorola A1000 multimedia communicator.



Motorola, Inc., Consumer Advocacy Office  
1307 East Algonquin Road  
Schaumburg, IL 60196

1-800-331-6456 (United States)  
1-888-390-6456 (TTY/TDD United States)  
1-800-461-4575 (Canada)

[www.motorola.com](http://www.motorola.com) (United States)  
[www.motorola.ca](http://www.motorola.ca) (Canada)

MOTOROLA and the Stylized M Logo are registered in the US Patent & Trademark Office. All other product or service names are the property of their respective owners. The Bluetooth trademarks are owned by their proprietor and used by Motorola, Inc. under license.

© Motorola, Inc. 2004.

### **Software Copyright Notice**

The Motorola products described in this manual may include copyrighted Motorola and third party software stored in semiconductor memories or other media. Laws in the United States and other countries preserve for Motorola and third party software providers certain exclusive rights for copyrighted software, such as the exclusive rights to distribute or reproduce the copyrighted software. Accordingly, any copyrighted software contained in the Motorola products may not be modified, reverse-engineered, distributed, or reproduced in any manner to the extent allowed by law. Furthermore, the purchase of the Motorola products shall not be deemed to grant either directly or by implication, estoppel, or otherwise, any license under the copyrights, patents, or patent applications of Motorola or any third party software provider, except for the normal, non-exclusive, royalty-free license to use that arises by operation of law in the sale of a product.

Manual number: 68XXXXXX61

# Contents

---

<b>Welcome</b> .....	1
<b>Contents</b> .....	3
<b>Safety and General Information</b> .....	9
<b>European Union Directives</b>	
<b>Conformance Statement</b> .....	15
<b>Getting Started</b> .....	16
What's in the Box? .....	16
About this Guide .....	17
Optional Features .....	17
Optional Accessories .....	17
Installing the USIM Card .....	17
Installing the Memory Card .....	19
Battery Use .....	20
Installing the Battery .....	21
Charging the Battery using the Travel Charger .....	22
Charging the Battery using the Desktop	
Charging Cradle .....	23
Turning Your Communicator On and Off .....	23
Setting Up Your Communicator for the First Time .....	24
Making and Answering Calls .....	24
Making a Call .....	25
Answering a Call .....	25
<b>Using Your Communicator</b> .....	26
Communicator Display .....	26
Using Touchscreen Control .....	27
Using the 8-way Navigation Key .....	27
Using the 3 Key .....	27
Using the Game Keys .....	28

Game Key A and Game Key B .....	28
Opening Applications .....	28
Folders .....	30
Switching Folders .....	30
Filing New Entry in Folder .....	30
Moving Entry to a Different Folder .....	31
Adding, Renaming, and Deleting Folders .....	31
Status Indicators .....	31
Entering Text .....	34
Handwriting Recognition .....	34
Virtual Keyboard .....	36
Using AGPS Location Information .....	36
Limitations of AGPS .....	36
<b>Home Screen.</b> .....	38
Displaying the Home Screen .....	38
Screen Contents .....	38
Personalizing Home Screen .....	40
<b>Calling Features</b> .....	41
Opening Phone Application .....	41
Displaying Your Phone Number .....	42
Using the Internal Speakerphone .....	42
Adjusting the Volume .....	42
Making a Voice Call .....	43
Dialing with the Keypad .....	43
Dialing Stored Phone Numbers .....	43
Redialing Failed Voice Calls .....	43
Making a Video Call .....	43
Making a Video Call to Another Phone .....	44
Making a Video Call to a Computer .....	45
Calling an Emergency Number .....	46
Using AGPS During an Emergency Call .....	46
Dialing the Call .....	48

Answering Calls . . . . .	48
Switching to Airplane Mode . . . . .	49
Turning off Call Ringing . . . . .	49
<b>Messages and Email</b> . . . . .	50
Setting up Messaging Accounts . . . . .	50
Email . . . . .	50
MMS and SMS . . . . .	51
Opening Messaging Application . . . . .	52
Creating and Sending Messages . . . . .	53
Email and SMS . . . . .	53
MMS . . . . .	54
Receiving and Reading Messages . . . . .	57
<b>Contact List</b> . . . . .	58
Opening Contacts Application . . . . .	58
Adding Contacts . . . . .	59
Adding New Fields . . . . .	61
Recording Voice Tags for Contacts . . . . .	62
Deleting Voice Tags . . . . .	63
Editing Contacts . . . . .	64
Communicating with Contacts . . . . .	64
Using Voice Dialing . . . . .	65
<b>Customizing Communicator Settings</b> . . . . .	66
Setting the Wallpaper Image . . . . .	66
Setting the Screen Brightness . . . . .	66
Setting the Screen Calibration . . . . .	67
Setting the Volume for System Sounds . . . . .	67
Setting a 3 Key Shortcut . . . . .	68
Choosing Ring Tones . . . . .	68
Choosing Ring Tones for Calls . . . . .	68
Choosing Ring Tones for Messages . . . . .	69
Choosing a Vibrate Pattern . . . . .	69



<b>Getting More Out of Your Communicator</b> . . . . .	71
Installing the A1000 Desktop Suite . . . . .	71
Connecting a Bluetooth Device . . . . .	72
Changing Your Bluetooth Settings . . . . .	73
Connecting to a Computer . . . . .	74
Setting Up a USB Cable Connection . . . . .	74
Setting Up a Bluetooth Connection . . . . .	74
Using the Desktop Suite . . . . .	75
Using Remote Synchronization . . . . .	75
Setting Up Your Account . . . . .	75
Configuring the Settings . . . . .	76
Using PicseL Viewer . . . . .	77
Opening Documents . . . . .	77
Navigating Documents . . . . .	78
Setting Preferences . . . . .	80
<b>Personal Organizer Features</b> . . . . .	81
Calendar . . . . .	81
Adding a Calendar Entry . . . . .	81
Switching Calendar Views . . . . .	83
Moving Entries to the To Do Application . . . . .	84
To Do . . . . .	84
Adding Entries: . . . . .	85
Marking Tasks as Complete . . . . .	86
Deleting Entries . . . . .	87
Moving Entries to Calendar . . . . .	87
Notes . . . . .	88
Adding Notes . . . . .	88
Time . . . . .	88
Setting the Time and Date . . . . .	89
Setting Location . . . . .	90
Setting Alarms . . . . .	91
Responding to Alarms . . . . .	91

Turning Alarm Sounds Off .....	92
Calculator .....	92
Making Voice Recordings .....	92
Playing a Recording .....	94
Deleting a Recording .....	94
Sending a Recording .....	94
<b>Security</b> .....	95
Locking and Unlocking Communicator .....	95
Establishing Password Protection .....	95
<b>News and Entertainment</b> .....	97
Web Browser .....	97
Setting Up Your Internet Account .....	97
Opening Web Browser .....	97
Opening Web Pages .....	98
Adding Bookmarks .....	98
Saving Web Pages .....	99
Downloading Audio, Video, and Pictures .....	99
Music .....	100
Opening Music .....	100
Playing an Audio Track .....	101
Managing Music Playlists .....	103
Playing a Music Playlist .....	104
Saving Audio Files .....	106
Camera .....	107
Opening Camera Application .....	107
Using the Front and Back Camera Lens .....	108
Using the Camera Control Keys .....	108
Taking Still Pictures .....	109
Selecting Camera Settings .....	109
Recording Video Clips .....	110
Using Self-Timer .....	110
Available Memory Indicator .....	111

Switching to Pictures .....	111
Switching to Video .....	111
Video .....	112
Opening Video .....	112
Playing a Video Clip .....	113
Playing Streaming Video and Audio .....	114
Saving Video Clips .....	115
Sending Video Clips .....	115
Pictures .....	116
Opening Pictures .....	116
Viewing Pictures .....	117
Viewing Slideshow .....	118
Editing Pictures .....	119
Sending Pictures .....	119
<b>Specific Absorption Rate Data .....</b>	<b>121</b>
<b>Motorola Limited Warranty for the United States and Canada .....</b>	<b>123</b>
<b>Index .....</b>	<b>128</b>

# ***Safety and General Information***

---

IMPORTANT INFORMATION ON SAFE AND EFFICIENT OPERATION.  
READ THIS INFORMATION BEFORE USING YOUR PHONE.

The information provided in this document supersedes the general safety information in user's guides published prior to December 1, 2002.

## ***Exposure To Radio Frequency (RF) Energy***

Your phone contains a transmitter and a receiver. When it is ON, it receives and transmits RF energy. When you communicate with your phone, the system handling your call controls the power level at which your phone transmits.

Your Motorola phone is designed to comply with local regulatory requirements in your country concerning exposure of human beings to RF energy.

## ***Operational Precautions***

To assure optimal phone performance and make sure human exposure to RF energy is within the guidelines set forth in the relevant standards, always adhere to the following procedures.

### ***External Antenna Care***

Use only the supplied or Motorola-approved replacement antenna. Unauthorized antennas, modifications, or attachments could damage the phone.

Do NOT hold the external antenna when the phone is IN USE. Holding the external antenna affects call quality and may cause the phone to operate at a higher power level than needed. In addition, use of unauthorized antennas may result in non-compliance with the local regulatory requirements in your country.

## ***Phone Operation***

When placing or receiving a phone call, hold your phone as you would a wireline telephone.

## ***Body-Worn Operation***

To maintain compliance with RF energy exposure guidelines, if you wear a phone on your body when transmitting, always place the phone in a Motorola-supplied or approved clip, holder, holster, case, or body harness for this phone, if available. Use of accessories not approved by Motorola may exceed RF energy exposure guidelines. If you do not use one of the body-worn accessories approved or supplied by Motorola, and are not using the phone held in the normal use position, ensure the phone and its antenna are at least 1 inch (2.5 centimeters) from your body when transmitting.

## ***Data Operation***

When using any data feature of the phone, with or without an accessory cable, position the phone and its antenna at least 1 inch (2.5 centimeters) from your body.

## ***Approved Accessories***

Use of accessories not approved by Motorola, including but not limited to batteries and antennas, may cause your phone to exceed RF energy exposure guidelines. For a list of approved Motorola accessories, visit our website at [www.Motorola.com](http://www.Motorola.com).

## ***RF Energy Interference/Compatibility***

**Note:** Nearly every electronic device is susceptible to RF energy interference from external sources if inadequately shielded, designed, or otherwise configured for RF energy compatibility. In some circumstances your phone may cause interference.

## ***Facilities***

Turn off your phone in any facility where posted notices instruct you to do so. These facilities may include hospitals or health care facilities that may be using equipment that is sensitive to external RF energy.

## ***Aircraft***

When instructed to do so, turn off your phone when on board an aircraft. Any use of a phone must be in accordance with applicable regulations per airline crew instructions.

## ***Medical Devices***

### **Pacemakers**

Pacemaker manufacturers recommend that a minimum separation of 6 inches (15 centimeters) be maintained between a handheld wireless phone and a pacemaker.

Persons with pacemakers should:

- ALWAYS keep the phone more than 6 inches (15 centimeters) from your pacemaker when the phone is turned ON.
- NOT carry the phone in the breast pocket.
- Use the ear opposite the pacemaker to minimize the potential for interference.
- Turn OFF the phone immediately if you have any reason to suspect that interference is taking place.

### **Hearing Aids**

Some digital wireless phones may interfere with some hearing aids. In the event of such interference, you may want to consult your hearing aid manufacturer to discuss alternatives.

### **Other Medical Devices**

If you use any other personal medical device, consult the manufacturer of your device to determine if it is adequately shielded from RF energy. Your physician may be able to assist you in obtaining this information.

## ***Use While Driving***

Check the laws and regulations on the use of phones in the area where you drive. Always obey them.

When using your phone while driving, please:

- Give full attention to driving and to the road.
- Use handsfree operation, if available.
- Pull off the road and park before making or answering a call if driving conditions so require.

Responsible driving best practices may be found in the “Wireless Phone Safety Tips” at the end of this manual and at the Motorola website:

[www.Motorola.com/callsmart](http://www.Motorola.com/callsmart).

## ***Operational Warnings***

### ***For Vehicles With an Air Bag***

Do not place a phone in the area over an air bag or in the air bag deployment area. Air bags inflate with great force. If a phone is placed in the air bag deployment area and the air bag inflates, the phone may be propelled with great force and cause serious injury to occupants of the vehicle.

### ***Potentially Explosive Atmospheres***

Turn off your phone prior to entering any area with a potentially explosive atmosphere. Do not remove, install, or charge batteries in such areas. Sparks in a potentially explosive atmosphere can cause an explosion or fire resulting in bodily injury or even death.

**Note:** The areas with potentially explosive atmospheres referred to above include fueling areas such as below decks on boats, fuel or chemical transfer or storage facilities, areas where the air contains chemicals or particles, such as grain, dust, or metal powders. Areas with potentially explosive atmospheres are often but not always posted.






### ***Blasting Caps and Areas***

To avoid possible interference with blasting operations, turn OFF your phone when you are near electrical blasting caps, in a blasting area, or in areas posted “Turn off electronic devices.” Obey all signs and instructions.

## Batteries

Batteries can cause property damage and/or bodily injury such as burns if a conductive material such as jewelry, keys, or beaded chains touch exposed terminals. The conductive material may complete an electrical circuit (short circuit) and become quite hot. Exercise care in handling any charged battery, particularly when placing it inside a pocket, purse, or other container with metal objects. **Use only Motorola original batteries and chargers.**

Your battery or phone may contain symbols, defined as follows:

Symbol	Definition
	Important safety information will follow.
	Your battery or phone should not be disposed of in a fire.
	Your battery or phone may require recycling in accordance with local laws. Contact your local regulatory authorities for more information.
	Your battery or phone should not be thrown in the trash.
	Your phone contains an internal lithium ion battery.

## Seizures/Blackouts

Some people may be susceptible to epileptic seizures or blackouts when exposed to flashing lights, such as when watching television or playing video games. These seizures or blackouts may occur even if a person never had a previous seizure or blackout.

If you have experienced seizures or blackouts, or if you have a family history of such occurrences, please consult with your doctor before playing video games on your phone or enabling a flashing-lights feature on your phone. (The flashing-light feature is not available on all products.)



Parents should monitor their children's use of video game or other features that incorporate flashing lights on the phones. All persons should discontinue use and consult a doctor if any of the following symptoms occur: convulsion, eye or muscle twitching, loss of awareness, involuntary movements, or disorientation.

To limit the likelihood of such symptoms, please take the following safety precautions:

- Do not play or use a flashing-lights feature if you are tired or need sleep.
- Take a minimum of a 15-minute break hourly.
- Play in a room in which all lights are on.
- Play at the farthest distance possible from the screen.

### ***Repetitive Motion Injuries***

When you play games on your phone, you may experience occasional discomfort in your hands, arms, shoulders, neck, or other parts of your body. Follow these instructions to avoid problems such as tendonitis, carpal tunnel syndrome, or other musculoskeletal disorders:

- Take a minimum 15-minute break every hour of game playing.
- If your hands, wrists, or arms become tired or sore while playing, stop and rest for several hours before playing again.
- If you continue to have sore hands, wrists, or arms during or after play, stop playing and see a doctor.

# **European Union Directives Conformance Statement**

---



Hereby, Motorola declares that this product is in compliance with

- The essential requirements and other relevant provisions of Directive 1999/5/EC
- All other relevant EU Directives

IMEI: 350034/40/394721/9

**CE0168**

Type: MC2-41H14

The above gives an example of a typical Product Approval Number.

You can view your product's Declaration of Conformity (DoC) to Directive 1999/5/EC (to R&TTE Directive) at [www.motorola.com/rtte](http://www.motorola.com/rtte). To find your DoC, enter the product Approval Number from your product's label in the "Search" bar on the web site.

# Getting Started

---



## What's in the Box?

Your multimedia communicator comes with a:

- Rechargeable battery
- Rapid charger and regional adapter
- Desktop charging station
- Stylus
- Stereo headset with send/end key
- CD-ROM with PC sync software, downloadable media files, utilities, and various applications
- USB data cable
- Removable memory card with SD/MMC adapter (see Note)
- Protective carrying case (see Note)
- User documentation

**Note:** The in-box items may vary by country. Contact 3 for more details.

You can customize your communicator for maximum performance and portability. To buy Motorola Original™ accessories, contact the Motorola Customer Call Center at 1-800-331-6456 in the United States or 1-800-461-4575 in Canada.

For more information, visit:  
[www.motorola.com](http://www.motorola.com) (United States)  
[www.motorola.ca](http://www.motorola.ca) (Canada)

## **About this Guide**

This user's guide describes the basic features in your multimedia communicator.

**Note:** A **More Here** reference guide for your communicator is provided on the in-box CD that describes your communicator's features in more detail.

## **Optional Features**



This label identifies an optional network, USIM, or subscriber-dependent feature that may not be offered by all service providers in all geographical areas. Contact your service provider for more information.

## **Optional Accessories**



This label identifies a feature that requires an optional Motorola Original™ accessory.

## **Installing the USIM Card**

Your USIM (Universal Subscriber Identity Module) card contains your phone number, service details, and phonebook/message memory.




**Caution:** Do not bend or scratch your USIM card. Avoid exposing your USIM to static electricity, water, or dirt.




### Action

- 1 Push down the release latch, and slide the back cover down to remove it.




Release Latch

- 2 Slide the USIM card door toward the top, then lift upward to open.




- 3 Insert the USIM card into the tray (gold plated contacts facing down, and notch to the right).



## Action

- 4 Close the USIM card door, then slide downward to lock, as shown on the door and in the illustration.




## Installing the Memory Card

The memory card lets you store multimedia files, such as audio clips, pictures, and video clips.


## Action

- 1 If back cover is on, remove it as described in the procedures.
- 2 Slide the memory card door to the left, as shown in the illustration, and lift open.



- 3 Insert the memory card into the tray (gold plated contacts facing down, and notches to the right).
- 4 Close the memory card door, then slide downward to lock it.

## Battery Use



Battery performance depends on many factors including your wireless carrier's network configuration; signal strength; the temperature at which you operate your phone; the features and/or settings you select and use; items attached to your phone's accessory connector port; your voice, data, and other application usage pattern.

**Caution:** To prevent injuries or burns, do not allow metal objects to contact or short-circuit the battery terminals.

To maximize your battery's performance:

- Always use Motorola Original™ batteries and battery chargers. The phone warranty does not cover damage caused by using non-Motorola batteries and/or battery chargers.
- New batteries or batteries stored for a long time may require a longer charge time.
- Maintain the battery at or near room temperature when charging.
- Do not expose batteries to temperatures below -10°C (14°F) or above 45°C (113°F). Always take your phone with you when you leave your vehicle.
- When you do not intend to use a battery for a while, store it uncharged in a cool, dark, dry place, such as a refrigerator.
- Batteries gradually wear down and require longer charging times. This is normal. If you charge your battery regularly and notice a decrease in talk time or

an increase in charging time, then it is probably time to purchase a new battery.

The rechargeable batteries that power this phone must be disposed of properly and may need to be recycled. Refer to your battery's label for battery type. Contact your local recycling center for proper disposal methods.



**Warning:** Never dispose of batteries in a fire because they may explode.


## ***Installing the Battery***



Use only Motorola Original™ batteries and accessories. Store batteries in their protective cases when not in use.

### **Action**


- 1** Remove the battery from its plastic bag
- 2** If the back cover is on, remove it as described in the procedures.
- 3** Insert the battery under the tab and push down.





**Action**

- 4 Replace back cover and slide into place until it locks.



---


---

## ***Charging the Battery using the Travel Charger***

New batteries are shipped partially charged. Before you can use your communicator, you need to install and charge the battery, as indicated by the following instructions. Some batteries perform best after several charge/discharge cycles.

**Action**

- 1 Plug the charger in with the release tab up.




- 2 Plug the other end into an electrical outlet. While the battery is charging, **Charging Battery** and the battery's current charge level (**Very Low** to **High**) display on the screen.
  - 3 When **Charging Complete** displays, press the release tab and remove the charger.
- 
-

## Charging the Battery using the Desktop Charging Cradle

### Action


- 1 Plug the travel charger, release tab end, into the back of the charging cradle with the charging cradle with the release tab up.
- 2 Plug the other end into an electrical outlet.



Getting Started

## Turning Your Communicator On and Off

After you turn the communicator on, your personal home page displays after the startup sequence (see page 38).



Slide switch down for 1 second to turn on or off.

## **Setting Up Your Communicator for the First Time**



When you turn on the communicator for the first time, you need to:

- Install the A1000 Desktop Suite from the in-box CD. See page 72 for set up and installation procedures.
- Select primary and secondary languages
- Calibrate the screen for accurate screen taps (see page 67).
- Set time and date (see page 88).



## **Making and Answering Calls**

To make and answer calls, your communicator must:

- be turned on
- have a USIM card installed
- have a network connection with adequate signal strength




## Making a Call

### Action

- 1 Press  or tap .
- 2 Select a voice or video call by tapping:

 voice call



 video call

- 3 Use the stylus to tap the number you want to dial on the keypad.
- 4 Press .
- 5 Press  to turn on the speakerphone during the call (see page 42).  
**Note:** You must be in an active call to use the speakerphone.
- 6 To end the call, press .

## Answering a Call

When you receive a call, the communicator rings or vibrates (unless set to Silent mode).

### Action

- 1 Press  or tap **Answer**.
- 2 To end the call, press .




# Using Your Communicator

See page 1 for a basic phone diagram.

## Communicator Display




Using Your Communicator



<b>Application Selector Bar</b>	Shows six icons that allow easy to access to commonly used applications.
<b>Menu Bar</b>	Shows menus for the open application.
<b>Application Space</b>	Shows the open application.
<b>Button Bar</b>	Shows buttons you can select in the open application.
<b>Status Bar</b>	Shows communicator status information.

## Using Touchscreen Control

The stylus fits in a compartment on the side of the communicator. Using the stylus, tap once on an icon, text, or on-screen button to select and open an item.



## Using the 8-way Navigation Key



Navigation Key

You can press the navigation key up, down, left, or right to highlight an item. Press the center key to select the highlighted item.

**Note:** This guide describes how to use touchscreen control to use the features. In most cases, it does not include the equivalent 8-way Navigation key for using the feature.

## Using the 3 Key

The 3 key (📄) provides access to unique features from 3. See the 3 welcome package for more details.




- Press to open the browser.
- Press and hold for 3 seconds to go to **My Shortcut**.

**Note:** The default shortcut is Home. To change the shortcut, see page 68.





## Using the Game Keys



### Game Key A and Game Key B


These keys are used when you play games on your communication. The action of each key varies depending on the game being played.

**Tip:** You can press Game Key A () to open the first (leftmost) menu in the menu bar. Press  again to close the menu.

### Opening Applications
















Your communicator has many built-in applications for communications, personal organization, and entertainment. Each application has an associated icon.

You can open an application in the following ways:

- Select an icon in the Application Selector bar.
- Select . The Application Launcher displays, showing icons of all of your communicator's applications. Select the application you want to open.

**Note:** You don't have to save and close an application before going to another. Changes or entries in the opened application are automatically saved.

The following icons open the communicator applications:

	Calendar (see page 81)		Messaging (see page 50)
	Calculator (see page 81)		Phone (see page 41)
	Desktop Suite (see page 74)		Time (see page 88)
	Contacts (see page 58)		To do (see page 84)
	Control Panel (see page 66)		Browse (see page 97)
	Notes (see page 88)		Pictures (see page 116)
	Music (see page 100)		Camera (see page 107)
	Video (see page 112)		Home (see page 38)
	SyncML (see page 75)		PicSesl Viewer (see page 100)
	SimApps (see page 120)		Voice (see page 92)






## Folders

Many applications include a group of folders. The current folder name appears on the right side of the menu bar at the top of the screen.

You can use folders to organize your entries. For example, you can create separate folders for business and personal entries.



### Switching Folders

Tap the current folder name, then select a folder from the list. To view every entry in every folder, select **All**.

### Filing New Entry in Folder

#### Action

- 1 In the application, select a folder.
  - 2 Create a new entry. The entry is automatically assigned to the folder.
- 
-

## Moving Entry to a Different Folder

### Action

- 1 Open the entry.
- 2 Select a different folder. The entry is moved to the folder.


## Adding, Renaming, and Deleting Folders

### Action

- 1 Tap the current folder, then select **Edit folders**.
- 2 To add a new folder, tap **Add**.  
To rename a folder, tap **Rename**.  
To remove a folder, tap **Delete**.

## Status Indicators

The status bar at the bottom display the following status indicators:






**Clock** – Shows the current time. Tap clock to briefly display the date.



**Keyboard Launcher** – Tap to display the on-screen keyboard. (The keyboard displays only when the cursor is in a text-entry field.)

**Alert Mode** – Shows the current alert mode:

Audio:  Vibrate:  Silent: 

The alert mode indicates how the communicator notifies you of an incoming call or message.

To change the alert mode, tap the indicator, then select a new setting.

**Bluetooth Status** – Shows the current Bluetooth status:

On: White      Off: Gray

**Tip:** You can tap the icon, then select to turn on or turn off Bluetooth (see page 72).

**Location Mode** – Shows if the GPS (Global Positioning System) Location service is off, idle (in standby), or busy (requesting location information). The color indicates the Location mode:


Off: Gray      Idle: White      Busy: Green


To turn the Location service on or off, tap the indicator, then select the setting you want. The Location service allows you to track your current location on the communicator screen.

**Phone** – Shows the status of an active call:

Connected:  Muted: 

When not in an active call:

Voicemail waiting: 


Videomail waiting: 




**Note:** Videomail may not be offered by all service providers in all geographical areas.

**Message** – Shows that you have a new message and the type of message:


Email:  SMS:  MMS: 


If an MMS or SMS message sender's phone number is in your Contact list, the indicator is white. If the sender's phone number is not in your Contact list, the indicator is amber. If multiple types of new messages are available,  displays.


**Network** – Shows the type of network service connection:


No service:  (gray)

Emergency service:  (red)

Connected to GSM home network:  (one green segment)

Connected to GPRS home network:  (two green segments)

Connected to 3G home network:  (three green segments)



Roaming to non-home type network:  (three amber segments)

Airplane mode (phone disabled): 



To turn Airplane mode on or off, tap the indicator, then select the setting you want (see page 49).

**Signal Strength** – Shows the network signal strength. The more bars, the stronger the network signal.


**Battery Strength** – Shows the amount of charge in your battery. The more bars, the greater the charge. The indicator is amber when the communicator is using a large amount of battery power, such as during a video call. When  displays, the battery is charging, and when  displays, the battery cannot receive a charge.

## **Entering Text**


Two text entry methods make it easy to enter names, numbers, and text messages on your communicator.

### ***Handwriting Recognition***

**Note:** You can use the handwriting pad only when the screen cursor is in a field that allows you to enter text.

You can use the stylus as a pen to write letters, numbers, and punctuation. To write with the stylus, tap  in the status bar. The handwriting pad or the keyboard displays

(depending on which you used last). If the keyboard displays, tap , then tap **Handwriting** in the popup menu.





To write, tap the letter, number, or characters button on the left side of the handwriting pad. Then use the stylus to write in one of the two writing spaces. For best performance, alternate between the writing spaces so recognition can occur in one while you write in the other.

To enter punctuation marks, special characters, spaces, and returns, tap the buttons beneath the writing spaces.



## Virtual Keyboard

**Note:** You can use the keyboard only when the screen cursor is in a field that allows you to enter text.


To use the on-screen keyboard to type text, tap  in the status bar. The handwriting pad or the keyboard displays (depending on which you used last). If the handwriting pad displays, tap  again, then tap **Roman Keyboard** in the popup menu.

To type, tap the keyboard keys with the stylus.



## Using AGPS Location Information

Your communicator can use Assisted Global Positioning Service (AGPS) to tell the network where you are physically located.

To change your Location Mode setting, tap the Location Mode icon () in your communicator's status bar (page 32).

## Limitations of AGPS

Sometimes adequate signals from multiple satellites are unavailable, usually because your AGPS phone's antenna

cannot establish a view of a wide area of open sky. In these cases, the AGPS feature **will not work**. Such situations include, but are not limited to, the following:

- in underground locations
- inside of buildings, trains, or other covered vehicles
- under any other metal or concrete roof or structure
- between tall buildings or under dense tree cover
- near a powerful radio or television tower
- when your AGPS antenna is covered (for example, by your hand or other object) or facing the ground
- when there are temperature extremes outside the operating limits of the phone

Even where location information can be calculated in such situations, it may take more time than usual, and your location estimate may not be as accurate. Walking or driving very slowly may also substantially reduce AGPS performance.

Even where adequate signals from multiple satellites are available, your AGPS feature will provide only an approximate location, often within 150 feet (45 meters) but sometimes much farther from your actual location.

The satellites used by your phone's AGPS feature are controlled by the U.S. government and are subject to changes implemented in accordance with the Department of Defense AGPS user policy and the Federal Radio Navigation Plan. These changes may affect the performance of your phone's AGPS feature.





# Home Screen

---

The Home screen shows a variety of content. This could be a summary of your appointments, messages, and personal links to content such as news, entertainment, and sports.


## Displaying the Home Screen

The Home screen displays after the startup sequence when you turn on the communicator. You can also display the Home screen by tapping  in the Application Selector bar.

### Screen Contents



Home Screen



**Information Snacks** – Shows the three most recently received information snacks (headlines). Tap a snack to go to a Web page with more information.

**Note:** See the 3 welcome package for information about information snacks.

**Personal Information** – Shows information you want displayed in your Personal Information section. Depending on the items you select, this section shows the number of new voicemail, messages, appointments, and active tasks you have.

**Application Shortcuts** – Shows 3 icons for fast access to your favorite applications.

Draft



Home Screen

## Personalizing Home Screen

### Action

- 1 Go to the Home screen (if not already shown).
- 2 Tap **Home > Preferences**.
- 3 Tap **Events** tab.
- 4 Select up to six items you want displayed in the Personal Information section by tapping the appropriate checkbox.  
**Note:** When six items are already selected, the other items are no longer selectable. To change or add a selection, you must remove the checkmark from a currently selected item.
- 5 Tap **Applications** tab.
- 6 Select the three applications you want displayed in the Applications Shortcuts section, then tap **Done**.




**Note:** To receive updated information from 3, tap **Contents** tab, then tap **Update**. Refer to the 3 package for more details.


# Calling Features

---


## Opening Phone Application

Use the Phone application to make voice and video phone calls. You can open this application in the following ways:


- Press . When the Phone application opens, a list of the most recently dialed calls displays.
- Press  or tap  in the Application Selector bar or Application Launcher. When the Phone application opens, the dialing keypad displays:




## Displaying Your Phone Number

Your phone number must be programmed on your USIM card to use this feature. Tap  in the Application Selector bar. Tap **Phone > My line(s)**. The communicator shows your phone number(s).


## Using the Internal Speakerphone

To turn on the internal speakerphone during an incoming or active call, press .



## Adjusting the Volume






Press the top of the volume key to increase volume or the bottom of the key to decrease volume for the earpiece, speakerphone, or headset during a call.



## Making a Voice Call

### Dialing with the Keypad

#### Action

- 1 Tap  in the Application Selector bar or Application Launcher.
- 2 Select a voice call by tapping (  )
- 3 Tap the phone number on keypad.
- 4 If you make a mistake while dialing, tap  to delete the last digit entered. Tap and hold  to delete multiple or all digits.
- 5 Press  to make the call.

### Dialing Stored Phone Numbers

You can automatically dial stored phone numbers (see page 58)

### Redialing Failed Voice Calls

If a voice call fails (busy or not answered), **Call Failed** displays. To redial the call, tap the **Retry** button.

### Making a Video Call

You can make video calls to other devices that have video call capabilities.




## Making a Video Call to Another Phone

You can make a video call to another phone by dialing the phone number on the keypad.



**Shortcut:** You can automatically place video calls to stored phone numbers.

### Action

- 1 Tap  in the Application Selector bar or Application Launcher.
- 2 Position the front camera lens or P2P (point-to-point) lens so that it faces the image you want to send, (see page 108.)

**Note:** The speakerphone automatically turns on during a video call.

- 3 Tap the phone number on keypad.


If you make a mistake while dialing, tap  to delete the last digit. Tap and hold  to delete multiple or all displayed digits.



## Action

4 Tap  .

When the call connects, the screen shows the remote camera image on top and the local image on the bottom.



## Making a Video Call to a Computer

To make a video call to a computer, you can use:

- **Call History List** – To call a computer in your call history list, tap the email address you want to call.
- **Contacts** – To call stored phone numbers, see page 58.





- **Embedded email address** – To call a computer's email address, tap the address in an email, SMS, MMS, or text message, or an HTML page.

## **Calling an Emergency Number**

Your service provider may program one or more emergency phone numbers, such as 911 or 112, that you can call under any circumstances, even when your communicator is locked or the USIM card is not inserted.



Your service provider can program additional emergency numbers into your USIM card. However, your USIM card must be inserted in your phone in order to use the numbers stored on it. See your service provider for additional information on this issue.

**Note:** Emergency numbers vary by country. Your communicator's preprogrammed emergency number(s) may not work in all locations, and sometimes an emergency call cannot be placed due to network, environmental, or interference issues.

## **Using AGPS During an Emergency Call**

When you make an emergency call, your phone's assisted-Global Positioning System (AGPS) feature can calculate your approximate location and help emergency service personnel find you.

## Notes:

- This feature can work only if the emergency response center can receive and process location information. If you are concerned about whether your local emergency response center can receive AGPS location information, contact your local authorities.
- In order for the AGPS feature to work when making emergency calls, the service must be turned on (see page 32).

For best results, you should be located where your phone's antenna can establish a clear view of the open sky. This allows your phone to access AGPS satellite signals. Even under good conditions, it may take 30 seconds or more to determine your approximate location. This time increases and the accuracy of the results decreases with reduced access to satellite signals.


If your communicator does not have access to AGPS satellite signals, the location of the nearest cell tower in contact with your phone is automatically provided to the emergency response center.

Because of the limitations of the AGPS feature, always provide your best knowledge of your location to the emergency response center, just as you would when using a phone without AGPS capabilities. Also, remain on the phone for as long as the emergency response center instructs you.



## Dialing the Call

### Action

- 1 Press keypad keys to dial the emergency number.
- 2 Press  to call the emergency number.

## Answering Calls

When you receive an incoming voice or video call, the communicator rings or vibrates (unless set to Silent mode).

### Action

Press  or tap **Answer** to answer the call.

**Note:** Press  to turn on the speakerphone.

If you do not want to accept the call, press  or tap **Busy**.




**Notes:** Video calls display  to the left of the call.

## Switching to Airplane Mode

If you want to use the communicator's personal organization and entertainment features in a situation where telephone use is not allowed (such as on a plane), switch the communicator to Airplane mode.

In Airplane mode, you cannot connect to the network to make phone calls or send messages. Also, Bluetooth and GPS Location service are not available.

### Action

- 1 Tap the Network indicator () in the Status bar.
- 2 In the Connection Mode box, tap **Aeroplane Mode**.
- 3 Tap **Done**.  
 displays when the communicator is in Airplane mode.
- 4 To return to normal operation, tap , then tap **Handset On**.

## Turning off Call Ringing

You can turn off ringing for incoming calls by setting the communicator's alert mode to vibrate or silent (see page 32).



# Messages and Email

---

You can create, send, and receive email, MMS (Multimedia Message Service), and SMS (Short Message Service) messages.

To send stored audio, video, and picture files with your email and MMS messages. See the “News and Entertainment” beginning on page 97.

## Setting up Messaging Accounts



Before you can send and receive messages, you must set up your accounts. Contact your service provider for account details.


### Email

To send and receive email, you must set up an Internet account and an email account

The communicator supports IMAP4, POP3, and SMTP protocols.

To create an Internet account:

#### Action

- 1 Open Control Panel application (  ).
- 2 Tap **Connections** tab > **Internet accounts** > **Accounts** tab.
- 3 Tap **New**.




## Action

- 4 Enter information about your account.
- 5 Tap **Done**.

To create an email account:

## Action

- 1 Open Control Panel application (  ).
- 2 Tap **Connections** tab > **Messaging accounts** > **Email** tab.
- 3 Tap **New**.
- 4 Enter information about your account on the **Basic**, **Inbox**, **Outbox**, and **Advanced** tabs.
- 5 Tap **Done**.


**Note:** See the A1000 **More Here** reference guide on the in-box CD for more information.

## **MMS and SMS**

Your service provider should already have set up MMS and SMS (text messages) accounts on your communicator.

To check account settings:

## Action

- 1 Open Control Panel application (  ).
- 2 Tap **Connections** tab > **Messaging accounts**.




**Action**

- 3 Tap the **Email**, **Text message**, **Multimedia message**, or **Info Service** tabs to view account settings. Tap the left and right arrows to move between the account tabs.


**Opening Messaging Application**

Use the Messaging application to create, send, and receive messages.

**Action**

Tap  in the Application Selector bar or Application Launcher. When the Messaging application opens, it shows a list of your established accounts.

**Note:** The account stores data received using Bluetooth (see page 72).




Accounts	New	Out
Info Service	0	
DefaultmodEMail1	0	0
DefaultmodEMail3	0	0
DefaultmodEMail2	0	0
Text message	0	0
Multimedia message	0	0
Beamed	0	



# Creating and Sending Messages

## Email and SMS

### Action

- 1 Tap the email or SMS account in the list of accounts.
- 2 Tap **Message > New**.
- 3 Tap **Text only**, **Media only**, or **Text & media**, then tap **Done**.
- 4 In the **To** field, enter the recipient's address (email) or phone number (SMS).  
To enter a stored address or phone number from Contacts, tap **To**.  
To enter several addresses or phone numbers, enter a comma between each.
- 5 In the **Subj** field (email only), write a subject line.
- 6 In the text area, write the text message.
- 7 To add an attachment, tap the  tab, then tap **Add**.
- 8 In the **Type** field, select the file type you want to attach, then tap **Done**.
- 9 Tap the stored file you want to attach, then tap **Add**.  
**Note:** You cannot send or forward media files that are forward-locked.
- 10 When message is complete, tap **Send**.





**Note:** If you accept a video call while composing an email or SMS message, the message is automatically saved to either the email or SMS draft folder.


## MMS

You can create and send MMS messages that contain one or more slides with audio, video, images, and documents.

### Action

- 1 Tap the MMS account in the list of accounts.
- 2 Tap **Message > New**.
- 3 Tap **Text only**, **Media only**, or **Text & media**, then tap **Done**.

The first slide of the message displays:




## Action

- 4 In the **To** field, enter the recipient's phone number or email address. (The recipient must also subscribe to MMS messaging.)

To enter a stored number from **Contacts**, tap **To**.

To enter several phone numbers, enter a comma between each.

- 5 Tap  to add a sound. You can then record a new sound or select a stored audio file.

You can add WAV and AMR audio files to an MMS message.

**Note:** You cannot send or forward media files that are forward-locked.

- 6 Tap  to add an image, then select a stored image file.

You can add the following types of stored image files to an MMS message: BMP, WBMP, GIF, PNG, JPEG, and TIFF.

**Note:** You cannot send or forward media files that are forward-locked.


- 7 Tap the text area to place a cursor in the text area. Enter text with stylus or virtual keyboard.



## Action

- 8 To set the slide duration, tap the duration label (**10/10s**). Specify how long (in seconds) you want the slide to play before automatically advancing to the next slide in the message.

The first number in the duration label indicates the duration of the current slide. The second number indicates the total duration of all slides in the message.

- 
- 9 To add another slide to the message, tap .

- 10 To play the slide presentation, tap **Play**.

- 
- 11 When message completes, tap **Send**.
- 
- 

### Notes:

- The maximum file size of an MMS message is 30 KB. If you exceed this size, a warning message displays. Remove audio or video files to reduce the file size.
- If you accept a video call while composing and email or SMS message, the message is automatically saved to either the email or SMS draft folder.



## Receiving and Reading Messages

When a new message is received, a message indicator displays in the status bar (see page 31).

### Action

- 1 Tap the message indicator in **Status** bar.

The Messaging application opens, showing a list of established accounts. The number of unread messages displays next to each account.

---

- 2 Tap the account containing the message you want to read.

A list of messages displays. Unread messages display in bold.

---

- 3 Tap the message you want to read.
- 

- 4 Attachments display with a . Tap the attachment to open it.
- 
- 





# Contact List





Use the Contacts application to store details such as names, phone numbers, and email addresses in an alphabetical list of entries. You can call or send a message to any stored contact from this list.

## Opening Contacts Application

Tap  in the Application Selector bar or Application Launcher. An alphabetical list of stored contacts displays:



The following icons can display next to a contact name:

-  – Displays if contact has a voice tag assigned to a phone number (see page 62).
-  – Displays if contact is saved in the USIM folder.

To see each contact's preferred phone number next to their name, tap **Edit** > **Preferences**, then tap the **Show preferred phone number** tab.

## Adding Contacts

### Action

- 1 Open the folder in which you want to save the contact. To store the contact on your USIM card, open the USIM folder.

- 2 Tap **Contacts** > **New** to display the Contact information form.

Contacts Edit Unfiled

First name **Adam**

Last name **Carol**

Job title

Mobile ▾ **617-555-8420**

Voice tag:

Phone (w) ▾ **617-5558413**

Voice tag:

Phone (h) ▾ **781-555-0080**

Voice tag:

Email (w) ▾

10:10


- 3 Enter contact name, phone numbers, email address, and other information.










## Action

**Note:** If you enter more than one phone number, (for example, a work and home number), you can select which number displays in the contact list as the preferred phone number. To do so, tap **Edit > Preferred number**, then select the desired preferred phone number from the list.

- 4 Tap ▼ preceding each phone number to select its communication method: Phone (land line), Mobile, Email, Web, or Web call (email address for 2-stage dialing video call).
- 5 To record a voice tag, refer to “Recording Voice Tags for Contacts” on page 62.
- 6 To assign a unique ring tone to the contact, tap the down arrow, if necessary, then tap the **Ring tone** box.
- 7 Select a tone from the list. When you receive a voice or video call from this contact, the selected ring tone plays.
- 8 Tap  to play the selected ring tone.
- 9 To add a new field to the contact, tap **Edit > Add Field**. “Adding New Fields” on page 61.  
**Note:** This step is optional. However, the fields must be added when entering the contact information. You can not add new fields after you save the contact.



## Action

- 10 To add a note to a contact, tap , then enter the note.
  - 11 You can mark a note as Private. Private notes are not included when you send or synchronize contact details.
- 
- 12 To assign a stored photo or image to the contact, tap , then , then select the photo or image.  
**or**  
tap  to take a photo  
The contact's assigned image displays when you make a call to or receive a call from the contact.
- 
- 13 When you have entered all contact information, tap .  
The contact now displays in the alphabetical list of contact names.

## Adding New Fields

### Action

- 1 When entering information for a new contact, tap **Edit > Add field**.
- 
- 2 Tap **New Field**, then the field from the list.





### Action

#### 3 Tap **Add**.

The Contact Information form displays and **(new field)** displays next to the added field.

---

#### 4 Repeat these steps to add more fields.

---

---

## **Recording Voice Tags for Contacts**

You can record a voice tag when adding a new contact (page 59), or when editing a contact (page 64).

**Note:** The contact must have at least one phone number entered to assign a voice tag.

You can record a voice tag for all phone numbers for a contact. However, each phone number must have a unique voice tag.

**Tip:** Make your recording in a quiet location. Hold the communicator about 4 inches (10 centimeters) from your mouth, and speak directly into the communicator in a normal tone.

### Action

#### 1 When adding or editing a contact, tap the **Voice tag** box under the phone number.

---

#### 2 When prompted, tap **Record** and speak the desired voice tag.

---

## Action

- 3 When prompted, tap **Record** again and repeat the voice tag.


A checkmark (✓) in the **Voice tag** box indicates the voice tag has been recorded.

- 4 Tap the field next to the **Voice tag** box, then select **Voice call** or **Video call**.

- 5 Repeat these steps to record additional voice tags for this contact.

## Deleting Voice Tags

### Action

- 1 Tap  in the Application Selector bar or Application Launcher to display your list of contacts.

- 2 Tap a contact in the list.

- 3 Tap **Edit > Edit Contact**.

- 4 Tap the **Voice tag** box for the tag you want to delete.


- 5 Tap **Yes**.





## Editing Contacts

### Action

- 1 Tap  in the Application Selector bar or Application Launcher to display your list of contacts.
- 2 Tap a contact in the list.
- 3 Tap **Edit** > **Edit Contact**.


**Note:** Your changes are automatically saved.

## Communicating with Contacts

You can easily phone, email, or send messages to your stored contacts.

### Action








- 1 In the list of contact entries, tap the contact name. The contact's defined phone numbers and email addresses display:



## Action


A phone number or email address might have additional icons next to it, depending on its defined communication method.


### 2 Tap the icon for the call or message you want:

-  or  Voice Call to a phone
-  Video Call to a phone or computer (for phone number contacts)
-  Video Call to a computer (for email address contacts)
-  Email message to a phone or computer
-  MMS message to a phone or computer
-  SMS message to a phone



## Using Voice Dialing

Press and release  (speakerphone key) then say the recorded voice tag within 2 seconds.



# Customizing Communicator Settings


---

## Setting the Wallpaper Image

You can set an image to display in the background of the Application Launcher.



### Action

- 1 Open Application Launcher (  ).
  - 2 Tap **View** > **Appearance**.
  - 3 Tap **Background** and select from the list, or select **Find image** to select a stored image.
  - 4 Tap **Done**.
- 
- 

## Setting the Screen Brightness

### Action



- 1 Open Control Panel application (  ).

**Note:** Tap **Screen** from the **Handset** tab.

- 2 Slide the **Brightness** switch button to the desired setting.
  - 3 Tap **Done**.
- 
-

## Setting the Screen Calibration


### Action

- 1 Open Control Panel application (  ).
- 2 Tap **Screen** from the **Handset** tab.
- 3 Tap **Calibrate**.
- 4 When prompted, tap the center of points 1, 2, and 3 to calibrate the screen.  
**or**  
Press the center of the screen to reset calibration to the factory default setting.  
**or**  
Press  in any direction to exit without making changes.
- 5 Tap **Done**.

## Setting the Volume for System Sounds

Set the volume level for screen taps, button presses, alerts, and system notices.


### Action

- 1 Open Control Panel application (  ).
- 2 Tap **Sound** from the **Handset** tab.
- 3 Select desired settings for button clicks, screen taps, ringer, and alert mode.
- 4 Tap **Done**.






## Setting a 3 Key Shortcut

The 3 key () has 1 default shortcut setting, Browser, and one shortcut that you can customize to open your favorite application, for example, Camera.

### Action

- 1 Open Control Panel application (  ).

---

- 2 Tap **Shortcut key** from the **Handset** tab.

---

- 3 Select an application from the list.

---

- 4 Tap **Done**.

---


## Choosing Ring Tones

When you set the alert mode to audio, the communicator rings during an incoming call or message (see page 32).

Personalized ring tones assigned to stored contacts override the ring tones you select here (see page 59).

## Choosing Ring Tones for Calls


### Action

- 1 Open the Phone application (  ).

---

- 2 Tap **Settings > Tones**.

---

- 3 Select the ring tones you want for line 1, line 2 (if applicable), video, voicemail, and videomail.  
To hear the selected ring tone, tap .

---

- 4 Select a setting for **Keypad** tones.



---

- 5 Tap **Done**.

---

## Choosing Ring Tones for Messages

### Action

- 1 Open the Messaging application (  ).
- 2 Tap **Edit** > **Preferences**.
- 3 Select the ring tones you want for each messaging account.  
To hear the selected ring tone, tap .
- 4 Tap **Done**.




## Choosing a Vibrate Pattern

When you set the alert mode to vibrate, the communicator vibrates to indicate an incoming call or message. You can select from the different vibrate patterns provided.

**Note:** See page 32 to view and set the alert mode.

### Action

- 1 Open Control Panel application (  ).
- 2 Tap **General** tab.
- 3 Tap **Ringtone Manager**.
- 4 Tap the **Vibrate** tab.
- 5 Tap the vibrate pattern you want to use. To test the pattern, tap the left arrow.
- 6 Tap **Done**.





Draft

# Getting More Out of Your Communicator

---

## Installing the A1000 Desktop Suite

**Important:** Before connecting your communicator to another device such as a computer or Bluetooth device, install the A1000 Desktop Suite, located on the in-box CD. Follow the on-screen prompts for installation instructions. This program enables you to establish a connection with a computer or Bluetooth device to:


- Synchronize email and Calendar, Contacts, and To Do entries between your communicator and a computer
- Back up and restore information between your communicator and a computer
- Transfer files between your communicator and a computer
- Install applications on your communicator



## Connecting a Bluetooth Device

**Important:** Before connecting your communicator to a Bluetooth device, set up the other device as described in its user guide.

### Action

- 1 Open Control Panel application (  )
- 2 Tap **Connections** tab > **Bluetooth**.
- 3 Tap the **Devices** tab, then tap **Add**.

Your communicator searches for all Bluetooth enabled devices in the vicinity.

or

Tap **Show**, select from the list of available devices, then tap **Refresh**,


- 4 In the list of available devices, tap the one you want to bond.

If prompted, enter a passkey, then tap **Done**.

A passkey is a set of numbers or letters (at least four characters) that you agree to exchange with the owner of the other device. When the communicator accepts the passkey, the bonding process completes.

## Changing Your Bluetooth Settings

### Action

- 1 Open Control Panel application (  )
- 2 Tap **Connections** tab > **Bluetooth** > **Settings** tab.
- 3 To turn on Bluetooth, tap the box next to **Bluetooth on**. A check mark in the box indicates Bluetooth hardware is turned on.
- 4 Tap a selection in **Visible for other devices**.
- 5 You can change your **Receiving items** settings (see below), and enter a Bluetooth name for your communicator.
- 6 Tap **Done**.

**Receiving Items** settings determine what your communicator does when it receives information from connected Bluetooth devices.

Setting	Description
<b>Always receive</b>	accepts the information
<b>Ask first</b>	prompts you to accept the information
<b>Never receive</b>	rejects the information




## Connecting to a Computer

**Important:** Before connecting your communicator to a computer, ensure the A1000 Desktop Suite, located on the in-box CD has been installed.



### Setting Up a USB Cable Connection

Connect the USB cable from the accessory port on the bottom of the communicator to the USB port on the computer.

To complete the connection, tap  (**Desktop Suite**) in the Application Launcher, then tap **Connect**.

### Setting Up a Bluetooth Connection

#### Action

- 1 Make sure the PC is Bluetooth enabled, then establish a connection as described on page 72.
- 2 Open Control Panel application (  )
- 3 Tap **Connections** tab > **Desktop Suite**.
- 4 In the **Link using**, field tap **Bluetooth**.
- 5 To select a **Preferred PC**, tap the box next to it, then tap **Done**.
- 6 To complete the connection, tap  (**Desktop Suite**) in the Application Launcher and tap **Connect**.

## ***Using the Desktop Suite***

After connecting your communicator to the computer, start the A1000 Desktop Suite program on the computer. Refer to the A1000 Desktop Suite online help for more information about using the program.

## ***Using Remote Synchronization***

The communicator allows you to synchronize Calendar, To Do, and Contract entries over the air (OTA) with a synchronization server. It is designed to synchronize with basic features of the initial release of many popular Personal Information Management (PIM) software and hardware products.

## ***Setting Up Your Account***


To use remote synchronization, contact your service provider to set up an account. To synchronize over the Web, you also need an Internet account.



## Configuring the Settings

When you have your account information, you can configure the communicator for remote synchronization.

### Action

- 1 Tap (  ).
- 2 Tap **Edit** > **Settings**.
- 3 Enter the **Server address**, **Username**, and **Password**.
- 4 Tap **Done**.
- 5 Tap on a task you want to enable.
- 6 Tap **Enable task** checkbox.
- 7 Enter the path to the **Server database**.
- 8 Tap **Done**.
- 9 Tap **Edit** > **Settings**, then tap the **Protocol** tab.
- 10 Tap **Use transporter login** checkbox.
- 11 Enter a **Username** and **Password**.
- 12 Tap **Done**.


## Using Picstel Viewer

Picstel Viewer automatically reformats many popular file formats such as text, presentation, and database management files, to fit in the display area of your communicator.

Use Picstel Viewer to open documents from the internet, received messages, and documents stored on your A1000 communicator or personal computer. The stylus and icons allow you to open, scroll, zoom, and navigate through documents with ease.

### Opening Documents

#### Action



- 1 Open Picstel Viewer (  ).
- 2 Locate the document from your saved **Bookmarks**, **History** list, folders, or lists.
- 3 Tap on the document name to open it.  
**Document** options allows you to display and select options such as send, delete, rename, view history, and bookmarks.














## Navigating Documents

Icons on the navigation bar allows you to easily zoom in and out, change views, and move to other pages of the document.



Getting More Out of Your Communicator

Navigation Icon	Description and Procedure
Expand control bar (  )	Displays thumbnail images of a document 3 pages at a time. The larger thumbnail indicates the currently displayed page. Tap a thumbnail to display its page. Tap the left arrow twice to go to the first page, tap the right arrow twice to go to the last page.

<b>Navigation Icon</b>	<b>Description and Procedure</b>
Fit to width (  )	Display a document to the full width of the viewing area.
Fit to page (  )	Display a document to the full width and height of the viewing area.
Zoom in (  )	Increase document size
Zoom out (  )	Decrease document size
Display as actual size (  )	Display a document or image in its full, original size.  Tapping the Expand control bar displays thumbnails for easier navigation. Tap and hold the red box in the thumbnail to move around the current screen.
Full screen mode (  )	Display a document or image in its full, original size and hides the status and application bars.
Rotate screen (  )	Rotate screen horizontally. Tap again to go back to vertical view.
Go back (  )	Display previous page



## Setting Preferences

### Action

1 Tap **Edit** > **Preferences**.

---

2 Make your selections from the list.

**Page flick** – go to the next or previous page in a document by tapping and sliding the stylus across the bottom of the display.

- Slide stylus right to go to the previous page
- Slide stylus left to go to the next page.

**Show pictures** – available only for HTML and PDF documents

**Reflow text** – reformats documents to fit the width of the display.

**Keep for** – select the number of days documents are kept before they are automatically deleted.


**Clear history** – delete all history documents

---

3 Tap the filename to open the document.

---

---



# Personal Organizer Features

---

## Calendar

Use Calendar to schedule and organize events such as appointments and meetings. You can review your schedule of events for the day, week, or month, and have the communicator play a reminder alarm for specific events.

**Note:** Ensure the correct time and date are set before using Calendar (page 88).

## Adding a Calendar Entry

You can enter the following types of Calendar entries:

- **Appointment** – An entry with a start and end time (for example, a meeting)
- **Reminder** – An entry that does not need a time (for example, a birthday)
- **All day event** – An entry with a start and end date, but no specific times. Use an all day event for an entry that lasts a whole day or several days (for example, a conference).




To add a Calendar entry:

## Action

- 1 Open Calendar (  ).

- 2 Tap **Calendar** > **New**.

The Calendar Entry form displays.



- 3 Use the stylus or virtual keyboard to enter a description.
- 4 Select the type of entry.
- 5 Enter the date, time, and location of the event.
- 6 Tap the **Alarm** box if you want the communicator to sound a reminder alarm for this entry.

The time and date of the alarm display below the **Alarm** box. To change when the alarm sounds, tap the time or date.


## Action

- 7 If this entry recurs, tap **Repeat** to select a repeat interval. Check the **Forever** box to have the alarm repeat indefinitely.


---

- 8 To mark this entry as Private when you synchronize Calendar entries with a computer, tap **Private**.

---

- 9 To add a note to the entry, tap , then enter the note.

---


- 10 Tap  to save the entry.


## Switching Calendar Views

You can see your Calendar entries in several views: Day, Week, or Month. When you first open Calendar, the Day view displays.

To switch to Week, tap .

To switch to Month, tap .

To switch back to Day, tap .

To return to the current day in the selected view, tap .

To see the details of an entry, tap the entry.



## ***Moving Entries to the To Do Application***

You can move Calendar entries to the To Do application, which lists tasks you need to complete.

### **Action**

- 1 Open the entry.
- 2 Tap **Calendar > Move to To do.**

**Notes:** To Do entries do not have repeats, times, or locations, so Calendar entries that you move to To Do lose this information. If you copy an entry back to Calendar, the information is not restored. If you move an entry with an alarm, it sounds in To Do.


## ***To Do***

Use the To Do application to list and track tasks you need to complete. You can set due dates for activities, reminder alarms, and mark tasks as completed.




## Adding Entries:

### Action

- 1 Open **To do** (  ).
- 2 Tap **To do** > **New**.

The To Do entry form displays.



The screenshot shows the 'To do' entry form on a mobile device. At the top, there is a navigation bar with icons for home, back, forward, messages, contacts, and a grid. Below the navigation bar, the form has a title bar with 'To do', 'Edit', and 'Unfiled' (with a dropdown arrow). The main content area contains the task description 'Pick up flowers for Sarah's Birthday.' Below this, there are several fields: 'Completed' with an unchecked checkbox, 'Priority' set to '1' with a dropdown arrow, 'Due date' checked with a checkbox and the date '2004/06/19', 'Alarm' checked with a checkbox and the time '11:17 pm' and date '2004/06/19', and 'Private' with an unchecked checkbox. At the bottom of the form, there are icons for a list, a document, and a 'Delete' button with a circular arrow icon. The device's status bar at the very bottom shows the time '10:17' and various system icons.

- 3 Use stylus or virtual keyboard to enter a description.
- 4 Select a priority (1-9, with 1 highest) for the task.
- 5 Tap the **Due date** box if you want to this task to have a due date.

The current date displays next to the **Due date** box. To select a different due date, tap the date, and select a date from the displayed calendar.






**Action**

- 6 Tap the **Alarm** box if you want the communicator to sound a reminder alarm for this entry.

The time and date of the alarm displays below the **Alarm** box. To change the alarm, tap the time or date.

- 
- 7 To mark this entry as Private when you synchronize To Do entries with a computer, tap **Private**.

- 
- 8 To add a note to the entry, tap  and enter the note.

- 
- 9 Tap  to save the entry.
- 
- 

## Marking Tasks as Complete

When you open To Do, a list of tasks and their due dates displays.

**Action**

To mark a task as completed, tap the box next to it. The due date disappears, indicating the task is completed.

---

**Note:** To hide completed entries, tap **Edit > Preferences**, then remove the check from **Display completed**.

---

---



## ***Deleting Entries***

When you no longer need a record of your completed entries, delete them.

### **Action**

To delete an individual entry, tap the entry in the list and tap **Delete**.

To delete all completed entries, in your list of entries, tap **To do > Delete completed**.

## ***Moving Entries to Calendar***

You can schedule To Do entries on your calendar by moving them to the Calendar application (page 81).

### **Action**

- 1 Open the entry.
- 2 Tap **To do > Move to Calendar**.

**Notes:** If you do not set a due date for the To Do entry, the communicator uses the current date for the new entry.

If you move an entry with an alarm, it sounds in Calendar.




## Notes

Use Notes to write notes and sketch graphics.

### Adding Notes

#### Action

- 1 Open Notes ()


---

- 2 Tap **Notes > New**.

---

- 3 Enter the note using the stylus or virtual keyboard.


---

- 4 To add a graphic to the note, tap .

---

- 5 Use the stylus to sketch your graphic.  
Use the on-screen buttons to change line width and color, and erase lines.

---

- 6 Tap  to save the note.

## Time


Use Time to set the current time and date, and to set alarms you do not want to include in your Calendar or To Do list.




## Setting the Time and Date

If you have not already set the current time and date::

### Action

- 1 Open Time (  ). The Date and Time screen displays:



- 2 Tap **Time** > **Set time & date**.
- 3 Enter the current time and date.
- 4 To set the time and date format, tap the **Format** tab, then select the format from the lists of available formats.
- 5 Tap **Done**.



## Setting Location

Time can display time and date information for two locations:

- **Current** – The place where you are at the moment. The time and date of your current location display in the top half of the screen.
- **Other** – A city of your choice. The time and date of this city displays below the time and date of your current location. If you are abroad, you can check the time at home by setting this location to your home city.

### Action

1 Tap **Date and Time** > **Set location**.

---

2 Select your current location from the **Current country** and **Current city** lists.

**Note:** If the city you want is not listed, select another city in the same time zone.

---

3 Select another location (optional) from the **Other country** and **Other city** lists.

---

4 Tap **Done**.

---

---



## Setting Alarms

You can use Time as an alarm clock. It is ideal for wake-up alarms and other regular alarms you do not want to include in your Calendar or To Do list.

You can set up to three alarms in Time. The alarm slots display in the lower half of the Time screen.

### Action


1 Tap one of the alarm slots.

---

2 Set the following alarm details:

**Time** – time of day you want the alarm to sound.

**When** – how often you want the alarm to sound: once, during the next 24 hours, daily, on workdays only, or weekly.

**Alarm sound** – the sound you want the alarm to make. Tap  to listen to the selected sound.

**Message** – one of several preset alarm messages or enter your own.

---

3 Tap **Done**.

---

4 Tap the alarm checkbox to turn on the alarm.

---

---



## Responding to Alarms

When an alarm sounds, the message you selected displays. Tap the **Snooze** button to reset the alarm to sound again in 5 minutes.


**Note:** The alarm does not sound while you are making a phone call or recording a voice note.

## Turning Alarm Sounds Off

To silence an alarm before it sounds, do one of the following:

- Uncheck the alarm slot checkbox.
- Tap the alarm slot, then select **Silent** in **Alarm sound**.

## Calculator

To open Calculator, tap  in the Application Launcher. Use the calculator by tapping the on-screen keys.

## Making Voice Recordings

You can record personal messages on your communicator.




**Note:** Recording of phone calls is subject to varying State and Federal laws regarding privacy and recording of phone conversations.


**Tip:** Make your recording in a quiet location. Hold the communicator about 4 inches (10 centimeters) from your mouth, and speak directly into the communicator in a normal tone.



**Tip:** Adjust your volume setting for playback.


## Action


- 1 Open Voice (  ).
- 2 Tap **Voice** > **New Voice note** or tap **New** (at the bottom of the screen).
- 3 Tap  to begin recording.
- 4 Tap  to stop recording.




- 5 Tap  to playback the recording.

A counter at the top of the screen indicates the number of the current recording and the total number of recordings. For example, **1 / 2** indicates you are on the first of two records.

Tap  to pause during playback.

Tap  to resume playback.

Tap  and slide left to decrease volume or right to increase volume during playback.

To delete a recording, tap **Delete** while on the record.










## Playing a Recording


### Action

- 1 Open Voice (  ).

---


  - 2 Tap  or  to go to the recording you want to play.

---



  - 3 Tap  to play the recording.
- 
- 

## Deleting a Recording

### Action


- 1 Open Voice (  ).

---



  - 2 Tap  or  to scroll to the recording you want to delete, then tap **Voice > Delete note** or tap **Delete** (at the bottom of the screen).
- 
- 

## Sending a Recording

### Action

- 1 Open Voice (  ).

---

  - 2 Tap  or  to scroll to the recording you want to send, then tap **Voice > Send as**.

---



  - 3 Tap one of the selections in the **Send as** box, then press **Done**.


---

  - 4 Follow the normal procedure for your selection.
- 
-

# Security

## Locking and Unlocking Communicator

You can lock the communicator so that the touchscreen and keys do not work. When you lock the communicator, you can still use the  and  keys for incoming phone calls.




Slide up to lock. Slide down to center to unlock.

## Establishing Password Protection

You can establish password protection to prevent unauthorized access to information in the communicator.

### Action

- 1 Open Control Panel application (  ).
- 2 On the **Handset** tab, tap **Password**.
- 3 Tap the **Security** tab, then tap **Set Security Code**.
- 4 Tap in your current security code, then tap **Done**.
- 5 Enter a new security code, then tap **Done**.  
Confirm the new security code, then tap **Done**.



**Action**

- 6 To set a phone lock code, tap **Phone Lock > Set lock code**. Enter a lock code, then tap **Done**. Confirm the lock code, then tap **Done**.

Tap the **On** or **Off** button for **Auto Phone Lock**.

To delete the code, tap **Clear**, enter your current code, then tap **Done**.

- 
- 7 If you want the password entry screen to display owner information:
- a Tap **Owner**.
  - b In the **Owner Information** box, enter the text that you want displayed.
  - c Tap **Done**.
- 
-

# News and Entertainment

---

## Web Browser



The Web browser lets you open Web pages and use Web-based applications (such as on-line banking, shopping, and games) on your communicator.



## Setting Up Your Internet Account

Before you can use the Web browser, you must set up an Internet account (see page 50).

## Opening Web Browser

Tap  in the Application Launcher or Application Selector Bar.

To open the Web browser and go directly to the Hutchison portal, press .

If you have saved bookmarks and/or Web pages, an alphabetical list of your bookmarks or saved Web pages displays, depending on which you displayed last.

**Note:** If your bookmarks or saved pages do not display, tap **Browse > Bookmarks** or **Saved pages**.



## Opening Web Pages

### Action

- 1 Tap the bookmark or saved Web page you want to open.
- 2 Tap **Browse > Open new**. Enter the Web page address, in the **Location** field, then tap **Open**.

**Note:** you can omit the `http://`.

- 3 Change the **Title** if desired, then tap **Save**.

## Adding Bookmarks

To add a bookmark for a Web page so you can return to the page without having to enter its address:

### Action

- 1 Open the Web page.
- 2 Tap **Browse > Page information**.
- 3 Tap **Bookmark**.

**Note:** You can change the Title before saving the bookmark, if desired, in the **Title** field.

- 4 Tap **Add**.

## ***Saving Web Pages***

To save a Web page so you can view it later when not connected to the Internet (offline browsing):

### **Action**

- 1 Open the Web page.
- 2 Tap **Browse** > **Page information**.
- 3 Tap **Save** and change the **Title** if desired.

**Note:** You can change the Title before saving the page, if desired, in the **Title** field.

- 4 Tap **Save**.

## ***Downloading Audio, Video, and Pictures***

You can download audio files, video clips, and pictures from the Web. To download a file, follow the instructions on the Web page.

When the download completes, the file opens in the browser or in another communicator application (depending on the file type). You can save the file to a folder in the communicator or to the memory card.



You need a license to open media files that have digital rights protection. If you do not have a license for a protected file, your communicator prompts you to launch the Web browser and download one.



## Music

Use Music to listen to the following types of audio files: AU, AMR, MIDI, MP3, and WAV. You can listen to audio files that you downloaded from the Web, received as an email attachment, or stored on the removable memory card.



### Opening Music

Tap  in the Application Launcher. When Music opens, it shows a list of all saved audio tracks.

To see the audio tracks saved in a specific folder, tap the current folder name (upper right corner) and select the desired folder from the list.

Sample music files are provided on the CD supplied with the communicator.



You need a license to open media files that have digital rights protection. If you do not have a license for a protected file, your communicator prompts you to launch the Web browser and download one.

**Note:** Audio tracks must be stored in the proper directory on the memory card for you to see and play them in Music. When you copy audio files to the memory card from a computer, ensure that the files are stored in a third-level directory under: **Media Files\Audio\**

For example, you can store audio files in any of the following directories:

**Media Files\Audio\Classical**

**Media Files\Audio\Rock**

**Media Files\Audio\Unfiled**

## ***Playing an Audio Track***

### **Action**

- 1 In the list of tracks, tap the track you want to play. Information about the track displays (artist, album, etc.) and the track begins to play.
- 









## Action

- 2 While the track plays, you can tap the following buttons at the bottom of the screen:

 Tap and hold down to rewind the track.

 Tap to stop playing and return to the start of the track.

 Tap to switch between play and pause mode.

 Tap and hold down to advance (fast forward) the track.

**Note:** The  $\cdot\phi\cdot$  key also controls audio play: left = rewind, right = fast forward, center = play/pause.


---


## Managing Music Playlists

Music can play all of the tracks in a folder in a sequence that you specify. To specify the sequence, you must edit the folder's playlist:



### Action

- 1 Open the folder containing the tracks you want to play.
- 2 Tap  to switch to Playlist view.
- 3 Tap **Edit > Edit Playlist**. The Reorder Playlist screen displays:





- 4 To arrange the sequence, tap a track and then tap the arrows to move it up or down in the sequence.
- 5 When the tracks are arranged in the sequence you want, tap **Done**.



## Playing a Music Playlist


### Action

- 1 Open the desired folder.
- 2 Tap  to switch to the Playlist view
- 3 Tap  to play the highlighted track

or


Select a track by tapping on it. The track automatically starts playing.

The Music Player plays the tracks in the sequence you selected.




## Action


- 4 While the playlist plays, you can tap the following buttons at the bottom of the screen:

 Tap and release to start playing from the beginning of the current track or to jump to the beginning of the previous track in the playlist (if already at the start of the current track).

Tap and hold down to rewind the current track.

 Tap to stop playing and return to the start of the track.

  Tap to switch between play and pause mode.

 Tap and release to start playing from the beginning of the next track in the playlist.

Tap and hold down to advance (fast forward) the current track.

---






## Saving Audio Files

When you download an audio file from the Web or open an audio email attachment, the **Save Audio File** screen displays. To save the file to a folder in the communicator or to the Memory card:

### Action

- 1 Tap the down arrow to the left of the filename.  
The **File Information** screen displays.

---

- 2 In the **Audio** screen, tap  to play the audio file, or the right arrow to install as a Ring Tone.

---

- 3 Tap **Save**.

---

- 4 Select the location to which you want to save the file.

---

- 5 Tap **Save**.

---


---

**Note:** To ensure optimum use of communicator memory, save audio clips to the memory card when possible.

## Camera


You can use the built-in camera to take still pictures and record video clips.


### Opening Camera Application

Tap  in the Application Launcher. When the Camera application opens, a camera viewfinder displays the image viewed by the camera lens.




## Using the Front and Back Camera Lens

You can use the front or back of the camera to take pictures. To switch between the front or the back lens, tap .



## Using the Camera Control Keys

You can hold your communicator like you would hold a standard camera to take pictures. When in camera mode, the volume keys are used for zooming the image in and out.










Press the right side to zoom in, and the left side to zoom out.

Press to take a picture.

## Taking Still Pictures


### Action

- 1 Tap  to place camera in Still mode.
- 2 Point the camera lens at the subject.
- 3 Tap  or press  (center key) to take the picture.  
The picture displays in the viewfinder.
- 4 Tap  or press  (center key) to save the picture.  
If you want to delete the picture without saving it, press  (right arrow) or tap .

## Selecting Camera Settings

You select the picture size, quality, lighting, and flicker settings.

### Action

- 1 Tap  to place camera in Still mode.
- 2 Tap **Camera > Camera settings**.
- 3 Select the desired settings.
- 4 Tap **Done**.










## Recording Video Clips

You can use the camera to record a video clip up to 60 seconds long.

### Action

- 1 Tap  to place camera in Video mode.
- 2 Point the camera lens at the subject.
- 3 Press  (center key) and hold for 2 seconds to start recording the video.

The video image displays in the viewfinder.

- 4 To stop recording, press  (center key) again.  
The video is saved to the currently selected folder.


## Using Self-Timer

The camera has a self-timer that automatically takes a picture or records a video clip 5 seconds after you turn it on.

### Action

- 1 Set camera to desired mode (still or video), as described in the previous sections
- 2 Point the camera lens at the subject.
- 3 Tap **Camera > Self timer on.**

## Action

- 4 Press  (center key) and hold for 1 seconds to start the timer.

The camera starts counting down from 5 to 0. When it reaches 0, it takes the picture or starts recording.

---

---



## **Available Memory Indicator**

The available memory indicator below the viewfinder shows an estimation of how many more pictures or video clips you can take before the selected folder's memory is full. When memory is full, the camera stops recording.

## **Switching to Pictures**

When the Camera is in Still mode, you can quickly switch to **Pictures** to view, edit, and send the pictures you have taken. See “Pictures” on page 116.

To switch to **Pictures**, tap .

## **Switching to Video**

When the Camera is in Video mode, you can quickly switch to **Video** to watch and send the video clips you have recorded. See “Video” ahead.


To switch to **Video**, tap .

## Video



Use Video to watch video clips and streaming video and audio from the Web. You can watch video clips that you recorded with the communicator's camera, downloaded from the Web, received as an email attachment, or stored on the removable memory card.

### Opening Video

Tap  in the Application Launcher. When Video opens, it shows a list of all saved video clips.

To view the video clips saved in a specific folder, tap the current folder name (upper right corner) and select the desired folder from the list.

Sample video files are provided on the in-box CD supplied with the communicator.



You need a license to open media files that have digital rights protection. If you do not have a license for a protected file, your communicator prompts you to launch the Web browser and download one.

**Note:** Video clips must be stored in the proper directory on the memory card for you to see and play them in Video. When you copy video files to the memory card from a computer, ensure that the files are stored in a third-level directory under:

## Media Files\Video\

For example, you can store video files in any of the following directories:

**Media Files\Video\Movie Trailers**

**Media Files\Video\Home**


**Media Files\Video\Unfiled**

## *Playing a Video Clip*

### Action

- 1 In the list of video clips, tap the clip you want to play.

The video begins to play in portrait (vertical) view:





## Action

- 2 While the video plays, you can tap the following buttons at the bottom of the screen:



Tap to switch between play and pause mode.



Tap to stop the video and return to the beginning.



Tap to open the Camera application.



Tap to return to the list of video tracks.

**Note:** The  key also controls video play: left = rewind, right = fast forward, center = play/pause.

---

---

To see the video in landscape (full-screen) view, tap anywhere on the playing video. To return to portrait view, tap the playing video again.

### ***Playing Streaming Video and Audio***

To play streaming video and audio from the Web, use the Web browser to select the link to the video or audio clip or broadcast. The communicator establishes a connection with the server and buffering begins. When buffering completes, the video or audio starts playing.



## ***Saving Video Clips***

When you download a video clip from the Web or open a video email attachment, the clip begins playing in Video. You can save the clip to a folder in the communicator or to the memory card.

### **Action**

- 1 Tap **Video > Save**.

---

- 2 Select the location to which you want to save the file.

---

- 3 Tap **Save**.

---

---

**Note:** To ensure optimum use of communicator memory, save video clips to the memory card when possible.

## ***Sending Video Clips***

You can send video clips by email, SMS message, MMS message, or Bluetooth.

**Note:** For more information on Bluetooth, see page 72.

### **Action**

- 1 In the list of video clips, tap the clip you want to send.

---

- 2 Tap **Video > Send as**.

---

- 3 Select the method by which you want to send the video clip.

---

- 4 Tap **Done**.

---


---



## Pictures

Use **Pictures** to view and edit picture files. You can view pictures that you took with the camera, downloaded from the Web, received as an email attachment, or stored on the removable memory card.

### Opening Pictures

Tap  in the Application Launcher. When **Pictures** opens, it shows small thumbnail pictures of all saved picture files or a list of picture files (depending on the view you selected when Pictures was last open).

To switch views, tap **Setting > List**.

To see the pictures saved in a specific folder, tap the current folder name and select the desired folder from the list.

**Note:** Pictures must be stored in the proper directory on the memory card for you to see them in **Pictures**. When you copy picture files to the memory card from a computer, ensure that the files are stored in a third-level directory under:

**Media Files\Image\**

For example, you can store pictures in any of the following directories:

**Media Files\Image\Kids**


**Media Files\Image\Vacation**

**Media Files\Image\Unfiled**

## Viewing Pictures

### Action

- 1 Tap the thumbnail picture or file name you want to view. The picture displays.

If the original picture is larger than the display area, it reduces to fit. To see the picture in its original size, tap **Pictures > Actual size view**. Use  (center) to scroll to see the entire picture.



- 2 While viewing the picture, you can tap the following buttons at the bottom of the screen:



Tap to see previous picture.



Tap to see next picture.



Tap to open the Camera application.



Tap to return to the list or thumbnails of pictures.







## Viewing Slideshow

You can view all of the pictures in a folder as a slideshow.

### Action

1 Open the folder with the pictures you want to view.

2 Tap **Pictures** > **View slideshow**.

The pictures in the folder display in the order listed.

**Note:** The default interval between slides is 3 seconds. To change this interval, tap **Setting** > **Slideshow interval** before you start the slideshow.

If you select **Manual** mode, you must press  $\odot$  left and right to move through the slideshow.

## Editing Pictures

You can use **Pictures** to edit pictures in the following ways:

- Rotate image
- Draw on image
- Add a stamp to the image
- Add a frame to the image

To edit a picture, select the desired editing function from the **Edit** menu. See the *A1000 More Here* reference guide on the in-box CD for more information about editing pictures.

## Sending Pictures

You can send pictures by email, SMS message, MMS message, or Bluetooth.

### Action

- 1 Tap the thumbnail picture or file name you want to send.

---

  - 2 Tap **Pictures** > **Send as**.

---

  - 3 Select the method by which you want to send the picture.

---

  - 4 Tap **Done**.
- 
- 







## **SIM Applications (SimApps)**

Your USIM card may contain additional applications that process outgoing calls, text messages, and other services. Please contact 3 for additional

information.

### **Action**

- 1 Tap SimApps (  ) in the Application Launcher.



## ***Specific Absorption Rate Data***

---

**This model phone meets the international standards for exposure to radio waves.**

Your mobile phone is a radio transmitter and receiver. It is designed and manufactured not to exceed limits for exposure to radio frequency (RF) energy. These limits are part of comprehensive guidelines and establish permitted levels of RF energy for the general population. The guidelines are based on standards that were developed by independent scientific organizations through periodic and thorough evaluation of scientific studies. The guidelines include a substantial safety margin designed to assure the safety of all persons, regardless of age and health.

The exposure standard for mobile phones employs a unit of measurement known as the Specific Absorption Rate, or SAR. Under the guidelines for your phone model, the SAR limit is 2.0 W/kg.<sup>1</sup> Tests for SAR are conducted in accordance with CENELEC<sup>2</sup> testing procedures using standard operating positions with the phone transmitting at its highest certified power level in all tested frequency bands. Although the SAR is determined at the highest certified power level, the actual SAR of the phone while operating can be well below the maximum value. This is because the phone is designed to operate at multiple power levels so as to use only the power required to reach the network. In general, the closer you are to a base station, the lower the power output of the phone.

Before a phone model is available for sale to the public, it is tested to confirm compliance with the guidelines. The tests are performed in

- 
1. The SAR limit recommended by international guidelines (ICNIRP) for mobile phones used by the public is 2.0 watts/kilogram (W/kg) averaged over ten grams of tissue. The limit incorporates a substantial margin for safety to give additional protection for the public and to account for any variations in measurements.
  2. CENELEC is a European Union standards body.

positions that conform to a uniform testing methodology determined by an expert standards body. The highest SAR value for this model phone when tested for use at the ear is \_\_\_\_ W/kg.<sup>1</sup>

While there may be differences between the SAR levels of various phones and at various positions, they all meet the governmental requirements for safe exposure. Please note that improvements to this product model could cause differences in the SAR value for later products; in all cases, products are designed to be within the guidelines.

Draft

- 
1. Additional related information includes the Motorola testing protocol, assessment procedure, and measurement uncertainty range for this product.

# **Motorola Limited Warranty for the United States and Canada**

---

## **What Does this Warranty Cover?**

Subject to the exclusions contained below, Motorola, Inc. warrants its telephones, pagers, messaging devices, and consumer and professional two-way radios (excluding commercial, government or industrial radios) that operate via Family Radio Service or General Mobile Radio Service, Motorola-branded or certified accessories sold for use with these Products (“Accessories”) and Motorola software contained on CD-ROMs or other tangible media and sold for use with these Products (“Software”) to be free from defects in materials and workmanship under normal consumer usage for the period(s) outlined below. This limited warranty is a consumer’s exclusive remedy, and applies as follows to new Motorola Products, Accessories and Software purchased by consumers in the United States or Canada, which are accompanied by this written warranty:

### **Products and Accessories**

<b>Products Covered</b>	<b>Length of Coverage</b>
<b>Products and Accessories</b> as defined above, unless otherwise provided for below.	<b>One (1) year</b> from the date of purchase by the first consumer purchaser of the product unless otherwise provided for below.
<b>Decorative Accessories and Cases.</b> Decorative covers, bezels, PhoneWrap™ covers and cases.	<b>Limited lifetime warranty</b> for the lifetime of ownership by the first consumer purchaser of the product.
<b>Monaural Headsets.</b> Ear buds and boom headsets that transmit mono sound through a wired connection.	<b>Limited lifetime warranty</b> for the lifetime of ownership by the first consumer purchaser of the product.

<b>Products Covered</b>	<b>Length of Coverage</b>
<b>Consumer and Professional Two-Way Radio Accessories.</b>	<b>Ninety (90) days</b> from the date of purchase by the first consumer purchaser of the product.
<b>Products and Accessories that are Repaired or Replaced.</b>	<b>The balance of the original warranty or for ninety (90) days</b> from the date returned to the consumer, whichever is longer.

### ***Exclusions***

**Normal Wear and Tear.** Periodic maintenance, repair and replacement of parts due to normal wear and tear are excluded from coverage.

**Batteries.** Only batteries whose fully charged capacity falls below 80% of their rated capacity and batteries that leak are covered by this limited warranty.

**Abuse & Misuse.** Defects or damage that result from: (a) improper operation, storage, misuse or abuse, accident or neglect, such as physical damage (cracks, scratches, etc.) to the surface of the product resulting from misuse; (b) contact with liquid, water, rain, extreme humidity or heavy perspiration, sand, dirt or the like, extreme heat, or food; (c) use of the Products or Accessories for commercial purposes or subjecting the Product or Accessory to abnormal usage or conditions; or (d) other acts which are not the fault of Motorola, are excluded from coverage.

**Use of Non-Motorola Products and Accessories.** Defects or damage that result from the use of Non-Motorola branded or certified Products, Accessories, Software or other peripheral equipment are excluded from coverage.

**Unauthorized Service or Modification.** Defects or damages resulting from service, testing, adjustment, installation, maintenance, alteration, or modification in any way by someone other than Motorola, or its authorized service centers, are excluded from coverage.

**Altered Products.** Products or Accessories with (a) serial numbers or date tags that have been removed, altered or obliterated; (b) broken seals or that show evidence of tampering; (c) mismatched board serial numbers; or (d) nonconforming or non-Motorola housings, or parts, are excluded from coverage.

**Communication Services.** Defects, damages, or the failure of Products, Accessories or Software due to any communication service or signal you may subscribe to or use with the Products Accessories or Software is excluded from coverage.

### ***Software***

<b>Products Covered</b>	<b>Length of Coverage</b>
<b>Software.</b> Applies only to physical defects in the media that embodies the copy of the software (e.g. CD-ROM, or floppy disk).	<b>Ninety (90) days</b> from the date of purchase.

### ***Exclusions***

**Software Embodied in Physical Media.** No warranty is made that the software will meet your requirements or will work in combination with any hardware or software applications provided by third parties, that the operation of the software products will be uninterrupted or error free, or that all defects in the software products will be corrected.

**Software NOT Embodied in Physical Media.** Software that is not embodied in physical media (e.g. software that is downloaded from the internet), is provided “as is” and without warranty.

### ***Who is Covered?***

This warranty extends only to the first consumer purchaser, and is not transferable.

### ***What Will Motorola Do?***

Motorola, at its option, will at no charge repair, replace or refund the purchase price of any Products, Accessories or Software that does not conform to this warranty. We may use functionally equivalent



reconditioned/refurbished/pre-owned or new Products, Accessories or parts. No data, software or applications added to your Product, Accessory or Software, including but not limited to personal contacts, games and ringer tones, will be reinstalled. To avoid losing such data, software and applications please create a back up prior to requesting service.

### ***How to Obtain Warranty Service or Other Information***

<b>USA</b>	<b>Phones</b> 1-800-331-6456 <b>Pagers</b> 1-800-548-9954 <b>Two-Way Radios and Messaging Devices</b> 1-800-353-2729
<b>Canada</b>	<b>All Products</b> 1-800-461-4575
<b>TTY</b>	1-888-390-6456
For <b>Accessories</b> and <b>Software</b> , please call the telephone number designated above for the product with which they are used.	

You will receive instructions on how to ship the Products, Accessories or Software, at your expense, to a Motorola Authorized Repair Center. To obtain service, you must include: (a) a copy of your receipt, bill of sale or other comparable proof of purchase; (b) a written description of the problem; (c) the name of your service provider, if applicable; (d) the name and location of the installation facility (if applicable) and, most importantly; (e) your address and telephone number.

### ***What Other Limitations Are There?***

ANY IMPLIED WARRANTIES, INCLUDING WITHOUT LIMITATION THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, SHALL BE LIMITED TO THE DURATION OF THIS LIMITED WARRANTY, OTHERWISE THE REPAIR, REPLACEMENT, OR REFUND AS PROVIDED UNDER THIS EXPRESS LIMITED WARRANTY IS THE EXCLUSIVE REMEDY OF THE CONSUMER, AND IS PROVIDED IN LIEU OF ALL OTHER

WARRANTIES, EXPRESS OR IMPLIED. IN NO EVENT SHALL MOTOROLA BE LIABLE, WHETHER IN CONTRACT OR TORT (INCLUDING NEGLIGENCE) FOR DAMAGES IN EXCESS OF THE PURCHASE PRICE OF THE PRODUCT, ACCESSORY OR SOFTWARE, OR FOR ANY INDIRECT, INCIDENTAL, SPECIAL OR CONSEQUENTIAL DAMAGES OF ANY KIND, OR LOSS OF REVENUE OR PROFITS, LOSS OF BUSINESS, LOSS OF INFORMATION OR DATA, SOFTWARE OR APPLICATIONS OR OTHER FINANCIAL LOSS ARISING OUT OF OR IN CONNECTION WITH THE ABILITY OR INABILITY TO USE THE PRODUCTS, ACCESSORIES OR SOFTWARE TO THE FULL EXTENT THESE DAMAGES MAY BE DISCLAIMED BY LAW.

**Some states and jurisdictions do not allow the limitation or exclusion of incidental or consequential damages, or limitation on the length of an implied warranty, so the above limitations or exclusions may not apply to you. This warranty gives you specific legal rights, and you may also have other rights that vary from state to state or from one jurisdiction to another.**

Laws in the United States and other countries preserve for Motorola certain exclusive rights for copyrighted Motorola software such as the exclusive rights to reproduce and distribute copies of the Motorola software. Motorola software may only be copied into, used in, and redistributed with, the Products associated with such Motorola software. No other use, including without limitation disassembly of such Motorola software or exercise of the exclusive rights reserved for Motorola, is permitted.

# Index

---

## Numerics

3 key 27

## A

A1000 desktop suite  
  connecting to computer  
    74  
  installing 24  
A1000 desktop top suite 71  
accessories 16  
accounts  
  email 51  
  MMS 51  
  SMS 51  
adding folders 31  
airplane mode  
  status bar indicator 33  
  turning on and off 34, 49  
alarms  
  calendar 82  
  responding to 91  
  setting 91  
  to do 86  
  turning sound off 92  
alert mode 32  
  changing 32  
  status bar indicator 32  
answering calls 25, 48

application  
  icons 29  
  opening 28  
  shortcuts 39  
application launcher 28  
application selector bar 26  
application space 26  
appointments 81  
attachments, opening 57  
AU files 100  
audio mode indicator 32

## B

battery  
  charging 22  
  extending battery life 20  
  installing 21  
  strength indicator 34  
battery cover  
  removing 18  
  replacing 22  
Bluetooth 74  
  status bar 32  
bookmark  
  adding 98  
  opening 98  
box contents 16  
brightness

- screen 66
- button bar 26

## C

- calculator 92
- calendar 81
  - adding an entry 81
  - alarm, setting 82
  - entry types 81
  - moving entries to to do 84
  - private entries 83
  - recurring entries 83
  - views 83
- calibrate screen 24
- call
  - video 43
- calls
  - answering 25, 48
  - dialing with keypad 43
  - emergency 46
  - making 25
  - ring tones 68
  - to stored contacts 64
  - vibrate pattern 69
  - video 43
  - voice 43
- camera
  - control keys 108
  - front and back lens 108
  - landscape view 114
  - memory available 111

- opening application 107
- portrait view 114
- self-timer 110
- settings 109
- taking still pictures 109
- charging battery
  - travel charger 22
- clock 31
- computer
  - linking to 74
- contact fields
  - adding new 61
- contacts
  - adding 59
  - calling 64
  - fields 61
  - opening application 58
  - pictures, assigning 61
  - preferred phone number 59
  - ring tone, assigning 60
  - saving to USIM card 59
  - sending messages to 64

## D

- data call
  - wireless connection 74
- day view 83
- deleting
  - folders 31
- desktop suite
  - installing 24

- dialing
  - stored numbers 43, 64
  - using keypad 43

- display
  - brightness 66
  - calibration 67
  - described 26
  - wallpaper 66

- downloading
  - files 99

## **E**

- earpiece
  - volume, adjusting 42

- email
  - account 51
  - opening attachments 57
  - receiving 57
  - sending 53
  - sending to contact 64
  - status bar indicator 33

- emergency
  - making calls 46
  - status bar indicator 33

## **F**

- files
  - adding to MMS 55
  - attaching to email and SMS 53
  - downloading from web 99

- saving audio 106
- saving video 115
- sending 115, 119

- folders 30

## **G**

- game keys 28
- GPRS 33
- GPS 32, 49
- GSM 33

## **H**

- handwriting recognition 34
- home screen
  - displaying 38
  - personalizing 40

## **I**

- icons
  - applications 29
  - status bar 31
- information snacks 39
- installing
  - battery 21
  - memory card 19
  - USIM card 17
- internal speakerphone 42
- internet
  - opening web pages 98

## K

### keyboard

- launcher 32
- using 36

### keys

- camera 108
- center select 27
- game 28
- Hutchison 27
- navigation 27
- Power 23
- speakerphone 42
- volume 42

## L

### landscape view 114

### language

- selecting 24

### location service

- status bar indicator 32
- turning on and off 32

### location, time zone 90

### locking communicator 95

## M

### making a call 25

### memory available, camera 111

### memory card

- installing 19
- saving audio files to 106

### saving video files to 115

### menu bar 26

### messages

- accounts 50
- opening application 52
- opening attachments 57
- receiving 57
- ring tones 69
- sending 53
- status bar indicator 33
- vibrate pattern 69

### MIDI files 100

### MMS

- maximum size 56
- receiving 57
- sending 54
- status bar indicator 33

### month view 83

### MP3 files 100

### Multimedia Message Service. *See* MMS

### music

- file types supported 100
- managing playlists 103
- opening 100
- playing playlists 104
- playing tracks 101
- saving files 106

### mute

- status bar indicator 32

## N

- navigation key 27
- network
  - status bar indicator 33
- notes
  - drawing sketches 88
  - writing notes 88

## O

- opening applications 28
- optional accessories,
  - defined 17
- optional features, defined 17

## P

- password
  - setting protection level 95
- personal information 39
- phone
  - airplane mode 49
  - answering calls 25, 48
  - dialing with keypad 43
  - displaying own number 42
  - keypad display 41
  - making video calls 43
  - making voice calls 25, 43
  - opening application 41
  - status bar indicator 32
  - wireless connection 74

- phone number
  - dialing with keypad 43
  - storing in contact list 59
  - viewing your own 42

## Picxel Viewer 100

## pictures

- assigning to contacts 61
- opening application 116
- slideshow 118
- taking with camera 109
- viewing 117
- viewing pictures 117

## playing

- audio tracks 101
- video clips 113

## portrait view 114

## power

- key 23
- turning on and off 23

## private

- calendar entries 83
- to do entries 86

## R

## recording

- video clips 110
- recording voice tags 62
- reminders 81
- ring tones
  - assigning to contacts 60
  - choosing for calls 68

- choosing for messages
  - 69
- ringing
  - choosing tones 68
  - turning off 49
- roaming
  - status bar indicator 33
- S**
- saving
  - audio files 106
  - video files 115
- screen
  - brightness 66
  - calibrating 67
- security
  - locking communicator 95
  - password protection 95
- self-timer, camera 110
- sending
  - messages 53
  - pictures 119
  - video clips 115
- short message service,
  - SMS 50
- shortcut key
  - setting application 68
- signal strength indicator 34
- silent mode indicator 32
- sim applications 120
- SIM card. *See* USIM card
- sketching 88

- slideshow 118
- SMS
  - receiving 57
  - sending 53
  - status bar indicator 33
- snacks 39
- sounds, system 67
- speakerphone
  - turning on/off 42
  - using 42
- status bar 26, 31
- storing
  - email address 59
  - phone numbers 59
- streaming video 114
- stylus 27
- switching folders 30
- system sounds 67

- T**
- text entry 34
- time
  - alarms 91
- to do
  - adding entries 85
  - alarm 86
  - deleting entries 87
  - due dates 85
  - marking tasks as
    - complete 86
  - moving entries to
    - Calendar 87



- private entries 86
- touchscreen 27

## U

- UMTS 33
- unlocking communicator 95
- USIM card
  - installing 17
  - saving contacts to 59

## V

- vibrate mode
  - indicator 32
  - turning on and off 32
- vibrate pattern 69
- video
  - opening application 112
  - playing clips 113
  - saving files 115
  - sending clips 115
- video calls
  - calling computers 45
  - dialing with keypad 44
- video clips
  - playing 113
- virtual keyboard 36
- voice calls 43
- voice message indicator 32
- voice records 92
  - deleting 94
  - playback 94
  - sending 94

- voice tags
  - recording 62
- volume
  - adjusting 42
  - key 42

## W

- wallpaper 66
- warranty 123
- WAV files 100
- web
  - downloading files 99
  - opening pages 98
  - saving bookmarks 99
  - saving viewed pages 99
- week view 83
- WMA files 100
- writing
  - using stylus 34
  - using virtual keyboard 36

U.S. patent Re. 34,976

