

GYLPKB Wireless Keyboard





Gyration

Important Ergonomic Information

Some experts believe that using any mouse or trackball may cause serious injury to hands, wrists, arms, neck, or back. If you feel pain, numbness, or weakness in these areas, promptly consult with a qualified doctor.

TO REDUCE THE RISK OF INJURY, FOLLOW THESE PRECAUTIONS:

- Take frequent breaks, get up and walk around several times every hour
- Vary your tasks throughout the day
- Keep your shoulders relaxed with your elbows at your side
- Place your keyboard and mouse in a comfortable position
- Adjust your chair and keyboard and keyboard tray so your forearms and wrists are in a neutral position, which is the most natural.
- Avoid resting your wrists on sharp edges

System Requirement

Windows XP / Vista

Before you begin

- Keep this installation guide for future reference! It contains important troubleshooting information.
- Keep your old PS/2 or USB keyboard as back-up devices.

Getting Started

- By using the advanced RF technology, a 360° operation is possible and no line-of-sight is required between the receiver and the mouse.
- Low-power indicator LED's on the keyboard will blink when batteries need replacing.

Package Contains

Your GYLPKB package includes the following:

- The wireless Keyboard
- USB receiver
- User's manual
- 2 AAA alkaline batteries for the keyboard

Note: If any part is missing or damaged, please contact your dealer for a replacement immediately.

01






Hardware Installation

Battery installation

- 1.Remove the keyboard battery compartment cover.
- 2.Install batteries with the positive (+) & negative (-) in the correct direction indicated by the AAA battery compartment label.
- 3. Replace the battery compartment cover.




CAUTION:


Risk of Explosion if Battery is replaced by an incorrect Type. Dispose of Used Batteries According to the Instructions.

Connect the receiver with computer

Plug the USB receiver into any available USB port or hub connected to your computer. Windows will detect and install new hardware automatically.



 The keyboard have already been synchronized. To reestablish contact for the keyboard press the connect button of the mouse for 5 seconds. When the receiver blinks, the keyboard is connected.



3 I C






Operation Guide

BATTERY LOW INDICATION

When the batteries become low, the LED battery indicator on the top of the keyboard will blink. The keyboard can continue to operate for a period of time depending on usage, but batteries should be replaced immediately.



Easy Key Definition

Operation of Easy key:

y: [9+	F10
------	----	-----

Icon	Description	Icon	Description
▶/11	Play / Pause	J	Media
	Stop		Calculator
lee	Previous Track		My Computer
₩	Next Track	\boxtimes	E-Mail
		ιĒ	Browser

Hotkey Definition

Hotkey panel is located above the ten key area.

Icon	Description	Icon	Description
(())) (Volume Up	(6)	Mute
() V	Volume Down	(Sleeping Mode

OPERATIONS ON POWER SAVING MODE

In order to conserve battery power, the keyboard is designed to reduce power consumption gradually from standby mode to sleep mode, if it is not being used.



Gyration

Troubleshooting

When the keyboard do not work properly, the common troubleshooting steps.

- 1. Take the receiver out from your PC. After few seconds, plug the receiver into your PC again.
- 2. Make sure if the batteries are positioned correctly and connected well.
- 3. Please check to make sure that the batteries are not dead.
- 4. Press the connect button on the back side of the keyboard for 5 seconds. While the receiver blinks, release the connect button.

Information

FCC Statement

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions,

- 1. this device may not cause harmful interference, and
- 2. this device must accept any interference received, including interference that may cause undesired operation.

FCC RF Radiation Exposure Statement

- This equipment complies with FCC RF radiation exposure limits set forth for an uncontrolled environment.
- 2. This device and its antenna must not be co-located or operating in conjunction with any other antenna or transmitter.

Caution!

The manufacturer is not responsible for any radio or TV interference caused by unauthorized modifications to this equipment. Such modifications could void the user authority to operate the equipment.

NOTE:

This equipment has been tested and found to comply with the limits for a class B digital device, pursuant to Part 15 the FCC Rules . These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions , may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception , which can determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures.

- Reorient or relocate the receiving antenna
- Increase the separation between the equipment and receiver
- Connect the equipment into an outlet on a circuit different form that to which the receiver is connected
- Consult the dealer or an experienced radio/TV technician for help

Products with the CE Marking comply with the EMC Directive and the Low Voltage Directive issued by the Commission of the European Community.

Canada Statement

This Device complies with RSS-210 of the IC Rules, Operations is subject to the following two conditions:

- 1. This device may not cause interference and
- This device must accept any interference received, including interference

that may cause undesired operation.