

B750

TABLE OF CONTENTS

Chapter 1: Introduction	1
Welcome	1
To Open the System	1
Taking a look at this Notebook	2
Front View	2
Left View	3
Right View	3
Rear View	4
Chapter 2: Operating the Notebook	6
About Power Indicators	6
About the Keyboard	6
Using the Touch Pad	7
About the Status Indicators	8
Using Quick-Access Buttons	8
Using the Optical Drive	8
Inserting and removing s CD	8
About a Security Lock	9
Using the Video Features	9
Settings	9
Setting the External Monitor & Television	10
Using the Audio Features	10
Sound Ports	10
SPDIF Ports	10
Using the Communication Features	11
Using the LAN	11
Using the Modem	11
Using the Battery Pack	11
To Change the Battery Pack	12
Battery Charging	12
Battery Discharging	12
Battery Low Warnings	12
Using Power Management	12
Suspend to RAM	13
Suspend to Disk	13

Initiating Standby or Hibernate Mode	13
Chapter 3: Getting Start.....	15
Connecting Power to the System.....	15
Using this Computer	16
System Setup and Installation	18
CHAPTER 4: CONFIGURING THE NOTEBOOK	20
System Configuration Utility.....	20
Using the System Configuration Utility	20
Navigating	20
Startup	22
Memory	23
Disks.....	24
Components.....	24
Power.....	26
Exit.....	26
CHAPTER 5: EXPANDING THE NOTEBOOK.....	28
Using PC Cards.....	28
PC Card Type	28
CardBus Support	28
Inserting and removing a PC Card	28
Using Infrared Port	29
Establishing an Infrared Connection	30
Connecting an IEEE 1394 Device	30
Connecting a PS/2 Device.....	31
Connecting a Parallel Device.....	31
Connecting a USB Device	31
Connecting a TV.....	31
Connecting an External Monitor.....	32
Internal Computer Upgrade	32

IMPORTANT INFORMATION

Copyright

This publication, including all photographs, illustrations and software, is protected under international copyright laws, with all rights reserved. Neither this manual, nor any of the material contained herein, may be reproduced without the express written consent of the manufacturer.

Disclaimer

The information in this document is subject to change without notice. The manufacturer makes no representations or warranties with respect to the contents hereof and specifically disclaims any implied warranties of merchantability or fitness for any particular purpose. Further the manufacturer reserves the right to revise this publication and to make changes from time to time in the content hereof without obligation of the manufacturer to notify any person of such revision or changes.

Trademark Recognition

Microsoft, MS-DOS and Windows are registered trademarks of Microsoft Corp.

Pentium-4 are a registered trademarks of Intel Corporation.

VGA, OS/2, PS/2 are registered trademarks of International Business Machines.

Other product names used in this manual are the properties of their respective owners and are acknowledged.

SAFETY & COMPLIANCE

Federal Communications Commission (FCC) - Notebook

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- ☐ Reorient or relocate the receiving antenna.
- ☐ Increase the separation between the equipment and the receiver.
- ☐ Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- ☐ Consult the dealer or an experienced radio/TV technician for help.

Shielded interconnect cables and shielded AC power cable must be employed with this equipment to insure compliance with the pertinent RF emission limits governing this device. Changes or modifications not expressly approved by the system's manufacturer could void the user's authority to operate the equipment.

Declaration of Conformity

This device complies with part 15 of the FCC rules. Operation is subject to the following conditions:

- ☐ This device may not cause harmful interference.
- ☐ This device must accept any interference received, including interference that may cause undesired operation.

Federal Communications Commission (FCC) – Fax/modem

This equipment complies with Part 68 of the FCC Rules. On this equipment is a label that contains, among other information, the FCC registration number and Ringer Equivalence Number (REN) for this equipment. You must, upon request, provide this information to your telephone company.

If your telephone equipment causes harm to the telephone network, the Telephone Company may discontinue your service temporarily. If possible, they will notify in advance. But, if advance notice isn't practical, you will be notified as soon as possible. You will be informed of your right to file a complaint with the FCC.

Your telephone company may make changes in its facilities, equipment, operations, or procedures that could affect proper operation of your equipment. If they do, you will be notified in advance to give you an opportunity to maintain uninterrupted telephone service.

The FCC prohibits connecting this equipment to party lines or coin-telephone service.

In the event that this equipment should fail to operate properly, disconnect the equipment from the phone line to determine if it is causing the problem. If the problem is with the equipment, discontinue use and contact your dealer or vendor.

The FCC also requires the transmitter of a FAX transmission be properly identified (per FCC Rules Part 68, Sec. 68.381 (c) (3)).

Canadian Department of Communications-Notebook

This class B digital apparatus meets all requirements of the Canadian Interference-causing Equipment Regulations.

Cet appareil numérique de la classe B respecte toutes les exigences du Règlement sur le matériel brouilleur du Canada.

VCCI

この装置は、情報処理装置等電波障害自主規制協議会（VCCI）の基準に基づく第二種情報技術装置です。この装置は、家庭環境で使用することを目的としていますが、この装置がラジオやテレビジョン受信機に近接して使用されると、受信障害を引き起こすことがあります。

取扱説明書に従って正しい取り扱いをして下さい。

DHHS- the CD-ROM Drive

FDA Regulations require the following statement for all laser-based devices:

"Caution, Use of controls or adjustments or performance of procedures other than those specified herein may result in hazardous radiation exposure."

**CLASS 1 LASER PRODUCT
LASERSCHUTZKLASSE 1 PRODUKT
TO EN60825**

Caution: This appliance contains a laser system and is classified as a "CLASS 1 LASER PRODUCT". To use this model properly, read the instruction manual carefully and keep this manual for future reference. In case of any trouble with this model, please contact your nearest "Authorized Service Station". To prevent direct exposure to the laser beam, do not try to open this enclosure.

UL/TUV Battery & FAX/Modem Caution and Important Safety Instructions

CAUTION

Danger of explosion if battery is incorrectly replaced.

Replace only with the same or equivalent type recommended by the manufacturer. Discard used batteries according to the manufacturer's instructions.

VORSICHT!

Explosionsgefahr bei unsachgemäßen Austausch der Batterie Ersatz nur durch denselben oder einem vom Hersteller empfohlenem ähnlichen Typ. Entsorgung gebrauchter Batterien nach Angaben des Herstellers.

IMPORTANT SAFETY INSTRUCTIONS

When using your telephone equipment, basic safety precautions should always be followed to reduce the risk of fire, electric shock and injury to persons, including the following:

Do not use this product near water, for example, near a bath tub, wash bowl, kitchen sink or laundry tub, in a wet basement or near a swimming pool.

Avoid using a telephone (other than a cordless type) during an electrical storm. There may be a remote risk of electric shock from lightning.

Do not use the telephone to report a gas leak in the vicinity of the leak.

Use only the power cord and batteries indicated in this manual. Do not dispose of batteries in a fire. They may explode. Check with local codes for possible special disposal instructions.

This product intended to be supplied by a Listed Power Unit, marked "Class 2" or "LPS" and output rated +17.2 ~ 20V dc, 6.5 ~ 2.8 A"

CTR21 Notice

The equipment has been approved in accordance with Council Decision 98/482/EC for pan-European single terminal connection to the public switched telephone network (PSTN). However, due to differences between the individual PSTNs provided in different countries, the approval does not, of itself, give an unconditional assurance of successful operation on every PSTN network termination point.

In the event of problems, you should contact your equipment supplier in the first instance.

ANNEX II

The equipment has been approved in accordance with Council Decision 98/482/EC for pan-European single terminal connection to the public switched telephone network (PSTN). However, due to differences between the individual PSTN's provided in different countries the approval does not of itself give an unconditional assurance of successful operation on every PSTN network termination point.

In the event of problems, you should contact your equipment supplier in the first instance.

Note: The manufacturer should ensure that the vendor and user of the equipment is clearly informed of the above information by means of packaging and/or user manuals or other forms of user instructions.

ANNEX III

This declaration will indicate the networks with which the equipment is designed to work and any notified networks with which the equipment may have interworking difficulties.

Network compatibility declaration to be made by the manufacturer to the user.

This declaration will indicate the network with which the equipment is designed to work and any notified networks with which the equipment may have interworking difficulties. The manufacturer shall also associate a statement to make it clear where network compatibility is dependent on physical and software switch settings. It will also advise the user to contact the vendor if it is desired to use the equipment on another network

CE Declaration of Conformity

The system computer model B700 and accessories conform to the following production specifications:

Manufacturer Name:

Manufacturer Address:

Model Name: B700

Is herewith confirmed to comply with the requirements set out in the Council Directive on the Approximation of the Laws of the Member States relating to Electromagnetic Compatibility (89/336/EEC) and Low-voltage Directive (73/23/EEC & 93/68/EEC). For the evaluation regarding the Electromagnetic Compatibility and Low-voltage Directive the following standards were applied.

Standards

89/336/EEC-EMC Directive

EN 55022 : 1998/A1:2000(Class B)	Limits and methods of measurement of radio disturbance characteristics of information technology equipment.
EN 61000-3-2 : 1995/A1/A2:1998/A14:2000	Disturbances in supply systems caused by household appliance and similar electrical equipment "harmonics".
EN 61000-3-3 : 1995/A1:1998	Part 2: harmonics/parts: voltage fluctuations.

EN 55024:1998 ITE Immunity Standard

IEC 61000-4-2 : 1995/A1:1998/A2:2000	Electrostatic discharge requirements
IEC 61000-4-3 : 1996/A1:1998/A2:2000	Immunity to radiated, radio frequency electromagnetic fields
IEC 61000-4-4 : 1995/ A1:2000	Electrical fast transient requirements
IEC 61000-4-5 : 1995/ A1:2000	Surge requirements
IEC 61000-4-6 : 1996/ A1:2000	RF Common Mode requirements
IEC 61000-4-8 : 1993/ A1:2000	Power Frequency Magnetic Field requirements

IEC 61000-4-11 : 1994/
A1:2000

Voltage Interruptions and Voltage Dips requirements

73/23/EEC-Low Voltage Directive

EN 60950 1992
+A1+A2+A3+A4+A11

Safety for information technology equipment including
electrical business equipment

The following manufacturer/importer is responsible for this declaration:

Company Name:

Company Address:

Person responsible for making this declaration:

Name:

Position:

Place

Date:

Chapter 1 : Introduction


Welcome

The state-of-the-art computer possesses the abilities of high powerful data computing and advanced 2/3D graphics acceleration. Also, it supports a variety of expansible function for upgrading CPU, expanding memory and so on.



To Open this System

Slide the locking latch on the front edge of the notebook to the right and lift the screen up to a comfortable viewing angle.




Taking a look at this Notebook

This section describes the function of the notebook.

Note : Depending on the model of you purchased, the appearance of the notebook may not exactly the same as those shown in this manual.

Front View



1. LCD screen
2. Power indicators
Indicating the power status of this computer. (P.6)
3. Internal microphone (P.10)
4. Power button
To turn the computer ON or OFF
5. Keyboard (P.6)
6. Touchpad (P.7)
7. Left speaker (P.10)
8. Status indicators
Indicating the operation status of this computer. (P.8)
9. Quik-Acess button


To quick launch the default or specified applications. (P.8)

10. Scroll button

To roll up or roll down the contents of windows. (P.7)

11. Right Speaker (P.10)

Left View




1. Floppy driver

To load 1.44MB floppy disks for reading or writing data.

Note : Depending on exact model type you purchased, there may is not a attached floppy driver.

Right View



1. Optical CD-ROM/DVD-ROM/CD-RW/COMBO (P.8)

Note : Exact configuration depends on your purchase.

2. PC Card Slot

To load pc cards for expanded functions. (P.28)

3. IR Port

To communicate with IrDA-Compliant devices. (P.29)

4. IEEE 1394 Port

To connect 1394 devices. (P.30)

5. SPDIF Port

To connect SPDIF devices. (P.10)

6. External Microphone port


To connect an external microphone. (P.10)

7. External Audio Port

To connect external audio devices, e.g. headphone, speaker, and etc. (P.10)

Note : *Certain model may not support PC Card Slot, IR Port and SPDIF Port.*

Rear View



1. Security Lock (Kensington lock)

An anchor point for the locking mechanism on standard notebook security cables. (P.9)

2. PS/2 Port

To connect external PS/2 devices, e.g. PS/2 mouse. (P.31)

3. Parallel Port

To connect the parallel devices, e.g. printers. (P.31)

4. USB Port

To connect the USB devices. (P.31)

5. LAN Port

To connect LAN by RJ-45 LAN wire. (P.11)

6. Communication Port

To used Modem for telecommunication by RJ-11 phone line. (P.11)

7. TV-OUT Port

To transit display data to TV by S-Video TV cable. (P.31)

8. External CRT Port

To present display data to external display devices. (P.32)

9. Airflow vent holes

Note : *Please keep the vent holes well aired to prevent overheating of the notebook.*

10. DC-IN Port

To connect the AC adapter. (P.15)

Chapter 2 : Operating The Notebook

This chapter describes some of the built-in hardware and provides information about the use of the notebook.

About Power Indicators




The two power indicators are located on the down edge of both side display panel.






Left-side Indicators (Power)		Right-side Indicators (Battery)	
Steady	System is ON	Steady	Battery is fully charged
Flashing	System is suspended	Flashing	Battery is charging

About the Keyboard

The exact layout of your keyboard depends on the language/system you're using. Displayed here is a standard US/Windows keyboard.

The table below shows the meaning of the function key icon, and other embedded keyboard icons :


Keystrokes	Icon	Description
FN + F2		Serves as the sleep button that you can define with Windows "Power Management". (See the "Using Power Management" in this Chapter)
FN + F6		This key combination turns off the built-in speakers, and any speakers that are connected to the speaker sound port.
FN + F7		This key combination increases the volume of the speakers, and any speakers attached to the sound port.

FN + F8		This key combination decreases the volume of the speakers, and any speakers attached to the sound port.
FN + F9		This key combination increases the brightness of the built-in screen.
FN + F10		This key combination decreases the brightness of the built-in screen.
		This key activates the Start button Windows Task Bar.
		This key opens the pull down menu of a selected icon or object. Its action is the same as right-clicking an icon or object with a mouse or Touchpad.

Using the Touch pad

The touch pad acts exactly like a roller mouse. You can move your fingertip across the pad's surface to control the cursor. The left and right buttons act exactly like a mouse's left and right buttons. The up and down button can scroll a window's contents up and down.

You can use the Windows Mouse Control Panel to configure the touch pad.



About the Status Indicators



The five status indicators, from left to right, are: Mail, Hard Disk, Num Lock, Caps Lock and Scroll Lock.

Using Quick-Access Buttons



You can quick launch as many as four applications using quick-access buttons. The first two are your system's default browser and E-mail client. The rest of them (P1 and P2) are two user-defined applications. You can define the applications using the supplied Control Panels.

Using the Optical Drive

The optical drive uses removable 5.25-inch silver discs, which installed in the right side of the notebook. Depending on the model, your drive is one of the following:

1. CD-ROM drive can read data CDs, audio CDs, CD-R and CD-RW discs.
2. DVD-ROM can read DVD discs in addition to the above discs.
3. CD-RW drive can write to CD-R and CD-RW discs in addition to CD-ROM function.
4. COMBO drive can work both as a DVD-ROM drive and CD-RW drive.

Inserting and removing a CD

Please follow the following procedure to insert or remove a CD.

1. Turn on the computer.
2. Press the eject button on the front of the drive. When the disc tray opens, carefully pull it all the way out of the drive.
3. Place the CD in the drive tray with the label side up. Press the disc down carefully so that the central spindle on the CD tray inserts into the hole in the center of the CD.

To removably insert a CD, hold the CD by its outer edge and lift it up from the tray

4. Gently push the tray back into the drive.

About a Security Lock

This is a strong flexible cable that has a lock at one end and a loop at the other. You can loop the cable around an immovable fixture, and then lock the other end of the cable into your notebook.

Your notebook has an anchor point for the locking mechanism on standard notebook security cables. It is located on the rear side of the notebook.

Using the Video Features

The flat-panel screen is a large, color liquid crystal display (LCD) panel. The screen uses a technology called TFT (Thin Film Transistor) that provides a very high contrast display. You can adjust the brightness of the display by using the video hot keys.

Settings

Left-click on the settings tab to display the basic display settings of your notebook display. Here you can set the color depth and screen resolution. The Advanced Properties button allows access to the video graphics software driver, 3D settings (SiS 650 chipset), monitor settings, color management, display modes and performance.

Setting the External Monitor & Television

This computer supports Single, Mirror and Multi-monitor three display modes that provide the user to setting their displays device such as external monitor or television.

Single Mode: This mode only provides display in internal LCD or external monitor or television.

Mirror Mode: This mode provides the external monitor or television displays the same contents as the internal LCD.

Multi-Monitor Mode: This mode provides the desktop expansion function. You can expand you're the desktop to another display device.

You can use the Advanced Properties in the Display Properties to configure your display modes. Beside, before changing the display modes please disable the auto detects function first.

Using the Audio Features

The sound system includes the built-in microphone and speakers, the audio circuitry, the sound ports, and the audio software. When a sound file is playing, you can use the audio function keys to turn the speakers on or off, or adjust the volume of the speakers.

Note: *The audio volume function keys only affect the audio file currently playing. If you want to change the notebook's default sound volume, use the Windows audio utilities.*

Sound Ports

Use the microphone jack to connect an external microphone to the notebook. Use the speaker jack to output the notebook's sound to external loudspeakers, headphones or other audio device. When the jack is used, the built-in speakers are disabled.

SPDIF Ports

This computer has one SPDIF (Sony & Phillip Digital Interface) port on the right of the notebook. It can output sound from the computer by digital mode and provides high quality of sound effect. You can directly

connect SPDIF devices to this computer y SPDIF Port.

Using the Communication Features

Using the LAN

The internal 10/100 Base-T Ethernet LAN modules allows you to connect your notebook to the network. It supports data transfer rata 10 and 100Mbps.The Ethernet jack is a standard RJ 45 jack. You can attach a standard RJ 45 connector into this jack to connect your network environment.

Using the Modem

The internal 56K fax/data modem can be an invaluable tool when you take your notebook on the road. With appropriate software installed, you can make a remote connection to your office computer or Local Area Network. Using the Internet, you can send and receive E-mail, and use the World Wide Web to gather data and resources. The Modem jack is a standard RJ-11 jack. You can use a modem cable to connect the notebook to a wall telephone outlet. Or you can disconnect the cable from a telephone, and connect it to your notebook temporarily.

Using the Battery Pack

The battery pack contains Lithium-Ion (Li-ION) that can be installed in the right device bay.

Caution: Only use the battery pack that is supplied with this notebook. If you need a replacement battery, ask your system vendor for a replacement. Never try to use a battery pack that is not designed and approved for use in this notebook.

Notice: Since batteries are consumables, the warranty will be ensured within six months while you purchased.

To Change the Battery Pack

To change the battery, shut down the system, and turn your computer over. Unlock and remove your battery, replace it with a charged battery.

Battery Charging

When the battery pack is installed in the right device bay and the computer is connected to a power supply with the AC adapter, the battery pack automatically gets charged.

You can check on the charging status of the battery using the right side power indicator, located on the front edge of the keyboard area.

Battery Discharging

When your notebook is turned on and not connected to a power supply, it will operate by discharging the battery. Battery life is reduced if your notebook is consuming a lot of energy; for example playing sound files and frequently accessing disk drives. Battery life will also be reduced if your battery is not in good condition.

Battery Low Warnings

Your notebook will alert you to a low battery condition by emitting a continuous beeping sound. This warning happens when the battery has only 10% of total charge remaining.

If you continue using your computer after the battery low warning, the notebook will continue to operate normally until the charge level drops to around 5% of total charge. At this point, without warning, the notebook will automatically save to disk and turn off the system.

Using Power Management

This notebook supports APM (Advanced Power Management) and ACPI (Advanced Configuration and Power Interface) for power management. When you are running your notebook from the internal battery, it is important that you use the power management routines to

reduce the system power consumption. They routines consist of a series of power saving modes; suspend to RAM mode, and suspend to Disk mode.

Suspend to RAM

In a Suspend-to-RAM, the contents of your computer's memory are held intact, while practically all the rest of the components in your notebook turn off completely, or reduce power consumption to a minimum. In a Suspend-to-RAM, your computer remains active but with the minimum possible power consumption. You can return the computer to full power by pressing [Fn] + [F2]. If you are operating your notebook on battery power, a fully charged battery can maintain a Suspend-to-RAM for many hours.

Suspend to Disk

Suspend-to-Disk is really another way of turning off your computer. When you suspend to disk, the contents of your computer's memory are copied to your hard disk drive as a file. When the contents of the memory have been safely stored to disk, your computer turns off. The next time the computer is turned on after a Suspend to disk, the file on the hard disk is quickly read back into memory. In just a few moments, your computer appears exactly as it was when you last suspended to disk.

Suspend to disk is very useful for Windows users who like to have many different programs open on the Windows desktop. You can take quite a few minutes to get a busy Windows desktop up and running, and then you have to shut down each program one by one when you want to turn off your computer.

Initiating Standby or Hibernation Mode

This notebook computer does not support standby or hibernation mode automatically. But you can follow the following procedure initiating

standby or hibernation mode.

The following is power management setting under windows Operating System environment:


1. Click "Start", then "Settings", then "Control Panel".
2. Start the "Power Management" item.
3. Select the "Hibernate" page, select "Enable hibernate support" "click "Apply" button.
4. Select the "Advanced" page, see the power button area and select lids, power button or sleep button to Standby (if you want to press "Fn+F2" then enter Suspend to RAM, please select "Standby" in sleep button, but if you want to press "Fn+F2" then enter Suspend to, Disk please select "Hibernate" in sleep button), then press "OK" button.

Chapter 3 : Getting Start

Connecting Power to the System

This notebook computer runs on its rechargeable battery. You can also plug its AC adapter into a wall socket for continuous high-performance operation or battery recharge.

Warning : It is particularly important that you use only the AC adapter supplied from your dealer in order to avoid damaging your notebook computer.



To use the AC adapter, plug it into a wall socket, plug its DC cable into your notebook's DC jack. This notebook computer's AC adapter has a voltage sensor that accepts different countries' voltages without manual adjustment.

1. Plug the power cord into a regular AC power supply outlet.
2. The power indicator on the AC adapter will turn on to show that it is connected to AC power.
3. Plug the direct current cable from the AC adapter into the DC-IN port on left side of the notebook.
4. The right side indicator on the front edge of the notebook will begin flashing with a green light. This indicates that the AC adapter has begun charging the internal battery.

Note: It is particularly important that you give your battery a full charge the first time that you use it. We recommend that you leave the system connected to the AC adapter until the battery is fully charged. The right indicator LED on the front edge of the notebook will stop flashing when the notebook is fully charged.

Using this Computer

After hardware setup, your notebook computer is ready for service.

***Note:** Typically your computer comes with a copy of pre-installed OEM version of Microsoft Windows. Depending on your system's configuration and use, your operating system could be Windows ME (Millennium Edition) or others version of Windows that's most suitable to your needs. Different versions of Windows may have slightly different interfaces and functions.*

If the Windows operating system is partially installed on your system, the installation is completed when you turn on the computer for the first time. At that point, Windows will run a setup program which gathers important information about you and your computer preferences, so that Windows operates the way you want it to. Throughout the setup procedure, Windows will present dialog boxes on the screen. When you have read the dialog box and wish to proceed with the installation, use the Touch pad to point to the Next button and then click it.

1. Turn on your notebook by pressing the power button.
2. When Windows starts, you may see a Safe Recovery message.
This means that the notebook has been turned on at least once

since the partial installation of Windows, and Windows has registered the fact that the final installation was not completed at that time. You can ignore the safe recovery message and proceed.

3. The setup program will ask for the language and layout of your keyboard. Select the appropriate items from the list provided and proceed.
4. Setup will then ask for your name, and company name if applicable. Enter the information and proceed.
5. Setup will then display the Windows license agreement. This document details the terms and condition under which you are licensed to use the Windows software. You must read it over and then click on the "I accept the agreement" check box in order to proceed.
6. Setup will then ask you to type in the registration number on the Certificate of Authenticity (COA). The COA is generally pasted on the front cover of the Windows manual that is shipped with this system.
7. Setup will then begin to configure your computer. After a while, you will be asked to restart the computer.
8. When the notebook has restarted, setup will ask you to select a printer for your system. You can select a printer at this time, or leave it till later if you prefer.
9. Setup will then display a Time Zone window. Select the correct time zone for you location, and reset the time and date.
10. At the end of the setup session, a backup utility appears which allows you to make backup diskettes of the Windows operating system. This requires two or more boxes of diskettes. If you have a Windows CD-ROM, or Windows diskettes, you can

ignore this procedure, or delay it to a later time.

You can learn a lot about your computer by using the windows My Computer utility, located on you desktop. If you click on the icon, it will show a graphical representation of the media devices on your system.

Note : *The above installation procedure only for reference, because different OS (Operating System) has different installation procedure.*

System Setup and Installation

Note: *This section describes a typical procedure for rebuilding a hard disk drive. You may not need to carry out every step on your own hard disk. Read all the README files that ship with the support software. They may contain important information that is not included here.*

1. Place a Windows boot diskette in the floppy diskette drive and turn on your system.
2. If you are creating new partitions on the drive, use the Windows FDISK program to create the partitions.
3. Use the Windows FORMAT program to format the new partitions.
4. After format the new partition, install your Windows CD in the optical device. The Windows installation should begin automatically. If it doesn't begin automatically, run the SETUP program on the disk.
5. Follow the instructions to install Windows.
6. After a successful Windows installation, place the utility software CD in the optical device and start installing the drivers and utilities that you need for the system. Depending on the configuration of your notebook, you may not need to install all the software on the

utility CD.

7. The software is installed in separate folders, and there may be sub-folders which contain different language versions, or different versions for different operating systems such as Win XP, Win 2000, Win ME, Win 98SE and so on. The names of the folder will indicate what they contain.
8. Look for a README file inside the folder of the software that you are about to install. It may contain special installation instructions, or updated information that is not included in this section.
9. Look for the installation program and run it. This program is usually called SETUP or INSTALL. Follow the instructions on the screen to install the drivers and/or utilities.
10. You will probably need to install the following software from utility CD:

Video: SIS/VGA

Audio: SIS/Audio

LAN: SIS/LAN

MDC: MDC(MODEM)

Quick Button : Utility/Qbutton/QB

Touchpad: Driver/TouchPad/


Chapter 4: Configuring the Notebook

System Configuration Utility

The System Configuration Utility (SCU) lets you use the firmware installed on the notebook to configure your system according to the kind of hardware that you install. Using setup, you can define drive specifications, control power management, and so on.

Using the System Configuration Utility

You can only display the setup utility by pressing the F2 key combination shortly after the system is turned on. A prompt appears on the screen that reads *"F2 to enter System Configuration Utility"*. When you see this prompt, press the key combination and the setup utility will display the main page of the System Configuration Utility program.



Navigating

The main screen of the utility program is divided into three major sections.

The top section holds a menu bar.

The middle section shows three windows, i.e. *Devices*, *System* and *Memory*. These windows provide a quick overview of the current setup settings of your system. Some values are detected automatically while other values are set to a default value and can be changed through the menu bar at the top of the screen.

The third section, at the bottom of the screen, displays hints messages relevant to the topic highlighted at the moment.

[Alt]: Press the Alt key to activate menus.

Cursor arrow keys: Lets you move and highlight through the header list of setup windows.

[Enter]: When the option you need is highlighted, press this key to select an option.

[Esc]: Cancels the current action, closes a menu, returns you to the main menu, and/or exits the System configuration Utility program.

Startup, Memory, Disks, Components, Power, and Exit, is the principal options in the main menu bar for system configuration. When you select one of these options, the screen displays a list of items in a drop down menu. Some items you can only enable or disable. Others bring up a separate dialog box once you select them.

_ Or V: Items that can only be disabled or enabled.

► :Within a dialog box you can use

[Tab] to select a control.

[OK] or **[Enter]** to confirm an entry.


[Cancel] or **[Esc]** to cancel an entry.

To change the value of a field, use the cursor keys, space bar, and/or numeric keys.

At any given point, you can use the **[Alt]** key in combination with a letter, highlighted red, and use it as a shortcut to jump directly to that function.

Startup

This option displays basic information about your system and hardware.



Date and Time

When you select this option, a dialog box will pop up allowing you to customize the date and time to be used by the system clock.

Language

This option let you choose most suitable keyboard language including English 、 German 、 Japanese.

Fast Boot

You can either enable or disable this option. If enabled you allow the system to boot fast without first testing all functions.

Boot Device

When you select this option, a dialog box will pop up allowing you to customize the order of devices the system tries to boot from consecutively. You can choose from three devices: Hard disk C, CD-ROM Drive, and Diskette A. Set the most important boot device in the 1st Boot Device box, and continue with the second and third box. The system will only move on to the alternative boot devices after a previous one failed.

Set Admin Password

When you select this option, you can set the administrator password. Once being set, the administrator password is always required for starting up to the system and entering SCU.


Set User Password

The user password is under the supervision of the administrator password. You can set the user password to be required for starting up the system and/or entering SCU when the administrator password has been set. Beside, the user password only allows you to use some limited items for setting in the SCU.

SCU Color Scheme

When you select this option, you can change the color of the SCU display.

Memory




Cache Systems

When you select this option, a dialog box will pop up allowing you to customize the system's use of Cache memory. The default setting is Write Back.

Shared Memory

When you select this option, a dialog box will pop up allowing you to change the memory size that you want to share for video memory.

Disks



Internal HDC

You can either enable or disable this option. Set this option to enable in order to use the internal hard disk drive.

IDE Settings

When you select this option, a dialog box will pop up allowing you to set the IDE HDD transfer rate.

HDD Password

When you select this option, you can set password for your Hard Disk.

Virus Alert

You can either enable or disable this option. When this option is enabled, your computer will be protected to some degree against computer viruses, which try to infect the boot sector of disks and diskettes. If you ever need to create a new partition structure on your disk drive, you might need to set this option to disabled.

Components

Use the components item on the menu bar to configure some of the peripheral devices found in your notebook.

Components

COM Port
LPT Port
TV Status: PAL
Legacy USB
Keyboard Numlock
Keyboard Repeat

COM Port

When you select this option, a dialog box will pop up allowing you to enable/disable and to modify the settings of the different serial (COM) ports.

LPT Port

When you select this option, a dialog box will pop up allowing you to customize the parallel port located on the rear of the notebook.

TV Status: PAL

You can either enable or disable this option. If enable your TV output mode is PAL, else is NTSC.

Legacy USB

You can either enable or disable the system's support for the USB port in DOS mode. This item includes USB Keyboard and USB Floppy . The default setting is enabled.

Keyboard Numlock

You can either enable or disable this option. If enabled the keyboard Numlock function will always be on by default when you start your system.


Keyboard Repeat

When you select this option, a dialog box will pop up allowing you to customize the keyboard auto repeat rate and repeat delay. These

options set the reaction speed of your keyboard to your typing.

Power

Use the power item on the menu bar to define the progressive power reduction of your computer when it is not being used.



Enable Power Saving

You can either enable or disable this option, which acts like a master switch for all the other power down functions on this menu. If you disable this field, none of the other system powerdowns in the setup program will function and will thus be grayed out. If it is enabled, you are able to set more specific power saving functions through the other options on the menu.


Suspend Controls

When you select this item, a dialog box will pop up allowing you to manually customize some Suspend controls.

Exit

When you have made changes to the setup utility, either press the [Esc] key, or highlight the Exit option on the menu bar.

Exit



Save and Exit

When you select this item, a dialog box will pop up asking you to confirm your choice to save the changes you just made and restart the computer. This dialog box will also appear if you press the [Esc] key in the main screen area of the system configuration utility.

Exit (No Save)

When you select this option, a dialog box will pop up asking you to confirm your choice to discard any changes you just made and restart the computer. The computer will then restart using the old values.

Default Settings

When you select this option, a dialog box will pop up asking you to confirm your choice to load the default values for all fields. The computer does not restart. You must use the Save and Exit option above to restart the computer using the default values.

Restore Settings

When you select this option, a dialog box will pop up asking you to confirm your choice to restore the current setup values to the original custom values. The computer does not restart. You must use the Save and Exit option above to restart the computer using the default values.

Chapter 5: Expanding The Notebook

This chapter delivers the information about expanding your notebook computer by connecting other peripheral devices.

Using PC Cards

This computer is installed with one PC card slot on the right side of the notebook. PC Cards are credit card-sized peripheral products based on the standards developed by PCMCIA (Personal Computer Memory Card International Association) such as a modem card, a network card A flash memory card, SCSI card and so on.

PC Card Type

This computer's PC Card slot allows uses a type II card.


CardBus Support

This computer's PC Card slot supports CardBus specification. CardBus is the 32-bit extension of the original 16-bit PC Card specification. CardBus cards provide higher performance.

Inserting and Removing a PC Card

You can install or change PC cards while your notebook is turned on.

Note : *Some PC Cards require additional system resources. Before using this PC Card, you must to free other system resource for the PC Card.*




1. Orient the card correctly. The label side of the card faces up. One of the narrow edges has a double row of pinholes. This edge inserts

into the slot.

2. Insert the card into the slot. The slot had protected by cover. The covers will fold out of the way when you insert the card. When the card is nearly all the way inserted, press quite firmly to ensure that the card mates properly with the connector inside the slot.
3. Your notebook will emit two beeps (in rising tones) to let you know that the card has been recognized by the system. If Windows has the appropriate drivers to use the card; they will be loaded automatically. For some cards, you may have to install drivers or software, supplied by the card manufacturer.
4. Before ejecting a CardBus card, it is important that you tell Windows to stop using the card. Click on the card icon on the right side of the Windows task bar. When the stop button appears, click on it. Windows will display a message that the card can now be safely removed.
5. When you insert a card, the card eject button will be forced outward from the edge of the case. To eject a card from the slot, press the eject button back into the notebook. The card will disconnect from the internal connector and you can remove it from the slot. The notebook will emit two beeps (in falling tones) to let you know that the card has ejected.

Using Infrared Port

The infrared transmitter and receiver are located on the right side of the computer. To communicate two devices using the infrared port, you have to let their infrared ports face each other and place them as near as possible.



Establishing an Infrared Connection

1. Make sure that your infrared port is set to the same protocol as the target infrared device. You can change protocol with the System Configuration Utility (SCU) under Components/Com Ports. Supported protocols are Normal (16550), IrDA (HPSIR), ASK IR, FAST IR.
2. Place your notebook so that the infrared port is directly facing the infrared port of the target device. If the angle between the ports exceeds about 15 degrees in any direction, you might fail to establish communication. The infrared ports should be no more than 1 meter (38 inches) apart or you might fail to establish communication.
3. If you have utility software that supports infrared communication, such as TranXit or IntelliSync, use the software to make the infrared link, and follow the software's instructions.
4. If you don't have infrared software, use the infrared software included with the Windows operating system.

Connecting an IEEE 1394 Device

This computer has one IEEE 1394 port on the right side of the notebook for IEEE 1394 device.

IEEE 1394 has high-speed data transfer, multi-channel communication link and "Hot Plug" connectivity. The IEEE 1394 device includes scanner, printer, DVCAM, VCR and so on.

To connect the IEEE 1394 device, simply plug the device cable into the IEEE 1394 port of the notebook.

Connecting a PS/2 Device

The PS/2 port located on the rear of the computer that allows you connect an external keyboard to your system, such as a full size AT-enhanced keyboard, or an external pointing device to your system, such as a mouse or a Trackball. The PS/2 device must have a mini-DIN PS/2 connector.

Connecting a Parallel Device

The 25-pin parallel port is usually used to connect your notebook to a parallel device such as a printer or a plotter. When you add a printer to your system, you usually need to load a driver for the printer from the original Windows CD or diskettes. The Printer icon in the Control Panel has an Add New Printer icon to help you install a printer. The parallel port identified by your notebook as LPT1.

Connecting a USB Device

This computer has two USB (Universal Serial Bus) ports for connecting USB devices such as mouse, keyboard, camera, scanner and so on. It supports "Plug and Play" technology so you can install and remove USB devices without turning off the computer.

Connecting a TV

This computer has one S-Video jack on the rear side of the computer for connecting a TV. You need a video cable for connection. You can attach a video cable into this S-Video jack to connect your notebook to a TV.

Connecting an External Monitor

This computer supports one 15-pin external monitor port on the rear of the computer for external display device.

IF you want to use a larger screen display screen with higher resolution, you can attach a video cable into this port to connect your notebook to a external CRT monitor or LCD monitor.

Internal Components Upgrade

Here is a list of upgrading options that are not user-serviceable:

1. Processor
2. Optical drive
3. Mini PCI bus (For wireless LAN card only)
4. DDR Memory
5. Internal hard disk

Caution: *We recommend that you contact your dealer and ask them to install any additional components. Installing these components by yourself may cause damage to your system.*