

# Index

---

## —A—

- Altitude and temperature, 3-9
- Antenna
  - Installing, 4-29, 4-30, 4-33
  - Patch, 3-14
  - Receive, 3-13, 8-19
  - Replacing, 13-3, 13-4
  - Transmit, 3-13
- Application configuration
  - Add defaults screen, 8-10
  - Currency display, 8-15
  - EPL display, 8-13
  - Field descriptions, 8-9, 8-10, 8-13, 8-16
  - Parameter screen, 8-8
- Automated messaging system
  - Customizing, D-12
  - Syntax, D-12
  - Time interval, D-12

## —B—

- Backup copies, 5-3
- Base hardware configuration, 8-17
- basesw.cfg file (NT), C-2
- basesw.cfg file (UNIX), C-23
- Battery replacement, 13-6
- Bedcheck, 12-27

## —C—

- Cables
  - Cable extension illustrations, 4-11
  - Cable usage table, 4-9
  - Connecting secondary CBSs, 4-27
  - Converter to primary CBS, 4-28
  - Converter to secondary CBS, 4-28
  - General layout instructions, 4-4
  - Pin out charts and illustrations, B-1
- CBS
  - Address configuration, 8-18
  - Characteristics, 3-10
  - Communication speed, 4-15
  - Configuring communication port, 8-5
  - Connector locations, 4-7
  - Diagnostics and troubleshooting, 12-1
  - DIP switch diagnostics, 12-6
  - Enabled/disabled, 8-19
  - ID, 4-15
  - Initiating diagnostics, 12-2
  - Installing, 4-12, 4-16
  - LEDs used for diagnostics, 12-5
  - Level 0 diagnostics, 12-3
  - Level 1 diagnostics, 12-6
  - Master address configuration, 8-18
  - Model number and codes, A-1
  - Replacing, 13-2
  - Self-diagnostics, 12-3
  - Setting the address, 4-13
  - Switch settings for diagnostics, 12-2

- System cable connections, 4-6
- Type 1 (lab) installation, 4-18
- Type 2 (store) installation, 4-23
- Using tally read information, 12-14
- cbsparam.tbl file (UNIX), C-34
- Chapter summaries, 1-2
- Characteristics
  - CBS, 3-10
  - Patch antenna, 3-14
  - Power supply, 3-12
  - Receive antenna, 3-13
  - SmarTalker IIs, 3-17
  - SmarTalkers, 3-15
  - Transmit antenna, 3-13
  - Weight and dimensions table, 3-20
- Communication speed, 4-15
- Configuration files (NT)
  - Application (esappl.cfg), C-9
  - Base software (basesw.cfg), C-2
  - EPL backup (eplbackup.ini), C-20
  - EPL status tag manager (status.cfg), C-21
  - Log monitor (logmon.cfg), C-15
  - Measurement units table (esmeasur.tbl), C-13
  - Overview, C-1
  - Serial Number Configuration (eplserial.cfg), C-14
- Configuration files (UNIX)
  - Application (esappl.cfg), C-30
  - Base software (basesw.cfg), C-23
  - CBS parameter file (cbsparam.tbl), C-34
  - EPL backup (eplbackup.ini), C-40
  - EPL status tag manager (status.cfg), C-41
  - Log monitor (logmon.cfg), C-35

- Measurement units (esmeasur.tbl), C-34
- Overview, C-1
- Configuring
  - Base hardware, 8-17
  - CBS address, 8-18
  - Master CBS address, 8-18
  - Number of power supplies
  - Receive antenna, 8-19
  - Windows NT services, 8-24
- Converter, 4-20, 4-25
- Customer responsibilities, 3-2

### —D—

- DecisioNet run as a service
  - Automatic start, 8-25
  - Manual start, 8-26
- DecisioNet run as an application
  - Manual start, 8-26
- DecisioNet software, 2-5
- DecisioNet system
  - Customizing, D-1
- Diagnostics
  - Diagnostic logs, 12-16
  - EPL audit log, 12-20
  - EPL data send log, 12-18
  - EPL system error log, 12-17
  - Level 0, 12-3
  - Level 1, 12-6
  - Level 3, 12-7
  - Using tally read information, 12-14
- DIP switch, 4-13
- DIP switch settings, 4-14

### —E—

- Electrical requirements, 3-3

Environmental requirements, 3-6  
   Altitude and temperature, 3-9  
   Health and safety, 3-9  
   Temperature and humidity, 3-6  
 EPL administration  
   Diagnostics, 12-7  
   Starting, 8-7  
 EPL application  
   Base hardware configuration, 8-17  
   Label data maintenance, 8-20  
 EPL audit log, 12-20  
 EPL backup file  
   Backup file list, D-28  
   Customizing, D-27  
   List location (NT), D-28  
   List location (UNIX), D-29  
   Starting at DOS or UNIX prompt, D-27  
 EPL data resend, 9-14  
 EPL data send log, 12-18  
   Viewing, 9-11  
 EPL maintenance  
   Loading pre-EPL file, 9-7  
 EPL removal tool, 10-6  
 EPL system error log, 12-17  
 eplbackup.ini file (NT), C-20  
 eplbackup.ini file (UNIX), C-40  
 eplserial.cfg file (NT), C-14  
 esappl.cfg file (NT), C-9  
 esappl.cfg file (UNIX), C-30  
 esmeasur.tbl file (NT), C-13  
 esmeasur.tbl file (UNIX), C-34  
 External data interface  
   Customizing, D-10  
   Syntax, D-11  
   Time interval, D-10

## —F—

Failure detection and analysis (FDA)  
   Customizing, D-30  
   Error types, 12-21  
   Run from EPL administration, 12-26  
   Run from system prompt, 12-23  
   Syntax, D-31  
   Time interval, D-30  
   Using, 12-21

## —G—

Grounding requirements, 3-4

## —H—

Hardware infrastructure, 2-5  
 Hardware installation, 4-1  
 Health and safety, 3-9

## —I—

Initializing SmarTalkers, 9-1  
 Installation  
   Antennas, 4-29  
   CBS, 4-12  
   Hardware, 4-1  
   Key points to remember, 4-3  
   NCR UNIX software, 6-3  
   Patch antenna, 4-33  
   Power supply, 4-21  
   Power supply to primary CBS, 4-26  
   Power supply to secondary CBS, 4-27  
   Process overview, 2-1  
   RS-232/RS-422 Converter, 4-20, 4-25  
   SCO UNIX software, 7-2  
   Transmit and receive antennas, 4-30  
   Windows NT software, 5-3

Installation tasks, 2-7

—K—

Kit numbers, A-3

—L—

Label data maintenance, 8-20

Label data manager

- All files type parameter, 8-22
- Change files type parameter, 8-22
- Configuration file parameters, D-5
- Customizing, D-4
- Customizing prescript and postscript files, D-6
- Date files type parameter, 8-23
- Granularity and records number, D-4
- Granularity parameter, 8-23
- Measure parameter, 8-21, D-4
- Number of records parameter, 8-23
- Package size parameter, 8-22
- PLU number parameter, D-4
- PLU number parameter, 8-21
- Price level parameter, 8-21, D-4
- Print file layout, D-6
- Quick files type parameter, 8-22
- Select files type parameter, 8-23
- Serial number parameter, 8-21, D-4
- Unit of measure parameter, 8-21, D-4

Level 0 diagnostics, 12-3

Level 1 diagnostics, 12-6

Level 3 diagnostics, 12-7

Licensed Product Identification Numbers (LPINs)

- NCR UNIX, 6-2
- SCO UNIX, 7-2
- Windows NT, 5-2

Log monitor

- basesw.cfg file options, D-21
  - Customizing, D-18
  - Customizing configuration file, D-24
  - Editor, D-21
  - Report, D-18
  - Syntax, D-22
  - Time interval, D-22
  - User-defined actions, D-21
- logmon.cfg file (NT), C-15
- logmon.cfg file (UNIX), C-35
- LPINs
- NCR UNIX, 6-2
  - SCO UNIX, 7-2
  - Windows NT, 5-2

—M—

Maintenance, 13-1

Mounting devices, 2-4

—N—

NCR UNIX

- Check for existing packages, 6-2
- Configuring the system, 8-7
- Disabling UNIX port monitoring, 6-3
- LPINs, 6-2
- Software installation, 6-3
- Starting the system, 8-6
- System environment, 6-1

—O—

Orphan tag report

- Customizing, D-25
  - Syntax, D-25
- Overlays, 2-3

## —P—

- Parts order information, A-1
- Passwords
  - Changing, 8-27
  - Defaults, 8-27
  - General, 8-27
  - Security levels, 8-27
- Patch antenna, 4-29
  - Replacing, 13-3
- Power requirements, 3-3, 3-4
- Power supply
  - Characteristics, 3-12
  - Configuring, 8-18
  - Connector location, 4-8
  - Replacing, 13-5
- Pre-EPL file
  - Comma-separated example, 9-6
  - From overlay supplier, 9-5
  - Layout, 9-1
  - Loading, 9-1, 9-7
- Pre-installation procedures
  - Phase 1, 2-2
  - Phase 2, 2-3
  - Phase 3, 2-4
  - Phase 4, 2-5
  - Phase 5, 2-6
  - Phase 6, 2-6
- Price verifier
  - Customizing, D-14
  - Syntax, D-14
  - Time interval, D-14
- Promotional message verifier
  - Customizing, D-8
  - Syntax, D-9
  - Time interval, D-8

## —R—

- Receive antenna, 3-13, 4-29, 8-19
  - Replacing, 13-3
- Reference materials, 1-4
- Resending EPL data, 9-14
- Rotary switch, 4-13
- Rotary switch settings, 4-14
- RS-232/RS-422 Converter, 4-20, 4-25

## —S—

- Sale price verifier
  - Customizing, D-16
  - Syntax, D-17
  - Time interval, D-16
- SCO UNIX
  - Check for existing packages, 7-3
  - Configuring the system, 8-7
  - Copying files from install tapes, 7-3
  - LPINs, 7-2
  - Software installation, 7-2
  - Starting the system, 8-6
  - System environment, 7-1
- Scripts - start and stop, D-2
- Security levels, 8-27
- Site certification tools, 1-4
- Site preparation, 3-1
- Site scan, 2-3
- Site survey, 2-2
- SmarTalker
  - Analyzing problems, 12-28
  - Attachment to angled rails, 10-5
  - Attachment to C-channel, 10-4
  - Battery replacement, 13-6
  - Characteristics, 3-15
  - Displays and symbols, 3-15
  - Installation, 2-6

- Installation overview, 10-1
  - Installing and removing, 10-6
  - Installing clips, 10-5
  - Rail attachment, 10-1
  - Recommended tools, 10-2
  - Replacing, 13-5
  - Viewing angle, 10-1
  - SmarTalker II
    - Analyzing problems, 12-28
    - Battery replacement, 13-6
    - Characteristics, 3-17
    - Displays and symbols, 3-18
    - Installation overview, 1
    - Installing and removing, 7
    - Installing clips, 5
    - Installing rails, 4
    - Rail attachment, 2
    - Replacing, 13-5
    - Viewing angle, 2
  - SmarTalkers
    - Checking initialization, 9-11
    - Initializing, 9-1
  - Software
    - NCR UNIX, 6-2
    - SCO UNIX, 7-2
    - Windows NT, 5-2
  - Software installation
    - NCR UNIX, 6-3
    - SCO UNIX, 7-2
    - Windows NT, 5-3
  - Status tag manager
    - Configuration file parameters, D-34
    - Creating a status file, D-38
    - Customizing, D-32
    - Displaying status information, D-33
    - Modes, D-32
    - Sample status file, D-36
    - Starting, D-38
  - status.cfg file (NT), C-21
  - status.cfg file (UNIX), C-41
  - System configuration
    - Base hardware, 8-17
    - CBS Communication port, 8-5
    - Label data maintenance, 8-20
    - Set Windows NT performance boost, 8-4
  - System environment
    - Configuring after installation, 8-1
    - NCR UNIX, 6-1
    - SCO UNIX, 7-1
    - Windows NT, 5-1
- T—
- Temperature and humidity, 3-6
  - Tools and supplies, 4-2
  - Transmit antenna, 3-13, 4-29
    - Replacing, 13-4
- U—
- UNIX automatic restart, D-43
  - UNIX environment
    - How to navigate, 8-2
- V—
- Validate installation, 2-6
- W—
- Windows NT
    - Configuring services, 8-24
    - Configuring the system, 8-7
    - LPINs, 5-2
    - Set performance boost, 8-4

Software installation, 5-3  
Starting the system, 8-6

System environment, 5-1  
Windows NT automatic services, D-40



