

Making a Voice/Videophone Call

1 Dial the other party's number, starting with the area code

The "Phone number entry" screen appears.
Always start with the area code, even for calls within the same area.

Area code — Local code — Phone number

A number of up to 80 digits can be entered for making a call although the numbers disappear from the display one by one from the beginning after the number exceeds 26 digits.

2




The phone number disappears briefly and then reappears from the right as it is dialed.
The "📞" icon flashes during dialing and remains lit during a call.

The "FOMA voice in-call" screen appears.


■ To switch to a videophone call during a voice call

"Changing a call from voice to videophone" → p.3

■ If you hear the busy tone

The line is busy. Press , and call again after a while.

■ If you hear the message saying that the other party cannot be reached

The other party's mobile phone or PHS phone is not switched on or is out of signal range. Press , and call again after a while.

■ If you hear the message requesting your caller ID

The other party has set the Caller ID Request service to "Activate". Call again with your caller ID shown.

■ If you set "2in1 setting" to "Dual mode"

The outgoing number selection screen appears. Select a phone number.

3

To end the call, press 

● Making a videophone call

1

Phone number entry screen  (Vophone)

The "Videophone in-call" screen appears.
You can talk hearing the other party's voice through the speaker.
The "📞" icon flashes during dialing and remains lit during a videophone call.


■ To switch to a voice call during a videophone call

"Changing a call from videophone to voice" → p.3


■ To switch between camera image and substitute image during a videophone call

▶ Select "Substitute image" or "My side" from the function menu.

■ To mute voice to send during a videophone call (microphone mute)

▶  (1 second or longer)

"MUTE" appears while in mute. Video is transmitted as it is.

To cancel mute, press  again for 1 second or longer.

2

To end the call, press 

● If you entered a wrong phone number

■ To insert a number

Press ⏪ or ⏩ to move highlight to the number on the left of the insert position and enter the number.

■ To delete a number

Press ⏪ or ⏩ to move highlight to the number to delete and press [CLR].

Pressing [CLR] for 1 second or longer deletes the highlighted number and all numbers on the left side of the highlighted number.

■ To reenter a number

Move highlight to the beginning or end of the number and press [CLR] for 1 second or longer to return to the standby screen.

● If a videophone call is not connected

If a videophone call is not connected, a message giving the reason for the connection failure appears. However, in some circumstances, an explanatory message may not be displayed. Also, depending on the type of phone used by the other party and the possible lack of a network service subscription, the reason given may not accurately reflect the other party's actual status.

Message	Reason
Check number then redial	The dialed phone number is currently not used.
Busy*	The line is busy.
Busy with packet transmission	Packet communication is in progress on the other party.
Out of service area/power off	The other party's phone is out of service or the power is turned off.
Set caller ID to ON	The call is connected without showing your caller ID (when dialing visualnet).
Your call is being forwarded	The call is being forwarded (into a videophone call if the forwarding party has a videophone that complies with 3G-324M).
Redial using voice call	The forwarded party is non-videophone-terminal.
Please activate caller ID before dialing again	The Caller ID Request service is set on the other party.
At the user's request, your call can not be connected	The Nuisance Call Blocking service is set on the other party.
Upper limit has been exceeded Connection failed	The upper limit set for a Limit billing plan (Type Limit and Family Wide limit) is exceeded.
Connection failed	Set "Caller ID Notification" to "ON" and then try again. • This message may also be displayed in other situations.
Please make your call from the i-mode web page	You attempted to make a videophone call to watch V-live without browsing the i-mode official site.


*: This message may also appear during packet communication depending on the type of other party's terminal.

Changing a Call from FOMA Voice to Videophone

- You can only change the call mode when you are the caller. When you are a callee, you cannot change the call mode.
- You can repeatedly change the call mode between voice and videophone.

● Changing a call from voice to videophone

You can change the call mode during a voice call you dialed.

- If the other party uses a FOMA terminal that can change the call mode, " " appears during a voice call and you can change the call mode between voice and videophone. (This function is available between terminals that support change between voice call and videophone call.)

1 In-call screen "YES"

While a voice call is being changed to a videophone call, the screen showing that the call mode is being changed appears and the voice guidance is given.

Select "NO" on the "Ntfy switch-mode" message screen to return to the in-call screen.

● Changing a call from videophone to voice

The caller can change the call mode to voice during a videophone call.

- If the handset of other party is a FOMA terminal supporting the call change, "Change to voice" can be selected from the function menu during a videophone call and you can change the call mode. (This function is available between terminals that support change between voice call and videophone call.)

1 Videophone in-call screen [ch] (FUNC) "Change to voice"

While the call mode is being changed from videophone to voice, the screen showing that the call mode is being changed appears and the voice guidance is given.

<WORLD CALL>

Making International Calls

WORLD CALL is an international dialing service available for DoCoMo mobile phones.

FOMA service subscribers have also subscribed to "WORLD CALL" (excluding those who indicated that they did not require the service).


* This service is unavailable with some billing plans.

- WORLD CALL is available for calls to around 240 countries and regions worldwide.
- WORLD CALL is included in the bill for your monthly call charges.
- In addition to dialing a phone number, you can make an international call by adding "+" or selecting "Int'l call" or "Prefix numbers" from the function menu on the phone number entry, Redial/Dialed calls, Received calls or phonebook detail screen.

Changes to the international dialing procedure

Since communication from mobile devices such as mobile phones is not covered by the "MY LINE" service, this service cannot be used to access WORLD CALL. However, with the introduction of the "MY LINE" service, the procedure used to make international calls from a mobile phone has changed. Note that the conventional dialing procedure (the one described below with "010" removed) can no longer be used.

For additional information regarding WORLD CALL, refer to the contact information provided on the back cover of this manual.

"International videophone calls" can be made to users of some specific overseas 3G mobile terminals by pressing  to make a call after following the dialing procedure below.

- See the DoCoMo website for information about accessible countries and carriers.
- Depending on the type of the phone used by the other party, the other party's image shown on your FOMA terminal may be distorted during an international videophone call or the connection may fail.


Dialing to make an international call

- 1 **Dial a number in the following order: 009130 → 010 → (country code) → (area code (long distance code)) → (the other party's phone number)**

If an area code begins with a zero (0), omit the zero. However, when you call some countries or regions such as Italy, "0" may be required.




An international call is made.

- 3 **To end the call, press** 

Using "+" to make an international call

Using the "+" prefix allows you to make international calls without having to dial an IDD prefix code (e.g. 009130-010).

- "Auto int'l call set." in "Int'l dial assistance" is set to "ON" (automatically added) at the time of purchase so that a FOMA terminal automatically dials the IDD prefix code.

- 1 **On the standby screen, dial the following: + ( (1 second or longer)) → (country code) → (area code) → (other party's phone number)**

If an area code begins with a zero (0), omit the zero. However, when you call some countries or regions such as Italy, "0" may be required.



An international call is made.

- **To make a call without converting "+" into the IDD prefix code**

- ▶ "Original phone No."

- * This function is unavailable for your FOMA terminal.

- **To cancel a call**

- ▶ "Cancel"

Making an international call with international call codes added <Int'l call>

Add a country code or IDD prefix code to a phone number to make an international call.

- This function is available on the phone number entry screen and the detail screens of phonebook, Received calls, Dialed calls and Redial.

<Example: To use the Int'l call function on the phone number entry screen>

- 1 **Enter the other party's phone number**


- 2 **[ch] (FUNC) ▶ "Int'l call" ▶ Select a country code ▶ Select an international access name (IDD prefix code)**

The selected country code and IDD prefix code are added. If an area code begins with a zero (0), the zero is automatically deleted. If "イタリア" (Italy) is selected for the country code, the zero is not deleted.



● Converting “+” automatically

Set this function to add “+” automatically when making international calls.

- 1  ▶ "SETTINGS" ▶ "Dialing" ▶ "Int'l dial assistance" ▶ "Country Code setting"
- 2 Select a country code ▶ Select an IDD prefix code



● Editing a country code

See the DoCoMo website for more information about country codes.

- 1  ▶ "SETTINGS" ▶ "Dialing" ▶ "Int'l dial assistance" ▶ "Country Code setting"
The "Country Code set" screen appears.
- 2 Highlight an item and press  (Edit)
- 3 Enter a country name ▶ Enter a country code

● Storing an IDD prefix code

You can store up to 3 IDD prefix codes, each of 10 digits max.





- 1  ▶ "SETTINGS" ▶ "Dialing" ▶ "Int'l dial assistance" ▶ "IDD Prefix setting"
- 2 Highlight “<Not recorded>” and press  (Edit)
 - To edit a stored item
 - ▶ Highlight an item to edit and press  (Edit)
- 3 Enter an international access name
- 4 Enter the IDD prefix code

Using the Redial/Received Calls Record




● Dialing a previously dialed number <Redial/Dialed calls>

Information such as a phone number, date and time you called is recorded as the Redial/Dialed calls record.

- The Redial record can hold up to 30 phone numbers for voice call, videophone call and PushTalk call entries. The Dialed calls record can hold up to 30 voice call, videophone call and PushTalk call entries and up to 30 packet communication and 64K data communication entries.
- If you have dialed to the same phone number twice or more, only the latest call is logged in the Redial record while all the calls are logged in the Dialed calls record.
- When the number of Redial/Dialed calls record entries exceeds the maximum, existing entries are overwritten starting with the oldest one.
- You cannot view the Redial/Dialed calls record during a videophone call.










- 1 On the standby screen ▶ 
- 2 Select a Redial/Dialed calls record entry to check
- 3  or 
- 4 To end the call, press 

Receiving a Voice/Videophone Call

- 1 When a call arrives, press  or 
When a call arrives, a FOMA terminal rings, the incoming call lamp flashes and the "Ringing" screen appears. Unless "FOMaPhone" under "Vibrator" is set to "OFF", the FOMA terminal also vibrates to notify you of the call.
- 2 To end the call, press 

● Receiving a videophone call

Use this procedure to receive an incoming videophone call. If you cannot answer a videophone call with your camera image, you can receive the call showing the caller a substitute image instead of your camera image.

- 1 When a videophone call arrives, press  () or 
The "videophone in-call" screen (p.1) appears.
You can talk hearing the other party's voice through the speaker.
 - To switch between the camera and alternative images during a videophone call
 - ▶ Select "Substitute image" or "My side" from the function menu.
 - To send the rear camera image during a videophone call
 - ▶ 
During a videophone call, you can switch between the front and rear cameras (CHG camera-mode) by pressing .
 - To mute voice to be sent during a videophone call (microphone mute)
 - ▶  (1 second or longer)
 appears while in mute. Video is transmitted as it is.
To cancel mute, press  again for 1 second or longer.
- 2 To end the call, press 

Changing a Call Between Voice and Videophone (the Other Party)

The mode of a call you have received can be changed by the caller (the other party).

- You can only change the call mode when you are a caller. When you have received a call, you cannot change the call mode. (This function is available between terminals that support change between voice call and videophone call.)
- To enable a caller to change the call mode, "Ntly switch-mode" must be set to "Indication ON" on the caller's phone beforehand.

● Changing a call from voice to videophone (the other party)

1 In-call screen ▶ The other party changes the call mode ▶ "YES"

While the call mode is being changed from voice to videophone, the screen showing that the call mode is being changed appears and the voice guidance is given.

The call mode is changed to videophone and a camera image is sent to the caller.

■ To send a substitute image to the caller

▶ "NO"

The specified substitute image is sent to the caller.

<Answer setting>
































MENU58

Using a Dial Key to Receive Calls

Default setting
Any key answer

This setting enables you to quickly turn off a ring tone or answer the call when you receive a voice, videophone or PushTalk call. This is useful when you receive a call in a place where a ring tone may disturb people around you.

1 ▶ "SETTINGS" ▶ "Incoming call" ▶ "Answer setting" ▶ Select any item

Any key answer	Press one of the following keys to answer a call: Voice call:  ,  , [0] to [9], [X], [CLR],  ,  or  Videophone call:  ,  ,  ,  ,  PushTalk call:  ,  ,  , [0] to [9], [X], [CLR],  or 
Quick silent	Press one of the following keys or open a FOMA terminal to stop a ring tone or vibrator. When you stop a ring tone or vibrator in this way, the caller continues to hear the ring tone. Voice call*, PushTalk*: [0] to [9], [X], [CLR],  ,  , or  Videophone call*: [0] to [9], [X], [CLR],  , or  *: To answer a call, press  ,  ,  (Videophone) (only for videophone) or  (only for PushTalk).
OFF	Press one of the following keys to answer a call: Voice call:  or  Videophone call:  ,  or  (Videophone) PushTalk call:  ,  or 