Calling

Making/Receiving Calls

Making a call


- From the application list screen, "Phone"
- 2 "Dial"
 - Tap "Favorites" to display contacts saved to Phonebook. → P.97
- Enter the phone number
 - If you enter a wrong number, tap
 delete the number. Touch and hold to
 delete all the entered numbers.
 - Set Caller ID notification manually

 " □ " "Caller ID notification" ■

"Notify"/"Not notify"

- You can set to notify/not notify your number by entering "186"/"184" before entering the number.
 - * Effective for that call only.
- Using Koe-no-Takuhaibin (P.93)
- ▶ "Koe-Taku"





NOTE

- When using services where you must type in additional numbers during the call, such as for checking your bank account balance or for using ticket reservation services, "Add 2-sec pause" (,) or "Add wait" (;) can be used to enter the main telephone number and additional number together beforehand for making the call.
 - If you use ":" Madd 2-sec pause" after the main telephone number is dialed, the additional number is dialed automatically after waiting for 2 seconds.
- If "i" > "Add wait" is used, after the main telephone number is dialed, a wait is automatically added. Then, once a confirmation message for sending the additional number is displayed, tapping "Yes" will send the additional number.

■Emergency call

Emergency call	Phone number
Police emergency	110
Fire brigade/Ambulance	119
emergency	
Maritime distress call	118

 The terminal supports "Emergency Location Report".

Calls made to emergency service organizations (e.g. by dialing 110, 119 or 118) disclose information on the caller's location to the organization receiving the call. Emergency service organizations may not identify the correct location depending on the caller's location and the receiving condition. The location information and phone number are not disclosed when, before each individual call made, "184" or another blocking prefix is dialed first. If the information is deemed necessary for the protection of life, etc., this information may be acquired by the organization being called.

Locations/timing planned for adoption of this feature vary according to the status of the preparations by the relevant emergency service organizations.

 When calling 110, 119 or 118 from the terminal, first say you are calling from a mobile phone, give your number, and state your location clearly, because the police or fire department may call you back for confirmation.

Also, do not move around when making the call. Do not turn off the power immediately after ending the call, but leave it turned on for ten minutes or so, so that you can receive a call.

 Depending on the area you are calling from, you may not be connected with the nearest police or fire department, etc.

NOTE

- When you have locked the screen, you can make an emergency call without drawing screen unlock pattern and entering the Lock Number for each screen. On each screen, tap "Emergency call". The "Emergency Dialer" screen appears; you can make phone calls only to the emergency phone numbers.
- In Japan, the 110, 119, and 118 emergency numbers cannot be dialed when the miniUIM is not set to it, from the PIN1 code entry screen, during PIN code lock, PUK lock activated, or Encryption (P.133) is set to this terminal.

Making an international call (WORLD CALL)

WORLD CALL is an international phone service that can be used from DOCOMO mobile phones. Customers who have subscribed to the FOMA service would also have automatically subscribed to "WORLD CALL" at the same time (excepting those who have declined it).

- For details on WORLD CALL, refer to DOCOMO "International Services website".
- Using international dial assist → P.188
 - From the application list screen, "Phone"
- Dial"
- Touch and hold "0"
 A plus sign "+" appears.

- Enter the country code enter the area code (city code) enter the recipient's mobile phone number "
 - If "+" is converted to an international prefix when making a call based on the settings in "Automatic conversion function" (P.188), tap "Converted number" in the "International dial assist" screen.

NOTE

 If the area code begins with "0", omit "0".
 However, "0" may be required for calling some countries or areas, such as Italy.

Receiving a call

- When a call is received, "Activate" ▶ "Accept"
 - ■Turn off the ring tone and the vibrator.
 - **▶** "**▲**"/"**▼**"
 - Declining a call
 - ▶ "Activate" ▶ "Reject"
 - Declining calls and transmitting by SMS
 - ► "Activate" ► "Reject call with SMS" ► Tap the message
 - The selected message is sent to the other person as SMS.

■Putting an incoming call on hold

- ▶ "**!**" ▶ "On hold"
- The call is connected and immediately placed on hold.

■ Record message

- ▶ " " Record message "
- Play record message →P.94
- When the call is finished, " ==== "

NOTE

 If you decline an incoming call when Voice Mail service or Call Forwarding service are set to Activate, the call is forwarded to the Voice Mail service center or the designated forwarding number.

Settings

Wi-Fi settings

Using other Wi-Fi network functions

- Please turn on Wi-Fi beforehand.
- From the application list screen, "Settings" ▶ "Wi-Fi"
- "■" ► Select any item:

Scan······This starts a Wi-Fi network scan and displays a list of available Wi-Fi networks.

Change priority......Change the priority of Wi-Fi networks to be used. Touch and hold the name of a network you want to change to switch its priority.

WPS Pin Entry.....A connection is made to the access point using the WPS PIN code input method.Register the PIN (number) displayed on the screen to the access point.

Wi-Fi Direct·····P.114

Advanced Configure advanced settings.

Network notification.....Set whether or not to send a notice when the open network of Wi-Fi is detected.

Keep Wi-Fi on during sleep......
Maintain Wi-Fi connection during sleep.
Set whether or not to use Wi-Fi (kept connected) during sleep mode. Set this to use Wi-Fi to reduce the amount of mobile data to be used. You can set whether or not to use it only for charging in order to use it during sleep mode (Wi-Fi disconnected). If you set it

Avoid poor connections.....This sets so that a Wi-Fi network is used only when a connection to a stable Wi-Fi network is possible.

so as not to use Wi-Fi, the amount of

mobile data to be used may increase.

Automatic······Sets whether to enable Wi-Fi automatic ON/OFF (P.61).

Handover.....Set whether to enable handover.

 Enable this to change over to the access point with the same "Network SSID", "Security" and "Password".

Frequency band/Channel setting.....Selects the frequency band or channel used for Wi-Fi connections. This can be set when the Wi-Fi function is set to OFF.

MAC address ······ A MAC address is displayed.

IP address······The IP address currently used is displayed.

Attention.....Displays the usage precautions for the Wi-Fi function.

NOTE

- Packet communication is still available when Wi-Fi is turned on. However, if the terminal is connected to a Wi-Fi network, the Wi-Fi network takes precedence. When the Wi-Fi network is disconnected, the terminal automatically connects to the LTE/3G/GPRS network. If you continue using the terminal connected to the LTE/3G/GPRS network, you may incur costly packet communication charges.
- If an incorrect password (security key) is entered when selecting and connecting an access point, the message "Avoided poor Internet connection" or "Authentication problem" appears. Check the password (security key). If a message "Avoided poor Internet connection" appear even though the password has been entered correctly, the correct IP address may not be obtained. Check the radio wave condition and reconnect it.

Using Wi-Fi Direct

This terminal supports Wi-Fi direct to easily use Wi-Fi. Use Wi-Fi direct to connect Wi-Fi to other devices without going through access points and the Internet.

- Tap "OFF" to set Wi-Fi to "ON".

 Tap "OK" when "Wi-Fi tethering" and "USB tethering" is ON.
- "■" ▶ "Wi-Fi Direct"
 - This automatically scans for compatible devices and displays a list of available devices
- Tap the name of the device you want to connect to
 - If the connection setting request is accepted at the device that you want to connect to, a connection is established by Wi-Fi Direct.
 - Disconnecting the Wi-Fi Direct connection
 - ➤ Tap the name of the device that you want to disconnect ➤ "OK"

NOTE

- You are required to download and install applications supporting data exchange of Wi-Fi Direct to exchange data such as video and still images using Wi-Fi Direct.
 Some applications allow you to connect to other compatible devices such as printers.
- If Wi-Fi and Wi-Fi Direct are set to different channels, they cannot be used at the same time.

Bluetooth Communication

Connect the terminal and a Bluetooth-compatible device via Bluetooth communication. You can connect a Wireless Earphone Set 02 (option), etc. to the terminal, and talk on the phone or listen to music while the terminal is still in your bag.

- There is no guarantee that the terminal is capable of wireless communication with all types of Bluetooth devices.
- For information about the settings and operation procedures, see also the instruction manual of the Bluetoothcompatible device.

Precautions when using Bluetooth devices

- Note the following in order to ensure a good connection.
 - Connect with another Bluetooth device within about a 10-meter viewable distance. Depending on surroundings (walls, furniture, etc.) and building structure, the connectable distance is shorter. The connectable distance will also be shorter if an obstacle is between the terminal and another Bluetooth device. Connection may be unestablishable if the terminal and the device are located on opposite sides of walls containing metal rods, such as on upper and lower storeys or in adjoining rooms, especially in a building made of reinforced concrete. Also note that the above connection distances are not quaranteed.