


BT-CRADLE ASSY(LB)BK Connecting Manual

MODEL:LO(BTCP)

● Mounting Procedure



Insert the lug on the Multifunctional telephone unit into the hole in the BT-CRADLE ASSY(LB)BK.
Slide the BT-CRADLE ASSY(LB)BK unit the stopper clicks into position.
Insert the cradle connecting cable of the BT-CRADLE ASSY(LB)BK into the telephone unit connector.

● Usage

- How to turn on/turn off the power supply of the BT-CRADLE ASSY(LB).
 - Multifunctional telephone is turned on.
 - The "Pair" button of a multifunctional telephone is pushed (for 2.5 to 7.5 seconds).
Then, the power supply of the BT-CRADLE ASSY(LB) turns on.
If the power supply of the BT-CRADLE ASSY(LB) turns on,
Pair LED will blink in a cycle of 1 second.
 - When the BT-CRADLE ASSY(LB) is the power supply on.—
The "Pair" button is pushed (2.5 seconds or more).
Then, the BT-CRADLE ASSY(LB) turns off.

- PairingMode
 - The BT-CRADLE ASSY(LB) is turned off— The "Pair" button is pushed (for 2.5 to 7.5 second).
Then, it shifts to PairingMode.
 - If it shift to PairingMode, "Pair" LED will blink in a cycle of 0.2 second.

Item	Specification
Destination	Multifunctional telephone
Radio interface	Bluetooth® version 2.0 +EDR Class1(1 to 2.5mW)
Installed profiles	·HSP : Headset Profile·HFP : Hands Free Profile
Power consumption	About 1 W (excluding the telephone)
Power feeding	+2.97 to +3.6V (Power feeding from the multifunctional telephone)
Dimensions (L × W × H)	220mm × 60mm × 90mm (excluding projections)
Mass	About 1kg
Operating environment	Temperature: 0 to 40°C , Relative humidity: 10 to 90% (no dew condensing)
Restrictions	Keep the BT-CRADLE ASSY(LB)BK at least 1m apart from other BT-CRADLE ASSY(LB)BK UNITS and at least 3m apart from other radio equipment.

※The Bluetooth® word mark and logos are owned by the Bluetooth SIG, Inc.

a. FCC portion

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) This device must accept any interference received, including interference that may cause undesired operation.

Caution:

Any changes or modifications not expressly approved by the party responsible for product compliance could void the user's authority to operate the equipment.

Caution: RF Exposure to radio frequency radiation

To comply with FCC RF exposure compliance requirements, a separation distance of at least 20 cm must be maintained between the antenna of this device and all persons. This device must not be co-located or operating in conjunction with any other antenna or transmitter.

b. Industry Canada Portion

Canada Regulatory Compliance Statement

This Class B digital apparatus complies with Canadian ICES-003.

Cet appareil numérique de la classe B est conforme à la norme NMB-003 du Canada.

For Customers in Canada

This device complies with RSS 210 of Industry Canada (IC).

Operation is subject to the following two conditions:

- (1) this device may not cause interference, and
- (2) this device must accept any interference, including interference that may cause undesired operation of this device.

L' utilisation de ce dispositif est autorisée seulement aux conditions suivantes :

- (1) il ne doit pas produire de brouillage et
- (2) l' utilisateur du dispositif doit être prêt à accepter tout brouillage radioélectrique reçu, même si ce brouillage est susceptible de compromettre le fonctionnement du dispositif.

Caution: RF Exposure to radio frequency radiation

To comply with IC RF exposure compliance requirements, a separation distance of at least 20 cm must be maintained between the antenna of this device and all persons. This device must not be co-located or operating in conjunction with any other antenna or transmitter.