
Control System **a** (E DD1149 **Emitter Specification** Version NO. : A/o1 Type specification 3333333333333 -DC24V + -DC12V + Up--Negative electrode Down Com -Setting button DC1149 Three kinds of mode switching Setting button \times 65 Stops flashing, enter the Double pulse switch pulse switch mode (Noninterlocked) 4 LED flashes slowly aaaaaaa@aaaa 2220222222 -----Setting button $\times {}_{12}{\rm S}$ Fast flashing two times to enter Not rebound the non-bounce switch mode double switch LED flashes slowly 4 ----aaaaaaaaaaaaaaa 2222222002222 Setting button×205 Flashes three times quickly, Double loop switch enter the loop switch mode 4 LED flashes slowly 3333333333333 499999999999 aaaaaa**o**aaaa 222222222 2222222222

T

Technical support Technical specification Fucntion instruction Transmitter: you can choose emitter DC1149 • Input voltage: 12V/24V • Transmitting frequency: 433MHz • Transmitting power: 10 milliwatt • Operating temperature: -10°C-50°C • Transmitting distance: 200 meters open office, Notice: transmitter do not exposed to moisture and strike, so as not to affect life. 35 meters on two walls



FCC Warning:

1. This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference.

(2) This device must accept any interference received, including interference that may cause undesired operation.

2. Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules.These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, maycause harmful interferenceto radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

Reorient or relocate the receiving antenna.

Increase the separation between the equipment and receiver.

Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

Consult the dealer or an experienced radio/TV technician for help.

Warning:

This device complies with Industry Canada RSS-210. Operation is subject to the following two conditions: (1) this device may not cause interference, and (2) this device must accept any interference, including interference that may cause undesired operation of the device.

Le présent appareil est conforme aux CNR d'Industrie Canada applicables aux appareils radio RSS-210. L'exploitation est autorisée aux deux conditions suivantes :

- (1) l'appareil ne doit pas produire de brouillage, et
- (2) l'utilisateur de l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.

The device meets the exemption from the routine evaluation limits in section 2.5 of RSS 102 and compliance with RSS-102 RF exposure, users can obtain Canadian information on RF exposure and compliance.

Le dispositif rencontre l'exemption des limites courantes d'évaluation dans la section 2.5 de RSS 102 et la conformité à l'exposition de RSS-102 rf, utilisateurs peut obtenir l'information canadienne sur l'exposition et la conformité de rf.

This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter. This equipment should be installed and operated with a minimum distance of 5 mm between the radiator and your body.

Cet émetteur ne doit pas être Co-placé ou ne fonctionnant en même temps qu'aucune autre antenne ou émetteur. Cet équipement devrait être installé et actionné avec une distance minimum de 5mm entre le radiateur et votre corps.