

eBook

Electronic Book Reader

User Manual

Date:2010/05/12

FCC Interference Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

FCC Caution: Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate this equipment.

IEEE 802.11b or 802.11g operation of this product in the U.S.A. is firmware-limited to channels 1 through 11.

IMPORTANT NOTE:

FCC Radiation Exposure Statement:

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. End users must follow the specific operating instructions for satisfying RF exposure compliance. To maintain compliance with FCC RF exposure compliance requirements, please follow operation instruction as documented in this manual.

This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

Europe – EU Declaration of Conformity

This device complies with the essential requirements of the R&TTE Directive 1999/5/EC. The following test methods have been applied in order to prove presumption of conformity with the essential requirements of the R&TTE Directive 1999/5/EC:

- EN 60950-1
- EN 50371
- EN 300 328
EN 301 489-17







This device is a 2.4 GHz wideband transmission system (transceiver), intended for use in all EU member states and EFTA countries, except in France and Italy where restrictive use applies.

In Italy the end-user should apply for a license at the national spectrum authorities in order to obtain authorization to use the device for setting up outdoor radio links and/or for supplying public access to telecommunications and/or network services.

This device may not be used for setting up outdoor radio links in France and in some areas the RF output power may be limited to 10 mW EIRP in the frequency range of 2454 – 2483.5 MHz. For detailed information the end-user should contact the national spectrum authority in France.



Český [Czech]	<i>[Jméno výrobce]</i> tímto prohlašuje, že tento <i>[typ zařízení]</i> je ve shodě se základními požadavky a dalšími příslušnými ustanoveními směrnice 1999/5/ES.
Dansk [Danish]	Undertegnede <i>[fabrikantens navn]</i> erklærer herved, at følgende udstyr <i>[udstyrets typebetegnelse]</i> overholder de væsentlige krav og øvrige relevante krav i direktiv 1999/5/EF.
Deutsch [German]	Hiermit erkläre <i>[Name des Herstellers]</i> , dass sich das Gerät <i>[Gerätetyp]</i> in Übereinstimmung mit den grundlegenden Anforderungen und den übrigen einschlägigen Bestimmungen der Richtlinie 1999/5/EG befindet.
Eesti [Estonian]	Käesolevaga kinnitab <i>[tootja nimi = name of manufacturer]</i> seadme <i>[seadme tüüp = type of equipment]</i> vastavust direktiivi 1999/5/EÜ põhinõuetele ja nimetatud direktiivist tulenevatele teistele asjakohastele sätetele.
English	Hereby, <i>[name of manufacturer]</i> , declares that this <i>[type of equipment]</i> is in compliance with the essential requirements and other relevant provisions of Directive 1999/5/EC.
Español [Spanish]	Por medio de la presente <i>[nombre del fabricante]</i> declara que el <i>[clase de equipo]</i> cumple con los requisitos esenciales y cualesquiera otras disposiciones aplicables o exigibles de la Directiva 1999/5/CE.
Ελληνική [Greek]	ΜΕ ΤΗΝ ΠΑΡΟΥΣΑ <i>[name of manufacturer]</i> ΔΗΛΩΝΕΙ ΟΤΙ <i>[type of equipment]</i> ΣΥΜΜΟΡΦΩΝΕΤΑΙ ΠΡΟΣ ΤΙΣ ΟΥΣΙΩΔΕΙΣ ΑΠΑΙΤΗΣΕΙΣ ΚΑΙ ΤΙΣ ΛΟΙΠΕΣ ΣΧΕΤΙΚΕΣ ΔΙΑΤΑΞΕΙΣ ΤΗΣ ΟΔΗΓΙΑΣ 1999/5/ΕΚ.
Français [French]	Par la présente <i>[nom du fabricant]</i> déclare que l'appareil <i>[type d'appareil]</i> est conforme aux exigences essentielles et aux autres dispositions pertinentes de la directive 1999/5/CE.
Italiano [Italian]	Con la presente <i>[nome del costruttore]</i> dichiara che questo <i>[tipo di apparecchio]</i> è conforme ai requisiti essenziali ed alle altre disposizioni pertinenti stabilite dalla direttiva 1999/5/CE.
Latviski [Latvian]	Ar šo <i>[name of manufacturer / izgatavotāja nosaukums]</i> deklarē, ka <i>[type of equipment / iekārtas tips]</i> atbilst Direktīvas 1999/5/EK būtiskajām prasībām un citiem ar to saistītajiem noteikumiem.
Lietuvių [Lithuanian]	Šiuo <i>[manufacturer name]</i> deklaruojama, kad šis <i>[equipment type]</i> atitinka esminius reikalavimus ir kitas 1999/5/EB Direktyvos nuostatas.
Nederlands [Dutch]	Hierbij verklaart <i>[naam van de fabrikant]</i> dat het toestel <i>[type van toestel]</i> in overeenstemming is met de essentiële eisen en de andere relevante bepalingen van richtlijn 1999/5/EG.
Malti [Maltese]	Hawnhekk, <i>[isem tal-manifattur]</i> , jiddikjara li dan <i>[il-mudell tal-prodott]</i> jikkonforma mal-htigijiet essenzjali u ma provvedimenti oħrajn rilevanti li hemm fid-Dirrettiva 1999/5/EC.

 Magyar [Hungarian]	Alulírott, <i>[gyártó neve]</i> nyilatkozom, hogy a <i>[... típus]</i> megfelel a vonatkozó alapvető követelményeknek és az 1999/5/EC irányelv egyéb előírásainak.
 Polski [Polish]	Niniejszym <i>[nazwa producenta]</i> oświadcza, że <i>[nazwa wyrobu]</i> jest zgodny z zasadniczymi wymogami oraz pozostałymi stosownymi postanowieniami Dyrektywy 1999/5/EC.
 Português [Portuguese]	<i>[Nome do fabricante]</i> declara que este <i>[tipo de equipamento]</i> está conforme com os requisitos essenciais e outras disposições da Directiva 1999/5/CE.
 Slovensko [Slovenian]	<i>[Ime proizvajalca]</i> izjavlja, da je ta <i>[tip opreme]</i> v skladu z bistvenimi zahtevami in ostalimi relevantnimi določili direktive 1999/5/ES.
Slovensky [Slovak]	<i>[Meno výrobcu]</i> týmto vyhlasuje, že <i>[typ zariadenia]</i> spĺňa základné požiadavky a všetky príslušné ustanovenia Smernice 1999/5/ES.
 Suomi [Finnish]	<i>[Valmistaja = manufacturer]</i> vakuuttaa täten että <i>[type of equipment = laitteen tyyppimerkintä]</i> tyyppinen laite on direktiivin 1999/5/EY oleellisten vaatimusten ja sitä koskevien direktiivin muiden ehtojen mukainen.
 Svenska [Swedish]	Härmed intygar <i>[företag]</i> att denna <i>[utrustningstyp]</i> står i överensstämmelse med de väsentliga egenskapskrav och övriga relevanta bestämmelser som framgår av direktiv 1999/5/EG.

Replaceable battery caution

CAUTION

RISK OF EXPLOSION IF BATTERY IS REPLACED BY AN INCORRECT TYPE.

DISPOSE OF USED BATTERIES ACCORDING TO THE INSTRUCTIONS

TABLE OF CONTENTS

CHAPTER 1: INTRODUCTION.....	1
1.1. PACKAGE CONTENTS.....	1
1.2. OVERVIEW.....	1
1.3. PHYSICAL DETAILS.....	2
1.4. SD CARD INSTALLATION.....	5
1.5. CHARGING THE BATTERY.....	7
CHAPTER 2: CONTENT.....	8
2.1. FILE TRANSFER.....	8
2.2. ADOBE READER.....	9
CHAPTER 3: HOMEPAGE.....	10
3.1. FAVORITE.....	11
3.2. LIBRARY.....	11
3.3. MUSIC.....	13
3.4. EXPLORER.....	13
3.5. READING HISTORY.....	13
3.6. BOOKSTORE.....	13
3.7. DICTIONARY.....	17
3.8. PICTURE.....	17
3.9. SETTINGS.....	17
CHAPTER 4: WHAT YOU CAN DO WITH EBOOK READER.....	21
4.1. READING EBOOKS.....	22
4.2. WATCHING PICTURES AND COMICS.....	24
4.3. LISTENING TO MUSIC.....	25
APPENDIX.....	26
APPENDIX A: RESET.....	26
APPENDIX B: CLEANING AND SAFETY.....	27
APPENDIX C: SPECIFICATIONS.....	28

Chapter 1: Introduction

Thank you for purchasing the product. Read this chapter to know about your eBook Reader including features, components, and capabilities.

1.1. Package Contents

Before using eBook Reader, please check your package contents to ensure that all items have been included. If any of the listed items are missing, please contact your reseller from where you purchased eBook Reader for assistance.

The package includes:

1. eBook Reader*1
2. AC Power Adapter*1
3. USB cable*1
4. Earphone*1
5. Leather case*1
6. Quick start guide*1
7. Warranty card*1

1.2. Overview

Lightweight and super-portable, this eBook Reader can hold hundreds of electronic books inside. Just like carrying a portable library, you can enjoy reading at anytime and anywhere!


Our eBook Reader is integrated with the E-Ink display to bring rich text and picture without needing a backlight and is easy to read in bright environments. The high-contrast screen is as close to actual ink on paper. It is natural, anti-glare and easy on the eyes. Furthermore, it is very power-saving, capable running up to 30 hours, 8000 pages available with a full single charged.

eBook Reader displays files in pdf, epub, html, txt, mob, prc, or doc formats with library management functions. And keep all images in JPG format. It is also able to display books in a number of the world's most popular languages including English, Deutsch, French, Españoles, Pycckññ, Traditional Chinese, and Simple Chinese.

This reader embedded ARM11 CPU, it is 4 times speed of turning page, opening files and turning on the device. Additionally, with the function of turn page, add bookmark, screen orientation, and zoom in, zoom out, eBook Reader is suitable from young to old.


No more paper, no more heavy books, with this eBook Reader, you can bring lots of books with you without increasing the heaviness on your backpack, and reduce the burden on your wrist. Reading becomes more comfortable than ever!

Downloaded eBooks...



...and then transfer!

1.3. Physical Details









Control Button

1. Power	7. SD Card Slot
2. Favorites	8. Volume/Font Adjust
3. Rotate Screen	9. Reset Button
4. Return Button	10. Headphone Port (optional)
5. Menu	11. USB Port & AC Power Adapter Port
6. Cursor Key & Select Button	

Product Characteristics

Model	E60822
Touch Screen	–
Wi-Fi	V
Bluetooth	–
3G/3.5G	–
RSS/News	–
Bookstore	V
Web Browser	–
Handwriting	–
E-mail	–

Function & Basic Operation

Cursor Key & Select Button		HomePage	Reading Page
	1	Select Button	Menu / Select Button
	2	Move cursor up	Previous item
	3	Move cursor down	Next item
	4	Move cursor left	Previous page
	5	Move cursor right	Next page
Functional hot key	 Volume/ Font Adjust	NA	Volume or font size adjusting
	 Favorite	Add/remove my favorite list from Library, Reading History, Favorite, Music and Picture.	Add/Remove Bookmark: Reader (Adobe& FB Reader)
	 Rotate Screen	NA	Rotate screen
	 Return	Back to previous layer	Back to library
	 Menu	Setting Menu: Power, Date/Time, Language, Default, About and Owner, etc.	Reader Menu: Bookmark, Contents, Rotate, Search, Page, etc.


1.4. SD Card Installation

eBook Reader supports SD type SDHC Card. Please follow the steps to properly insert/remove the SD card to the device.

INSERT SD CARD


STEP 1

Insert the SD card into the device as the picture shown. Be aware to the SD card direction!



STEP 2


Insert the SD card until it clicks into place.



REMOVE SD CARD


STEP 1

Gently push in the SD card. Then card jumps up immediately



STEP 2


Remove the SD card carefully from the slot.



1.5. Charging the Battery

eBook Reader has an internal, nonremovable battery. The battery is 80-percent charged in about two hours, and fully charged in about four hours. If you charge eBook reader by connecting it to your computer, it may take longer to charge.

To charge the battery with computer:





Connect eBook Reader to your computer with the USB cable in the package. When eBook reader connects to the computer, the device power turns red automatically and the screen shows "USB Link" status.

Important Advise:

The computer must be turned on and not in sleep mode during charging.


To charge the battery with power adapter:



Use the power adapter in the package. Insert the mini USB end of the cable to the device, and then plug the power adapter into an outlet. When eBook Reader connects to the power outlet, the device power turns red automatically. If the battery icon on the top-right corner of the eBook screen changes into , it means the battery is charging.

Battery Power Status:

When the device is not connected to a power source, a battery icon on the top-right corner of the eBook screen shows the battery status.

For example: this icon  shows the battery is about halfway charged.

Low Battery Warning:

This device provides low battery warning system.

Less than 20%: Battery low.

Less than 10%: Battery Critical.

Less than 5%: Battery empty, Power off in 2 seconds.

Chapter 2: Content


This chapter provides information to install the content to the eBook Reader Device.

2.1. File Transfer

When connecting to PC, the eBook Reader Device is recognized as a mass storage device.

Copy the eBook folders or files which you've bought/downloaded from the internet to the disk, and then disconnect the eBook Reader Device to start reading.

Or copy the eBook folders/files to a SD card, and plug the SD card to the device to read directly.



Important Advise:

It is recommended to make regular backups of the content of your eBook reader to prevent the total loss of files from physical damage, failure, loss or theft.

2.2. Adobe Reader

This eBook Reader is embedded with Adobe Reader Mobile 9. The Reader Mobile 9 enables eBook Reader devices to easily acquire, manage and display encrypted and unencrypted PDF and EPUB content. Users can adopt Adobe Digital Editions as eBook management Utility between PC and eBook Reader.

Adobe® Digital Editions (ADE) software offers an engaging way to view and manage eBooks and other digital publications. Use it to download and purchase digital content, which can be read both online and offline. Transfer copy-protected eBooks from computers or devices. Organize your eBooks into a custom library and annotate pages. Digital Editions also supports industry-standard eBook formats, including PDF/A and EPUB.

Installing ADE, following the authorization process to start reading and transfer Digital Rights Management (DRM) content to your eBooks Reader, and you are ready to enjoy over hundreds of books in just a few grams.

Step 1:

Apply an Adobe ID on Adobe Website <https://www.adobe.com/cfusion/membership/>

Step 2:

Download ADE from Adobe website <http://www.adobe.com/products/digitaleditions/>

Step 3:

After installation, ADE activates automatically, and asks for authorizing the PC. Please type in your account and password.

Step 4:

After authorizing your PC, please connect the eBook Reader to your PC, and use the same Adobe account and password to authorize the device.

Step 5:










After authorizing your PC and reader, you can enter eBook Store page to buy or download files. Then, you can enjoy reading on the device.

Chapter 3: Homepage

This chapter introduces the main page information.

The Homepage shows on the device as the main page. The following table lists the information and items of the Homepage.

Homepage interface information:

Icons	Information
 Favorite	Keeps all the reading, images, audio files marked favorite.
 Library	Keeps all the files in PDF, EPUB, HTML, TXT, RTF, MOBI, PRC, or DOC formats.
 Music	Keeps all the files in MP3 format, with music management functions.
 Explorer	List all the files in all kinds of formats, categorized by flash or SD card to indicate the file locations.
 Reading History	Keeps the reading records of the latest 5 files ever read/open.
 Bookstore	Browse/purchase/download the files online.
 Dictionary	Select dictionary type, open soft keyboard to input words and look up them inside the pre-loaded dictionary database.
 Picture	Keeps all the files in JPG formats.
 Settings	Device setting includes customized setting and wireless setting. Please refer to 3.9 Settings for more information of this function.

3.1. Favorite


Favorite List keeps all the files marked favorite. You can designate any file by marking the tag on library page or in reading statement.

Please refer to [3.2 Library](#) for more information of favorite page.

3.2. Library





Library keeps all the files in PDF, EPUB, HTML, TXT, RTF, MOBI, PRC, or DOC formats inside the device and SD card.

Please also refer to [4.1 Reading eBooks](#) to know more about the functions during reading.



Library Menu :

- On library page, press the [Menu Button].
- Open [Library Menu].
- The following table lists the information and items of Library Menu.

Item	Function/Operation
 Favorite	Add/remove files to/from my favorite list.
 Filter	<ol style="list-style-type: none"> 1. Filter the files by file type. 2. The library list displays the style as you wish.
 Sort	<ol style="list-style-type: none"> 1. Sort the files by date, file names, type, ascend, descend and size. 2. The device refreshes the page according to the sorting type you have selected. 3. Sorting type displays on the top-right corner of the screen.
 View	View all the files of eBook reader and SD card in list/thumbnail mode.

3.3. Music

Keep all the files in MP3 format, with music management functions.

Please refer to [4.3 Listening to Music](#) for more information while listening to music.

3.4. Explorer

Explorer lists all the files in all kind of formats, categorized by flash or SD card.

3.5. Reading History

Reading History records 5 files you have read or open recently.

3.6. Bookstore

This device provides users to browse/purchase/download the files online.

Please refer to the following steps to reach more information of [eBook Store].


STEP 1

- <http://www.todoebook.com> position as the main Book Store.
- Before buying the book on web by device, user needs to go to <http://www.todoebook.com> to register first.
- Device connects to the <http://www.todoebook.com>, it will use machine serial number for authentication.
- <http://www.todoebook.com> uses Adobe Content Server to provide PDF, ePUB DRM protect.







STEP 2

Enter [eBook Store] Page and auto check the ADE status, IP setting.

If the device hasn't authorized ADE and connected wireless, please refer to [2.2. Adobe Reader](#), [3.9. Settings](#).



eBook Store Page:

Item	Function/Operation
 TOP 10	List the most popular books.
 New	List the latest books.
 Recommend	List the most worth reading books that are recommend by readers.
 Category	List the files according to the subject classification.
 Search	Search books by default, title, author or ISBN.
 Trade History	List the transaction records.

STEP 3

Enter [Top 10], [New], [Recommend], [Category], [Search] page.
Select any file and press enter. Then, Open the information of the file.




STEP 4

If the file is free, you can download it without any payment.

Otherwise, you need to insert machine serial number and use cash card to buy and download the book.

The book will be stored in the Download File of [Explorer Page].

**Note:**

1. Before you purchase the books online, you need to buy a cash card on todoeBook Web.
2. If the machine serial number is incorrect, you are not allowed to buy the books.
3. When the cash card is insufficient to buy e-Books, please go to todoebook web to pre-paid the cash card first.

3.7. Dictionary

eBook Reader provides dictionary function for users to look up words inside the pre-loaded dictionary database.

3.8. Picture









In Picture File, it keeps the all images in JPG format of the device or SD card.

Please also refer to [4.2 Watching Pictures and Comics](#) for more information about this function.

3.9. Settings

Device setting includes customized settings and wireless setting.

Please follow the table below for more information.


Items	Function/Operation
 Power	Automatic power off setting.
 Date/Time	Date and time setting.
 Language	Select user interface language. Including: English, Deutsch, French, Españoles, Pycckññ, Traditional Chinese, and Simple Chinese.
 Default	Clean up the Digital Right Manager files created by users and reset the device.
 About	The information of this device.
 Owner	Configure owner's name and display on the top-left corner of the screen.
 Dictionary	Select the dictionary type and language.
 Connection	Wi-Fi setting. Please refer to Wireless Setting for more setting information.

Wireless Setting:

Set up New Connection:

STEP 1


Add the new connection.



STEP 2


Rescan Wi-Fi AP.

A list of Wi-Fi AP pops up.



STEP 3


Select the available AP to do the WEP/WPA setting, and connect the internet. Once connect to internet successfully, the AP information will pop up.

**Note:**

1. 📶 📶 📶 means the strength of wireless network.
2. [🔒] The one with lock means the AP with security and you must input the key password to use this Wi-Fi AP.

STEP 4

After connecting to the internet, the AP will be stored on [Connect Management Page]. Press [Menu Button] to open the wireless menu and edit the AP. You can delete the AP or re-input the key password to connect the wireless.



Chapter 4: What You Can Do with eBook Reader









This chapter introduces the reading page information and the basic operations.




4.1. Reading eBooks

- On [Library], [Reading History], [Favorite] page, select the files and enter to reading page.
- On reading page, press the [Select Button or Menu] to open [Reader Menu].
- Please refer to the table below for more information of [Reader Menu].









Reader Menu :

Item	Function/Operation
 Bookmark	Add/delete bookmarks.
 Contents	List the table of content in the reading book.
 Rotate	Switch the screen orientation.
 Search	Provide soft keyboard to key in English/Euuropean Language / Numbers and search a certain word in whole books.
 Page	Open the number keyboard to insert the appointed page.
 Font	Select the font size.
 Back	Back to the reading page.
 More	Enter Reader Menu Subcategory.

Reader Menu Subcategory:

- On Reader Menu, enter [ more].
- Open Reader Menu [Subcategory].
- Please refer to the table below for more information of the Reader Menu [Subcategory].

Subcategory:





Item	Function/Operation
 Annotation	Display the Bookmark list. You can select any Bookmark file to open the reading page and keep reading.
 Font Family	Change the font type.
 Full Screen	Change the reading screen into a full page mode.
 property	Show the information of the file you are reading.
 Favorite	Add/Delete the file to/from my favorite list.
 Delete	Delete the file.
 Alignment	Rearrange the reading page.
 Back	Back to main [Reader Menu].

4.2. Watching Pictures and Comics

This part introduces the image page information and basic operations.

- On Picture page, press [Select Button or Menu] to open the [picture menu].
- Please refer to the table below for more information of the [Picture Menu].

Picture Menu:

Item	Function/Operation
 Zoom	Zoom in/out the image.
 Rotate	Rotate the image to vertical or horizontal
 Sliding	Sliding pictures with time regulation from 0 to 20 seconds
 About	The information of the image file.

4.3. Listening to Music

This part introduces the audio page information and basic operations.

- On homepage, enter Music list.
- Use cursor key to select the file and press enter to start playing music.
- While listening to music, easily adjust the volume by pressing the [+/-] buttons.
- You can also press [Select or Menu button] to open [Music Setting].
- Please refer to the following table to reach more information of [Music Setting].

Music Setting:

Item	Function/Operation
Music On Music Off	Turn on/off the background music.
Play Mode	Select playing mode: repeat single, repeat all or random.
Exit Menu	Close [music setting].


Note:

1. By turning on background music, you can listen to music and read the files at the same time.
2. When listening to music, press [+/-] buttons only can adjust the volume.

Appendix

Appendix A: Reset

Reset eBook Reader by using a small pin or clip, the contents stored inside are not affected by resetting, and no information is erased.



Appendix B: Cleaning and Safety

➤ CLEANING

Before cleaning, please power off and disconnect cables from system and AC outlet. After finish of cleaning, please make sure that the monitor is completely dry before you reconnect cables and power it on. Please do not use any liquid or spray cleaners directly on surface of screen or case. Please use a soft, clean, lint-free cloth with cleaners to clear your monitor.

1. Screen

Please use a soft, clean, lint-free cloth to remove dust and dirt from the screen. For fingerprints & smudges, please use a soft cloth with cleaners.

2. Case

Please clean the case with a soft cloth slightly moistened with a mild detergent solution. Please rinse the cloth with clear water, wring it dry, and wipe the case to remove any detergent residue.

➤ SAFETY

1. To reduce risk of electric shock, please follow all safety notices, never open case of products by yourself, and turn off power before cleaning.
2. The products are equipped with a power adapter. (The type of power adapter may be different according to different countries.) The power adapter plug only fit into a safety ground outlet. Do not attempt to fit the plug into an outlet that has not been configured for this purpose. Please only use power adapter that comes with the products. Using an unauthorized power adapter may invalidate the warranty of the products.
3. Please do not insert or block any object inside four edges of the screen.
4. Please do not pour liquid into or onto products and wash with a wet cloth. If the products become wet, please do not turn on or attempt to repair by yourself. Please ask a qualified service technician to check it for you before you turn on the power again.
5. Please use products under suitable environment written in specification and protect products working away from extremely bad environment.
6. Please keep the products away from bumps and drops.
7. Please keep the products away from dust, sand, and dirt.

Appendix C: Specifications

Operating System	Linux 2.6.28
Interface	1 x USB Client v2.0 – Mini USB B connector 1 x 2.5mm stereo earphone connector 1 x SD card slot Buttons: 4 functional hot keys + 2 volume adjust buttons + 5 way buttons + power button
CPU	ARM11
Screen	6" E Ink® Vizplex Screen (4.8" x 3.6" – 122 x 91mm)
Resolution	600 x 800 pixels, 166 dpi B&W, 16 grayscale Daylight readable, no backlight
Power Source	Rechargeable Li-Polymer battery: 1000mAh AC power adapter: DC 5V 1000mA
Battery Life (continuous playback)	Approx. 8000 pages (when battery is full charged)
Memory	System Memory: 128 MB mDDR, 2 GB Mand Flash Expandable: SD type SDHC, up to 32GB
Connectivity	Wi-Fi Module Solution (AW-GH321 11b/g SiP module)
Support Language	English, Deutsch, French, Españoles, Pyccknñ, Traditional Chinese and Simple Chinese
Dimensions	118 x 188 x 8.5 mm – 4.7" x 7.4" x 0.3"
Weight	180g battery included
Temperature	Operating: 0° ~ 40°C Storage: –10° ~ 70°C
Humidity	10%~95% RH, non condensing
Regulatory Certification	FCC, CE Class B, Adobe Reader Mobile 9

Contains Reader® Mobile technology by Adobe Systems Incorporated.