


Quick Start Guide




NW6EAI-E




LED Indicators

LED Behavior:




COLOR	STATUS	DESCRIPTION	
	AMBER	Blinking (On for 1 second, Off for 1 second alternatively)	Undergoing power on
	AMBER	Blinking (AMBER for 1 second, RED for 1 second alternatively)	Undergoing firmware upgrade
	RED		
	GREEN	Solid on	On and normal
	AMBER	Solid on	No Internet access
	RED	Solid on	Abnormal with serious error
	BLUE	Solid on	Controller on and normal


In the Box




Device



Screw x 4
(For securing the ceiling mount bracket)



Ceiling mount kit bracket A
(metal)



Ceiling mount kit bracket B
(plastic)

Let's get started

1 Ceiling mount step 1 – combining ceiling mount bracket A and B with screws enclosed




Fig.1-1

2 Ceiling mount step 2 – attach ceiling mount bracket to Ceiling T-Bar




Fig.2-1




Fig.2-2

- 3** Ceiling mount step 3 – connect the ethernet with POE to the 2.5GE port or connect the DC12V and check LED indication for device boot up




Fig.3-1




Fig.3-2

- 4** Ceiling mount step 4 – attach the device the ceiling mount bracket




Fig.4-1

Remove device from brack

- 1** Step 1 – Lift the latch




Fig.1-1

- 2** Step 2 – Push the device out of bracket





Fig.2-1

Wall Mount Installation



Federal Communication Commission Interference Statement

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

FCC Caution: Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate this equipment.

This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter. This device meets all the other requirements specified in Part 15E, Section 15.407 of the FCC Rules.

Radiation Exposure Statement:

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator & your body. Operations in the 5.15-5.25 GHz band are restricted to indoor usage only.

For 6ID (Indoor Access Point)

- FCC regulations restrict the operation of this device to indoor use only.
- The operation of this device is prohibited on oil platforms, cars, trains, boats, and aircraft, except that operation of this device is permitted in large aircraft while flying above 10,000 feet.
- Operation of transmitters in the 5.925-7.125 GHz band is prohibited for control of or communications with unmanned aircraft systems.

Web UI sign-in

Customer can use WebUI to configure NW6EAI-E. In order to login WebUI, please

- Manually modify the IP address of your own laptop to 192.168.0.2
- Connect to the NW6EAI-E WiFi using the SSID/Password shown on the sticker of the device
- Use browser to open <http://192.168.0.1/> , then use the admin/password show on the back of the device to login

