



SIMPLE HOME™

AUTOMATED CONTROL



FOR AN EASY INSTALLATION VIDEO TUTORIAL
GO TO GOSIMPLEHOME.COM/YOUTUBE

SIMPLE GUIDE TO SIMPLE HOME

GUIDE SIMPLE POUR
SIMPLE HOME

GUÍA SIMPLE PARA
SIMPLE HOME



POWERED BY
XTREME™

855-999-8041
WWW.GOSIMPLEHOME.COM

MOTION SENSOR W/ MESSAGE ALERTS (MODEL: XHS7-1001)

Box Contents:

- 1) Motion Sensor with Power Cord Plug
- 2) Wall or Ceiling Mounting Kit
- 3) QR code hangtag (needed for setup)
- 4) User manual

Table of Contents:

What's in the Box?	Page 1
Product Features	Page 1 and 5
Setup and Installation	Pages 2-4
Trouble Shooting/Support/FAQ	Page 6
Spanish Manual (Manual de español).....	Page 7
French Manual (Manuel français)	Page 13
Product Warranty	Page 19

GETTING TO KNOW YOUR DEVICE

Product Features:

- Remotely monitor movement inside your home
- Uses Passive Infrared Sensors (PIR) to detect motion up to 15 feet away
- Alerts you when motion is detected with push notifications
- Can trigger other Simple Home products to turn on when motion is detected
- Save money and conserve energy by having devices turn on only when motion is detected
- All of your Simple Home products controlled by the Simple Home App

System Requirements:

- 1) Wi-Fi Router with a **2.4ghz** internet connection
- 2) Android mobile device version 4.0 or greater/ Apple iOS 8 or greater

These products are NOT compatible with Linux or Windows phones

Simple Guide for All Simple Home Products

STEP 1


- **DOWNLOAD THE SIMPLE HOME APP ONTO YOUR MOBILE DEVICE.**
- **ONCE DOWNLOADED, OPEN THE APP AND CREATE AN ACCOUNT**

- After your account has been created, it will prompt you to check your email to verify the account. Please allow up to five minutes for an email confirmation.

- **If you do not receive an email by then, please check your spam/junk mail before you resend another verification email.**

- **AFTER RECEIVING YOUR VERIFICATION EMAIL, PLEASE FOLLOW THE CONFIRMATION LINK**

- This will ensure that your account has been setup successfully.




STEP 2


- (A) • **GET AS CLOSE TO YOUR WIFI ROUTER AS POSSIBLE TO INSTALL PRODUCT**
- (B) • **PLUG IN YOUR DEVICE** (The light on the back of the motion sensor will blink)
- (C) • **CONNECT YOUR MOBILE DEVICE TO YOUR PRIMARY WIFI NETWORK.**




(B) Plug in Device



(C) Android WiFi



(C) Apple WiFi




(D) Log In

- (D) • **GO BACK TO THE SIMPLE HOME APP TO SIGN IN**


IPHONE USERS (Android users skip to next page)

STEP 3


- A. **PRESS THE ADD BUTTON [+] ON THE BOTTOM OF THE SCREEN TO ADD YOUR DEVICE**



- B. **SCAN YOUR QR CODE LOCATED ON THE HANGTAG INSIDE THE BOX OR ON THE BACK OF THE DEVICE**



- C. **MAKE SURE PRIMARY NETWORK IS DISPLAYED CORRECTLY**
D. **ENTER NETWORK PASSWORD**
E. **CHOOSE A DEVICE NAME** (*Location based names like Garage, Basement, and Attic work great!*)
F. **CLICK THE CHECK MARK AT THE TOP RIGHT CORNER TO BEGIN PAIRING**



- G. **GO TO YOUR WIFI NETWORK'S LIST AND SELECT "MOTION" FROM YOUR WIFI LIST.**
- This will replace your Wifi Network name. Please wait for it to successfully connect. Once connected, return to your Simple Home App. Final WIFI pairing of your product may take two to five minutes. Then once it connects, the app should direct you back to the home screen.
- If the app does not refresh after installation is complete, please shut down the app and restart your device.


• TO CONNECT OTHER DEVICES

- Follow steps 1-3 to connect your other devices.

ANDROID USERS

STEP 3


A. PRESS THE ADD BUTTON [+] ON THE BOTTOM OF THE SCREEN TO ADD YOUR DEVICE





B. SCAN YOUR QR CODE LOCATED ON THE HANGTAG INSIDE THE BOX OR ON THE PRODUCT



C. ENTER YOUR WIFI INFO (YOUR PRODUCT NAME, NETWORK, AND PASSWORD)
(Do not click the checkmark or click out of the Simple Home App)






D. PULL DOWN THE NOTIFICATION BAR, CLICK THE SETTINGS ICON AND THEN NAVIGATE TO WIFI SETTINGS





E. FIND THE PRODUCT YOU JUST SCANNED ON YOUR WIFI NETWORK SETTINGS LIST AND CLICK ON IT. ONCE THE PRODUCT SHOWS CONNECTED MOVE TO NEXT STEP

F. RETURN TO THE SIMPLE HOME APP. TAP THE CHECKMARK ON THE TOP RIGHT SIDE OF THE APP



G. SCREEN WILL OPEN SHOWING:

- STEP 1 OF 3
- DEVICE CONNECTING TO INTERNET
- ADDING DEVICE TO NETWORK
- SUCCESS



FEATURES OF THE MOTION SENSOR IN THE SIMPLE HOME APP

- Once setup is complete, press the sensor icon in the app's home screen. You are then going to see all the sensors connected. (Figure 1)
- Press on the green arrow to enter the sensor's settings (Figure 2)
- At the bottom of the page you are going to see three icons (Figure 2)
- Settings Icon: You can name your device. (Figure 3)
- Favorites Icon: Can select item to appear on the "Favorites List" for easy access. (Figure 4)
- Trash Icon: Allows you to delete the Simple Home product from your device. This also allows you to install this device in another location or in another WiFi Network. (Figure 5)




Figure 1




Figure 2




Figure 3




Figure 4




Figure 5




DEVICE STATUS

Checking the status of your Simple Home Product is easy! For any device simply click your device's icon on the home screen to view it's status. From there you will see a little arrow next to the device name. The color shows the status as well as the line beneath your device's nickname.

Green Arrow- Device is connected and online

Gray Arrow- Device is connecting

Red Arrow- Device is disconnected and offline



Trouble Shooting:

The reset pinhole is located on the bottom of the camera. You will need a paper clip or pen to push the reset button. If you can, delete the device from the app. Log out of your app and restart your phone. Press and hold the reset button for 8 seconds and the device should appear on the WiFi Network List. Log back into the app and reconnect the device like normal. If you are still having trouble please call: 855-999-8041 or visit GoSimpleHome.com/Youtube to see an easy to install tutorial.



FAQ:

Q: How do I add a new device into the app?

A: On the "All Devices" screen press the + sign at the bottom.

Q: How do I locate the QR code to set up my device?

A: Located on a hangtag inside the box and on the actual product

Q: What are 'Groups'?

A: Groups are a way for you to group items together.

Examples of groups could be; Upstairs, Outside, Kitchen, Playroom, Bedroom, Vacation Home . . .

Q: Can I combine devices from my different homes in one app?

A: Yes! If you are putting devices in different geographical locations then you can access them all within the Simple Home App without switching between locations. Here is a good place to use groups to separate the different locations, like Home and Vacation Home.

Q: What are 'Favorites'?

A: Favorites are where you can have the devices you use the most show up. To add a device to a favorite, simply press the little star on the device screen.

Q: How to see more options and settings for the sensor?

A: Press the 3 little dots in a circle on the bottom right corner of the sensor bar.

Q: What are 'Actions'?

A: Actions are our way of saying "If this happens then that happens." An example would be: If the motion detector detects motion, then the LED should turn on.

Q: What does it mean when LED on items blink?

A: If the indicator blinks blue and red it is resetting, once it is finished pairing the light will stay on.

Q: How do I get more help?

A: We are always here to help! Email us at Support@gosimplehome.com or call our customer service at 855-999-8041