



**Peloton Cycle Console**  
**Model No.: 001**

**User Manual**

Revision Draft  
2013/05/03



Welcome to the Peloton family!

We know that receiving these big boxes can be intimidating and so, before you do anything, we invite you to start your journey here:

**<http://pelotoncycle.com/welcome>**


We look forward to seeing you in class.

- *The Peloton Team*


# Basic Info

## Getting to Know Your Cycle Console

### Peloton Console Layout



### Peloton Console Rear View



## Getting Around Your Cycle console

- There are different ways to navigate around the Home screen, menus and application screens on your Cycle console. You can also change the screen orientation of the Cycle console as well..

- **Touch**







When you want to type using the onscreen keyboard, select items onscreen such as Join Class and personal profile icons and touch them with your finger.

- **Swipe or slide**

To swipe or slide means to quickly drag your finger vertically or horizontally across the screen.

- **Soft Key functions and status bar**

Touch the control keys on the front panel of your cycle console to do the following:

Key	Function
HOME 	<ul style="list-style-type: none"><li>• While on any application or screen, touch to return the main Home screen</li></ul>
BACK 	<ul style="list-style-type: none"><li>• Touch to go back to the previous screen, or to close a dialog box, options menu, or close the Notifications panels.</li><li>• Touch and hold to return to the main screen of the current application</li><li>• When the onscreen keyboard is open, touch to close the onscreen keyboard</li></ul>
Time 	<ul style="list-style-type: none"><li>• Display Local Time</li><li>• There is Date and Time in the setting, it will be change by time zone an user define.</li></ul>
Ethernet 	<ul style="list-style-type: none"><li>• Ethernet status icon</li><li>• There is Ethernet menu in the setting, it will connect to Ethernet automatically by connecting RJ45 Ethernet cable.</li></ul>
Wi-Fi 	<ul style="list-style-type: none"><li>• Wi-Fi status icon</li><li>• There is Wi-Fi menu in the setting, it could be configure to connect AP.</li></ul>
BT 	<ul style="list-style-type: none"><li>• Bluetooth status icon</li></ul>

# Getting Started

Once you've charged the DC adapter, you can turn on your Cycle Console and start using it.

## Turn your Cycle console on and off


### To turn on the Cycle console

Press the **POWER** key on the top side of the Cycle console.


### To turn off the Cycle console

- 1 Press and hold the **POWER** key until the **Power off** options menu opens.
- 2 Touch **OK** when prompted to turn off the Cycle console.

## Set up your Cycle console for the first time




When you turn on the Cycle console for the first time, you will be requested to connect to your Internet connection if any.




Please follow the instruction showed on the Cycle console.

## Home Screen



The Home screen is your starting point for using the applications on your Cycle console. You can control the icons on Home screen to process application.

# Settings

Press Status Bar on bottom Right of Cycle console screen, then touch  to open the Notification tab, and then touch Settings

<b>Ethernet configuration</b>	Configure your Cycle console's Ethernet connections,
<b>Wi-Fi</b>	Configure your Cycle console's WLAN connections,
<b>Bluetooth</b>	Configure your Cycle console's BT connections,
<b>Sound</b>	Set the notification ring tones
<b>Display</b>	Set the screen brightness and screen timeout.
<b>Storage</b>	Check internal Storage and Available storage
<b>Apps</b>	Manage applications in system and check memory status
<b>Security</b>	Select the password visible, or set the screen unlock pattern
<b>Language &amp; keyboard</b>	Set the operating system language and region. You can also set onscreen keyboard options.
<b>Backup &amp; Reset</b>	Backup the personal settings and other application data, restore the backed up and back to the factory setting
<b>Add Accounts</b>	Sync your data with Google services.
<b>Date &amp; time</b>	Set the date, time, time zone, and date or time format.
<b>About Cycle console</b>	View the Cycle console status such as the network type. You can also view the legal information and software version of your Cycle console.

## Ethernet configuration

Ethernet connect will automatically connect to network and when you insert RJ45 connector. You can Configure Ethernet connections for static IP, or DHCP etc, To uncheck option to Turn Off Ethernet automatic connection The internet connection will use Ethernet when Wi-Fi is Turn On.

## WLAN connection

Wi-Fi can only be used when it connects with home Wi-Fi Access Point (AP) or a free unsecured Wi-Fi hotpot. Under "Wireless & networks", tap "Wi-Fi" to turn it on. After a moment, your Wi-Fi network list should populate. If you need to rescan for available networks, tap "scan"

- **Turn on WLAN**

Tap “Settings” → then “Wireless & networks” → “Wi-Fi” to turn on Wi-Fi. Your Cycle console lists the networks it finds within range. Tap a network to connect. If necessary, enter Network SSID, Security, and Wireless password, and tap “Connect”. When your Cycle console is connected to the network, the wireless indicator appears in the status bar. Waves indicate connection strength.

## **BT connection**

- **Make device discoverable:**

You must pair your Cycle console with a device before you can connect to it. Once you pair your Cycle console with a device, they stay paired unless you unpair them. Under “Settings”, choose “Bluetooth”. Tap Bluetooth to turn on it and tap “Search for devices”. The Bluetooth indicator then appears in the status bar.

- **Scan for devices**

After scanning, there will be a list of the IDs of all available Bluetooth devices in range. If the device you want to pair with isn't in the list, ensure that the other device is turned on and set to be discoverable.

- **Pair with the Bluetooth device**

Tap the name of an available Bluetooth device to pair with. In the popup “Bluetooth pairing request” dialog, type a PIN. If the pairing is successful, your Cycle console connects to the device.

You can touch the right icon to unpair the device.

- **Note:** After pairing, it shows under the Bluetooth device “Paired but not connected”, but file transmission is still possible.



- **Adjusting the Volume**

Adjusting the Media volume changes the volume level of sound notifications and music or video playback.

**To adjust the media volume**

When playing music or watching video, touch the volume scroll bar to adjust the media volume or press volume keys directly to adjust. The Music/video volume window appears on the screen to display the volume level.


You can also adjust the media volume on the Settings screen.


1. Press **HOME**, then press **MENU**, and then touch **Settings**.
2. Touch **Sound >Volume**.
3. When the Media volume window appears, move the slider to the left (to lower the volume) or to the right (to increase the volume).
4. Touch **OK** to close the window.

**Using the Onscreen Keyboard**

When you start a program or select a field that requires text or numbers, the onscreen keyboard becomes available.

Touch to enter letters





**Tips**

- When you do not need the keyboard, you can close it by pressing **BACK**. To show the keyboard again, touch a text box onscreen.
- If you need to insert or delete a character, use the finger to position the cursor next to the character you want to edit.

**Note** The available keys on the keyboard will be different depending on the current text field selected. For example, in Browser, when you are in the URL field, some keys at the bottom row are replaced with alternate keys (for example, .com key) to make it faster for you to type web addresses.

## NOTICES

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

1. Reorient or relocate the receiving antenna.
2. Increase the separation between the equipment and receiver.
3. Connect the equipment into an outlet on a circuit different from that to which the receiver is needed.
4. Consult the dealer or an experienced radio/TV technician for help.

Warning: Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user authority to operate the equipment.

### CAUTION:

1. To comply with FCC RF exposure compliance requirements, a separation distance of at least 20 cm must be maintained between the antenna of this device and all persons.
2. This Transmitter must not be co-located or operating in conjunction with any other antenna or transmitter



This product is ANT+ certified and is compatible with ANT+ sensors that support heart rate monitoring.



## **SERVICE & SUPPORT**

Peloton Cycle  
227 West 29<sup>th</sup> Street, Ninth Floor  
New York, NY 10001 USA

<http://support.pelotoncycle.com>  
[support@pelotoncycle.com](mailto:support@pelotoncycle.com)