

# **INTERTEK TESTING SERVICES**

---

## **EXHIBIT 7**

### **INSTRUCTION MANUAL**


## INTERTEK TESTING SERVICES

---

### 7.0 Instruction Manual

Attached is a preliminary copy of the Instruction Manual.

This manual will be provided to the end-user with each unit sold/leased in the United States.



## CRAYOLA FUN FM MICROPONE

### INTRODUCTION

Your Crayola Fun FM Microphone is designed to be used with FM radios as a wireless microphone.

### CONTROLS

1. Microphone
2. Talk Button
3. Power Indicator Light
4. Antenna
5. Battery Compartment Cover

### BATTERY INSTALLATION

- Open the Battery Compartment Cover (5) using a screwdriver and insert 2 x AA (UM-3) batteries as shown.
  - Replace the Battery Compartment Cover (5).
- Note: The Microphone can be tested for operation by pressing the Talk Button (2) and the Power Indicator Light will be turned on.

- \* Do not mix old and new batteries.
- \* Do not mix alkaline, standard (carbon-zinc) or rechargeable (nickel-cadmium) batteries.

### DRAWINGS

### OPERATION

- Use any good FM radio. Turn the radio on and face the radio towards you. Adjust the radio volume to a low level.
  - Place the Microphone close to the radio, press the Talk Button (2) and speak into the Microphone (1) in a normal voice while tuning your FM radio back and forth across the 100 ~0.5 on the tuning dial.
  - After the FM radio is tuned to the microphone moves 5 feet away from the radio. You may need to re-adjust the tuning for the best reception.
  - When using the Microphone at a distance of 10 feet or more from the radio, it may be necessary to increase the radio volume and carefully tune the radio again for best reception.
- Note: For best results, stand 5 to 10 feet away from the radio with the Antenna (4) pointed towards the radio.

FCCID: LCH543998

## IMPORTANT NOTES

- Your Crayola FM Microphone is for use with FM radios only and will not work on the AM or other bands.
- The microphone is not tunable. The FM radio tuning range is 100 ~0.5 on the radio dial.
- The reception of the microphone may be affected by the environment, i.e. metal structure or the movement of people between the microphone and the radio.
- The reception of the microphone can also be affected by the batteries conditions from both of the microphone and the radio.
- If the microphone is not to be used for an extended period, remove the batteries from the unit.
- For best results use only alkaline batteries.
- Do not expose the microphone to excessive heat, moisture or rain.

## WARNING

The Manufacturer is not responsible for any radio or TV interference caused by unauthorized modifications to this equipment. Such modifications could void the user's authority to operate the equipment.

FCCID: L0H543888

**FCC REQUIREMENTS**

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- 1.) This device may not cause harmful interference, and
- 2.) This device must accept any interference received, including interference that may cause undesired operation.

**Warning:**

Changes or modifications to this unit not expressly approved by the appty responsible for compliance could void the user's authority to operate the equipment.

**Note:**

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is needed.
- Consult the dealer or an experienced Radio/TV technician for help.

FCCID: L0H543999