


TREE ASSEMBLY INSTRUCTIONS

Congratulations on purchasing your new tree from **Polygroup®**! This tree comes with Quick Set® and Simple Shape™ technology, which takes less than 10 minutes to set up and light up! Carefully follow the instructions below on how to quickly and easily set up your new tree:


1. Choose an appropriate location near a wall outlet.
2. Assemble the tree stand and place on a level surface. **(See Fig. A)**

Fig. A - Tree Stand Assembly




Unfold tree stand legs. Then slide the locking disc down until it snaps into place.

Fig. B - Tree and Light Assembly



3. Each tree section is numbered with a sticker. Please identify all sections before assembling.
4. Assemble the tree from the bottom to the top. Remove protective cap, and insert the center pole into the stand. Then slot together the remaining poles securely until the tree top is installed.
5. Plug the adaptor into the wall outlet **(See Fig. B)**. Your entire tree should now be lit.
6. This is a Simple Shape™ tree, which shaping is not required. Just slightly upswEEP all tips and shift branches to fill in any gaps for a fuller, uniform look. Your Christmas tree is now ready to be decorated.


Illumination Color Blast™ Remote Control Instructions



1. Remove the insulation tab.
2. Tap to turn lights ON or OFF.
3. Tap the Color Wheel to display all lights in one color as steady glow effect. Sweep around the color wheel to select your desired color.
4. Tap to display all lights in warm white color as steady glow effect.
5. Tap to display all lights in multicolor as steady glow effect.
6. Tap or to select from different preset lighting effects:
 - Warm White Twinkle
 - Color Twinkle
 - Fading
 - Multi Ball
 - Color Switching
 - Collision
 - Wave
 - Waterfall
 - Rainbow Shower
 - Rainbow
7. Tap or to adjust the speed of preset lighting effect.
8. Tap or to adjust the brightness of the lights.

Battery Replacement

1. Slide open the battery cover.
2. Replace two (2) new CR2032 button cell batteries with correct polarities (+ and -) as indicated.
3. Slide the battery cover closed.



NOTES:

- (1) Remove all batteries when the remote control will be left unused for an extended period of time, or when depleted.
- (2) Dispose of all exhausted batteries properly as per directions on batteries.
- (3) **WARNING: SMALL PARTS, KEEP AWAY FROM CHILDREN.**
- (4) Use only CR2032 button cell batteries for this remote control.
- (5) Clean the battery contact surfaces prior to battery installation.
- (6) Do not dispose of batteries in fire - batteries may explode or leak.

STORAGE INSTRUCTIONS


1. Unplug from the wall outlet. Then remove all ornaments and decorations.
2. Disassemble the tree from the top to the bottom. Gently lift the center pole straight up to remove from the section below, and fold all branches toward the pole. Continue until the tree bottom is removed from the tree stand.
3. Close the protective caps on the poles to avoid damaging the internal parts (**See Fig. C**).
4. Carefully place all tree sections into the shipping box and tape it shut.
5. Store your tree in a cool, dry place away from sunlight. Exposure to excessive heat or humidity may damage your tree.

**TROUBLESHOOTING TIPS****If Tree Does Not Illuminate / Some Bulbs Do Not Light or Flicker**

1. Check to make sure that the adaptor is properly plugged into the wall outlet as indicated in **Fig. B**.
2. Turn the center poles gently to make sure that pole-to-pole connection is secured.
3. Disconnect from power source. Then check for loose, broken or missing bulbs, and replace as needed.

Loose Hinge Pin

1. Place the branch into the slot of the bracket.
2. Insert a new hinge pin (included) through the hole, and secure with a retainer washer (included). (**See Fig. D**)

**SPARE PARTS**

This tree includes hinge pins/washers, and spare bulbs. If extra parts are needed, please contact our customer service center.

⚠WARNING

1. Use only the power adaptor supplied with this product. Using a different adaptor will damage the product and cause fire or electrical shock hazards.
2. For indoor use only.

IMPORTANT SAFETY INSTRUCTIONS

When using electrical products, basic precautions should always be followed including the followings:

- a) Read and follow all safety instructions that are on the product or provided with the product.
- b) Do not use this product outdoors.
- c) This seasonal use product is not intended for permanent installation or use.
- d) Do not mount or place near gas or electric heaters, fireplace, candles or other sources of heat.
- e) Do not secure the wiring of the product with staples or nails, or place on sharp hooks or nails.
- f) Do not let lamps rest on the power cord or on any wire.
- g) Unplug the product when leaving the house, when retiring for the night, or if left unattended.
- h) This is an electric product – not a toy! To avoid risk of fire, burns, personal injury and electric shock it should not be played with or placed where small children can reach it.
- i) Do not use this product for other than its intended use.
- j) Do not hang ornaments or other objects from cord, wire, or light string.
- k) Do not close doors or windows on the product or extension cords as this may damage the wire insulation.
- l) Do not cover the product with cloth, paper or any material not part of the product when in use.
- m) This product is equipped with push-in lamps. Do not twist lamps.
- n) Do not expose the product to humidity.
- o) **SAVE THESE INSTRUCTIONS.**


Use and Care Instructions

- a) Before using or reusing, inspect the product carefully. Discard any products that have cut, damaged or frayed wire insulation or cords, cracks in the lampholders or enclosures, loose connections, or exposed copper wire.
- b) This product should be fully disassembled for storage to avoid any undue strain or stress on conductors, connections and wires. Do not leave any parts of the product (including tree sections and the tree stand) connected when not in use.

Lamp replacement

Step 1. Grab the adaptor to disconnect from power source - do not unplug by pulling the extension cord.

Step 2. Lift up the lamp lock tab, then pull the lamp and its plastic base straight out from the lampholder.



Step 3. Replace with a new spare LED lamp provided with this tree.



(For reference only)

CUSTOMER SERVICE FOR CHRISTMAS TREES

For any questions, assistance, or missing parts, **Do Not Return To Place Of Purchase.** Please contact us at 1-888-919-0070 or visit our website at www.polygroup.com. One of our customer service representatives will be happy to assist you.

Tree ID#: _____	Customer Name: _____
Tree UPC#: _____	Address (No P.O. boxes): _____
Store Purchased: _____	City & State: _____
Specify Problem: _____	Zip Code: _____
_____	Day Phone: _____
_____	Date Purchased: _____

TREE ID# IS LOCATED ON END PANEL OF BOX. TREE ID# IS REQUIRED WHEN REQUESTING REPLACEMENT PARTS.

FCC notices:

WARNING: Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the users authority to operate the equipment. This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) this device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

Statement

This device contains licence-exempt transmitter(s)/receiver(s) that comply with Innovation, Science and Economic Development Canada's licence-exempt RSS(s).

Operation is subject to the following two conditions:

- (1) this device may not cause interference, and
- (2) this device must accept any interference, including interference that may cause undesired operation of the device.

This device comply with the requirement of the RF exposure.

Déclaration

Ce dispositif contient de(s) émetteur(s)/récepteur(s) sans licence conforme(s) à la norme d'exemption de licence pour les RSS de Innovation, Sciences et Développement économique Canada.

L'exploitation est autorisée aux deux conditions suivantes :

- (1) l'appareil ne doit pas produire de brouillage, et
- (2) l'utilisateur de l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.

Ce dispositif est conforme aux exigences d'exposition aux RF.