

PRIME[®]


Indoor and Outdoor Remote Control Outlets w/Wireless Transmitter

Model: TX6BBC

Each Box Contains:

- 2 White Indoor Remote Receivers
- 1 Black Outdoor Remote Receiver
- 1 6-Button Remote Control (3V CR2032 Battery Included)
- 1 Instruction Manual

I = On
O = Off
I, II, III = Corresponding Receiver



Required Tool:
Small Phillips Screwdriver (not included)



INSTRUCTIONS

Indoor Remote Control Unit

1. Plug the white indoor receiver into a grounded 3-wire indoor outlet.
2. Plug devices to be controlled into the receiver.
3. Turn the devices on.
4. Make sure there is power to the outlet the receiver is plugged into.
5. Remove the plastic battery tab from the battery compartment in the back of the remote control to activate CR2032, 3V pre-installed battery.
6. Press the ON (I) button for the corresponding receiver to activate the outlet.

Outdoor Remote Control Unit

1. Plug the black outdoor receiver into a grounded 3-wire outdoor or indoor outlet.

2. Plug devices to be controlled into the receiver.
3. Turn the devices on.
4. Make sure there is power to the outlet the receiver is plugged into.
5. Remove the plastic battery tab from the battery compartment in the back of the remote control to activate CR2032, 3V pre-installed battery.
6. Press the ON (I) button for the corresponding receiver to activate the outlet.

BATTERY REPLACEMENT

1. To replace spent batteries, use a Phillips screwdriver to unscrew the battery compartment cover on the backside of the remote control. The screw loosens when turning it counterclockwise.
2. After loosening the screw open the compartment door, and remove the battery with your finger.
3. Insert a new CR2032 3V Button-Cell Battery with the "+" polarity mark facing up.
4. Close the battery compartment door.
5. Use the Phillips screwdriver and rotate clockwise to close the battery compartment.

SYNCING THE REMOTE

1. Plug receiver into a properly grounded outlet.
2. The receiver LED flashes slowly for 1 minute while pairing.
 - a. If the receiver LED is not flashing or goes out after 1 minute, unplug the receiver from the outlet, plug it back in and start over from Step 1.
3. While the receiver LED is flashing, press the corresponding ON button on the remote for 5 seconds while pointing it at the receiver until the receiver LED becomes solid red. Pairing is then complete.
4. To test the remote:
 - a. Press the ON button on the remote, the LED on the corresponding receiver will turn on and stay on.
 - b. Press the OFF button on the remote, the LED on the receiver will turn off and stay off.
 - c. Repeat steps 4a, and 4b above for remaining receivers.

RESYNC INSTRUCTIONS

1. Plug receiver into a properly grounded outlet.
2. While the receiver LED is flashing, press any button on the remote for 5 seconds while pointing it at the receiver until the receiver LED becomes solid red.

IMPORTANT SAFETY INSTRUCTIONS

WARNING: This product contains a button cell battery. If swallowed, it could cause severe injury or death in just 2 hours. Seek medical attention immediately.

CAUTION: Danger of explosion if battery is incorrectly replaced. Batteries may explode or leak, and cause burns or injury if disposed in fire, mixed with a different battery type, inserted backwards, or disassembled.

1. Read these instructions.
2. Keep these instructions.
3. Heed all warnings.
4. Follow all instructions.
5. Do not use this apparatus near water.
6. Clean only with dry cloth.
7. Install in accordance with the manufacturer's instructions.
8. Do not install near any heat sources such as radiators, heat registers, stoves or other apparatus (including amplifiers) that produce heat.

- Replace only with the same or equivalent type of battery.
- Keep new and used batteries away from children.
- If the battery compartment is not closed securely, stop using the product and keep it away from children.
- If you think batteries might have been swallowed or placed inside any part of the body, seek immediate medical attention.
- Always purchase the correct size and grade of battery most suitable for the intended use.
- Always replace the whole set of batteries at one time, taking care not to mix old and new ones, or batteries of different types.
- Clean the battery contacts and also those of the device prior to battery installation.
- Ensure the batteries are installed correctly with regard to polarity (+ and -).
- Read and follow all instructions on the product and/or operating instructions provided with the product.
- Keep away from children and pets.
- Unplug this apparatus during lightning storms or when unused for long periods of time.

 For recycling and disposal of batteries to protect the environment, please check the Internet or your local phone directory for local recycling centres and/or follow local government regulations.

TROUBLESHOOTING

Problem:

The remote control doesn't work.

Possible Cause:

- The remote control is not synced properly.
- The distance between the remote control and the receiver is too far or the view is impeded.
- Battery is weak or spent.

Corrective Action:

- Move closer to the receiver when using the remote control. The range and response will be impeded if the signal is going through solid objects like walls, doors, trees or heavy furniture.
- Replace the battery in the remote control with a new 3V CR2032 battery. Follow the steps outlined in the Battery Replacement section of this manual.
- Re-sync the remote to the receiver as outlined in the Resync Instructions section of this manual.

FCC REGULATORY STATEMENT

WARNING: Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user authority to operate the equipment.

This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions:

1. This device may not cause harmful interference, and
2. This device must accept any interference received, including interference that may cause undesired operation.

Notes: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to

provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

1. Reorient or relocate the receiving antenna.
2. Increase the separation between the equipment and receiver.
3. Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
4. Consult the dealer or an experienced radio/TV technician for help.

RF WARNING STATEMENT

The device has been evaluated to meet general RF exposure requirements. The device can be used in portable exposure conditions without restriction.

IC REGULATORY STATEMENT

Under Industry Canada regulations, this radio transmitter may only operate using an antenna of a type and maximum (or lesser) gain approved for the transmitter by Industry Canada. To reduce potential radio interference to other users, the antenna type and its gain should be so chosen that the equivalent isotropically radiated power (e.i.r.p.) is not more than that necessary for successful communication.

This device complies with Industry Canada licence-exempt RSS standard(s). Operation is subject to the following two conditions: (1) this device may not cause interference, and (2) this device must accept any interference, including interference that may cause undesired operation of the device.

Le présent appareil est conforme aux CNR d'Industrie Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes: (1) l'appareil ne doit pas produire de brouillage, et (2) l'utilisateur de l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.