

GPS Tracker GV500MA

User Manual

TRACGV500MAUM001

Version:1.01



International Telematics Solutions Innovator

www.queclink.com

Document Title	GV500MA User manual
Version	1.02
Date	2018-11-26
Status	Release
Document Control ID	TRACGV500MAUM001

General Notes

Queclink offers this information as a service to its customers, to support application and engineering efforts that use the products designed by Queclink. The information provided is based upon requirements specifically provided to Queclink by the customers. Queclink has not undertaken any independent search for additional relevant information, including any information that may be in the customer’s possession. Furthermore, system validation of this product designed by Queclink within a larger electronic system remains the responsibility of the customer or the customer’s system integrator. All specifications supplied herein are subject to change.

Copyright

This document contains proprietary technical information which is the property of Queclink Limited., copying of this document and giving it to others and the using or communication of the contents thereof, are forbidden without express authority. Offenders are liable to the payment of damages. All rights reserved in the event of grant of a patent or the registration of a utility model or design. All specification supplied herein are subject to change without notice at any time.

Copyright © Shanghai Queclink Wireless Solutions Co., Ltd. 2013

Contents

Contents	2
Table Index	3
Figure Index	4
0. Revision history	5
1. Introduction	6
1.1. Reference	6
1.2. Terms and Abbreviations	6
2. Product Overview	7
2.1. Description	7
2.2. Parts List	8
2.3. Interface Definition	8
3. Getting Started	9
3.1. Opening the Case	9
3.2. Closing the Case	10
3.3. Installing a SIM Card	10
3.4. Device Status LED	11
3.5. Bluetooth	11

Table Index

TABLE 1: GV500MA PROTOCOL REFERENCE	6
TABLE 2: TERMS AND ABBREVIATIONS	6
TABLE 3: PART LIST	8
TABLE 4: DESCRIPTION OF OBD II CONNECTIONS	8
TABLE 5: DEFINITION OF DEVICE STATUS AND LED	11

Figure Index

FIGURE 1: APPEARANCE OF GV500MA	7
FIGURE 2: THE OBD II CONNECTOR ON THE GV500MA	8
FIGURE 3: OPENING THE CASE	9
FIGURE 4: CLOSING THE CASE	10
FIGURE 5: SIM CARD INSTALLATION	10
FIGURE 6: GV500MA LED ON THE CASE	11

0. Revision history

Revision	Date	Author	Description of change
1.00	2018-11-22	Vincent.tang	Initial

1. Introduction

The GV500MA is a vehicle tracking device that plugs into a vehicle's OBD II port. Its compact design allows easy installation. Its built in GNSS receiver has superior sensitivity and fast time to first fix. Its subsystem supports GPRS/EGPRS/LTE allowing the GV500MA's location to be monitored in real time or periodically tracked by a backend server and mobile devices. Its built in 3-axis accelerometer allows motion detection , BLE device allows near field location and communication, and extended backup battery life through sophisticated power management algorithms. System integration is straightforward as complete documentation is provided for the full featured @Track protocol. The @Track protocol supports a wide variety of reports including; emergency, geo-fence boundary crossings, driver behaviour, low battery or scheduled GNSS position and many other useful functions.

The device contains FCC ID: XMR201707BG96.

1.1. Reference

Table 1: GV500MA Protocol Reference

SN	Document name	Remark
[1]	GV500MA @Track Air Interface Protocol	The air protocol interface between GV500MA and backend server.

1.2. Terms and Abbreviations

Table2: Terms and Abbreviations

Abbreviation	Description
PWR	External Power Supply
GND	Ground
OBD	On-Board Diagnostics
SAE	Society of Automotive Engineers
HS_CAN	High Speed CAN
MS_CAN	Medium Speed CAN

2.2. Parts List

Table 3: Part List

Name	Picture
GV500MA Locator	49.49mm*48.5mm*21.9mm

2.3. Interface Definition

The GV500MA has an OBD II connector. The sequence and definition of the OBD II connector are shown in following figure:



Figure 2. The OBD II connector on the GV500MA

Table 4: Description of OBD II Connections

Index	Description	Comment
1	reserved	
2	reserved	
3	NC	No connect
4	GND	Power and digital ground
5	GND	Power and digital ground
6	NC	No connect
7	reserved	
8	reserved	
9	reserved	
10	reserved	
11	NC	No connect
12	reserved	
13	reserved	
14	NC	No connect

15	reserved	
16	PWR	External DC power input, 8-32V

3. Getting Started

3.1. Opening the Case

Insert the triangular-pry-opener into the gap of the case as shown below, push the opener up until the case unsnapped.



Figure 3. Opening the Case

3.2. Closing the Case

The step of closing case is shown as following:



Figure 4. Closing the Case

3.3. Installing a SIM Card

Open the rubber plug and insert the SIM card into the holder as shown below



Figure 5. SIM Card Installation

3.4. Device Status LED



Figure 6. GV500MA LED on the Case

Table 5: Definition of Device status and LED

LED	Device status	LED status
CELL (note1)	Device is searching GPRS/EGPRS/LTE network	Fast flashing (Note3)
	Device has registered to GPRS/EGPRS/LTE network.	Slow flashing (Note4)
GNSS (note 2)	GNSS chip is powered off	OFF
	GNSS sends no data or data format error.	Slow flashing
	GNSS chip is searching GNSS info.	Fast flashing
	GNSS chip has gotten GNSS info.	ON

Note:

- 1 - CELL LED cannot be configured.
- 2 - GNSS LED can be configured to turn off after a period of time using the configuration tool
- 3 - Fast flashing is about 60ms ON/ 780ms OFF
- 4 - Slow flashing is about 60ms ON/ 1940ms OFF

3.5. Bluetooth:

The device role of Bluetooth could be Master and Slave.

When the device role is Slave, the device will provide below services: device information service, battery information service, virtual serial port service. Other devices can read or use these services after connecting devices.

When the device role is Master, the device will provide below services: the others devices can read or use the above services after connecting devices, connect the designated device to read the data or related information of the designated Bluetooth devices. After reading the data, the server can be reported to the server by the corresponding message.

NOTE:

The frequency for LTE:

Band2:1850-1910MHz,Band4:1710-1755MHz,Band5:824-849MHz.

Band12:699-716MHz,Band13:777-787MHz, Band26:814-849MHz.

The LTE module FCC ID: XMR201707BG96.

The frequency for 2G:

GPRS/EGPRS850:824-849MHz

GPRS/EGPRS1900:1850-1910MHz

FCC Statement

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1)

This device may not cause harmful interference, and

(2) This device must accept any interference received, including interference that may cause undesired operation.

FCC Radiation Exposure Statement:

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment .This equipment should be installed and operated with minimum distance 20cm between the radiator& your body.