

# Radio Control Fire Engine with Bump

## INSTALLING BATTERIES


**WARNING:** Dispose of old batteries promptly and properly. Do not burn or bury them.

### CAUTIONS:

- Use only fresh batteries of the required size and recommended type.
- If you do not plan to use the Fire Engine for a week or more, remove the batteries from both the transmitter and the Fire Engine. Batteries can leak chemicals that can destroy electronic parts.


## CONTROLLER BATTERY INSTALLATION

Use a Phillips head screw driver to remove the battery compartment cover located on the back of the controller. Insert 1 "9V." alkaline battery in the correct position as marked in compartment. Replace cover and screw.



## FIRE ENGINE INSTALLATION

1. Follow all operating instructions and precautions to charge your "6V" rechargeable battery pack.  
Note: most rechargeable batteries need charging when newly purchased.
2. Insert fully charged battery pack into battery compartment the (+) and (-) ends match. Use a coin or Phillip screw to turn the battery lock and secure the battery in place.




## RADIO CONTROL DRIVING

1. Slide ON/OFF to ON underneath the Fire Engine.
2. Fully extend the antenna on the transmitter and slide OFF/ON on the transmitter to ON. The indicator on the transmitter lights.
3. Use the transmitter's control levers to move and steer the Fire Engine.
4. When you finish driving the Fire Engine, slide OFF/ON on the Fire Engine and the transmitter to OFF.

## FIRE ENGINE FUNCTION CONTROLS

Install fully charged rechargeable batteries into the Fire Engine battery compartment and transmitter in the correct position as indicated. Install transmitter antenna as indicated. Move power switches located underneath the Fire Engine and front of the transmitter to the "on" positions. Fully extend transmitter antenna. Place Fire Engine on a flat surface.

- To drive the Fire Engine, move "selector switch" to the left to select FireEngine operations.
  - Emergency lights will flash with siren sound when Fire Engine is moving.
  - To drive forward, move "joystick A" upward.
  - To drive in reverse, move "joystick A" downward.
  - To turn right, move "joystick A" upward and "joystick B" to the right.
  - To reverse left, move "joystick A" downward and "joystick B" to the left.
  - To reverse right, move "joystick A" downward and "joystick B" to the right.
  - To operate the ladder, move "selector switch" to the right to select ladder operations.
  - To extend and raise ladder, move "joystick A" to upward
  - To retract and lower ladder, move "joystick A" downward.
  - To rotate ladder to the right, move "joystick B" to the right.
  - To rotate ladder to the left, move "joystick B" to the left.
  - To squirt water, push the water button locate on the controller.
- Cautions : Do not point water pump at the eyes.



**NOTE:** This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference; and (2) This device must accept any interference received, including interference that may cause undesired operation. Warning: Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures: Reorient or relocate the receiving antenna. Increase the separation between the equipment and receiver. Connect the equipment into an outlet on a circuit different from that to which the receiver is needed. Consult the dealer or an experienced radio/TV technician for help.