

General Operation

The control panel	Card 1
Using the controls	Card 2
Setting up the display	Card 3
Using CompactFlash cards	Card 4

What can I see?

Understanding the chart	Card 5
Using the chart	Card 6
Displaying additional information	Card 7
Displaying additional information (continued)	Card 8
Understanding the 3D chart	Card 9
Using the 3D chart	Card 10

Basic Navigation

Working with waypoints	Card 11
How do I get to a point?	Card 12

What is around me?

Understanding the radar	Card 13
Avoiding a collision	Card 14
Using MARPA	Card 15
AIS	Card 16

Where am I going?

Monitoring a course	Card 17
---------------------	---------

What's under the boat?

Understanding the fishfinder	Card 18
Using the fishfinder	Card 19


Other functions

Monitoring data and engines	Card 20
Viewing video images	Card 20
Navtex and Sirius Weather Data	Card 21
Sirius Weather Data (continued)	Card 22
Autopilot Control	Card 23
Understanding the digital radar	Card 24
Operating a networked E-Series Display	Card 25

General Operation

The control panel

Card 1



WARNING: NAVIGATION AID

This unit is only an aid to navigation. Its accuracy can be affected by many factors, including equipment failure or defects, environmental conditions, and improper handling or use. It is the User's responsibility to exercise common prudence and navigational judgements. This unit should not be relied upon as a substitute for such prudence and judgement.

Always keep a proper look-out.

General Operation


Using the controls

Card 2

How do the controls work?

Buttons

- Access system functions or change what you see on-screen. Within the text of this document they are written in bold capitals e.g. **WPTS/MOB**.
- Press and hold to access short cuts - see individual buttons on facing page.




Example:

This example shows the series of button and soft key presses required to change the waypoint default symbol or group.

Soft keys

- They change depending on application or function being performed.
- Press and hold **MENU** to display help information for the currently displayed soft keys.
- Press the corresponding key (below the screen) to select.
- Further soft keys may be displayed. If a key has several options, each press will highlight the next option.
- If a key displays a single value or a slider above, use the rotary control to adjust.
- Within the text of this document they are written in capitals e.g. SORT LIST.



This process of pressing buttons and soft keys to navigate to the required function, is simplified within this guide and represented by a strip e.g.



The Cursor



The Cursor appears on the screen as a white cross.



To make it easier to locate on screen, the cursor changes to a circle with a cross in it, when it is moved after a 10 second period of inactivity.



The cursor is context-sensitive. When it is placed over an object e.g. a waypoint or chart feature, it changes color and a label or information associated with the object is displayed. When you place the cursor over certain items, the soft keys change to enable you to access related operations.

Simulator:

To practice using your Display without data from a GPS, scanner or fishfinder, switch on the simulator via the System Setup menu.

General Operation


Setting up the display

Card 3


How do I select how the applications are displayed?

The applications are shown using a combination of page sets, pages and windows. There are five page sets each containing five pages with a combination of windows and applications in each. These sets can be edited to define the combination that suits your particular needs.

Any changes you make will be saved to the system. You can change these preferences as many times as you wish.




How do I select the Page Set?




Note: Alternatively you can display the Select Page Set screen via the Menu key.

How do I select a Page?




Note: Alternatively, repeatedly press PAGE until the required page is highlighted.

How do I select a Window?



To temporarily maximise active window:



? More information See the 'General Operation' chapter of the Reference Manual

General Operation

Using CompactFlash cards

Card 4



CAUTION


CompactFlash Card

In order to protect your E-Series Display and CompactFlash cards from irreparable damage, please adhere to the following:

- Fit the card the correct way around. **DO NOT** force.
- Ensure card door is firmly closed at all times.
- **DO NOT** use a metallic instrument (e.g. screwdriver or pliers) to aid card removal.
- Follow the correct procedure for removing a card (see below).
- **DO NOT** remove card during either a read or write operation.

How do I insert a CompactFlash card?

1. Check that you are using the correct type of card. Raymarine recommend Navionics Chart cards or SANDISK CompactFlash cards.
2. Open the chart card door, located on the front left of the display.
3. Insert the card as shown, with the lip of the card facing inwards. It should position easily. If it does not, **DO NOT** force it, check the direction in which the lip is facing.
4. Gently press the card home and then firmly click the chart card door shut.



How do I remove a CompactFlash card?

... with the unit powered

1. Press **MENU**. The Setup menu is displayed.
2. Use trackpad (up/down) to highlight and then (right) to select CF CARD REMOVAL. The system will now complete its checks.
3. When instructed to do so, open the chart card door and remove the card.
4. Firmly click the chart door shut and press **OK** twice.

... with the unit powered down

1. Open the chart card door.
2. Grip the card and pull to remove it from its slot.
3. Firmly click the chart card door shut.

? More information... See the 'General Operation' chapter of the Reference Manual.

What can I see?


Understanding the chart

Card 5



What can I use the chart for?

- Find where you are.
- Interpret your surroundings.
- Place waypoints at specific locations.
- Navigate to a specific point.
- Monitor where you are going.
- Record where you have been.
- Measure the distance between two points.
- Build and follow routes.
- Manage and edit routes and tracks.
- Distinguish between fixed & moving objects
- (radar overlay).
- View photographs of ports and marinas.
- View information normally contained in an almanac.
- Display an aerial photo overlay.



How do I move around the chart?

To change the scale:



- Press **RANGE (OUT)** to see a larger area of the chart.
- Press **RANGE (IN)** to see a smaller area in more detail.

To pan the chart:





- Moves cursor. When cursor reaches window edge, chart pans to a different area.
- Press and hold to pan larger areas.

How do I find where I am on the chart?



The boat symbol indicates your position.

If you cannot find your boat symbol :




The screen automatically pans to your boat's position and re-activates the motion mode (see below - 'How do I change how my boat moves on the chart').

? More information... See 'Using the Chart' chapter of the E-Series Reference Manual

What can I see? Using the chart ...

Card 6



Viewing detail on the chart

- Display additional information on a cartographic feature:
- To show/hide individual cartographic features:
- To show/hide pre-set cartographic features:



How do I change the chart orientation?

The **orientation** of the chart refers to the relationship between the chart and the direction you are travelling in. It is used in conjunction with motion mode (see below) to control how your boat and chart relate to one another and how they are displayed on screen. The default mode is **North Up** (N-UP). This displays your chart with true north upwards. As your heading changes the boat symbol moves accordingly.

If desired, you can change the orientation mode to:

- **Head Up** (H-Up) - displays chart with boat's current heading upwards. As heading changes, boat symbol remains fixed
- **Course Up** (C-Up) - chart picture stabilized, current course upwards. Boat symbol moves as heading changes.

To change the orientation mode:



How do I change how my boat moves on the chart?


How your boat moves on the screen is referred to as the **motion mode**. The default setting for the chart is **Relative Motion**. This means that your boat is fixed on the screen and the chart moves relative to your boat i.e.



If desired, you can change the motion mode to:

- **True** (TM) - the chart is fixed and the boat moves in true perspective to fixed landmasses on the screen.
- **Autorange** (AR) - selects and maintains the largest possible scale of chart that will display both the boat and the target waypoint. This option is not available when radar/chart synchronization is ON.

To change the orientation mode:



NOTE: When you pan the chart or toggle FIND SHIP/CURSOR to CURSOR, the motion mode is suspended.


? More information... See 'Using the Chart' chapter of the Reference Manual

What can I see?

Displaying additional information

Card 7


Viewing object information




You can now:

- Locate the nearest waypoint, port, port service, tidal and current stations, wreck or obstruction, to the selected position.
- Search for a named port.
- View detailed data for the selected port, tidal or current station.
- View panoramic photographs (dependent on the type of chart card in use)


Finding nearby features and services:



Displaying port services:



Displaying tidal and current details:



? More information... See the 'Using the Chart' chapter of the Reference Manual.

What can I see?


Displaying additional information (continued)

Card 8

How do I display a panoramic photo?




If you are using a suitable chart card, you can display a panoramic photo(s) of many ports and marinas. The availability of photos is indicated by the camera symbol on the chart. This symbol is placed where the photo was taken and the angle of the shot is indicated by the camera symbol.




How do I display pilot book information?

This will enable you to view detailed information normally contained in an almanac..



How do I display aerial photo overlay?



The aerial photo overlay feature will help you to interpret your environment and its features. If you are using a suitable chart card, this overlay will appear by default on 3D chart windows and can be applied to individual 2D chart windows when required.

Applying aerial photo overlay to a 2D chart:



3D - Aerial photo overlay can be switched off via the 3D Chart Setup Menu.

2D - Adjust the opaqueness level using the rotary control. Specify land only or land/sea overlay via the cartographic menu.

? More information... See the 'Using the Chart' chapter of the Reference Manual.

What can I see? Understanding the 3D chart

Card 9

FIND SHIP

GOTO

ADJUST ON
EYE CENTRE

ADJUST
ROTATE PITCH


PRESENTATION



What can I use the 3D chart for?

If you are using a suitable chart card you will be able to:

- Display a 3D view of land, sea & features.
- Interpret your surroundings.
- Synchronize the 2D and 3D chart.
- Locate where you are.
- Monitor where you are going.
- Go to an existing waypoint.
- Navigate a route.



How do I move around the 3D chart?

To change the scale:

- Press **RANGE** (OUT) to see a larger area of the chart.
- Press **RANGE** (IN) to see a smaller area in more detail.



To pan the 3d chart:

- To pan a 3D chart to a different area




To adjust rotation/pitch

1. Select rotate or pitch:



Or **ADJUST ROTATE PITCH**
Toggle control to required function


2. Adjust the rotation/pitch:



Rotates the view or changes the vertical angle of view.

Changing the view on the 3D chart

To **enhance** objects and make it easier to see their shape and position:



To **show/hide** pre-set cartographic features:



Adjust factor as required

? More information... See 'Using the 3D Chart' chapter of the E-Series Reference Manual


What can I see? Using the 3D chart ...

Card 10




How do I find where I am on the 3D chart?

Your position:



If you cannot see your boat symbol:



The 3D chart automatically redraws with the boat in forward looking view at your current position.

How do I change the motion mode?


Active motion mode

Default mode when 3D chart opened and there is a valid fix. Shows aerial view from above your boat.


Planning mode:

To view an area of the chart you are not currently in. The boat may not remain on the screen.

To change to planning mode and pan to the area of the 3D chart you want to view:




Using aerial photographs



The aerial photograph overlay helps you to interpret features in your environment. This option is accessed via the 3D Chart Setup menu.

Synchronize 3D chart with 2D chart



Note: When multiple windows are displayed and the current window is set to SYSTEM, changes made to the chart are reflected in all windows. If set to LOCAL no other window is affected.

With a 2D chart window active, synchronise 3D to 2D chart:



More information... See 'Using the 3D Chart' chapter of the Reference Manual.

Basic Navigation

Working with Waypoints

WAYPOINT AT CURSOR

WAYPOINT AT VESSEL

WAYPOINT AT LAT/LON


GO TO WAYPOINT OPTIONS

REVIEW AND EDIT WAYPOINTS

Card 11

What is a waypoint?

A waypoint is a position marked on a chart, radar or fishfinder screen to indicate a site (for fishing, diving etc), or as a position to go to. You can place a waypoint at the cursor or your boat's position or at a specified position. Waypoints are represented in chart or radar applications as an 'X' (default) and by a vertical line labeled WPT in Fishfinder. Active waypoints are displayed on 3D Chart and CDI windows. The details of each waypoint are stored in a waypoint list. Waypoints can be renamed, edited, grouped, or erased, as necessary. To make full use of waypoint features, ensure your display is receiving heading and position data. We recommend that you regularly back-up your waypoints by archiving them to a CompactFlash card. Waypoints can also be transferred to another NMEA compatible instrument.




Networked systems


If you have networked two or more E-Series Displays, the waypoints are stored on the master display and transferred to other displays via the SeaTalk High Speed network.

How do I place a waypoint?

... at the cursor?



... at the vessel?




How do I navigate to a point?



Always check that your route to a waypoint is safe before travelling towards it.

How do I navigate to a waypoint?


...using the waypoint list?



...using the cursor?



To stop navigation to a waypoint:



Can I edit a waypoint?

Once a waypoint has been placed it can be edited in a variety of ways. You can:

- Change the waypoint details
- Move a waypoint
- Change the default group or symbol
- Erase a waypoint

? More information... See the 'Working with Waypoints' chapter of the Reference Manual

Basic Navigation

How do I get to a point?

SHOW/HIDE ROUTES

FOLLOW ROUTE OPTIONS

BUILD NEW ROUTE


REVIEW AND EDIT ROUTES

Card 12


What is a route?

A route is made up of a series of waypoints. These waypoints can either be placed specifically for that route and/or you can use existing waypoints. You can save a route for future use or follow it immediately (Quick Route). Routes are stored in a route list. If you have networked two or more E-Series displays, the routes are stored in the master display and are transferred to the other displays via the SeaTalk High Speed network.


Routes can be named, edited, erased and archived. After routes have been created you can choose which ones are displayed on your chart.



How do I build a route by placing waypoints on screen?



How do I follow a route?



? More information...

See the 'Using the Chart' chapter in the Reference Manual, for more information on routes.


What is around me? Understanding the radar

Card 13

VRM/EBL | TARGET TRACKING | GAIN | ENHANCE ECHOES... | PRESENTATION



What does the radar show me?....



Typically your boat's position is at the centre of the display, and its dead ahead bearing is indicated by a vertical heading line, known as the Ship's Heading Marker (SHM).

Remember that the radar picture may vary from visual observations that you make; a nearby small object may appear the same size on the screen as a distant large object. However, with experience the approximate size of different objects can be determined by the relative size and brightness of the echoes.

How do I measure distances, ranges and bearings with the radar?

	<p>VRMs Align a VRM on a target to display its range from your boat: e.g. ADJUST VRM 1.800nm</p>		<p>EBLs Align an EBL on a target to display its bearing relative to your boat's heading: e.g. ADJUST EBL 30.0°S</p>
	<p>Combined VRM/EBL Combine a VRM and EBL to measure range and bearing of specified target. e.g. ADJUST VRM 1.800nm ADJUST EBL 30.0°S</p>		<p>Range rings Use the range rings to gauge the approximate distances between two points or from your boat.</p>


Note: Range/bearing also displayed when VRM/EBL selected with the cursor.

? More information... See the 'Using the Radar' chapter of the Reference Manual

What is around me?

Avoiding a collision

Card 14



How can the radar help me avoid a collision?

You can set up your E-Series Display to sound an alarm when anything comes within a pre-set range of the boat. These guard zones allow you to take any necessary action to avoid a collision.

Guard zones

A sector or circular zone fixed with respect to the Ships Heading Marker (SHM). If the SHM moves, or the centre is offset, or the range scale changes, the zone moves accordingly.

What does a guard zone display?

Sector Zone

Circular Zone

IMPORTANT

A guard zone:

- Will only operate when a whole zone is displayed on screen, or displayed by offsetting the centre.
- Is inactive for 10 seconds after it is placed or re-sized, to avoid inappropriate alarms.

How do I set up a circular guard zone?

1. Select guard zone function:

TARGET TRACKING... → MONITOR IN ZONES... → ZONE 1 ON OFF → SET UP ZONE 1

Toggle to ON

2. Select guard zone option:


ZONE SHAPE SECTOR CIRCLE → SET INNER xx.xx nm → Turn → Press → Turn → OK

Toggle to required shape

Turn to set inner boundary

Turn to set outer boundary

How do I distinguish between fixed and moving objects?



To switch radar overlay on/off:

You can overlay radar image data on your chart allowing better distinction between fixed objects and other marine traffic.


With a 2D chart window active:



To switch chart/radar synchronization on/off

For best results, also switch on chart/radar synchronization.

With a 2D chart window active:



To change scanner range in this mode:



? More information... See the 'Using the Radar' chapter of the Reference Manual.

What is around me? Using MARPA....

Card 15

MONITOR
IN ZONES

ACQUIRE TARGET

MARPA & AIS
OPTIONS

MARPA LIST

AIS LIST


What is MARPA?

Mini Automatic Radar Plotting Aid (MARPA) functions are used for target tracking and risk analysis. MARPA improves your standards of collision avoidance by obtaining detailed information for up to 10 targets, and provides continuous and rapid situation evaluation.


MARPA tracks the selected targets and calculates target bearing, range, true speed, course, Closest Point of Approach (CPA), and Time to Closest Point of Approach (TCPA). Each tracked target can be displayed with a CPA graphic depicting the approximate target speed (vector length) and course (vector direction). Alternatively, move the cursor over the target to display the range and CPA. You can now access bearing and speed. Each target is continually assessed. An alarm sounds if a target becomes dangerous or lost.

NOTE: For MARPA to operate, fast heading data is required.


How do I set up the MARPA functions?




How do I acquire a MARPA target?



How do I view details of MARPA targets?



How do I cancel MARPA target(s)?



? More information... See the 'Using the radar' chapter of the Reference Manual.

What is around me? Using AIS

Card 16

AIS VECTOR
ON OFF

AIS DATA
AUTO ON OFF

VIEW FULL
AIS DATA

What is AIS?

AIS uses digital radio signals to broadcast 'realtime' information between vessels and shore based stations via dedicated VHF frequencies. This information is used to identify and track vessels in the surrounding area and to provide collision avoidance data. AIS will augment your radar application, as it can operate in radar blind spots.


In order to use the AIS feature, you will need a GPS and compass for timing and position information together with data from a suitable AIS receiver.

How do I display AIS?

On chart windows:



On radar windows:



How is AIS data displayed?

The AIS system displays other AIS equipped vessels in the surrounding area as targets overlaid on a chart or radar window. Up to 100 targets are displayed and are scaled according to the size of the vessel. A vector indicates the direction of travel of the vessel. As the vessel's status changes, the symbol for the target will change accordingly.

You can view detailed AIS data, safety critical target information, Alarm message (ALR) and Safety Related Message (SRM) messages. You can also set up a safe zone.

How do I view target information?



How do I view detailed AIS data?



Where am I? Monitoring a course....


Card 17

How do I monitor my course?....

- Your course is shown on the chart application whilst motion mode is active.
- Using COG and heading vectors (Press DATA - CHART VECTORS - COG/HDG VECTORS).
- Use the Course Deviation Indicator (CDI). With your display receiving accurate heading and position information, you can monitor your course and accurately steer to a target waypoint.


What does the CDI show me?....

The CDI gives a graphical representation of your boat's course. This 'rolling road' format represents a width of sea equal to the Cross Track Error (XTE) limits that you have specified in the Setup menu. As you travel towards the target waypoint, the checkered pattern moves down the screen to simulate movement at a rate proportional to your boat's speed.




What do the steering instructions tell me?

On course



- Boat on center line.
- Zero XTE

Off course



- Boat off center line.
- Correction arrow(s) indicate direction to steer to maintain course to target waypoint.
- The greater the XTE, the more arrows.

? More information... See the 'Using the CDI' chapter of the Reference Manual

What's under the boat?

Understanding the fishfinder

Adjust P1
SINGLE

PRESET 2
DUAL

PRESET 3
SHALLOW

PRESET 4
DEEP


PRESENTATION

Card 18


What's under the boat?

The fishfinder application, when connected to a suitable Digital Sounder Module (DSM) and transducer, will help you to see fish, bottom structure and underwater obstructions. The image scrolls from right to left at an automatically selected range and frequency to provide a record of the echoes seen. You can mark with a waypoint any positions of interest that you may wish to return to. These waypoints are added to the waypoint list and can be used by other applications.

What can I see on the screen?



How do I interpret the bottom?



What influences target display?

The shape and size of echoes indicating targets, is influenced by a combination of:

- Boat speed - flatter at slower speeds
- Transducer frequency - broader at lower frequencies
- Target depth - larger near the surface
- Target size - larger targets return larger echoes

? More information... See the 'Using the Fishfinder' chapter of the Reference Manual.

What's under the boat?

Using the fishfinder....

Card 19

Adjust P1 SINGLE	PRESET 2 DUAL	PRESET 3 SHALLOW	PRESET 4 DEEP	PRESENTATION
---------------------	------------------	---------------------	------------------	--------------



How do I change the range or shift the image?


Your system automatically adjusts the display depth range, selecting the shallowest depth that keeps the bottom on the lower half of the window. You can however, set this manually if required and move the image within the selected page up or down. Using the range controls will affect all fishfinder windows.



Press RANGE
(IN or OUT)



IN - decrease depth.
OUT - increase depth.




Turn to alter
value.

How do I change Presets?


The Fishfinder application window allows you to have up to 4 user configurable preset modes, this allows you to select and configure the transducer frequency and screen view's (see E-Series reference manual section 6.6 Display mode settings, and section 6.10 Editing presets).



Select the preset
to change




Highlight required view
with trackpad



Use the softkeys to select the different modes (unless instructed otherwise)




Select required
zoom mode



Select required
zoom range



Select required
zoom position



Turn to alter
value




How do I change the gain mode?

The system automatically adjusts the gain control to display the sharpest image. If required, you can select the gain level to suit your fishing mode:

• **Low** - when cruising

• **Med** - when trolling

• **High** - when fishing



Highlight required
preset



Select gain level

To define the gain mode still further, and to define other settings available on this page, select manual gain mode and then adjust the level using the rotary control.

? More information... See the 'Using the Fishfinder' chapter of the Reference Manual.

● Monitoring data and engines

● Viewing video images

Card 20

How do I monitor data?....

NAVIGATION	WAYPOINT	ROUTE	FISHING	SAILING
------------	----------	-------	---------	---------


Ves Pos 25°45'.940N 080°09'.718W	GOTO CURSOR 220°T 1.28nm	TTG --h--m--s	VMG Wpt -, -kt
Depth 78.8ft	Cog Sog 286°T 0.0kt	Heading 293°T	Speed 0.0kt
Set Drift 355°T 0.0kt	XTE 0.00nm Steer >	Trip 0.00nm	Local Time 01:42:12

The **data application** enables you to view numeric data generated by the system or by instruments available on NMEA 0183, SeaTalk, SeaTalk², NMEA 2000 and SeaTalk^{hs}. This information is displayed in a series of panels which contain data relating to a particular function or activity. These can be reconfigured to your needs.

Press the appropriate soft key to select the panel of your choice.

How do I monitor the engine(s)?....

ENGINE	ENGINE & FUEL	FUEL RESOURCES	ENGINE & RESOURCES	TWIN ENGINE
--------	---------------	----------------	--------------------	-------------



The **engine monitor application** enables you to view data from up to three compatible engines. The information is displayed in a series of panels which contain data relating to engine, fuel and fuel resources. These can be reconfigured to your needs.

Press the appropriate soft key to select the panel of your choice.

To view data from 3 engines, change the 'No. of engine' setting in the Panel Setup Menu

How do I view video images?....

VIDEO 1	VIDEO 2	VIDEO 3	VIDEO 4	PRESENTATION
---------	---------	---------	---------	--------------



The **video application** enables you to view images from a satellite TV, video or DVD player or on-board camera.

Press the appropriate soft key, to select the video input of your choice or set CYCLE VIDEO to ON (via the PRESENTATION key), to cycle through the video inputs.

Note: Video images can only be viewed on the display to which the video source is connected. They cannot be networked to other Displays.


? More information... See the appropriate chapter of the Reference Manual.

Navtex and Sirius Weather Data

Card 21

Navtex

If connected to a Navtex receiver, you can use your display to view navigation, meteorological and search and rescue alerts. You can choose which category of alerts will automatically be displayed when one is received by your display. After you have read the message you can either erase it or save it to the database (100 maximum). You can view the list of saved messages at any time. Messages are viewed and alerts set-up via the Setup Menu option Navtex Messages.



The Sirius Weather application (USA only)

To run the Sirius Weather application you will need to purchase an SR100 weather receiver and a subscription to Sirius weather.


Once connected, the weather application superimposes historical, current and forecasted weather graphics and environmental conditions on the world map and provides textual forecasts and warnings. These help you to determine the actual conditions in your vicinity or at a particular location.

As in the chart application, use the cursor to move around the map and view different locations, and the range button to zoom in and out.

To re-center the map on your boat use the FIND SHIP soft key.

Note: As with all weather services, the information presented is advisory only and you should be aware that errors may occur.

Note: If you have an SR100 connected, you can also control your Sirius satellite audio via your E-Series display.



? More information... See the appropriate chapter for the Reference Manual.

Sirius Weather Data (continued)

Card 22

FIND SHIP	DISPLAY GRAPHICS	ANIMATE WEATHER	WEATHER REPORTS	PRESENTATION

By default, all weather graphics are set to OFF.
To display the required weather graphic:

DISPLAY GRAPHICS... →

Weather Graphics		
NOWRad	OFF	OFF ON
Storm Cast	OFF	
Sea Surface Temp	OFF	
Canadian Radar	OFF	

Highlight, select and switch graphic on/off as required

Weather symbols (USA only)

Storm cast	Waves (blues-green-red)	Canadian radar (light green- dark red)	Lightning (light-med-dark yellow)	Wind (see below for details)
Sea surface temperature (blue-green-yellow -orange-red)	Surface observation station (pink)	Cities (grey)	Rain (green-yellow-red) Snow (blues) Mixture (pinks)	Marine zones

Surface pressure

High pressure (blue)	High pressure (red)	Warm front (red)	Cold front (blue)	Occluded front (purple)
Stationary front (red-blue)	Trough (brown)	Squall line (red)	Dry line (brown)	Isobars (grey)

Storm Tracks symbols

Shown in three different colours:
 • Grey - historical • Red - current • Orange - forecast
 Note: Highlight the symbol for additional information

Hurricane (Category 1-5)	Tropical storm	Tropical disturbance or tropical depression

Wind speed symbols (knots)

																				etc.
3-7	8-12	13-17	18-22	23-27	28-32	33-37	38-43	44-47	48-52	53-57	58-62	63-67	68-72	73-77	78-82	83-87	88-93	94-97	98-102	

? More information... See the Weather (USA only) chapter of the Reference Manual.

Autopilot Operation

Using the Autopilot controls

Card 23

How do I access Auto and Standby from my E-Series?

Enabling the Autopilot from set up:


- Enabling and engaging the autopilot
To allow the E-Series to control autopilot functions, you need to enable autopilot control on the display unit. With autopilot control enabled, the unit lets you engage the autopilot whenever it has a target waypoint. You can see information for the target waypoint on the Pilot Control pop-up. The default autopilot setting is disabled.
- To enable autopilot control on the E-Series display:
 - Press the MENU button to open the Setup Menu.
 - Select System Setup > System Integration > Autopilot Control > Enabled.
 - Press the OK button.

What are the Autopilot symbols?




How do I engage and disengage the Autopilot in normal operation?


- When the autopilot is enabled, the E-Series prompts you to engage the autopilot whenever you initiate a GOTO or FOLLOW ROUTE.



- Select GOTO or FOLLOW ROUTE to display the Engage Pilot screen.




- Select ENGAGE PILOT to display the Pilot Control screen.




NOTE:

If you press OK, CANCEL or the page times out without engaging the autopilot, you go back to the navigation screen with the autopilot disengaged.

How do I disengage the Autopilot in an emergency?

You can choose to disengage the pilot quickly if required by pressing the Power key 

Select 'AUTOPILOT STANDBY' to put the pilot in the autopilot into standby mode and take control of the helm manually



? More information... See Autopilot control chapter of the Reference Manual.

What is around me?


Understanding the digital radar

Card 24

VRM/EBL | TARGET TRACKING | GAIN | ENHANCE ECHOES... | PRESENTATION




What do the digital radar colors show me?....



The colors displayed represent the strength of the echoes received from targets. For most targets the echo strength is closely related to their size. Colors also help to distinguish targets within Clutter. Normally, targets will be displayed as a stronger color than the surrounding clutter. For example, a Buoy with a radar reflector will show clearly in sea clutter.

How do I change the radar gain settings?....

The Radar application window allows you to select 4 user configurable preset modes, Buoy, Harbour, Coastal & Offshore. They allow you to configure the Gain, Color Gain, Rain & Sea Clutter settings to aid you in customising the display to suit the conditions (see E-Series Reference manual, 'Tuning the radar display'). For each gain preset, Auto mode is recommended, but you can change settings manually for each preset to suit individual situations.



? More information... See the 'Using the Radar (Digital)' chapter of the Reference Manual

Operating a networked E-Series Display

Card 25

What does a networked system do?


If you have connected two or more E-Series Displays (via either a crossover coupler or SeaTalk High Speed Switch), all system data (from NMEA 0183, SeaTalk, SeaTalk², NMEA 2000, SeaTalk^{hs} waypoints, routes etc) can be transferred across the network enabling you to input, view and maintain data across all your displays irrespective of the Display from which the data originated (excepting Video Input).

How is the network controlled?

The display that has been installed and nominated as the master, should always be switched on (preferably first). The master display maintains the waypoint, route and track lists as well as data from NMEA and SeaTalk. Each time the master display detects a change on any display e.g. waypoint, route or track added or edited, the data is copied to the database which in turn is copied to all other Displays that are switched on.

If the system does not detect a master, either because it is not switched on or because a master has not been selected, an alarm will sound and you will be prompted to set a master display.

How do I change the master display?



Raymarine Ltd
Quay Point
Northharbour Road,
Portsmouth, Hampshire
England PO6 3TD
+44 (0)23 9269 3611
www.raymarine.com

Raymarine Inc.
21 Manchester Street,
Merrimack,
NH 03054-4801
USA
1-603 881 5200
www.raymarine.com

Raymarine

Document No 86114_4