


BTA-131 Stereo Headset Adapter User Manual

Stereo Headset Adapter overview



1. LED indicator
2. Power On/Off
3. Pairing button
4. Audio connector
5. Mini USB charging port
6. Audio jack

Charging your Stereo Headset Adapter

Plug one end of the charger into your **Stereo Headset Adapter** and the other end into an electrical outlet. The red LED indicator lights up when charging and off when **Stereo Headset Adapter** fully charged.

The rechargeable batteries that power this product must be disposed of properly and may need to be recycled. Contact your local recycling center for proper disposal methods. Never dispose of batteries in a fire because they may explode.



Turn on/off your Stereo Headset Adapter

To turn the **Stereo Headset Adapter** on, set the switch to **On**.

To turn the **Stereo Headset Adapter** off, set the switch to **Off**.

The LED indicator flashes blue when the **Stereo Headset Adapter** is operating. When running out of battery, the LED indicator will flash red slowly.

Pairing and connecting

At the first time using the **Stereo Headset Adapter**, you must pair with the other Bluetooth headset.

Please take the instructions step by step.

1. Power on the both devices.
2. Make your Bluetooth headset into a pairing mode (refer to the user guide enclosed with the product).
3. Place the **Stereo Headset Adapter** in pairing mode by pressing the Pairing button lasting for seconds. Release the button when the LED indicator begins to flash red and blue alternately.
4. When the blue LED flashes slowly, the **Stereo Headset Adapter** is successfully paired.
5. If pairing fails, please try again the above steps.
Note: In some circumstances the pairing process can take up to 2 minutes to complete.
6. The **Stereo Headset Adapter** will automatically initiate a paired connection (when powered on) with the last paired headset. In case the connection is undone, you can manually connect the **Stereo Headset Adapter** to the headset by pressing the Pairing button (less than 1 sec).

Using your Stereo Headset Adapter

The **Stereo Headset Adapter** is compatible with most popular non-Bluetooth devices with a standard 2.5mm headset jack. You can connect the **Stereo Headset Adapter** to the non-Bluetooth devices with the attached audio connector.

Federal Communication Commission Interference Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful

interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one of the following measures:

Reorient or relocate the receiving antenna.

Increase the separation between the equipment and receiver.

Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

Consult the dealer or an experienced radio/TV technician for help.

FCC Caution: Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate this equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment complies with FCC RF radiation exposure limits set forth for an uncontrolled environment. To maintain compliance with FCC RF exposure compliance requirements, please avoid direct contact to the transmitting antenna during transmitting.