

INSTRUCTIONS FOR OPERATION

SETTING THE OPERATING CONTROLS

1. This device which one of black lines series with AC 120V power supply. Now, we take 60Hz power supply to afford power supply of transmitter when it trough rectify. So, there is no troubles with change batteries forever.
2. Store the controller away from excess heat or humidity .
3. This remote control unit is required with 32 code combinations. To prevent possible interference from or to other remote units such as garage door openers, car alarm or security system . If you find that your fan and light kit go on and off without using your control , simply change the combination code in your transmitter and receiver .
4. Operation buttons on the panel of transmitter .



key – For fan speed Reverse .



key – For light brightness and light ON/OFF control .



key – For fan speed control . fan 1 2 3 4 --> 4 3 2 1 speed cycle.




key – For FAN OFF control .




key – POWER SW , for POWER ON/OFF

5. Fan control :

Turn the FAN on touching the  button .
pressing the button , fan 1 2 3 4 --> 4 3 2 1 speed cycle.

6. Fan reverse control :

Press the  button Change the direction of the fan to run

7. Light control :

Turn the light on or off by only touching the LIGHT CONTROL button .

Keep pressing the button in excess of 0.7 second it becomes a dimmer ,
the light varies cyclically in 0.8 second .

One of the important feature of this control is AUTO-RESUME . After power on , it allows the light return to where it was off .

8. Power switch

Turn off the power for Fan and Light

GENERAL INFORMATION :

This REMOTE controller is designed to separately control your ceiling fan speed and light brightness .

INSTRUCTIONS FOR INSTALLATION AND OPERATION OF FAN SPEED CONTROLLER

1. Setting the code on your new transmitter .

Within 60 seconds of turning the AC power on, press and hold the OFF/STOP button for 5 seconds. The receiver will then lock in the chosen frequency. If your fan has a light it will blink twice, for fans without lights check operation using the transmitter

NOTICE :

The changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

THIS DEVICE COMPLIES WITH PART 15 OF THE FCC RULES. OPERATIONS IS SUBJECT INTERFERENCE AND (2) THIS DEVICE MUST ACCEPT ANY INTERFERENCE RECEIVED, INCLUDING INTERFERENCE THAT MAY CAUSE UNDESIRABLE OPERATION.

IMPORTANT NOTE:

To comply with the FCC RF exposure compliance requirements, no change to the antenna or the device is permitted. Any change to the antenna or the device could result in the device exceeding the RF exposure requirements and void user's authority to operate the device.

The term "IC:" before the radio certification number only signifies that Industry Canada Technical specifications were met.

This device complies with Industry Canada licence-exempt RSS standard(s). Operation is subject to the following two conditions: (1) this device may not cause interference, and (2) this device must accept any interference, including interference that may cause undesired operation of the device.

Le present appareil est conforme aux CNR d'Industrie Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes : (1) l'appareil ne doit pas produire de brouillage, et (2) l'utilisateur de l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.